



3 - 4 Tonne



# service manual



3-4 tonne



This manual has been written to provide maintenance and service information necessary to keep the Thwaites machine operating safely and efficiently throughout its service life.



### **Prior to Commencing Maintenance Work You Must :**

- Read and fully understand the enclosed working instructions.
- Ensure that any required safety precautions have been taken.
- Adhere to safety notices contained within this manual.
- Fully understand the risks involved and be competent to perform the work.
- Use only genuine spare parts as replacement items.
- Ensure that prior to the machine being used, after maintenance work has been completed, all safety checks and tests have been completed.



**Any problems please contact your local distributor**

In compiling this document we have endeavoured to provide the most up to date and accurate information.

Due to Thwaites continual product development we reserve the right to amend information contained within this manual without prior notice.



## Contents

Technical Data

Section  
1

Maintenance




2



### Contents

	Page
<b>Machine Identification</b>	1.1
<b>Location of Major Components</b>	1.2
<b>Torque Settings/Capacities</b>	1.3

## Machine Identification



## Serial Numbers

Note machine serial numbers. Always quote them in communication with Thwaites dealer or Head Office.

**Model Type (Fig 1.)**


**Vin N° (Fig. 1)**

**Engine Serial N° (Fig. 2)**


**Axle Serial N° (Fig. 3)**

**Gearbox Serial N° (Fig. 4)**

**Transfer Gearbox Serial N° (Fig. 5)**




## Location of Major Components



1. Tipping Ram
2. Skip/Bucket
3. Operator Manual Pocket
4. Wheel
5. Axle
6. Propshaft
7. Transfer Box
8. Gearbox
9. Chassis Locking Bar
10. Battery Box
11. Hydraulic Tank
12. Engine
13. Radiator/Oil Cooler
14. Fuel Tank
15. Top Propshaft
16. Steering Ram
17. Kinklink
18. Slew Ram
19. Slew Ring
20. Skip Prop

**System Fluid Capacities**

Ltrs

**Engine oil  
(with filter)**

5.8

**Axle Front  
Axe Rear**

6.0

**Gearbox**

2.0

**Transfer Box**

0.6

**Cooling system**

11.0

**Hydraulic system**

45.0

**Brake reservoir**

0.33

**Fuel tank**

45.00

**Torque Settings**

Nm

Centre Pivot 486

Kinglink Bearing Pins Upper 330

Bearing Mounting Plate Bolt 56

Wheel Nuts 270

Roll Bar Mounting Bolts 127

Slew Ring Bolts 169

Engine/Chassis Bolts 100

Engine Brackets/Engine Mounts 56

Diesel/Hydraulic Tank Drain Plugs 25

Axe Bolts 206

Propshaft Bolts 56

Transfer Box Mounting 206

Ram Pin Nuts 250


## Contents

	Page		Page
<b>Lubrication and Maintenance Chart</b>	2.1	<b>50 Hour Service - Axle/Brake Oil</b>	2.10
<b>Lubrication and Maintenance Schedule</b>	2.2	<b>250 Hour Service - Engine Oil &amp; Filter</b>	2.11
<b>Safe Working Practice</b>	2.3	<b>250 Hour Service - Fuel Filter</b>	2.12
<b>First 50 Hour Service - (Engine)</b>	2.4	<b>250 Hour Service - Fuel System</b>	2.13
<b>First 50 Hour Service - (Hydraulic)</b>	2.5	<b>500 Hour Service - Fuel System</b>	2.14
<b>First 50 Hour Service - (Drive Belt)</b>	2.6	<b>1000 Hour Service - Axle Oil</b>	2.15
<b>10 Hour Service - Cooling/Engine Oil</b>	2.7	<b>1000 Hour Service - Cooling Sys.</b>	2.16
<b>10 Hour Service - Air Filter Elements</b>	2.8	<b>2000 Hour Service - Hydraulic Oil Replace</b>	2.17
<b>10 Hour Service - Park Brake</b>	2.9	<b>Recommended Lubricants</b>	2.18

## Note:

The following service period recommendations are the maximum permissible and should never be exceeded.

## Lubrication and Maintenance Chart



	COOLANT	1	H <sup>2</sup> O + 33% Antifreeze
	ENGINE OIL	2	SAE 10w 30 NA/Turbo
	HYDRAULIC OIL	3	Mobil DTE 24
	OTHER SERVICES	4	Wheel Nut Tightness
	INDUCTION	5	Clean Filters
	BRAKES	6	Operation of Brakes
	FUEL	7	Diesel
	GEAR/TRANSFER BOX	8	MOBIL HD 90
	AXLE OIL	8	MOBILFLUID 422
	OTHER SERVICES	9	Tyre Pressure - Refer to Operators Manual
	GREASE	10	Mobilplex Special or Mobilplex 47
	BRAKE SYSTEM	11	Mobil DTE 24
	OTHER SERVICES	12	Fan/Drive Belts
	OTHER SERVICES	13	Hoses
	BATTERY	14	Battery Cable Connections
	OTHER SERVICES	15	Bolt tightness (Ref Page 1.3)
	LAP BELTS	16	Replace
	WIRING	17	Inspect

## IMPORTANT NOTE

After first 50 hours - Change engine oil - Change engine oil filter - Change hydraulic oil filter element- Adjust fan belt tension.

## Lubrication and Maintenance Schedule

Interval	Position	Item	CHECK	CLEAN	CHANGE LUBE
Every 10 Hours or Daily	1	Coolant level	•		
	2	Engine oil level	•		
	4	Wheel nut tightness	•		
	5	Air cleaner indicator	•		
	6	Operation of brakes (Park/Foot)	•	•	
	3	Hydraulic oil level	•		
Every 50 hours or weekly	8	Axle oil level front and rear	•		
	8	Gearbox oil level	•		
	8	Transfer case oil level	•		
	9	Tyre pressure front and rear	•		
	10	Pins:-			
	10	Steering rams and pins			•
	10	Tipping rams and pins			•
	10	Slew rams and pins			•
	10	Kinglink			•
	10	Skip pins			•
	10	Turntable			•
	10	Centre lock (Swivel)			•
	10	Propshaft			•
	10	Park brake levers			•
3.7.8.10	11	Brake fluid reservoir	•		
	12	Condition and tension of fan/drive belts	•		
		Any fluid leak	•		

Interval	Position	Item	CHECK	CLEAN	CHANGE LUBE
Every 250 hours	2	Engine oil with filter			•
	13	Hoses tightness/chaffing	•		
	7	Fuel Filter Element		•	
	7	Sediment filter bowl		•	
	15	Torque settings:-			
	15	Slew ring bolts	•		
	15	Spherical bearing bolts	•		
	14	Engine mounting Brackets	•		
	15	ROPS mounting Bolts	•		
	14	Battery cables/connections	•		
Every 500 hours	7	Harness routing (chaffing)	•		
	7	Fuel Filter Element			•
	3	Replace sediment element			•
	5	Hydraulic oil filter element			•
	15	Air filter elements (If not changed earlier)	•		•
		Check axle mounting bolts	•		
Every 1000 Hours	8	Axle oil front & rear			•
	1	Coolant (yearly)			•
		Adjust engine valve clearances etc (consult dealer)			
Every 2000 Hours	3	Hydraulic oil			•
	16	Lap Belt			•

## Safe Working Practice

**Before lubrication and maintenance tasks:**

- Machine must be on firm level ground.
- Apply parking brake.
- Stop engine and remove ignition key.
- Isolate the Battery.
- Allow engine to cool.
- Place motion/gear lever in neutral.
- Fit pivot lock (Fig. 1).
- Chock wheels.
- Prop bucket when working beneath.
- Lock tip lever (Fig. 2).

**Lubrication General** **Warning - Fluids**

Handle fluids with care. Avoid skin contact with used oil. Protect hands with an effective barrier cream and/or gloves.

Fluids under pressure can escape from extremely small holes.

When checking for leaks use a piece of card, **NEVER** use your hand.

Always dispose of waste lubricants and filters in a responsible manner.

 **Caution**

The alternator wiring must be disconnected when welding. Avoid damaging the alternator.

**Warning - Fuel Handling**

Diesel fuel is FLAMMABLE. Never refuel or service the fuel system while smoking or near naked flames. Never refuel the machine while the engine is running.

Fig. 1




Fig. 2

**Warning-Hydraulic Connections**

Ensure all hydraulic connections are tight. Relieve all pressure by moving the hydraulic control levers and allow the system to cool before disconnecting hoses or lines.

**Warning - Tyre Fitting**

Do not attempt to fit a tyre unless you have the proper equipment and experience to perform the task.

Failure to follow the correct procedure when fitting a tyre on to a wheel rim can cause an explosion.


**Change Engine Oil With Filter (2)**

- Drain oil with engine hot.
- Clean area around drain plug (Fig. 1(B)).
- Position a suitable container beneath drain plugs on sump.
- Unscrew the drain plugs and drain oil.

**Caution**

Hot oil avoid scalding


- Allow ten to fifteen minutes for oil to drain completely.



- Position container beneath oil filter.
- Remove filter (Fig 1(A)).
- Wipe filter mounting surface.
- Smear sealing ring of new filter with clean engine oil.

**Change Engine Oil With Filter (2) (Continued)**

- Screw filter into position and tighten **BY HAND ONLY**.
- Clean and refit drain plugs.
- Refill engine using correct amount of recommended lubricant.
- Allow to settle.
- Refit filler cap (Fig. 2), start engine and check for leaks.

**IMPORTANT NOTE**




After first 50 hours - Change engine oil - Change engine oil filter - Change hydraulic oil filter element- Adjust fan/drive belt tension.

## Change Hydraulic Oil Filter Element (9)

**Caution**

It is imperative that hydraulic oil is clean.  
Avoid damage to hydraulic components.

- Remove filler cap (Fig. 1(A)).
- Remove filter element (Fig. 3(C)).
- Clean all parts and lubricate 'O' rings.
- Fit new filter element, ensuring element clip is fitted and visible from the top of the tank (Fig. 2(B)).
- Refit filler cap and hand tighten.

**IMPORTANT NOTE**




After first 50 hours - Change engine oil - Change engine oil filter - Change hydraulic oil filter element- Adjust fan/drive belt tension.

## Check Fan/Drivebelt Tension (15)



## Warning

Before servicing or making adjustments to the electrical system, Isolate the battery.



- Loosen the pivot bolts (Fig. 1(A)) and adjusting link bolt (Fig. 2(C)).
- Move the alternator to give 10-15mm movement in the drive belt (Fig. 2(C)).
- Tighten the adjusting link bolt and pivot bolts.

## Section 2 - Maintenance


## Check Coolant level (1)



DO NOT attempt to remove radiator cap until system has cooled down.

- Pull lever (Fig. 1(B)) to release filler flap.
- Remove radiator cap (Fig. 1 (C)).
- Check water level is visible in the radiator, top up as required.
- Maintain coolant at indicated level (Fig. 1 (A)).  
Ensure radiator fins are clean and clear of all obstructions.

Solution	Starts to freeze at deg C	deg F
15%	-8	17
33%	-19	-2
57%	-30	-22




## Check oil level (2)

Check engine oil level with machine on firm level ground and the engine cold.

Maintain level between marks on dipstick.

- Fully remove dipstick (Fig 2(D)).
- Wipe clean.
- Re insert fully.
- Withdraw dipstick and check oil level.
- Top up oil level, through filler cap, as required.
- Replace dipstick.




**Note:-** In climates where antifreeze is not required a reputable corrosion inhibitor must be added.

## Section 2 - Maintenance

### Check Air Cleaner Elements (5)

- When window 'D' shows RED replace or clean filter.
- Pull release clip (Fig.1(A)) and twist to remove the end cup (B).
- Remove primary element (C) and secondary element.
- Clean inside body (Fig. 1(B)).
- Refit or replace elements ensuring correct seating.
- Refit the end cup (Fig. 1(B)) and secure clip (A).




#### Caution

DO NOT run engine with air cleaner removed.


### Check Hydraulic Oil Level

- Check hydraulic oil level in tank (Fig. 3(E)).



## Section 2 - Maintenance

Fig. 1



## Initial Set-up of Parkbrake Cable/Lever

- Connect handbrake cable to Parkbrake Lever and set cable adjuster (Fig. 2 (E)) to 10mm.
- Set the Parkbrake to the off position.
- Before the cable is connected, the 2 levers (Fig. 1), distance at 'A' is between:
  - Min 190mm
  - Max 215mm

Connecting the Parkbrake cable, setting the trunnions so the dimension at 'B' is 6mm greater than the dimension at 'A'.

Therefore if    'A' = 197mm,  
                  'B' = 203mm.

- Apply the Parkbrake, if too much effort is required to apply the Parkbrake, remove the rubber lever grip, release the locking screw(2mm hexagonal key) and rotate the adjusting collar, one turn at a time anti clockwise.
- Carry out the Parkbrake Test procedure, the machine must stall in 3rd gear with the parkbrake applied.
- After setting, re tighten the locking screw on the Parkbrake lever, if applicable, and replace the rubber grip.


## Check Park Brake Operation (6)

*If the Machine has moved and therefore failed the brake test, the cable will require adjustment:*

- Loosen locknuts (Fig. 2 (D)) and use a full turn of these locknuts into the adjustment of the cable (F).
- Tighten locknuts and repeat the handbrake test procedure.

*When there is no more cable adjustment at the lever, to prolong the life of the cable, adjustment can be made at the lever end of the cable (Fig. 1(C)).*

Fig. 2



## Section 2 - Maintenance

## Check Brake Oil Level (14)



## Warning


Before maintenance on braking system, ensure dumper is on firm level ground, wheels chocked securely.

Brake master cylinder reservoir must be checked regularly. If oil level is low check system for leaks at all joints and pipes for damage. Top up to correct level with approved oil (Fig. 1(A)).

Should brake reservoir need frequent additions of oil, machine **must not be used**. A thorough check of brake system must be carried out.

**Note:** Before removing filler cap clean area carefully to prevent contamination.

Fig. 1



USE MINERAL OIL ONLY

2.10

## Axles and Transfer Case (8)

## Check oil level

- Park on firm level ground.
- Chock wheels on axle not being checked.
- Clean area around level plug and remove (Fig. 2,3(B)).

## Note:

- Top up with recommended lubricant until excess flows from level hole, if required.
- Clean level plug and refit (Fig. 2,3(B)).

Fig. 2





Fig. 3



## Gearbox Oil Level Check (8)

Fig. 4




Fig. 5



- Clean area around dipstick plug (Fig. 4) and remove dipstick.
- Wipe clean and re insert fully.
- Withdraw dipstick and check oil level.

Maintain level between marks on dispstick. (Fig. 5)

## Section 2 - Maintenance

## Change Engine Oil With Filter (2)


- Drain oil with engine hot.
- Clean area around drain plug (Fig. 1(B)).
- Position a suitable container beneath drain plugs on sump.
- Unscrew the drain plugs and drain oil.



## Caution

Hot oil avoid scalding


- Allow ten to fifteen minutes for oil to drain completely.



- Position container beneath oil filter.
- Remove filter (Fig 1(A)).
- Wipe filter mounting surface.
- Smear sealing ring of new filter with clean engine oil.

## Change Engine Oil With Filter (2) (Continued)

- Screw filter into position and tighten BY HAND ONLY.
- Clean and refit drain plugs.
- Refill engine using correct amount of recommended lubricant.
- Allow to settle.
- Refit filler cap (Fig. 2), start engine and check for leaks.




## Section 2 - Maintenance

### Check Fuel Filter (7)

- Unscrew the filter bowl retaining ring (Fig. 1(A)) and remove the bowl (B).

*Provision should be made for spillage containment*

- Remove the fuel filter.
- Clean the element with light oil and blow compressed air (2-3 Kg/cm<sup>2</sup>) through the element to remove dust.
- Remove the dust and water deposited on the bottom of the trap in the filter bowl.
- Reassemble in the reverse order ensuring cleanliness and that the filter retaining ring is hand tight only.




Note - Removal of Air Locks refer to [page 2.13](#)

### Check Fuel Sediment Bowl (7)

- Unscrew the sediment bowl retaining ring (Fig. 2(C)) and remove the bowl (D).

*Provision should be made for spillage containment*

- Remove the sediment filter.
- Clean the element with light oil and blow compressed air (2-3 Kg/cm<sup>2</sup>) through the element to remove dust.
- Remove the dust and water deposited on the bottom of the trap in the sediment bowl.
- Reassemble in the reverse order ensuring cleanliness and that the sediment retaining ring is hand tight only.



KEEP NAKED FLAMES AWAY FROM FUEL SYSTEM.

## Section 2 - Maintenance

**Note - Removal of Air Locks (Fig. 1)**

- Turn fuel filter cock (Fig. 1(A)) to 'OPEN'
- Bleed air by loosening (one at a time) the air bleed screws (Fig. 1(B.C.D)).
- Operate the fuel filter priming lever (Fig. 2(E)) until all air bubbles are removed and re tighten all bleed points.

Fig. 1




Fig. 2

**Warning**

KEEP NAKED FLAMES AWAY FROM FUEL SYSTEM.

**Hydraulic Oil Sample (6)****Caution**


Ensure hydraulic system has cooled down before attempting to obtain an oil sample.

Wear suitable gloves whilst following out this procedure.

*Provision should be made for spillage containment*

- Fit gauge point hose to pressure gauge point.
- Start Engine and allow approximately 0.1 of a litre of oil to be drained off and discarded.
- Fill sterile clean sample bottle with oil. Reseal.
- Stop engine and remove hose. Replace cap on gauge point.

Fig. 1



The required standard of the oil sample is:-

Grade '8' - NAS1638 STD or  
Grade '17 - 14' ISO4406 STD

Anything above this standard the oil will need changing. (Page 2.17)


## Section 2 - Maintenance

**Change Fuel Filter (7)**


- Unscrew the filter bowl retaining ring (Fig. 1(A)) and remove the bowl (B).

*Provision should be made for spillage containment*

- Remove the fuel filter.
- Remove the dust and water deposited on the bottom of the trap in the filter bowl.
- Fit new filter element.
- Reassemble in the reverse order ensuring cleanliness and that the filter retaining ring is hand tight only.

**Change Fuel Sediment Filter (7)**

Follow the same procedure as the Fuel Filter.



(9) Hydraulic oil filter, refer to [page 2.5](#)

(5) Air filter elements, refer to [page 2.8](#)





**Warning**

KEEP NAKED FLAMES AWAY FROM FUEL SYSTEM.

## Section 2 - Maintenance

**Change Axle, Transfer & Gear Box Oil (8)**

- Position machine on firm level ground.
- Apply parkbrake.
- Clean area around drain plug (Fig. 1,2,4(A)) and filler plug/dipstick (Fig. 1,3,4(B)).
- Place a suitable container under drain plugs.
- Remove plug/s and allow to drain.
- Clean and refit drain plugs.
- Fill with correct quantity of recommended lubricant, until excess flows from (B) (Fig. 1&4).
- Allow for settling and check level.
- Check gearbox oil level - refer to [page 2.10](#)
- Top up as required.
- Clean and refit level plug (B).



## Section 2 - Maintenance

## Drain And Refill Cooling System (1)



## Warning



DO NOT attempt to remove radiator cap until system has cooled down.

Ensure radiator fins are clean and clear of all obstructions.

- Place a suitable container beneath bottom hose.
- Remove filler cap (Fig. 1(A)) Disconnect bottom hose (Fig. 2 (C)) and allow to drain .
- When coolant has drained, replace hose and refill system via cap (A) with pre-mixed water/antifreeze solution.

*Allow 15 minutes to fill, this gives time for air to rise to top of system.*

- Add water/anti-freeze solution to expansion bottle level (B).
- When the engine is started the level will drop and must be topped back up to the maximum.





## Section 2 - Maintenance

## Change Hydraulic Oil (9) (if not changed earlier)

**Caution**

It is imperative that hydraulic oil is clean.  
Avoid damage to hydraulic components.

- Ensure all rams are closed.
- Remove filler cap (Fig. 1(A))
- Place suitable container beneath oil drain plug.
- Unscrew oil drain plug (Fig. 2(B)) and allow oil to drain.
- Clean and refit drain plug.
- Fill tank with recommended lubricant
- Replace filler cap.
- Start engine, activate all hydraulic cylinders until filled with oil and free from air.
- Stop engine and fill tank to level marker.



## Recommended Lubricants

Engine

MOBIL DELVAC SPECIAL 10 W 30  
Oil specification MIL-L-46152C  
(See viscosity chart).

Gearbox/Transfer Box

MOBILUBE HD 90

Axles

MOBILFLUID 422

Hydraulic System

MOBIL DTE 24

Brake System

MOBIL DTE 24

Grease

MOBILPLEX SPECIAL or  
MOBILPLEX 47


Engine Coolant

B.S. 6580-1992  
Specification for corrosion inhibiting  
Engine coolant concentrate (antifreeze)

**SYNTHETIC OILS SHOULD NOT BE USED IN THESE ENGINES****USE ONLY GENUINE THWAITES FILTERS, REFER TO YOUR  
PARTS MANUAL FOR PART NUMBERS.**

## Thwaites Recommended Lubricants and Coolant

## Recommended SAE Viscosity Grades



3-4 tonne



**Thwaites**  
The logo consists of the word 'Thwaites' in white on a dark blue background, with 'allparts' in dark blue on an orange background below it. The 'a' in 'allparts' has three diagonal stripes to its left.  
**allparts**

**genuine parts**  
The logo consists of the word 'genuine parts' in orange on a dark blue background, with a decorative pattern of blue and orange diagonal stripes below it.

Thwaites Ltd Allparts Division Leamington Spa Warwickshire CV32 7NQ  
T +44 (0)1926 833295 F +44 (0)1926 450458 W [www.thwaitesdumpers.co.uk](http://www.thwaitesdumpers.co.uk)

**USE ONLY GENUINE THWAITES  
SPARE PARTS.  
YOUR WARRANTY MAY BE INVALIDATED  
IF INFERIOR ITEMS ARE FITTED.**

