

# SHIFT LOCK SYSTEM

40082-03

## ON-VEHICLE INSPECTION

### 1. CHECK SHIFT LOCK OPERATION


- Shift the shift lever to P position.
- Turn the ignition switch to LOCK.
- Check that the shift lever cannot be shifted to any other positions than P.
- Turn the ignition switch ON, depress the brake pedal and check that the shift lever can be shifted to any other positions.

### 2. CHECK SHIFT LOCK RELEASE LINK OPERATION

- Using a small screwdriver, remove the shift lever cap.
- When operating the shift lever with the shift lock release link pressed, check that the lever can be shifted to any position other than P.

### 3. CHECK KEY INTERLOCK OPERATION

- Turn the ignition switch ON.
- Depress the brake pedal and shift the shift lever to any other position than P.
- Check that the ignition key cannot be turned to LOCK.
- Shift the shift lever to P position, turn the ignition key to LOCK and check that the ignition key can be removed.




### 4. INSPECT SHIFT LOCK CONTROL ECU SUB-ASSY

- Using a voltmeter, measure the voltage at each terminal.

HINT:

Do not disconnect the shift lock control ECU connector.

Terminal	Measuring Condition	Voltage (V)
1 (KLS+) - 7 (E)	(1) Ignition switch ACC and P position	0
	(2) Ignition switch ACC and except P position	7.5 - 11
	(3) Ignition switch ACC and except P position (After approx. 1 second)	6 - 9
4 (ACC) - 7 (E)	Ignition switch ON	10 - 14
	Ignition switch ACC	10 - 14
	Ignition switch OFF	0
9 (STP) - 7 (E)	Depress brake pedal	10 - 14
	Release brake pedal	0
5 (IG) - 7 (E)	Ignition switch ON	10 - 14
	Ignition switch OFF	0



- (b) Using an ohmmeter, measure the resistance at terminal E (7) and body ground.
- HINT:  
Do not disconnect the shift lock control ECU connector.

Terminal	Measuring Condition	Specified Value
7 (E) - Body ground	Always	Continuity