

PROBLEM SYMPTOMS TABLE

If a normal code is displayed during the DTC check but the problem still occurs, check the circuits for each problem symptom in the order given in the table below and proceed to the relevant troubleshooting page.

NOTICE:

When replacing skid control ECU, sensor or etc., turn the ignition switch OFF.

Symptom	Suspect Area	See page
ABS does not operate BA does not operate EBD does not operate	If the symptoms still occur even after the following circuits in suspect areas are inspected and proved to be normal, replace the skid control ECU. 3. Check the DTC again and make sure that the normal code is output. 4. IG power source circuit 5. Speed sensor circuit	05-307 05-368 05-331 05-336
ABS does not operate efficiently BA does not operate efficiently EBD does not operate efficiently	If the symptoms still occur even after the following circuits in suspect areas are inspected and proved to be normal, replace the skid control ECU. 1. Check the DTC again and make sure that the normal code is output. 2. Speed sensor circuit 3. Stop light switch circuit	05-307 05-331 05-336 05-377
ABS warning light abnormal	1. ABS warning light circuit 2. Skid control ECU	05-416 05-408
DTC of ABS check cannot be done	If the symptoms still occur even after the following circuits in suspect areas are inspected and proved to be normal, replace the skid control ECU. 1. Check the DTC again and make sure that the normal code is output. 2. Tc terminal circuit	05-307 05-432
Sensor signal check cannot be done	1. Ts terminal circuit 2. Skid control ECU	05-434 05-408
TRAC does not operate	If the symptoms still occur even after the following circuits in suspect areas are inspected and proved to be normal, replace the skid control ECU. 1. Check the DTC again and make sure that the normal code is output. 2. IG power source circuit 3. Check the hydraulic circuit for leakage. 4. Speed sensor circuit	05-307 05-368 - 05-331 05-336

Symptom	Suspect Area	See page
VSC does not operate	<p>If the symptoms still occur even after the following circuits in suspect areas are inspected and proved to be normal, replace the skid control ECU.</p> <ol style="list-style-type: none"> 1. Check the DTC again and make sure that the normal code is output. 2. IG power source circuit 3. Check the hydraulic circuit for leakage. 4. Speed sensor circuit 5. Deceleration sensor circuit 6. Yaw rate sensor circuit 7. Steering sensor circuit 	<p>05-307</p> <p>05-368</p> <p>-</p> <p>05-331</p> <p>05-336</p> <p>05-362</p> <p>05-399</p> <p>05-351</p> <p>05-365</p> <p>05-357</p>
SLIP indicator light abnormal	<ol style="list-style-type: none"> 1. SLIP indicator light circuit 2. Skid control ECU 	<p>05-428</p> <p>05-408</p>
VSC OFF indicator abnormal	<p>If the symptoms still occur even after the following circuits in suspect areas are inspected and proved to be normal, replace the skid control ECU.</p> <ol style="list-style-type: none"> 1. Check the DTC again and make sure that the normal code is output. 2. VSC OFF switch circuit 	<p>05-307</p> <p>05-423</p>
DTC of VSC check cannot be done	<p>If the symptoms still occur even after the following circuits in suspect areas are inspected and proved to be normal, replace the skid control ECU.</p> <ol style="list-style-type: none"> 1. Check the DTC again and make sure that the normal code is output. 2. Tc terminal circuit 	<p>05-307</p> <p>05-432</p>
VSC warning light abnormal	<p>If the symptoms still occur even after the following circuits in suspect areas are inspected and proved to be normal, replace the skid control ECU.</p> <ol style="list-style-type: none"> 1. Check the DTC again and make sure that the normal code is output. 2. VSC warning circuit 	<p>05-307</p> <p>05-418</p>