

DOOR GLASS GOES DOWN DURING AUTO UP OPERATION**CIRCUIT DESCRIPTION**

If the door glass or the power window regulator does not smoothly operate, the jam protection function may operate abnormally, resulting in this symptom.

INSPECTION PROCEDURE**1 RESET POWER WINDOW REGULATOR MOTOR**

- (a) Turn the ignition switch ON.
- (b) Open the back door glass.
- (c) Push down the back door power window switch until the door glass is fully closed, and hold the switch 1 second more even after the door glass is fully closed.
- (d) Check that the AUTO UP/DOWN function operates completely.

OK**END****NG****2 CHECK POWER WINDOW REGULATOR W/MOTOR**

- (a) Remove the back door glass (See page [75-39](#)).
- (b) Operate the power window regulator via the back door power window switch without the back door glass installed.
- (c) Check that the power window regulator operates smoothly.

OK**REPLACE BACK DOOR GLASS RUN****NG****REPLACE BACK DOOR POWER WINDOW REGULATOR SUB-ASSY**