


MANUAL UP/DOWN FUNCTION DOES NOT OPERATE

CIRCUIT DESCRIPTION


If the back door power window does not operate, the retract switch in the rear wiper motor or the back door power window motor or the wire harness is abnormal.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 CHECK REAR WIPER OPERATION



- Turn the ignition switch ON.
- Operate the rear wiper and turn the rear wiper switch OFF.
- Check the rear wiper stops at the retract position when the rear wiper switch is turned OFF.

NG

REPLACE REAR WIPER MOTOR ASSY

OK

2 INSPECT BACK DOOR POWER WINDOW REGULATOR SWITCH ASSY

- (a) Using the hand-held tester, read the DTC when the back power window switch is operated.
- (1) When DTC B1287 is output, proceed to A.
 - (2) When no DTC is output, proceed to B.
 - (3) When DTC B1241 is output, proceed to C.

A**INSPECT MULTIPLEX COMMUNICATION SYSTEM (See page 05-1285)****B****INSPECT BACK DOOR POWER WINDOW REGULATOR SWITCH ASSY (See page 05-1 131)****OK****3 READ VALUE OF HAND-HELD TESTER**


- (a) Check the condition of the retract switch using the data list.

Standard:**Data list for back door ECU:**

| Measurement Item | Label | Parameter |
|----------------------|----------------|-----------|
| Wiper retract switch | WIPER RTRCT SW | ON |

NG**Go to step 6****OK****4 CHECK HARNESS AND CONNECTOR (BACK DOOR ECU ↔ POWER WINDOW MOTOR)****Wire Harness Side**

B9
Multiplex Network Door ECU Back
(Back Door ECU)



B11
Power Window Regulator
Motor Assy LH (Back Door)




B62905

- (a) Disconnect the B9 back door ECU connector.
- (b) Disconnect the B11 motor connector.
- (c) Check the continuity between the wire harness side connectors.

Standard:

| Terminal No. | Specified Condition |
|----------------------|---------------------|
| 25 ↔ 5 | Continuity |
| 13 ↔ 4 | Continuity |
| 13, 25 ↔ Body ground | No continuity |

NG**REPAIR OR REPLACE HARNESS AND CONNECTOR****OK**

5 INSPECT POWER WINDOW REGULATOR MOTOR ASSY LH (BACK DOOR)


- (a) Remove the motor.
- (b) Apply battery voltage between the motor terminals and check that the motor rotates smoothly.

Standard:

| Terminal No. | Specified Condition |
|--|--------------------------------|
| Battery positive voltage ↔ 5 Battery negative voltage ↔ 4 | Motor rotates counterclockwise |
| Battery positive voltage ↔ 4 Battery negative voltage ↔ 5 | Motor rotates clockwise |

NG**REPLACE POWER WINDOW REGULATOR MOTOR ASSY LH (BACK DOOR)****OK****CHECK AND REPLACE MULTIPLEX NETWORK DOOR ECU BACK****6 CHECK HARNESS AND CONNECTOR (BACK DOOR ECU ↔ REAR WIPER MOTOR)****Wire Harness Side**

B9
Multiplex Network Door ECU Back
(Back Door ECU)



R23
Rear Wiper Motor Assy



B62909

- (a) Disconnect the B9 back door ECU connector.
- (b) Disconnect the R23 rear wiper motor connector.
- (c) Check the continuity between the wire harness side connectors.

Standard:

| Terminal No. | Specified Condition |
|----------------------|---------------------|
| 12 ↔ 1 | Continuity |
| 18 ↔ 2 | Continuity |
| 12, 18 ↔ Body ground | No continuity |

NG**REPAIR OR REPLACE HARNESS AND CONNECTOR****OK****REPLACE REAR WIPER MOTOR ASSY**