


BUZZER DOES NOT SOUND (KEY REMINDER WARNING, SEAT BELT WARNING)

WARNING DIAGRAM



INSPECTION PROCEDURE

1 CHECK VEHICLE CONDITION

(a) Check the vehicle model with the chart below.

HINT:

Seat belt warning buzzer is equipped with U.S.A. and Canada model only.

A	U.S.A., Canada model
B	Mexico model

B Go to step 3

A

2 CHECK BUZZER(KEY REMINDER WARNING, SEAT BELT WARNING)


(a) Check that the all of the warning buzzers sound.

A	Key reminder warning buzzer does not sound
B	Seat belt warning buzzer does not sound

B Go to step 5

A

3 CHECK COMBINATION METER ASSY



(a) Check the voltage.

- (1) Remove the combination meter assy.
- (2) Check the continuity between terminal C10-8 of the combination meter connector and body ground.

Standard:

Door position	Continuity
Open	Continuity
Close	No continuity

OK CHECK AND REPLACE COMBINATION METER ASSY

NG

4 CHECK HARNESS AND CONNECTOR(BETWEEN MULTIPLEX NETWORK BODY ECU AND COMBINATION METER ASSY)

- (a) Check the continuity between terminals B6-11 of the multiplex network body ECU and C10-8 of the combination meter connector.

Standard: There is continuity


NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

GO TO FLOW CHART (KEY REMINDER WARNING SYSTEM) (See page 05-1213)

5 CHECK COMBINATION METER ASSY



- (a) Remove the combination meter assy.
 (b) Check the continuity between terminal C9-12 of the combination meter connector and body ground.

Standard:


Condition	Continuity
Seat belt is fastened	Continuity
Seat belt is unfastened	No continuity

OK

CHECK AND REPLACE COMBINATION METER ASSY

NG

6 INSPECT FRONT SEAT INNER BELT ASSY LH



- (a) Check the resistance.
 (1) Check resistance between terminals 1 and 4 of the front seat inner belt assy LH.

Standard:

Condition	Resistance (Ω)
Seat belt is fastened	330
Seat belt is unfastened	1,330

NG

REPLACE FRONT SEAT INNER BELT ASSY LH

OK

REPAIR OR REPLACE HARNESS OR CONNECTOR