

DIAGNOSTIC TROUBLE CODE CHART

If a malfunction code is indicated during the DTC check, check the circuit listed for that code in the table below, and proceed to the appropriate page.

DTC No. (See Page)	Circuit Inspection	Trouble Area
P0500/21 (05-354)	Vehicle Speed Sensor "A"	<ul style="list-style-type: none"> • Combination meter assy • Vehicle speed sensor • Vehicle speed sensor circuit • ECM
P0503/23 (05-354)	Vehicle Speed Sensor "A" Intermittent/Erratic/High	
P0571/52 (★)	Brake Switch "A" Circuit	<ul style="list-style-type: none"> • Stop lamp switch assy • Stop lamp switch assy circuit • ECM
P0607/54 (★)	Control Module Performance	<ul style="list-style-type: none"> • ECM

★: See Pub. No. RM1001U