

## PROBLEM SYMPTOMS TABLE

If a normal code is displayed during the DTC check but the problem still occurs, check the circuits for each problem symptom in the order given in the table below and proceed to the relevant troubleshooting page.

Symptom	Suspect Area	See page
Main switch cannot be turned ON. (Cruise indicator light in combination meter is not lit.)	1. Cruise control switch circuit 2. CRUISE MAIN indicator light circuit 3. ECM	05-355 ★ 01-35
Vehicle speed setting cannot be done. (Although indicator light in combination meter is lit when the main switch is turned ON, they go off when vehicle speed is set.)	1. Cruise control switch circuit 2. ECM	05-355 01-35
Setting cannot be done. (Indicator light in combination meter is lit when the main switch is turned ON and they remain ON while setting.)	1. Cruise control switch circuit 2. Stop lamp switch circuit 3. PNP switch circuit 4. Combination meter system 5. ECM	05-355 ★ 05-291 ★ 01-35
While the vehicle is driving with cruise control, the set control is canceled. (Indicator light and CRUISE remain ON.)	1. Cruise control switch circuit 2. Vehicle speed sensor circuit 3. Stop lamp switch circuit 4. CRUISE MAIN indicator light circuit 5. PNP switch circuit 6. ECM	05-355 05-354 ★ ★ 05-291 01-35
Hunting (Speed is not constant.)	1. Vehicle speed sensor circuit 2. ECM	05-354 01-35
Setting cannot be cancelled. (When Coast, Acceleration, Resume, Set speed change and Control switch are operated.)	1. Cruise control switch circuit 2. ECM	05-355 01-35
DTC is not output, or is output when should not be.	1. Diagnosis circuit 2. ECM	★ 01-35
CRUISE MAIN indicator light does not light up.	1. Cruise control switch circuit 2. CRUISE MAIN Indicator light circuit 3. ECM	05-355 ★ 01-35

★: See Pub. No. RM1001U