

DTC	B2795	UNMATCHED KEY CODE
------------	--------------	---------------------------

CIRCUIT DESCRIPTION

This DTC is output when an unregistered key is inserted.

DTC No.	DTC Detection Condition	Trouble Area
B2795	Key with different ID code inserted in ignition switch	• Key

INSPECTION PROCEDURE

1	DELETE DTC AND INSERT ALL PRESENTLY AVAILABLE KEYS TO CHECK WHETHER ENGINE STARTS OR NOT
----------	---

- (a) Check whether the engine starts, after the re-registration of the key with which the engine does not start.

OK

**NO PROBLEM
(BECAUSE OF KEY RE-REGISTRATION)**

NG

REPLACE KEY WITH WHICH ENGINE DOES NOT START