

DTC	B2797	COMMUNICATION MALFUNCTION NO.1
------------	--------------	---------------------------------------

CIRCUIT DESCRIPTION


This DTC is output when an error occurs in the normal communication.

HINT:

Some noise exists in the communication line.

DTC No.	DTC Detection Condition	Trouble Area
B2797	Keys are positioned too close each other, or noise occurred in communication line	<ul style="list-style-type: none"> • Key • Wire harness • Transponder key amplifier (transponder key coil) • Transponder key ECU assy

WIRING DIAGRAM



INSPECTION PROCEDURE

1	CHECK OPERATION OF TRANSPONDER KEY AMPLIFIER
----------	---

(a) After exchanging the transponder key ECU, check that the engine starts.

OK

**NORMAL
(TRANSPONDER KEY AMPLIFIER DEFECTIVE)**

NG

REPLACE TRANSPONDER KEY ECU ASSY
