

## PROBLEM SYMPTOMS TABLE

Problem Symptom	Suspected Area	See Page
Engine does not start	1. Key	<a href="#">05-1238</a> <a href="#">05-1239</a> <a href="#">05-1240</a> <a href="#">05-1241</a> <a href="#">05-1244</a>
	2. Transponder key amplifier (transponder key coil)	<a href="#">05-1241</a> <a href="#">05-1244</a> <a href="#">05-1245</a>
	3. Transponder key ECU assy	<a href="#">05-1241</a> <a href="#">05-1244</a>