


AUTOMATIC LIGHT CONTROL SYSTEM DOES NOT OPERATE

WIRING DIAGRAM



C

E64841

INSPECTION PROCEDURE

1 CHECK LIGHT


- (a) Check that headlamp and taillight light up.

NG

FLOW CHART (GO TO FLOW CHART OF HEADLIGHT OR TAILLIGHT)

OK

2 INSPECT HEADLAMP DIMMER SWITCH ASSY



- (a) Inspect light control switch continuity.
 (1) Check that there is a continuity between terminals at each switch position as shown in the chart.

Standard:


Switch operation	Tester connection	Specified condition
OFF	-	No continuity
TAIL	14 - 16	Continuity
HEAD	13 - 16 - 14	Continuity
AUTO	16 - 12	Continuity

NG

REPLACE HEADLAMP DIMMER SWITCH ASSY

OK

3 CHECK AUTOMATIC LIGHT CONTROL SENSOR



- (a) Measure voltage between terminals as shown in the chart below.
 (b) Check the continuity between terminal 3 (CLTE) and body ground as shown in the chart below.
 (c) Using an oscilloscope, check that signal waveform appears between terminals.

Standard:

Terminal No. (Symbol)	Tester connection	Condition	Specified condition
1 (CLTB)	1 - 3	Constant	10 - 14 V
3 (CLTE)	3 - Body ground	Constant	Continuity
4 (CLTS)	4 - 3	IG SW ON Dimmer SW AUTO	Signal waveform appears depending on outside brightness

NG

REPLACE AUTOMATIC LIGHT CONTROL SENSOR

OK

4**CHECK HARNESS AND CONNECTOR(BETWEEN MULTIPLEX NETWORK BODY ECU AND AUTOMATIC LIGHT CONTROL SENSOR)**

- (a) Check that signal waveform appears between terminal B6-4 (CLTS) and B6-21 (CLTE) of the multiplex network body ECU.

Standard: Bar appears

- (b) Measure voltage between terminals B6-6 (CLTB) and B6-21 (CLTE) of the multiplex network body ECU.

Standard: 10 - 14 V

- (c) Check the continuity between terminal B6-21 (CLTE) of the multiplex network body ECU and body ground.

Standard: There is continuity

NG**REPAIR OR REPLACE HARNESS OR CONNECTOR****OK****CHECK AND REPLACE MULTIPLEX NETWORK BODY ECU**