

PROBLEM SYMPTOMS TABLE

1. HEADLAMP AND TAIL LAMP

Symptom	Suspect Area	See page
Only one headlamp comes on.	1. Bulb 2. HEAD LH fuse (LWR, UPR) 3. HEAD RH fuse (LWR, UPR) 4. Harness or connector	- - - -
Headlamp does not light up.	-	05-849
"HI-Beam" does not light (All).	1. Headlamp dimmer switch 2. Harness or connector	65-4 -
"HI-Beam" does not light (One side).	1. Bulb 2. Harness or connector	- -
"Flash" does not light.	1. Headlamp Dimmer Switch 2. Turn signal flasher relay 3. Harness or connector	65-4 65-4 -
Headlamp is dark.	1. Bulb 2. Harness or connector	- -
Only one tail lamp light up.	1. Bulb 2. Harness or connector	- -
Tail lamp does not light up. (Headlamp is normal)	-	05-851
Tail lamp does not light up. (Headlamp does not light)	1. Light Control Switch 2. Harness or connector	65-4 -
Rear combination light does not light up.	1. Bulb 2. Harness or connector	- -
Headlamp does not light up with engine running and light control switch is in OFF (Day time running light operation).	1. Turn signal flasher and DRL relay 2. Generator L terminal 3. Parking brake switch 4. Multiplex network body ECU 5. Harness or connector	65-4 - - 05-828 -

2. AUTOMATIC LIGHT CONTROL SYSTEM

Symptom	Suspect Area	See page
Automatic light control system does not operate	-	05-855

3. LIGHT AUTO CUT SYSTEM

Symptom	Suspect Area	See page
Light auto turn off system does not operate.	-	05-858
Headlamp and tail lamp do not come on.	1. Multiplex network body ECU 2. Harness or connector	05-828 -
Headlamp and taillight stay on.	1. Multiplex network body ECU 2. Harness or connector	05-828 -

4. FOG LAMP SYSTEM

Symptom	Suspect Area	See page
Front fog lamp does not light up with light control SW HEAD (Headlamp is normal).	1. FOG Fuse 2. FOG relay 3. Fog lamp switch 4. Harness or connector	- - 65-4 -
Only one front fog lamp does not light up.	1. Bulb 2. Harness or connector	- -

5. TURN SIGNAL AND HAZARD WARNING SYSTEM

Symptom	Suspect Area	See page
"Hazard" and "Turn" do not light up.	1. IG1 Fuse 2. Ignition switch 3. Turn signal flasher 4. Harness or connector	- - 65-2 -
Hazard warning light does not light up. (Turn is normal)	1. Hazard warning switch 2. Harness or connector	65-4 -
Turn signal does not light up. (Hazard is normal)	1. Turn signal switch 2. Harness or connector	65-4 -
Turn signal does not light up in one direction.	1. Turn signal switch 2. Harness or connector	65-4 -
Only one bulb does not light up.	1. Bulb 2. Harness or connector	- -

6. ILLUMINATED ENTRY SYSTEM

Symptom	Suspect Area	See page
Room lamp assy No.1 does not light up.	-	05-837
Room lamp assy No.1 does not go off.	-	05-843
Courtesy lamp does not light up.	1. Courtesy lamp 2. Courtesy lamp switch 3. Harness or connector 4. Driver side junction block assy	- - - -
Courtesy lamp does not go off.	1. Courtesy lamp switch 2. Harness or connector 3. Courtesy lamp 4. Driver side junction block assy	- - - -
Side step lamp does not light up.	1. Side step lamp 2. Courtesy lamp switch 3. Harness or connector 4. Multiplex network body ECU	- - - -
Side step lamp does not go off.	1. Courtesy lamp switch 2. Harness or connector 3. Side step lamp 4. Multiplex network body ECU	- - - -