

DTC	B1214	DOOR SYSTEM COMMUNICATION BUS MALFUNCTION (+B SHORT)
------------	--------------	---


DTC	B1215	DOOR SYSTEM COMMUNICATION BUS MALFUNCTION (GND SHORT)
------------	--------------	--

CIRCUIT DESCRIPTION

B1214 and B1215 are output when +B and the body ground is short-circuited on the communication bus. Detecting this condition disables all the BEAN communication and outputs some DTCs.

DTC No.	DTC Detection Condition	Trouble Area
B1214	Communication circuit and +B battery system short	<ul style="list-style-type: none"> • Theft warning ECU Assy (Theft deterrent ECU) • Multiplex network door ECU back (Back door ECU) • Wire harness • Instrument panel junction block Assy (Body ECU)
B1215	Communication circuit and body ground short	<ul style="list-style-type: none"> • Theft warning ECU Assy (Theft deterrent ECU) • Wire harness • Multiplex network door ECU back (Back door ECU) • Instrument panel junction block Assy (Body ECU)


WIRING DIAGRAM



INSPECTION PROCEDURE

1 CHECK DIAGNOSTIC TROUBLE CODE (A ECU)

- (a) Check whether the output of the DTC stops when the A ECU connector is disconnected.

**NOTICE:**

Disconnect the connectors in the operational sequence, and start the next Step after the connector is connected.

HINT:

In this case, the A ECU represents the back door ECU.

Standard: When the output of the DTC stops, the disconnected A ECU is abnormal .


OK

REPLACE A ECU

NG

2 CHECK DIAGNOSTIC TROUBLE CODE (B ECU)

- (a) Check whether the output of the DTC stops when the B ECU connector is disconnected.



NOTICE:

Disconnect the connectors in the operational sequence, and start the next step after the connector is connected.

HINT:

In this case, the B ECU represents the theft deterrent ECU.

Standard: When the output of the DTC stops, the disconnected B ECU is abnormal.


OK

REPLACE B ECU

NG

3 CHECK WIRE HARNESS BETWEEN BODY ECU AND A ECU OR B ECU

- (a) Disconnect the A ECU, B ECU and body ECU connectors.
 (b) Check the wire harness (MPX line) between the A ECU, B ECU and body ECU.



- (1) Turn the ignition switch ON.
 (2) Check the voltage between the wire harness (MPX lines) and body ground.

Standard:

MPX Line ↔ Body ground	Voltage
Body ECU or A ECU (Back door ECU) ↔ Body ground	0 V
Body ECU or B ECU (Theft deterrent ECU) ↔ Body ground	

If the output voltage is not 0 V, the wire harness (MPX line) may be short-circuited with +B.

- (3) Check the continuity of the wire harness (MPX lines) and body ground.

Standard:

MPX Line ↔ Body ground	Continuity
Body ECU or A ECU (Back door ECU) ↔ Body ground	No continuity
Body ECU or B ECU (Theft deterrent ECU) ↔ Body ground	

If there is continuity, the wire harness (MPX line) and body ground may be short-circuited with the body ground.

NG

**REPAIR OR REPLACE WIRE HARNESS
BETWEEN BODY ECU AND A ECU OR B ECU**

OK

REPLACE INSTRUMENT PANEL JUNCTION BLOCK ASSY