

## MAP IS DISPLAYED IN WHITE OR BLUE SCREEN (SWITCHED AND VEHICLE POSITION MARK ARE DISPLAYED)

### INSPECTION PROCEDURE

#### 1 CHECK SETTING

(a) Check the settings

(1) Check that the map display is normal when set up the scale of the map widest area.

**STANDARD: Map display is normal**

OK

NORMAL

NG

#### 2 CHECK AND OPERATE AGAIN

(a) Clean the map disk

(1) After wiping the map disk in the circumference direction with a soft cloth, insert it again.

OK

NORMAL

NG

#### 3 REPLACE DISC PLAYER DISC

NG

#### CHECK AND REPLACE NAVIGATION ECU