

PROBLEM SYMPTOMS TABLE

Flow chart No.	Symptom	See page
1	Even when pressing "PWR/VOL" switch or any audio switch, the screen remains black.	05-987
2	Panel switch does not function.	05-989
3	Although "PWR/VOL" switch is pressed, no sound is heard (Display and switch operation is normal).	05-990
4	No navigation screen displayed when "NAVI" "MAP/VOICE" or "DEST" switch pressed (Screen cannot be switched).	05-992
5	Navigation screen not stabilized (Synchronous error).	05-995
6	Color on navigation screen is unusual (RGB signal error).	05-998
7	Front speaker (Driver side) only is not heard (Radio, cassette tape, CD).	05-1002
8	Map DVD cannot be inserted.	05-1005
9	Map screen displayed does not appear (Disc caution screen does not change).	05-1007
10	Map is displayed in white or blue screen (Switched and vehicle position mark are displayed).	05-1008
11	Screen cannot be dimmed when light control switch is turned to "TAIL" position.	05-1009
12	Touch switch does not function (Navigation screen only).	05-1012
13	Vehicle position is deviated from correct point badly.	05-1013
14	GPS mark does not appear.	05-1015
15	No voice navigation.	05-1016
16	Vehicle position mark rotates without control (Map rotates without control).	05-1018
17	Driving directions opposite to moving direction of vehicle position mark.	05-1020
18	CD cannot be inserted / is ejected right after insertion / cannot be played.	05-1022
19	CD cannot be ejected.	05-1024
20	Cassette tape cannot be inserted or played.	05-1022
21	Cassette tape cannot be ejected.	05-1024
22	CD sound skips.	05-1026
23	Noise occurs.	05-1032
24	Radio broadcast cannot be received. (Bad reception).	05-1034
25	Rear seat entertainment system does not respond to any remote control operations.	05-1036
26	Quality of sound from wireless headphone is poor or no sound can be heard.	05-1038

EXAMPLES OF MISUNDERSTANDING SYMPTOMS AS MALFUNCTIONS

Condition	Cause	Procedure to recover
Screen displays "AUDIO OFF", even when "PWR/VOL" switch is turned off.	"PWR/VOL" switch turns the audio off, but not the screen. To turn off the screen, "SCREEN OFF" switch must be pressed.	Press "DISPLAY" switch → Press "SCREEN OFF" switch on screen
The screen is too dark or too bright, when the screen is changed between navigation and audio.	The contrast set up of the screen between navigation and audio is different. The contrast needs to be set up for each of the navigation and audio screen.	*Navigation: Press "DISPLAY" and adjust by "BRIGHTNESS" switch. *AUDIO: Press "DISPLAY" and adjust by "CONTRAST" switch.
Present position is not displayed even when "NAVI" switch is pressed.	Pressing "NAVI" switch displays the previous screen. For present position, "MAP/VOICE" switch must be pressed.	Press "NAVI" switch → Press "MAP/VOICE" switch.
Even when pressing the panel switch, it doesn't function.	*Since this switch is pressure sensitive type, press the switch securely. *The panel switch toned down does not work even if is pressed.	Press the panel switch securely, if the pressure is weak or time is insufficient, the switch does not function.