

DOOR GLASS GOES DOWN DURING AUTO UP OPERATION**CIRCUIT DESCRIPTION**

If the door glass or the power window regulator does not smoothly operate, the jam protection function may operate abnormally, resulting in this symptom.

INSPECTION PROCEDURE**1 RESET POWER WINDOW REGULATOR MOTOR**

- (a) Turn the ignition switch ON.
- (b) Open the driver side door glass.
- (c) Pull up the AUTO switch of the master switch 2 notches until the window glass closes.
- (d) Check that the AUTO UP/DOWN function operates completely.

OK **END****NG****2 CHECK POWER WINDOW REGULATOR W/ MOTOR (DRIVER SIDE)**

- (a) Remove the driver side door glass (See page [75-15](#)).
- (b) Operate the power window regulator via the power window master switch without the door glass installed.
- (c) Check that the power window regulator operates smoothly.

OK **REPLACE FRONT DOOR GLASS RUN LH****NG****REPLACE FRONT DOOR WINDOW REGULATOR SUB-ASSY LH**