

# REAR AIR SUSPENSION SYSTEM

## HOW TO PROCEED WITH TROUBLESHOOTING

056A4-02

**1 VEHICLE BROUGHT TO WORKSHOP**



**2 CUSTOMER PROBLEM ANALYSIS (See page 05-231 )**




**3 CHECK AND CLEAR DTCS (See page 05-232 )**



**4 PROBLEM SYMPTOM CONFIRMATION**



**SYMPTOM DOES NOT OCCUR (Go to step 5)**




**SYMPTOM OCCUR (Go to step 6)**


**5 SYMPTOM SIMULATION (See page 01-25 )**



**6 DTC CHECK (See page 05-232 )**



**NORMAL CODE (Go to step 7)**



**MALFUNCTION CODE (Go to step 8)**

**7 PROBLEM SYMPTOMS TABLE (See page 05-246 )**



**8 DTC CHART (See page 05-240 )**



**9 CIRCUIT INSPECTION (See page 05-248 to 05-301 )**



10	IDENTIFICATION OF PROBLEM
----	---------------------------



11	REPAIR
----	--------



12	CONFIRMATION TEST
----	-------------------



END
-----

HINT:

The hand-held tester can be used for step 3, 6, 9 and 12.