

# DIAGNOSTIC TROUBLE CODE CHART

DTC No. (See page)	Detection Item	Trouble Area	SRS Warning Light
B0100/13 (05-629)	• Short in D squib circuit	• Horn button assy (squib) • Spiral cable sub-assy • Airbag sensor assy center • Instrument panel wire	ON
B0101/14 (05-634)	• Open in D squib circuit	• Horn button assy (squib) • Spiral cable sub-assy • Airbag sensor assy center • Instrument panel wire	ON
B0102/11 (05-638)	• Short in D squib circuit (to ground)	• Horn button assy (squib) • Spiral cable sub-assy • Airbag sensor assy center • Instrument panel wire	ON
B0103/12 (05-642)	• Short in D squib circuit (to B+)	• Horn button assy (squib) • Spiral cable sub-assy • Airbag sensor assy center • Instrument panel wire	ON
B0105/53 (05-646)	• Short in P squib circuit	• Instrument panel passenger airbag assy (squib) • Airbag sensor assy center • Instrument panel wire	ON
B0106/54 (05-649)	• Open in P squib circuit	• Instrument panel passenger airbag assy (squib) • Airbag sensor assy center • Instrument panel wire	ON
B0107/51 (05-652)	• Short in P squib circuit (to ground)	• Instrument panel passenger airbag assy (squib) • Airbag sensor assy center • Instrument panel wire	ON
B0108/52 (05-655)	• Short in P squib circuit (to B+)	• Instrument panel passenger airbag assy (squib) • Airbag sensor assy center • Instrument panel wire	ON
B0110/43 (*1) (05-658)	• Short in side squib (RH) circuit	• Front seat airbag assembly RH (squib) • Airbag sensor assy center • Floor wire	Blink
B0111/44 (*1) (05-661)	• Open in side squib (RH) circuit	• Front seat airbag assembly RH (squib) • Airbag sensor assy center • Floor wire	Blink
B0112/41 (*1) (05-664)	• Short in side squib (RH) circuit (to ground)	• Front seat airbag assembly RH (squib) • Airbag sensor assy center • Floor wire	Blink
B0113/42 (*1) (05-667)	• Short in side squib (RH) circuit (to B+)	• Front seat airbag assembly RH (squib) • Airbag sensor assy center • Floor wire	Blink
B0115/47 (*1) (05-670)	• Short in side squib (LH) circuit	• Front seat airbag assembly LH (squib) • Airbag sensor assy center • Floor wire No.2	Blink
B0116/48 (*1) (05-673)	• Open in side squib (LH) circuit	• Front seat airbag assembly LH (squib) • Airbag sensor assy center • Floor wire No.2	Blink
B0117/45 (*1) (05-676)	• Short in side squib (LH) circuit (to ground)	• Front seat airbag assembly LH (squib) • Airbag sensor assy center • Floor wire No.2	Blink
B0118/46 (*1) (05-679)	• Short in side squib (LH) circuit (to B+)	• Front seat airbag assembly LH (squib) • Airbag sensor assy center • Floor wire No.2	Blink
B0126/B0127/ 27 (05-682)	• Open in front seat inner belt (LH) circuit • Short in front seat inner belt (LH) circuit	• Front seat inner belt LH • Airbag sensor assy center • Floor wire No.2	ON

B0130/63 (05-686)	• Short in P/T squib (RH) circuit	• Seat belt pretensioner RH (squib) • Airbag sensor assy center • Floor wire	Blink
B0131/64 (05-690)	• Open in P/T squib (RH) circuit	• Seat belt pretensioner RH (squib) • Airbag sensor assy center • Floor wire	Blink
B0132/61 (05-693)	• Short in P/T squib (RH) circuit (to ground)	• Seat belt pretensioner RH (squib) • Airbag sensor assy center • Floor wire	Blink
B0133/62 (05-696)	• Short in P/T squib (RH) circuit (to B+)	• Seat belt pretensioner RH (squib) • Airbag sensor assy center • Floor wire	Blink
B0135/73 (05-699)	• Short in P/T squib (LH) circuit	• Seat belt pretensioner LH (squib) • Airbag sensor assy center • Floor wire No.2	Blink
B0136/74 (05-703)	• Open in P/T squib (LH) circuit	• Seat belt pretensioner LH (squib) • Airbag sensor assy center • Floor wire No.2	Blink
B0137/71 (05-706)	• Short in P/T squib (LH) circuit (to ground)	• Seat belt pretensioner LH (squib) • Airbag sensor assy center • Floor wire No.2	Blink
B0138/72 (05-709)	• Short in P/T squib (LH) circuit (to B+)	• Seat belt pretensioner LH (squib) • Airbag sensor assy center • Floor wire No.2	Blink
B1100/31 (05-712)	• Airbag sensor assy center malfunction	• Airbag sensor assy center	ON
B1135/24 (*1) (05-713-8)	• Half connection in airbag sensor assy connector	• Electrical connection check mechanism • Airbag sensor assy center	ON
B1140/32 (*1) (05-714)	• Side Airbag sensor assy center (RH) malfunction	• Side airbag sensor assy RH • Airbag sensor assy center • Floor wire	Blink
B1141/33 (*1) (05-719)	• Side Airbag sensor assy center (LH) malfunction	• Side airbag sensor assy LH • Airbag sensor assy center • Floor wire No.2	Blink
B1148/36 (05-724)	• Front airbag sensor (RH) malfunction	• Airbag front RH sensor • Airbag sensor assy center • Instrument panel wire • Engine room main wire	ON
B1149/37 (05-731)	• Front airbag sensor (LH) malfunction	• Airbag sensor front LH • Airbag sensor assy center • Instrument panel wire • Engine room main wire	ON
B1153/25 (05-738)	• Seat position sensor malfunction • Short in seat position sensor circuit (to ground and to B+)	• Seat position airbag sensor • Center airbag sensor assembly • Front seat inner belt assembly LH • Floor wire No.2	ON
B1160/83 (*1) (05-754)	• Short in curtain shield squib (RH) circuit	• Curtain shield airbag assy RH (squib) • Airbag sensor assy center • Floor wire	Blink
B1161/84 (*1) (05-758)	• Open in curtain shield squib (RH) circuit	• Curtain shield airbag assy RH (squib) • Airbag sensor assy center • Floor wire	Blink
B1162/81 (*1) (05-761)	• Short in curtain shield squib (RH) circuit (to ground)	• Curtain shield airbag assy RH (squib) • Airbag sensor assy center • Floor wire	Blink
B1163/82 (*1) (05-764)	• Short in curtain shield squib (RH) circuit (to B+)	• Curtain shield airbag assy RH (squib) • Airbag sensor assy center • Floor wire	Blink

## DIAGNOSTICS - SUPPLEMENTAL RESTRAINT SYSTEM

B1165/87 (*1) (05-767)	• Short in curtain shield squib (LH) circuit	• Curtain shield airbag assy LH (squib) • Airbag sensor assy center • Floor wire No.2	Blink
B1166/88 (*1) (05-771)	• Open in curtain shield squib (LH) circuit	• Curtain shield airbag assy LH (squib) • Airbag sensor assy center • Floor wire No.2	Blink
B1167/85 (*1) (05-774)	• Short in curtain shield squib (LH) circuit (to ground)	• Curtain shield airbag assy LH (squib) • Airbag sensor assy center • Floor wire No.2	Blink
B1168/86 (*1) (05-777)	• Short in curtain shield squib (LH) circuit (to B+)	• Curtain shield airbag assy LH (squib) • Airbag sensor assy center • Floor wire No.2	Blink
B1180/17 (05-780)	• Short in D squib (2nd step) circuit	• Horn button assy (squib (2nd step)) • Spiral cable sub-assy • Airbag sensor assy center • Instrument panel wire	ON
B1181/18 (05-784)	• Open in D squib (2nd step) circuit	• Horn button assy (squib (2nd step)) • Spiral cable sub-assy • Airbag sensor assy center • Instrument panel wire	ON
B1182/19 (05-788)	• Short in D squib (2nd step) circuit (to ground)	• Horn button assy (squib (2nd step)) • Spiral cable sub-assy • Airbag sensor assy center • Instrument panel wire	ON
B1183/22 (05-792)	• Short in D squib (2nd step) circuit (to B+)	• Horn button assy (squib (2nd step)) • Spiral cable sub-assy • Airbag sensor assy center • Instrument panel wire	ON
B1185/57 (05-796)	• Short in P squib (2nd step) circuit	• Instrument panel passenger airbag assy (squib (2nd step)) • Airbag sensor assy center • Instrument panel wire	ON
B1186/58 (05-799)	• Open in P squib (2nd step) circuit	• Instrument panel passenger airbag assy (squib (2nd step)) • Airbag sensor assy center • Instrument panel wire	ON
B1187/55 (05-802)	• Short in P squib (2nd step) circuit (to ground)	• Instrument panel passenger airbag assy (squib (2nd step)) • Airbag sensor assy center • Instrument panel wire	ON
B1188/56 (05-805)	• Short in P squib (2nd step) circuit (to B+)	• Instrument panel passenger airbag assy (squib (2nd step)) • Airbag sensor assy center • Instrument panel wire	ON
Normal (05-808)	• System normal	-	OFF
	• Voltage source drop	• Battery • Airbag sensor assy center	ON

\*1: w/ Side Airbag

## HINT:

- When the SRS warning light remains lit up and the DTC is the normal code, a voltage source drop is possible.  
This malfunction is not stored in memory by the airbag sensor assy center and if the power source voltage returns to normal, the SRS warning light will automatically go out.
- When 2 or more codes are indicated, smaller numbered code will be shown first.
- If a code not listed on the chart is displayed, the Airbag sensor assy center is at fault.
- In the case of any malfunction concerning any open circuit, ground short, or B+ short due to any squib, another malfunction code may not be detected. In this case, correct the malfunction currently indicated and then perform malfunction diagnosis again. Another malfunction code may then be detected.