

PROBLEM SYMPTOMS TABLE

HINT:

Proceed with troubleshooting of each circuit in the table below.

Symptom	Suspect Area	See page
<ul style="list-style-type: none"> When the ignition switch in ACC or ON position, the SRS warning light sometimes lights up after approx. 6 seconds have elapsed. SRS warning light is always lit up even when ignition switch is in the LOCK position. 	<ul style="list-style-type: none"> SRS warning light circuit malfunction (Always lights up, when ignition switch is LOCK position). 	05-811
<ul style="list-style-type: none"> With the ignition switch in ACC or ON position, the SRS warning light does not light up. 	<ul style="list-style-type: none"> SRS warning light circuit malfunction (Does not light up, when ignition switch is turned to ACC or ON). 	05-814
<ul style="list-style-type: none"> DTC is not displayed. SRS warning light is always lit up at the time of DTC check procedure. DTC is displayed without TC and CG terminal connection. 	<ul style="list-style-type: none"> TC terminal circuit 	05-816