



1003

INSPECTION PROCEDURE**1 CHECK CONNECTOR**

- (a) Disconnect the negative (-) terminal cable from the battery, and wait at least for 90 seconds.
- (b) Check the connection of the airbag sensor assy center connectors.


NG**CONNECT CONNECTORS****OK****2 PERFORM A VISUAL CHECK OF THE DISCONNECTION DETECTION PIN**

- (a) Disconnect the negative (-) terminal cable from the battery, and wait at least for 90 seconds.
- (b) With 3 connectors being connected to the airbag sensor assy center, place tester leads onto any 2 or 3 disconnection detection pins and check for continuity.

OK:**Continuity****NG****REPLACE AIRBAG SENSOR ASSY CENTER CONNECTOR****OK****3 CHECK COMBINATION METER ASSY**

- (a) Remove the combination meter assy (See page 71-12).
- (b) Connect the negative (-) terminal cable to the battery.
- (c) Turn the ignition switch to ON position.
- (d) Measure the voltage between the body ground and terminal C11-8 of the combination meter assy.


OK:**Voltage: 8 - 16 V****NG****REPAIR OR REPLACE COMBINATION METER ASSY****OK**

4 CHECK WIRE HARNESS

- Disconnect the negative (-) terminal cable from the battery, and wait at least for 90 seconds.
- Disconnect the connector from the airbag sensor assy center.
- Measure the resistance between the body ground and the terminal LA.

OK:**Resistance : 1 MΩ or Higher****NG**

**REPAIR OR REPLACE WIRE HARNESS
(AIRBAG SENSOR ASSY CENTER -
COMBINATION METER ASSY)**

OK**5 CHECK WIRE HARNESS**

- Measure the resistance between the terminal C11-8 of the combination meter assy connector and the terminal LA of the airbag sensor assy center connector.

OK:**Resistance: Below 1 Ω****NG**

**REPAIR OR REPLACE WIRE HARNESS
(AIRBAG SENSOR ASSY CENTER -
COMBINATION METER ASSY)**

OK**REPLACE AIR BAG SENSOR ASSY CENTER**