

PROBLEM SYMPTOMS TABLE

Proceed to the reference page shown in the table below for each malfunction symptom and troubleshoot each circuit.

HINT:

Troubleshooting of the theft deterrent system is based on the premise that the door lock control system and the wireless door lock control system are operating normally. Accordingly, before troubleshooting the theft deterrent system, first make certain that the door lock control system and the wireless door lock control system are operating normally.

Symptom	Suspected Area	See Page
Theft deterrent system cannot be set.	1. Security indicator light circuit 2. ECU power source circuit 3. Un-lock warning switch circuit 4. Door key lock and unlock switch 5. Back door key lock and unlock switch 6. Door courtesy switch circuit 7. Back door courtesy switch circuit 8. Engine hood courtesy switch circuit	05-1255 05-1258 05-1213 73-3 73-3 05-1250 05-1250 05-1262
Security indicator light does not blink when theft deterrent system is set.	1. Security indicator light circuit	05-1255
Alarm sounding state is not canceled when ignition switch is turned ON-OFF 10 times within 15 seconds.	1. Ignition switch circuit 2. Un-lock warning switch circuit	05-1260 05-1213
Theft deterrent theft deterrent system can be set even when any door is open.	1. Door courtesy switch circuit	05-1250
Horn does not sound while theft deterrent system is in warning operation.	1. Theft deterrent horn circuit	05-1265
Headlights do not flash while theft deterrent system is in warning operation.	1. Headlight circuit	05-849
Taillights do not flash while theft deterrent system is in warning operation.	1. Taillights circuit	05-851
Hazard warning lights do not flash while theft deterrent system is in warning operation.	1. Hazard warning switch	65-2
Room lamp does not flash while theft deterrent system is in warning operation.	1. Room lamp circuit	05-837
Horn sounds even when theft deterrent system is not set.	1. Theft deterrent horn circuit	05-1265
Headlights flash even when theft deterrent system is not set.	1. Headlight circuit	05-849
Taillights flash even when theft deterrent system is not set.	1. Taillights circuit	05-851
Hazard warning lights flash even when theft deterrent system is not set.	1. Hazard warning switch circuit	65-2
Room lamp flashes even when theft deterrent system is not set.	1. Room lamp circuit	05-837