

INSPECTION


1. INSPECT FUEL INJECTOR ASSY

(a) Inspect injector resistance

- (1) Using an ohmmeter, measure the resistance between the terminals.

Resistance: 11.6 - 12.4 Ω at 20°C (68°F)


If the resistance is not as specified, replace the injector.




(b) Inspect injector inspection

CAUTION:

Keep injector clear of sparks during the test.



- (1) Obtain the new No.1 fuel pipe (part No. 23801-31070) and take out the fuel tube connector from the pipe.



- (2) Install the fuel tube connector to a SST (hose), then connect the tube connect and fuel pipe.

SST 09268-41047 (95336-08070)

CAUTION:


Connect the fuel tube connector (quick type) after observing the precautions.





- (3) Remove the pressure regulator from the delivery pipe.
- (4) Install the O-ring to the fuel inlet of the pressure regulator.
- (5) Connect the SST (hose) to the fuel inlet of the pressure regulator with another SST (union) and the 2 bolts.

SST 09268-41047 (95336-08070, 09268-41091)

Torque: 7.5 N·m (80 kgf·cm, 66 in.-lbf)

- (6) Connect the fuel return hose to the fuel outlet of the pressure regulator.





- (7) Install the O-ring to the injector.
- (8) Connect SSTs (adaptor and hose) to the injector, and hold the injector and union with SST (clamp)
- SST 09268-41047 (09268-41140, 09268-41400, 95336-08070)
- (9) Put the injector into a graduated cylinder.

CAUTION:

Install a suitable vinyl tube onto the injector to prevent gasoline from splashing out.

- (10) Operate the fuel pump. (See Page 11-5)
- (11) Connect a SST (wire) to the injector and battery for 15 seconds, and measure the injection volume with a graduated cylinder. Test each injector 2 or 3 times.

SST 09842-30080

Volume: 76 - 91 cm³ (4.6 - 5.5 cu in.) per 15 seconds

Difference between each injector:

15 cm³ (0.9 cu in.) or less

If the injection volume is not as specified, replace the injector.

- (c) Inspect leakage
 - (1) In the condition above, disconnect the tester probes of the SST (wire) from the battery and check the fuel leakage from the injector.


SST 09842-30080

Fuel drop: 1 drop or less per 12 minutes

2. INSPECT FUEL PUMP RESISTOR

- (a) Inspect the fuel pump resistor resistance.
 - (1) Using an ohmmeter, measure the resistance between terminal.

Resistance: 0.70 - 0.76 Ω at 20°C (68°F)




3. INSPECT FUEL PUMP

- (a) Inspect fuel pump resistance.
 - (1) Using an ohmmeter, measure the resistance between terminals 4 and 5.

Resistance: 0.2 - 3.0 Ω at 20°C (68°F)
- (b) Inspect fuel pump operation
 - (1) Apply the battery voltage to both terminals. Check that the pump operates.

NOTICE:

- These tests must be done quickly (within 10 seconds) to prevent the coil from burning out.
- Keep fuel pump as far away from the battery as possible.
- Always do the switching at the battery side.



4. INSPECT FUEL PUMP RELAY ASSY

- (a) Continuity inspection.
 - (1) Using the ohmmeter, check that there is continuity between each terminal.

Specified condition:

Between terminals	Specified condition
1 - 2	Continuity
3 - 4	
3 - 5	No continuity

- (2) Using the ohmmeter, check that there is continuity between terminals 3 and 5 when the battery voltage is applied across terminals 1 and 2.

Specified condition: Continuity