

COMBINATION METER (1GR-FE)

710DR-01

ON-VEHICLE INSPECTION

1. INSPECT TACHOMETER

(a) Check the operation.

(1) Connect a tune-up test tachometer, and start the engine.

NOTICE:

- **Reversing the connection of the tachometer will damage the transistors and the diodes inside.**
- **When removing or installing the tachometer, be careful not to drop it or give it heavy shocks.**

(2) Compare the test and the tachometer indications.

DC 13.5 V, 25 °C at (77 °F)

Standard indication (r/min)	Allowable range (r/min) Data in () are for reference
700	630 - 770
1,000	(900 - 1,100)
2,000	(1,850 - 2,150)
3,000	2,800 - 3,200
4,000	(3,800 - 4,200)
5,000	4,800 - 5,100
6,000	(5,750 - 6,250)