

COMBINATION METER

PROBLEM SYMPTOMS TABLE

71068-03

Warning Lights and Buzzer:

Symptom	Suspect Area	See page
Charge warning light does not light up.	1. Wire Harness or Connector 2. Generator 3. Combination Meter Assy	- - -
Check Engine warning light does not light up.	1. Wire Harness or Connector 2. ECM 3. Combination Meter Assy	- 05-1 -
Brake warning light does not light up.	1. Wire Harness or Connector 2. Parking Brake Switch 3. Brake Fluid Level Switch 4. Skid Control ECU 5. Combination Meter Assy	- - - 05-303 -
ABS warning light does not light up.	1. Wire Harness or Connector 2. Skid Control ECU 3. Brake Master Cylinder Sub-assy 4. Combination Meter Assy	- 05-303 - -
SRS warning light does not light up.	1. Wire Harness or Connector 2. Airbag Sensor Assy 3. Combination Meter Assy	- 05-611 -
Open Door warning light does not light up.	1. Wire Harness or Connector 2. Door Courtesy Light Switch 3. MPX Body ECU 4. Combination Meter Assy	- 05-819 - -
Fuel Level warning light does not light up.	1. Wire Harness or Connector 2. Fuel Sender Gauge 3. Combination Meter Assy	- - -
Low Oil Pressure warning light does not light up.	1. Wire Harness or Connector 2. Low Oil Pressure Warning Switch 3. Combination Meter Assy	- - -
Window washer level warning does not lights up.	1. Wire Harness or Connector 2. Window washer level waring switch 3. Combination Meter Assy	- - -
AT Oil Temp. warning light does not light up.	1. Wire Harness or Connector 2. ECM 3. Combination Meter Assy	- 05-1 -

Indicator Lights:

Symptom	Suspect Area	See page
VSC, TRAC indicator light does not light up.	1. Wire Harness or Connector 2. Skid Control ECU 3. Combination Meter Assy	- 05-303 -
Shift indicator lights do not light up.	1. Wire Harness or Connector 2. Neutral Start Switch Circuit 3. Combination Meter Assy	- 05-436 -
High Beam indicator light does not light up.	1. Wire Harness or Connector 2. Headlight Dimmer Switch 3. Combination Meter Assy	- - -
TRAC OFF indicator light does not light up (2WD).	1. Wire Harness or Connector 2. TRAC OFF Switch Circuit 3. Skid Control ECU 4. Combination Meter Assy	- 05-303 05-303 -

VSC OFF indicator light does not light up (4WD).	1. Wire Harness or Connector 2. 4WD Control Switch Circuit 3. Skid Control ECU 4. Combination Meter Assy	- 05-303 05-303 -
DAC indicator light does not light up (4WD).	1. Wire Harness or Connector 2. Skid Control ECU 3. Combination Meter Assy	- 05-303 -
Center Difflock light does not light up (4WD).	1. Wire Harness or Connector 2. 4WD Control ECU 3. Combination Meter Assy	- 05-303 -
4LD light does not light up (4WD).	1. Wire Harness or Connector 2. 4WD Control ECU 3. Combination Meter Assy	- 05-303 -
Hight Control light does not light up.	1. Wire Harness or Connector 2. Suspension Control ECU 3. Combination Meter	- 05-229 -
SLIP indicator light does not light up.	1. Wire Harness or Connector 2. Skid Control ECU 3. Combination Meter Assy	- 05-303 -

Meter Gauges:

Symptom	Suspect Area	See page
Tachometer, Fuel Gauge and Water Temperature Gauge do not operate.	1. Wire Harness or Connector 2. GAUGE Fuse 3. Combination Meter Assy	- - -
Fuel Gauge does not operate or abnormal operation.	1. Wire Harness or Connector 2. Fuel Receiver Gauge 3. Inclination sensor 4. Combination Meter Assy	- - - -
Oil Maintenance lamp does not operate or abnormal operation	1. IGN Fuse 2. Wire Harness or Connector 3. Skid Control ECU 4. Combination Meter Assy	- - 05-303 -