








AUTOMATIC TRANSMISSION / TRANS



PREPARATION

0227V-01

SST

	09023-12700	Union Nut Wrench 17mm	TEMPERATURE SENSOR AUTOMATIC TRANSMISSION ASSY(A340E) AUTOMATIC TRANSMISSION ASSY(A340F)
	09032-00100	Oil Pan Seal Cutter	TRANSMISSION VALVE BODY ASSY(1GR-FE) TRANSMISSION WIRE(1GR-FE)
	09308-00010	Oil Seal Puller	AUTOMATIC TRANSMISSION EXTENSION HOUSING OIL SEAL(A340E)
	09325-40010	Transmission Oil Plug	AUTOMATIC TRANSMISSION EXTENSION HOUSING OIL SEAL(A340E)
	09350-32014	TOYOTA Automatic Transmission Tool Set	TORQUE CONVERTER CLUTCH AND DRIVE PLATE(1GR-FE)
	(09351-32010)	One-way Clutch Test Tool	TORQUE CONVERTER CLUTCH AND DRIVE PLATE(1GR-FE)
	(09351-32020)	Stator Stopper	TORQUE CONVERTER CLUTCH AND DRIVE PLATE(1GR-FE)

Recommended Tools

	09040-0001 1	Hexagon Wrench Set	TRANSMISSION VALVE BODY ASSY(1GR-FE) TRANSMISSION WIRE(1GR-FE)
	(09043-20100)	Socket Hexagon Wrench 10	TRANSMISSION VALVE BODY ASSY(1GR-FE) TRANSMISSION WIRE(1GR-FE)

Equipment

Straight edge	Torque converter
Vernier calipers	Torque converter
Dial indicator or dial indicator with magnetic base	Drive plate
Punch	
Torque wrench	

Lubricant

Item	Capacity	Classification
Automatic transaxle fluid		
Dry fill	12.3 liters (13.0 US qts, 10.8 Imp.qts)	ATF Type T-IV
Drain and refill	2.0 liters (2.1 US qts, 1.8 Imp.qts)	