


REPLACEMENT

1. REMOVE REAR WHEEL
2. DISCONNECT HEIGHT CONTROL SENSOR LINK SUB-ASSY REAR (W/ AIR SUSPENSION)
(See page 25-17)




3. REMOVE UPPER CONTROL ARM ASSY

- (a) Remove the nut, washer and bolt from rear axle housing.

HINT:


While fixing the bolt, turn and remove the nut.



- (b) Remove the nut, washer and bolt with the upper control arm assy.

HINT:

While fixing the bolt, turn and remove the nut.




4. INSTALL UPPER CONTROL ARM ASSY

- (a) Install the upper control arm assy, temporarily tighten the nut, washer and bolt.

HINT:

In the case of the air suspensions, install them by referring to the illustration.




- (b) Install the rear axle housing, temporarily tighten the nut, washer and bolt.

5. CONNECT HEIGHT CONTROL SENSOR LINK SUB-ASSY REAR (W/ AIR SUSPENSION)
(See page 25-17)

6. INSTALL REAR WHEEL

Torque: 112 N·m (1,137 kgf·cm, 83 ft·lbf)

7. STABILIZE SUSPENSION (See page 27-3)



8. FULLY TIGHTEN UPPER CONTROL ARM ASSY

- (a) Fully tighten the 2 nuts.

Torque: 80 N·m (816 kgf·cm, 59 ft·lbf)

HINT:

While fixing the bolt, turn and install the nut.