




PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
Driver side seat belt warning lamp does not light up	1. Fuse 2. Combination meter 3. Airbag sensor assy center 4. Front seat inner belt assy LH 5. Wire harness	 71-20 60-47 61-7 
Passenger side seat belt warning lamp does not light up	1. Fuse 2. Passenger side seat belt warning lamp assy 3. Front seat inner belt assy RH 4. Wire harness	 61-7 61-7 