

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
Seat heaters do not operate (Seat is not warmed up)	1. SEAT HEATER fuse	68-1
	2. IG 1 fuse	68-1
	3. IG relay	68-1
	4. Front seat cushion heater assy LH	72-27
	5. Front seat cushion heater assy RH	72-27
	6. Front seatback heater assy LH	72-27
	7. Front seatback heater assy RH	72-27
	8. Seat heater switch LH	72-27
	9. Seat heater switch RH	72-27
	10. Wire harness	72-27
Temperature of seat heater cannot be adjusted	1. Seat heater switch LH	72-27
	2. Seat heater switch RH	72-27
	3. Wire harness	72-27