


# INSPECTION




## 1. INSPECT SLIDING ROOF MOTOR SWITCH ASSY

- (a) Remove the sliding roof motor switch  
(See page 76-42 ).
- (b) Check the continuity between the terminals when operating the switch.

### Standard:

Terminals No.	Switch Operation	Specified Condition
1 ↔ 3	TILT UP is pressed	Continuity
2 ↔ 3	SLIDE OPEN is pressed	Continuity
1, 2 ↔ 3	OFF	No continuity

If the result is not as specified, replace the switch.



## 2. INSPECT HARNESS AND CONNECTOR (FOR SLIDING ROOF MOTOR ASSY)

- (a) Disconnect the sliding roof motor connector  
(See page 76-42 ).
- (b) Check the connector terminals of the wire harness side connector.

### Standard:

Terminals No.	Condition	Specified Condition
8 ↔ Body ground	Constant	Continuity
9 ↔ 8	Ignition switch ON	10 - 14 V
10 ↔ 8	Constant	10 - 14 V
1 ↔ 8	Constant	Continuity
7 ↔ 8	TILT UP is pressed	Continuity
6 ↔ 8	SLIDE OPEN is pressed	Continuity

If the result is not as specified, there may be a malfunction on the wire harness side.