

## PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
AUTO function does not operate	1. Sliding roof motor assy	<a href="#">74-2</a>
Sliding roof system does not operate	1. POWER fuse	-
	2. POWER relay	-
	3. Sliding roof housing assy	<a href="#">74-8</a>
	4. Sliding roof motor switch assy	<a href="#">74-5</a>
	5. Sliding roof motor assy	<a href="#">74-2</a>
	6. Wire harness	<a href="#">74-5</a>
Sliding roof system stops operation halfway	1. Sliding roof motor assy	<a href="#">74-2</a>
	2. Wire harness	<a href="#">74-5</a>
	3. Sliding roof housing assy	<a href="#">74-8</a>