







## PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
Rear window defogger does not operate (Indicator light ON)	6. DEFOG fuse 7. DEF relay 8. Rear window defogger wire 9. Wire harness 10. Instrument panel junction block assy	68-1 68-1 70-15  
Rear window defogger does not operate (Indicator light OFF)	1. DEFOG fuse 2. DEF relay 3. Air conditioning control assy 4. Rear window defogger wire 5. Wire harness 6. Instrument panel junction block assy	68-1 68-1 70-15 70-15  
Mirror defogger does not operate (Indicator light ON)	1. MIR HEATER fuse 2. DEF relay 3. Outer rear view mirror assy 4. Wire harness 5. Instrument panel junction block assy	68-1 68-1 70-15  
Mirror defogger does not operate (Indicator light OFF)	1. MIR HEATER fuse 2. DEF relay 3. Air conditioning control assy 4. Outer rear view mirror assy 5. Wire harness 6. Instrument panel junction block assy	68-1 68-1 70-15 70-15 