

SECTION **EL****CONTENTS**

PRECAUTIONS	2	Wiring Diagram (For USA) –H/LAMP–	46
Supplemental Restraint System (SRS) “AIR BAG”	2	Trouble Diagnoses (For USA)	47
HARNESS CONNECTOR	3	System Description (For Canada)	48
Description	3	Operation (Daytime light system for Canada)	49
STANDARDIZED RELAY	4	Schematic (For Canada)	50
Description	4	Wiring Diagram (For Canada) –DTRL–	51
POWER SUPPLY ROUTING	6	Trouble Diagnoses (For Canada)	54
Schematic	6	Bulb Replacement	56
Wiring Diagram –POWER–	7	Aiming Adjustment	56
Fuse	16	EXTERIOR LAMP	57
Fusible Link	16	Back-up Lamp/Wiring Diagram –BACK/L–	57
Circuit Breaker Inspection	16	License, Tail and Stop Lamps/Wiring Diagram –TAIL/L–	59
GROUND DISTRIBUTION	17	Front Fog Lamp/System Description	61
BATTERY	21	Front Fog Lamp/Wiring Diagram –F/FOG–	62
How to Handle Battery	21	Turn Signal and Hazard Warning Lamps/System Description	63
Memory Reset	23	Turn Signal and Hazard Warning Lamps/Wiring Diagram –TURN–	66
Service Data and Specifications (SDS)	24	Turn Signal and Hazard Warning Lamps/Trouble Diagnoses	68
STARTING SYSTEM	25	Combination Flasher Unit Check	69
System Description	25	Bulb Specifications	69
Wiring Diagram –START–	27	INTERIOR LAMP	70
Starter	30	Illumination/System Description	70
Pinion/Clutch Check	34	Illumination/Wiring Diagram –ILL–	72
Service Data and Specifications (SDS)	34	Interior and Trunk Room Lamps/System Description	74
CHARGING SYSTEM	35	Interior and Trunk Room Lamps/Wiring Diagram –INT/L–	76
System Description	35	METERS AND GAUGES/WITH TACHOMETER	78
Wiring Diagram –CHARGE–	36	System Description	78
Trouble Diagnoses	37	Combination Meter	79
Generator	38	Speedometer, Tachometer, Temp. and Fuel Gauges/Wiring Diagram –METER–	80
Diode Check	39	Inspection/Fuel Gauge and Water Temperature Gauge	81
Disassembly and Assembly	40	Inspection/Tachometer	82
Service Data and Specifications (SDS)	41		
COMBINATION SWITCH	42		
Combination Switch/Check	42		
Combination Switch/Replacement	43		
Steering Switch/Check	44		
HEADLAMP	45		
System Description (For USA)	45		

CONTENTS (Cont'd.)

Inspection/Speedometer and Vehicle Speed Sensor.....	83	Main Power Supply And Ground Circuit Check.....	136
METERS AND GAUGES/WITHOUT TACHOMETER	84	Electrical Components Inspection	136
System Description	84	Diagnostic Procedure	137
Combination Meter.....	85	DOOR MIRROR	139
Speedometer, Temp. and Fuel Gauges/Wiring Diagram –METER–	86	Wiring Diagram –MIRROR–	139
Inspection/Fuel Gauge and Water Temperature Gauge	87	SUNROOF	140
Inspection/Speedometer and Vehicle Speed Sensor.....	88	System Description	140
METERS AND GAUGES	89	Wiring Diagram –SROOF–	141
Fuel Tank Gauge Unit Check	89	HORN AND LIGHTER	142
Fuel Warning Lamp Sensor Check.....	89	REAR WINDOW DEFOGGER	143
Thermal Transmitter Check	89	System Description	143
Oil Pressure Switch Check.....	90	Wiring Diagram –DEF–	144
Vehicle Speed Sensor Signal Check.....	90	Trouble Diagnoses	146
WARNING LAMPS AND CHIME	91	Diagnostic Procedure	146
Warning Lamps/System Description.....	91	Electrical Components Inspection	148
Warning Lamps/Schematic	92	Filament Check.....	148
Warning Lamps/Wiring Diagram –WARN–	94	Filament Repair.....	149
Warning Chime/System Description	100	AUDIO	151
Warning Chime/Wiring Diagram –CHIME–.....	102	System Description	151
Warning Chime/Trouble Diagnoses	104	Wiring Diagram –AUDIO–	152
Symptom Chart.....	104	Trouble Diagnoses	153
Preliminary Check 1	105	MULTI-REMOTE CONTROL SYSTEM	155
Main Power Supply And Ground Circuit Check.....	107	System Description	155
Diagnostic Procedure 1	108	Wiring Diagram –MULTI–	158
Diode Check	113	Schematic	162
Warning Chime Check	113	Input/Output Operation Signal	163
WIPER AND WASHER	114	Smart Entrance Control Unit	163
System Description	114	Trouble Diagnoses	164
Wiring Diagram –WIPER–	116	Trouble Symptom	164
Trouble Diagnoses	119	Diagnostic Procedure 1	165
Diagnostic Procedure 1	119	Replacing Remote Controller or Control Unit.....	169
Wiper Installation and Adjustment	121	AUTOMATIC SPEED CONTROL DEVICE (ASCD)	170
Washer Nozzle Adjustment.....	122	System Description	170
POWER WINDOW	123	Component Parts and Harness Connector Location.....	172
System Description	123	Schematic	173
Component Layout.....	126	Wiring Diagram –ASCD–	174
Wiring Diagram –WINDOW–	128	Trouble Diagnoses	181
Trouble Diagnoses	130	Symptom Chart.....	181
POWER DOOR LOCK	131	Diagnostic Procedure 1	182
System Description	131	ASCD Wire Adjustment	189
Schematic	132	Electrical Components Inspection	190
Wiring Diagram –D/LOCK–.....	133	ASCD actuator/ASCD pump	190
Trouble Diagnoses	136	ASCD main switch	191
		ASCD steering switch	191
		ASCD cancel switch and stop lamp switch.....	191

CONTENTS (Cont'd.)

ASCD clutch pedal position switch (For M/T models)	191	GA Engine	240
Inhibitor switch (For A/T models)	191	SR Engine	241
Vehicle speed sensor	192	Room Lamp Harness	242
THEFT WARNING SYSTEM	193	2-Door	242
System Description	193	4-Door	242
Component Parts and Harness Connector Location	197	Air Bag Harness	243
Schematic	198	Tail Harness	244
Wiring Diagram -THEFT-	199	2-Door	244
Trouble Diagnoses	207	4-Door	244
System Operation Check	207	Front Door Harness (2-Door)	245
Power Supply And Ground Circuit Check	210	Left	245
Diagnostic Procedure 1	211	Right	245
Electrical Components Inspection	223	Front Door Harness (4-Door)	246
LOCATION OF ELECTRICAL UNITS	226	Left	246
Engine Compartment	226	Right	246
Passenger Compartment	227	Rear Door Harness (4-Door)	247
HARNESS LAYOUT	228	Left	247
How To Read Harness Layout	228	Right	247
Outline	229	Body Harness No. 2	248
2-Door	229	SUPER MULTIPLE JUNCTION (SMJ)	Foldout page
4-Door	229	Installation	Foldout page
Engine Room Harness	230	Terminal Arrangement	Foldout page
Passenger Compartment	230	JOINT CONNECTOR (J/C)	Foldout page
Engine Compartment	232	Location	Foldout page
Main Harness	234	Terminal Arrangement	Foldout page
Body Harness	236	HYBRID ELECTRIC CONTROL UNIT (HEC)	Foldout page
2-Door	236	Construction and Terminal Arrangement	Foldout page
4-Door	237	FUSE BLOCK/FUSIBLE LINK AND FUSE BOX	Foldout page
Engine Control Harness	238	Fuse Arrangement	Foldout page
GA Engine	238	CONTROL UNITS/MODULE	Foldout page
SR Engine	239		
Engine Harness No. 2 and Generator Harness	240		

When you read wiring diagrams:

- Read GI section, "HOW TO READ WIRING DIAGRAMS".

When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES" and "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT".

WIRING DIAGRAM REFERENCE CHART

ECCS (Ignition system)	EC SECTION
AUTOMATIC TRANSAXLE CONTROL SYSTEM, SHIFT LOCK SYSTEM	AT SECTION
ABS	BR SECTION
HEATER AND AIR CONDITIONING	HA SECTION



Supplemental Restraint System (SRS) "AIR BAG"

The Supplemental Restraint System "Air Bag", used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bag modules (located in the center of the steering wheel and on the instrument panel on the passenger side), a diagnosis sensor unit, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses are covered with yellow insulation either just before the harness connectors or for the complete harness, for easy identification.

Description


HARNESS CONNECTOR

- All harness connectors have been designed to prevent accidental looseness or disconnection.
- The connector can be disconnected by pushing or lifting the locking section.

CAUTION:

Do not pull the harness when disconnecting the connector.

[Example]



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX


SEL769D

STANDARDIZED RELAY

Description

NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS


Relays can be divided into three main types: normal open, normal closed and mixed type relays.



SEL881H

TYPE OF STANDARDIZED RELAYS













1M 1 Make 2M 2 Make
 1T 1 Transfer 1M-1B 1 Make 1 Break



SEL882H

STANDARDIZED RELAY

Description (Cont'd)

Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK
2M				BROWN
1M-1B				GRAY
1M				BLUE

G1

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS


BT

HA

EL

IDX

Schematic



AEL588



GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 FA
 RA
 BR
 ST
 RS
 BT
 HA
EL
 IDX

EL
IDX


POWER SUPPLY ROUTING

Wiring Diagram -POWER- (Cont'd)

EL-POWER-02





(E17)



POWER SUPPLY ROUTING

Wiring Diagram -POWER- (Cont'd)

EL-POWER-03



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA



EL

IDX

POWER SUPPLY ROUTING

Wiring Diagram -POWER- (Cont'd)



EL-POWER-04



POWER SUPPLY ROUTING

Wiring Diagram -POWER- (Cont'd)




EL-POWER-05



POWER SUPPLY ROUTING

Wiring Diagram -POWER- (Cont'd)




EL-POWER-06



POWER SUPPLY ROUTING

Wiring Diagram -POWER- (Cont'd)



EL-POWER-07



POWER SUPPLY ROUTING



Wiring Diagram -POWER- (Cont'd)

EL-POWER-08




POWER SUPPLY ROUTING

Wiring Diagram -POWER- (Cont'd)




POWER SUPPLY ROUTING



Fuse

- If fuse is blown, be sure to eliminate cause of problem before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for radio (clock) if vehicle is not used for a long period of time.




Fusible Link

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.

CAUTION:

- If fusible link should melt, it is possible that a critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check these circuits and eliminate cause of problem.
 - Never wrap outside of fusible link with vinyl tape.
- Important:** Never let fusible link touch any other wiring harness, vinyl or rubber parts.



Circuit Breaker Inspection

For example, when current is 30A, the circuit is broken within 8 to 20 seconds.

Circuit breakers are used in the following systems:

- Power door lock
- Power window
- Power sun roof

GROUND DISTRIBUTION

GROUND	CONNECT TO	CONN. NO.	CELL CODE	
E13/E25	BRAKE FLUID LEVEL SWITCH	E1	EL-WARN	GI
	COMBINATION SWITCH (FRONT FOG LAMP SWITCH)	E112	EL-F/FOG	
	COOLING FAN MOTOR-1 (Except SR engine and A/T)	E21	EC-COOL/F HA-A/C	MA
	COOLING FAN MOTOR-2 (Except SR engine and A/T)	E23	EC-COOL/F HA-A/C	
	COOLING FAN MOTOR-1 (With SR engine and A/T)	E20	EC-COOL/F HA-A/C	EM
	COOLING FAN MOTOR-2 (With SR engine and A/T)	E24	EC-COOL/F HA-A/C	
	COOLING FAN RELAY-3 (With SR engine and A/T)	E46	EC-COOL/F HA-A/C	
	FRONT FOG LAMP LH	E11	EL-F/FOG	LC
	FRONT FOG LAMP RH	E26	EL-F/FOG	
	FRONT SIDE MARKER LAMP LH	E9	EL-TAIL/L	EC
	FRONT SIDE MARKER LAMP RH	E28	EL-TAIL/L	
	FRONT TURN SIGNAL LAMP LH	E9	EL-TURN	FE
	FRONT TURN SIGNAL LAMP RH	E28	EL-TURN	
	HEADLAMP LH	E10	EL-H/LAMP EL-THEFT	CL
	HEADLAMP RH	E27	EL-H/LAMP EL-DTRL EL-THEFT	
	HOOD SWITCH	E35	EL-THEFT	MT
	HORN RELAY-2	E45	EL-THEFT	
	INHIBITOR SWITCH (GA engine)	E213	EC-PNP/SW AT-A/T, RL EL-START EL-ASCD EL-THEFT	AT
	INHIBITOR SWITCH (SR engine)	E212	EC-PNP/SW EL-START EL-ASCD EL-THEFT	
	NEUTRAL POSITION SWITCH	E205	EC-PNP/SW	FA
	WASHER FLUID LEVEL SWITCH	E32	EL-WARN	
	WIPER SWITCH	E109	EL-WIPER	RA
	WIPER SWITCH (With intermittent wipers)	E109	EL-WIPER	
A4	GENERATOR	A5	EL-CHARGE	
M43/M44/M60	ACCESSORY RELAY	M3	EL-POWER	BR
	ASCD CONTROL UNIT	M26	EL-ASCD	
	ASCD HOLD RELAY	M24	EL-ASCD	ST
	ASCD MAIN SWITCH	M6	EL-ASCD	
	A/T DEVICE (OVERDRIVE SWITCH)	M36	AT-A/T, RL AT-A/T, RE	RS
	BLOWER RELAY	M3	EL-POWER	
	CIGARETTE LIGHTER SOCKET	M35	EL-HORN	
	CLUTCH PEDAL POSITION SWITCH	M21	EL-START EL-THEFT	BT
	COMBINATION FLASHER UNIT	M40	EL-TURN	
	COMBINATION METER (AIR BAG)	M42	RS-SRS EL-WARN	HA
	COMBINATION METER (CRUISE INDICATOR LAMP)	M42	EL-ASCD	
	COMBINATION METER (FUEL GAUGE)	M42	EL-METER	EL
	COMBINATION METER (HIGH BEAM INDICATOR)	M42	EL-H/LAMP EL-DTRL	
	COMBINATION METER (SPEEDOMETER)	M42	EC-VSS AT-A/T, RE EL-METER EL-ASCD	IDX
	COMBINATION METER (TACHOMETER)	M42	EL-METER	
	COMBINATION METER (TURN SIGNAL LAMP)	M42	EL-TURN	
	COMBINATION METER (WATER TEMP. GAUGE)	M42	EL-METER	
	DATA LINK CONNECTOR FOR CONSULT	M4	EL-MIL AT-A/T, RE	
	DATA LINK CONNECTOR FOR GST	M25	EC-MIL	

GROUND DISTRIBUTION

GROUND	CONNECT TO	CONN. NO.	CELL CODE
M43/M44/M60	DAYTIME LIGHT CONTROL UNIT	M56	EL-DTRL
	DOOR MIRROR SWITCH	M5	EL-MIRROR
	FAN SWITCH	M48	HA-HEATER HA-A/C EC-LD/SIG
	IGNITION RELAY	M3	EL-POWER
	ILLUMINATION CONTROL SWITCH	M7	EL-ILL
	INTERMITTENT WIPER AMPLIFIER	M64	EL-WIPER
	PARK POSITION SWITCH	M36	AT-SHIFT
	POWER WINDOW RELAY	M1	EL-WINDOW EL-SROOF
	REAR WINDOW DEFOGGER SWITCH	M28	EL-DEF
	REAR WINDOW DEFOGGER TIMER	M38	EL-DEF
	RECIRCULATION SWITCH	M49	HA-A/C
	SHIFT LOCK CONTROL UNIT	M23	AT-SHIFT
	SHIFT LOCK SOLENOID	M36	AT-SHIFT
	SMART ENTRANCE CONTROL UNIT	M37	EL-INT/L EL-CHIME EL-D/LOCK EL-DEF EL-MULTI EL-THEFT
	SUNROOF RELAY	M2	EL-SROOF
	WARNING CHIME UNIT	M39	EL-CHIME
	WIPER MOTOR (Without ABS)	M61	EL-WIPER
	WIPER MOTOR (With ABS)	B101	EL-WIPER
	DOOR LOCK/UNLOCK SWITCH RH	D15	EL-D/LOCK
	FRONT DOOR LOCK ACTUATOR LH	D8	EL-D/LOCK
	FRONT DOOR LOCK ACTUATOR RH	D17	EL-D/LOCK
	FRONT DOOR LOCK ACTUATOR LH (DOOR UNLOCK SENSOR)	D8	EL-MULTI EL-THEFT
	FRONT DOOR LOCK ACTUATOR RH (DOOR UNLOCK SENSOR)	D17	EL-MULTI EL-THEFT
	FRONT LH DOOR KEY CYLINDER SWITCH	D7	EL-THEFT
	FRONT RH DOOR KEY CYLINDER SWITCH	D16	EL-THEFT
	MAIN POWER WINDOW AND DOOR LOCK SWITCH	D6	EL-D/LOCK EL-WINDOW
	AIR BAG DIAGNOSIS SENSOR UNIT	Z4	RS-SRS
B14/B17	FRONT DOOR SWITCH LH	B13	RS-SRS EL-CHIME
	FUEL PUMP	B16	EC-F/PUMP
	FUEL TANK GAUGE UNIT	B15	EL-METER EL-WARN
	SEAT BELT BUCKLE SWITCH	B12	EL-CHIME EL-WARN
	REAR DOOR LOCK ACTUATOR LH	D25	EL-D/LOCK
	REAR DOOR LOCK ACTUATOR RH	D21	EL-D/LOCK
	REAR DOOR LOCK ACTUATOR LH (DOOR UNLOCK SENSOR)	D21	EL-MULTI EL-THEFT
	REAR DOOR LOCK ACTUATOR RH (DOOR UNLOCK SENSOR)	D25	EL-MULTI EL-THEFT
B106	ABS CONTROL UNIT	B107	BR-ABS
	ABS RELAY BOX	B103	BR-ABS
B108	SHIELD WIRE (FRONT LH WHEEL SENSOR)	E3	BR-ABS
	SHIELD WIRE (FRONT RH WHEEL SENSOR)	B104	BR-ABS
	SHIELD WIRE (REAR LH WHEEL SENSOR)	B109	BR-ABS
	SHIELD WIRE (REAR RH WHEEL SENSOR)	B110	BR-ABS

GROUND DISTRIBUTION

GROUND	CONNECT TO	CONN. NO.	CELL CODE
F12/F23 (GA engine)	DISTRIBUTOR (CAMSHAFT POSITION SENSOR)	F4	EC-CMPS
	DISTRIBUTOR (POWER TRANSISTOR)	F4	EC-IGN/SG
	ECM (ECCS CONTROL MODULE)	F24	EC-FRO2/H EC-FUEL EC-MAIN EC-RR02 AT-A/T, RL
	IACV-FICD SOLENOID VALVE	F9	EC-FICD HA-A/C
	SHIELD WIRE [CAMSHAFT POSITION SENSOR (POS)]	F4	EC-CMPS
	SHIELD WIRE [CAMSHAFT POSITION SENSOR (REF)]	F4	EC-CMPS
	SHIELD WIRE [CRANKSHAFT POSITION SENSOR (GND-A)]	F3	EC-CKPS
	SHIELD WIRE [CRANKSHAFT POSITION SENSOR (RGC/S)]	F3	EC-CKPS
	SHIELD WIRE [FRONT HEATED OXYGEN SENSOR (O2SF)]	F1	EC-FRO2 EC-FRO2/H EC-FUEL
	SHIELD WIRE [FRONT OXYGEN SENSOR (O2SF)]	F2	EC-FRO2 EC-FUEL
	SHIELD WIRE (KNOCK SENSOR)	F102	EC-KS
	SHIELD WIRE (MASS AIR FLOW SENSOR)	F7	EC-MAFS
	SHIELD WIRE [REAR HEATED OXYGEN SENSOR (O2SR)]	F25	EC-RRO2
	SHIELD WIRE (RESISTOR)	F6	EC-IGN/SG
	SHIELD WIRE [THROTTLE POSITION SENSOR (TV01)]	F10	EC-TPS AT-A/T, RL
	DATA LINK CONNECTOR FOR GST	M25	EC-MIL
	POWER STEERING OIL PRESSURE SWITCH (Without ABS brake system)	M62	EC-PST/SW
	POWER STEERING OIL PRESSURE SWITCH (With ABS brake system)	B102	EC-PST/SW
	SHIELD WIRE [REAR HEATED OXYGEN SENSOR (O2SR)]	B11	EC-RRO2

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX

GROUND DISTRIBUTION

GROUND	CONNECT TO	CONN. NO.	CELL CODE
F12/F18 (SR engine)	A/T FLUID TEMPERATURE SENSOR	F9	AT-A/T, RE
	DISTRIBUTOR (CAMSHAFT POSITION SENSOR)	F4	EC-CMPS
	DISTRIBUTOR (POWER TRANSISTOR)	F4	EC-IGN/SG
	ECM (ECCS CONTROL MODULE)	F25	EC-MAIN EC-RRO2 AT-A/T, RE
	IACV-FICD SOLENOID VALVE	F20	EC-FICD HA-A/C
	SHIELD WIRE [CAMSHAFT POSITION SENSOR (POS)]	F4	EC-CMPS
	SHIELD WIRE [CAMSHAFT POSITION SENSOR (REF)]	F4	EC-CMPS
	SHIELD WIRE [CRANKSHAFT POSITION SENSOR (GND-A)]	F3	EC-CKPS
	SHIELD WIRE [CRANKSHAFT POSITION SENSOR (RGC/S)]	F3	EC-CKPS
	SHIELD WIRE [FRONT HEATED OXYGEN SENSOR (O2SF)]	F1	EC-FRO2 EC-FRO2/H EC-FUEL
	SHIELD WIRE (KNOCK SENSOR)	F56	EC-KS
	SHIELD WIRE (MASS AIR FLOW SENSOR)	F7	EC-MAFS
	SHIELD WIRE (RESISTOR)	F6	EC-IGN/SG
	SHIELD WIRE [THROTTLE POSITION SENSOR (TV01)] (A/T models)	F16	EC-TPS AT-A/T, RE
	SHIELD WIRE [THROTTLE POSITION SENSOR (TV01)] (M/T models)	F10	EC-TPS
	A/T CONTROL UNIT	M8	AT-A/T, RE
	DATA LINK CONNECTOR FOR GST	M25	EC-MIL
	POWER STEERING OIL PRESSURE SWITCH (Without ABS brake system)	M62	EC-PST/SW
	POWER STEERING OIL PRESSURE SWITCH (With ABS brake system)	B102	EC-PST/SW
	SHIELD WIRE [REAR HEATED OXYGEN SENSOR (O2SR)]	B11	EC-RRO2
T9/T10	HIGH-MOUNTED STOP LAMP (Models with rear air spoiler)	T5	EL-TAIL/L
	LICENSE PLATE LAMP LH	T3	EL-TAIL/L
	LICENSE PLATE LAMP RH	T3	EL-TAIL/L
	REAR COMBINATION LAMP LH (BACK-UP)	T2	EL-BACK/L
	REAR COMBINATION LAMP RH (BACK-UP)	T7	EL-BACK/L
	REAR COMBINATION LAMP LH	T8	EL-TURN EL-TAIL
	REAR COMBINATION LAMP RH	T11	EL-TURN EL-TAIL
	TRUNK KEY CYLINDER SWITCH (UNLOCK SWITCH)	T6	EL-THEFT
	TRUNK ROOM LAMP SWITCH	T4	EL-INT/L EL-THEFT

BATTERY

CAUTION:

- If it becomes necessary to start engine with booster battery and jumper cables, use a 12-volt booster battery.
- After connecting battery cables, ensure that they are tightly clamped to battery terminals for good contact.

CI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST


RS

BT


HA

EL


IDX



SEL189P



AEL618



SEL191P

How to Handle Battery

METHODS OF PREVENTING DISCHARGE

The following precautions must be taken to prevent over-discharging a battery.

- The battery surface (particularly its top) should always be kept clean and dry.
- The terminal connections should be clean and tight.
- **During every routine maintenance, check the electrolyte level.** This also applies to batteries designated as "low maintenance" and "maintenance-free".
- When the vehicle is not going to be used over a long period of time, disconnect the negative battery terminal.

- Check the condition of the battery. Periodically check the specific gravity of the electrolyte. Keep a close check on charge condition to prevent over-discharge.

CHECKING ELECTROLYTE LEVEL

WARNING:

Do not allow battery fluid to come in contact with skin, eyes, fabrics, or painted surfaces. After touching a battery, do not touch or rub your eyes until you have thoroughly washed your hands. If acid contacts eyes, skin or clothing, immediately flush with water for 15 minutes and seek medical attention.

Normally the battery does not require additional water. However, when battery is used under severe conditions, adding distilled water may be necessary during battery life.

BATTERY



How to Handle Battery (Cont'd)

- Remove the cell plug using a suitable tool.
- Add distilled water up to the MAX level.

SULPHATION


A battery (with specific gravity less than 1.100) will completely discharge when left unattended for a long period of time. This will result in sulphation on the cell plates.

A sulphated battery may sometimes be brought back into service by a slow charge, 12 hours or more. A capacity test should be run after the battery is charged to ensure the battery is not damaged.



SPECIFIC GRAVITY CHECK

- Read hydrometer and thermometer readings at eye level.



- When electrolyte level is too low, tilt battery case for easy measurement.

- Use the chart below to correct your hydrometer reading according to electrolyte temperature.

Hydrometer temperature correction

Battery electrolyte temperature °C (°F)	Add to specific gravity reading	Battery electrolyte temperature °C (°F)	Add to specific gravity reading
71 (160)	0.032	21 (70)	-0.004
66 (150)	0.028	16 (60)	-0.008
60 (140)	0.024	10 (50)	-0.012
54 (129)	0.020	4 (39)	-0.016
49 (120)	0.016	-1 (30)	-0.020
43 (110)	0.012	-7 (20)	-0.024
38 (100)	0.008	-12 (10)	-0.028
32 (90)	0.004	-18 (0)	-0.032
27 (80)	0		

Corrected specific gravity	Approximate charge condition	Corrected specific gravity	Approximate charge condition
1.260 - 1.280	Fully charged	1.170 - 1.190	1/4 charged
1.230 - 1.250	3/4 charged	1.140 - 1.160	Almost discharged
1.200 - 1.220	1/2 charged	1.110 - 1.130	Completely discharged

BATTERY

How to Handle Battery (Cont'd)

CHARGING THE BATTERY

CAUTION:

- Do not "quick charge" a fully discharged battery. CI
- Keep the battery away from open flame while it is being charged.
- When connecting the charger, connect the leads first, then turn on the charger. Do not turn on the charger first, as this may cause a spark. MA
- If battery electrolyte temperature rises above 60°C (140°F), stop charging. Always charge battery at a temperature below 60°C (140°F). EM

Charging rates:

LC

Amps	Time	EC
50	1 hour	
25	2 hours	
10	5 hours	FE
5	10 hours	

Do not charge at more than 50 ampere rate.

Note: The ammeter reading on your battery charger will automatically decrease as the battery charges. This indicates that the voltage of the battery is increasing normally as the state of charge improves. The charging amps indicated above are referred to as initial charge rate. CL

- If, after charging, the specific gravity of any two cells varies more than .050, the battery should be replaced. MT
- After the battery is charged, always perform a "capacity test" as follows, to assure that the battery is serviceable. AT

MEMORY RESET

FA

If the battery is disconnected or goes dead the following items must be reset:

- Radio AM and FM preset RA
- Radio Clock BR

STPSBTHAELIDX


BATTERY

How to Handle Battery (Cont'd)


- Check battery type and determine the specified current using the following table.

Fig. 1 DISCHARGING CURRENT
(Load tester)

Group Size	Current (A)
21F (USA)	245
24F (Canada)	275



SEL008Z



Voltage chart

Estimated electrolyte temperature °C (°F)	Minimum voltage under 15 second load
21 (70)	9.6
16 (60)	9.5
10 (50)	9.4
4 (40)	9.3
-1 (30)	9.1
-7 (20)	8.9
-12 (10)	8.7
-18 (0)	8.5

Service Data and Specifications (SDS)

Applied area		USA	Canada
Group size		21F	24F
Capacity	V-AH	12-60	12-65
Cold cranking current (For reference value)	A	490	550
Reserve capacity	Minutes	88	113

System Description

M/T models

Power is supplied at all times:

- to ignition switch terminal ①
- through 30A fusible link (letter **I** , located in the fusible link and fuse box).

With the ignition switch in the START position, power is supplied:

- through terminal ⑤ of the ignition switch
- to clutch interlock relay terminal ③.

Power is also supplied:

- to the 7.5A fuse (No. **26** , located in the fuse block [HEC]).

For models with theft warning system

With the ignition switch in the ON or START position, power is supplied:

- through 10A fuse (No. **21** , located in the fuse block [HEC])
- to theft warning relay terminal ①.

With the ignition switch in the START position, power is supplied:

- through 7.5A fuse (No. **26** , located in the fuse block [HEC])
- to theft warning relay terminal ③
- through theft warning relay terminal ④
- to clutch interlock relay terminal ①.

If the theft warning system is triggered, terminal ② of the theft warning relay is grounded and power to the clutch interlock relay is interrupted.

For models without theft warning system

With the ignition switch in the START position, power is supplied:

- through 7.5A fuse (No. **26** , located in the fuse block [HEC])
- to clutch interlock relay terminal ①.

Ground is supplied to clutch interlock relay terminal ②, when the clutch pedal is depressed through the clutch pedal position switch and body grounds **(M43)** , **(M44)** and **(M60)** .

The clutch interlock relay is energized and power is supplied:

- from terminal ⑤ of the clutch interlock relay
- to terminal ① of the starter motor windings.

The starter motor plunger closes and provides a closed circuit between the battery and the starter motor. The starter motor is grounded to the engine block. With power and ground supplied, cranking occurs and the engine starts.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX

STARTING SYSTEM

System Description (Cont'd)

A/T models

Power is supplied at all times:

- through 30A fusible link (letter **i** , located in the fusible link and fuse box)
- to ignition switch terminal ①.

For models with theft warning system (and with ASCD)

Power is supplied:

- through 10A fuse (No. **21** , located in the fuse block [HEC])
- to theft warning relay terminal ①
- to theft warning relay terminal ③
- through theft warning relay terminal ④
- to inhibitor relay terminal ①.

If the theft warning system is triggered, terminal ② of the theft warning relay is grounded and power to the inhibitor relay is interrupted.

When the theft warning system is not triggered and the ignition switch is in the START position, power is supplied:

- from ignition switch terminal ⑤
- to inhibitor relay terminal ⑥.

With the selector lever in the "P" or "N" position, ground is supplied:

- from inhibitor switch terminal ①
- to inhibitor relay terminal ②
- through inhibitor switch terminal ②
- to body grounds **(E13)** and **(E25)**.

The inhibitor relay is energized, and power is supplied:

- from inhibitor relay terminal ⑦
- to terminal ① of the starter motor windings.

The starter motor plunger closes and provides a closed circuit between the battery and starter motor. The starter motor is grounded to the engine block. With power and ground supplied, cranking occurs and the engine starts.

For models without theft warning system

Power is supplied:

- through 10A fuse (No. **21** , located in the fuse block [HEC])
- to inhibitor relay terminal ①.

With the ignition switch in the START position, power is supplied:

- from ignition switch terminal ⑤
- to inhibitor relay terminal ⑥ (models with ASCD)
- to inhibitor relay terminal ③ (models without ASCD).

With the selector lever in the "P" or "N" position, ground is supplied:

- from inhibitor switch terminal ①
- to inhibitor relay terminal ②
- through inhibitor switch terminal ②
- to body grounds **(E13)** and **(E25)**.

The inhibitor relay is energized and power is supplied:

- from inhibitor relay terminal ⑦ (models with ASCD)
- from inhibitor relay terminal ⑤ (models without ASCD)
- to terminal ① of the starter motor windings.



The starter motor plunger closes and provides a closed circuit between the battery and starter motor. The starter motor is grounded to the engine block. With power and ground supplied, cranking occurs and the engine starts.

STARTING SYSTEM

Wiring Diagram -START-

M/T MODELS

EL-START-01



Refer to last page (Foldout page).

M16, E101






GI
MA
EM
LG
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

STARTING SYSTEM

Wiring Diagram -START- (Cont'd)



A/T MODELS

EL-START-02



STARTING SYSTEM


Wiring Diagram -START- (Cont'd)



STARTING SYSTEM

Starter

SEC. 233
MIT72985A



- ① Sleeve bearing
- ② Gear case
- ③ Stopper clip
- ④ Pinion stopper
- ⑤ Pinion assembly
- ⑥ Internal gear
- ⑦ Shift lever

- ⑧ Plate
- ⑨ Packing
- ⑩ Planetary gear
- ⑪ Adjusting plate
- ⑫ Magnetic switch assembly
- ⑬ Packing
- ⑭ Yoke

- ⑮ Armature
- ⑯ Bearing
- ⑰ Brush (+)
- ⑱ Brush spring
- ⑲ Brush holder
- ⑳ Rear cover

STARTING SYSTEM

Starter (Cont'd)

SEC. 233
S114-701C

6.4 – 8.3
(0.65 – 0.85,
56 – 74)

7.4 – 9.8
(0.75 – 1.00, 65 – 87)

4.9 – 6.4
(0.50 – 0.65,
43 – 56)

1.7 – 2.4
(0.17 – 0.24,
14.8 – 21)

 : N·m (kg·m, in·lb)

 H : High-temperature grease point

AEL055A

- ① Gear case
- ② Bearing cover
- ③ Ball bearing
- ④ Pinion assembly
- ⑤ Shift lever
- ⑥ Dust cover
- ⑦ Torsion spring


- ⑧ Adjusting plate
- ⑨ Magnetic switch assembly
- ⑩ E-ring
- ⑪ Thrust washer
- ⑫ Center bracket
- ⑬ Pinion shaft
- ⑭ Planetary gear

- ⑮ Internal gear
- ⑯ Center bracket
- ⑰ Yoke assembly
- ⑱ Armature
- ⑲ Brush holder assembly
- ⑳ Rear cover
- ㉑ Dust cover


STARTING SYSTEM

Starter (Cont'd)

SEC. 233
M2T49283ZC




SEC. 233
S114-802A



STARTING SYSTEM

Starter (Cont'd)

SEC. 233
M0T80281ZC



- ① Sleeve bearing
- ② Gear case
- ③ Stopper clip
- ④ Pinion stopper
- ⑤ Pinion assembly
- ⑥ Internal gear

- ⑦ Planetary gear
- ⑧ Brush holder
- ⑨ Brush
- ⑩ Bearing
- ⑪ Rear cover
- ⑫ Armature

- ⑬ Packing
- ⑭ Magnetic switch assembly
- ⑮ Adjusting plate
- ⑯ Packing
- ⑰ Plate
- ⑱ Shift lever

STARTING SYSTEM

Pinion/Clutch Check

1. Inspect pinion teeth.
 - Replace pinion if teeth are worn or damaged. (Also check condition of ring gear teeth.)
2. Inspect reduction gear teeth.
 - Replace reduction gear if teeth are worn or damaged. (Also check condition of armature shaft gear teeth.)
3. Check to see if pinion locks in one direction and rotates smoothly in the opposite direction.
 - If it locks or rotates in both directions, or unusual resistance is evident, replace.

Service Data and Specifications (SDS)

STARTER

Type		M0T80281ZC	M2T42983ZC	S114-802A	S114-701C	M1T72985A
		MITSUBISHI		HITACHI		MITSUBISHI
		Reduction	Non-reduction	Reduction		
Applied model		GA with M/T		GA with A/T	SR	
		Federal	California			
System voltage	V	12				
No-load						
Terminal voltage	V	11.0	11.5	11.0		
Current	A	90 Max	53 Max	90 Max		
Motor revolution	rpm	2750 Min.	6000 Min.	2750 Min.	2950 Min.	3000 Min.
Minimum diameter of commutator mm (in)		28.8 (1.134)	31.4 (1.236)	28.0 (1.102)	32.0 (1.260)	28.8 (1.134)
Minimum length of brush mm (in)		7.0 (0.276)	11.5 (0.453)	10.5 (0.413)	11.0 (0.433)	12.0 (0.472)
Brush spring tension N (kg, lb)		11.8 - 23.5 (1.2 - 2.4, 2.7 - 5.3)	13.7 - 25.5 (1.4 - 2.6, 3.1 - 5.7)	14.7 - 17.7 (1.5 - 1.8, 3.3 - 4.0)	17.7 - 21.6 (1.8 - 2.2, 4.0 - 4.9)	13.7 - 25.5 (1.4 - 2.6, 3.1 - 5.7)
Clearance of bearing metal and armature shaft mm (in)		0.2 (0.0078) Max	0.2 (0.0078) Max	—	0.03 - 0.3 (0.0012 - 0.0118)	0.2 (0.0078) Max
Clearance between Pinion front edge and Pinion stopper mm (in)		0.5 - 2.0 (0.019 - 0.079)	0.5 - 2.0 (0.019 - 0.079)	0.3 - 2.5 (0.012 - 0.098)	0.05 - 1.5 (0.0020 - 0.0591)	0.5 - 2.0 (0.019 - 0.079)

System Description*

The generator provides DC voltage to operate the vehicle's electrical system and to keep the battery charged. The voltage output is controlled by the IC regulator.

Power is supplied at all times to generator terminal (S) through:

- 7.5A fuse (No. 31, located in the fusible link and fuse box).

Terminal (B) of the generator supplies current to charge the battery and operate the vehicle's electrical system. Voltage output at this terminal is controlled by the amount of voltage detected by the IC regulator at terminal (S). The charging circuit is protected by the 75A fusible link (letter G, located in the fusible link and fuse box).

Terminal (E) of the generator supplies ground through body ground (A4).

With the ignition switch in the ON or START position, power is supplied:

- through 10A fuse (No. 8, located in the fuse block [HEC])
- to combination meter terminal (41) (34) for the charge warning lamp.

Ground is supplied to terminal (35) (38) of the combination meter through terminal (L) of the generator. With power and ground supplied, the charge warning lamp will illuminate. When the generator is providing sufficient voltage the ground is opened and the charge warning lamp will go off.

If the charge warning lamp illuminates with the engine running, a fault is indicated. Refer to "Trouble Diagnoses", "CHARGING SYSTEM" (EL-37).



*: Terminal numbers in () are for models without tachometer.

CI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
ET
HA
EL
IDX

CHARGING SYSTEM

Wiring Diagram -CHARGE-

EL-CHARGE-01



Refer to last page (Foldout page).

(M16), (E101)


(M3)

Trouble Diagnoses

Before conducting a generator test, make sure that the battery is fully charged. A 30-volt voltmeter and suitable test probes are necessary for the test. The generator can be checked easily by referring to the Inspection Table.

Before starting diagnosis, inspect the fusible link.


WITH IC REGULATOR



- 1) Use fully charged battery.
- 2) Light : Charge warning light
G.C.G. : Generator parts except IC regulator
IC-RG : IC regulator
OK : IC-generator is in good condition.
- 3) When reaching "Damaged G.C.G.", remove generator from vehicle and disassemble, inspect and correct or replace faulty parts.
- 4) *Method of grounding F terminal (HITACHI make only)

Gasoline engine model

Contact tip of wire with brush and attach wire to generator body.




SEL030Z

- 5) Terminals "S", "L", "B" and "E" are marked on rear cover of generator.

CHARGING SYSTEM

Generator


SEC. 231
LR170-748



AEL059A

- | | | |
|-------------------|------------------|---|
| ① Pulley assembly | ⑥ Slip ring | ⑪ IC regulator assembly |
| ② Front cover | ⑦ Stator | ⑫ Diode assembly |
| ③ Front bearing | ⑧ Fan guide | ⑬ Rear cover |
| ④ Retainer | ⑨ Condenser | ⑭ Rear cover protector
(A/T models only) |
| ⑤ Rotor | ⑩ Brush assembly | |

SEC. 231
LR180-741H



AEL060A

- | | | |
|-------------------|-------------|-------------------------|
| ① Pulley assembly | ⑥ Slip ring | ⑩ Brush assembly |
| ② Front cover | ⑦ Stator | ⑪ IC regulator assembly |
| ③ Front bearing | ⑧ Fan guide | ⑫ Diode assembly |
| ④ Retainer | ⑨ Condenser | ⑬ Rear cover |
| ⑤ Rotor | | |


CHARGING SYSTEM

Diode Check


MAIN DIODES

- In order to check diodes, they must be unsoldered from the stator.
- Use an ohmmeter to check condition of diodes as indicated in chart below.
- If any of the test results are not satisfactory, replace diode assembly.

	Ohmmeter probes		Judgement
	Positive $\oplus$	Negative $\ominus$	
Diodes check (Positive side)	Positive diode plate	Diode terminals	Diode conducts in only one direction.
	Diode terminals	Positive diode plate	
Diodes check (Negative side)	Negative diode plate	Diode terminals	Diode conducts in only one direction.
	Diode terminals	Negative diode plate	




AEL818



Disassembly and Assembly

1. Remove rear cover.
 - Heat rear cover, using heat gun, to 50°C (90°F) above room temperature to prevent bearing damage.




2. Disconnect stator/diode.
 - Cut diode terminals.
 - Unsolder stator coil leads.


CAUTION:

Unsolder stator coil leads as fast as possible to avoid damaging diodes.

3. Remove stator and rotor.
4. Remove bearing retainer and bearing.
5. Assemble in reverse of disassembly.



- Insert stator coil lead into lower portion of diode terminal.
- Using pliers, crimp diode terminal around stator coil lead.
- Be sure stator coil leads do not protrude more than 3 mm (0.118 in.) past diode terminal.



- Solder stator coil lead and diode terminals.

CAUTION:

Solder stator coil leads and diode terminals as fast as possible to avoid damaging diodes. Use 9/1 Pb/Sn solder in assembly.

CHARGING SYSTEM

Service Data and Specifications (SDS)

GENERATOR

Type		LR180-741H	LR170-748
		HITACHI	HITACHI
Applied model		SR20DE	GA16DE
Nominal rating	V-A	12-80	12-70
Ground polarity		Negative	
Minimum revolution under no-load (When 13.5 volts is applied)	rpm	Less than 1,000	Less than 1,000
Hot output current	A/rpm	More than 23/1,300 More than 63/2,500 More than 77/5,000	More than 22/1,300 More than 50/2,500 More than 67/5,000
Regulated output voltage	V	14.1 - 14.7	
Minimum length of brush	mm (in)	6.0 (0.236)	6.0 (0.236)
Brush spring pressure	N (g, oz)	1.000 - 3.432 (102 - 350, 3.60 - 12.34)	1.000 - 3.432 (102 - 350, 360 - 12.34)
Slip ring minimum outer diameter	mm (in)	More than 26.0 (1.024)	More than 26.0 (1.024)
Rotor (Field coil) resistance	Ω	2.6 - 2.7	2.5 - 2.6

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT



HA

EL

IDX

COMBINATION SWITCH

Combination Switch/Check



LIGHTING SWITCH

	OFF			1ST			2ND		
	A	B	C	A	B	C	A	B	C
5									
6									
7									
8									
9									
10									
11									
12									

WIPER SWITCH

	OFF	INT	LO	HI	WASH
13					
14					
15					
16					
17					
18					



TURN
SIGNAL
SWITCH

	R	N	L
1			
2			
3			

FRONT FOG
LAMP SWITCH

	OFF	ON
2		
1		

COMBINATION SWITCH



Combination Switch/Replacement

- Each switch can be replaced without removing combination switch base.
- To remove combination switch base, remove base attaching screws.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT



HA

EL

IDX

COMBINATION SWITCH

Steering Switch/Check



System Description (For USA)*

The headlamps are controlled by the lighting switch which is built into the combination switch. Power is supplied at all times:

- to lighting switch terminal ⑤
- through 15A fuse (No. 39 , located in the fusible link and fuse box), and
- to lighting switch terminal ⑧
- through 15A fuse (No. 40 , located in the fusible link and fuse box).

Low beam operation

When the lighting switch is turned to the 2ND position and placed in LOW ("B") position, power is supplied:

- from lighting switch terminal ⑩
- to terminal ② of the LH headlamp, and
- from lighting switch terminal ⑦
- to terminal ② of the RH headlamp.

Terminal ③ of each headlamp supplies ground through body grounds (E13) and (E25). With power and ground supplied, the headlamp(s) will illuminate.

High beam operation/flash-to-pass operation

When the lighting switch is placed in the 2ND position and placed in HIGH ("A") or Pass ("C") position, power is supplied:

- from lighting switch terminal ⑥
- to terminal ① of the RH headlamp, and
- from lighting switch terminal ⑨
- to terminal ① of the LH headlamp, and
- to combination meter terminal ⑬ (⑫) for the HI BEAM indicator.

Ground is supplied to terminal ⑮ (⑪) of the combination meter through body grounds (M43), (M44) and (M60).

With power and ground supplied, the high beams and the HI BEAM indicator illuminate.

Theft warning system

The theft warning system will flash the high beams if the system is triggered. Refer to "System Description", "THEFT WARNING SYSTEM", (EL-194).

*: Terminal numbers in () are for models without tachometer.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT



HA

EL

IDX

Wiring Diagram (For USA) –H/LAMP–

EL-H/LAMP-01



HEADLAMP

Trouble Diagnoses (For USA)

Symptom	Possible cause	Repair order
LH headlamps do not operate.	1. Bulb 2. Grounds (E13) and (E25) 3. 15A fuse 4. Lighting switch	1. Check bulb. 2. Check grounds (E13) and (E25). 3. Check 15A fuse (No. 40, located in fusible link and fuse box). Verify battery positive voltage is present at terminal (8) of lighting switch. 4. Check lighting switch.
RH headlamps do not operate.	1. Bulb 2. Grounds (E13) and (E25) 3. 15A fuse 4. Lighting switch	1. Check bulb. 2. Check grounds (E13) and (E25). 3. Check 15A fuse (No. 39, located in fusible link and fuse box). Verify battery positive voltage is present at terminal (5) of lighting switch. 4. Check lighting switch.
LH high beam does not operate, but LH low beam operates.	1. Bulb 2. Open in LH high beam circuit 3. Lighting switch	1. Check bulb. 2. Check R/B wire between lighting switch and LH headlamp for an open circuit. 3. Check lighting switch.
LH low beam does not operate, but LH high beam operates.	1. Bulb 2. Open in LH low beam circuit 3. Lighting switch	1. Check bulb. 2. Check R/Y wire between lighting switch and LH headlamp for an open circuit. 3. Check lighting switch.
RH high beam does not operate, but RH low beam operates.	1. Bulb. 2. Open in RH high beam circuit 3. Lighting switch.	1. Check bulb. 2. Check R/G wire between lighting switch and RH headlamp for an open circuit. 3. Check lighting switch.
RH low beam does not operate, but RH high beam operates.	1. Bulb 2. Open in RH low beam circuit 3. Lighting switch	1. Check bulb. 2. Check P/L wire between lighting switch and RH headlamp for an open circuit. 3. Check lighting switch.
High beam indicator does not work.	1. Bulb 2. Grounds (M43), (M44) and (M60) 3. Open in high beam circuit	1. Check bulb in combination meter. 2. Check grounds (M43), (M44) and (M60). 3. Check R/B wire between lighting switch and combination meter for an open circuit.

System Description (For Canada)

The headlamp system for Canada vehicles contains a daytime light control unit. This unit activates the high beam headlamps at approximately half illumination whenever the engine is running. If the parking brake is applied before the engine is started, daytime lights will not be illuminated. The daytime lights will illuminate once the parking brake is released. Thereafter, the daytime lights will continue to operate when the parking brake is applied. For location of daytime light control unit, refer to EL-227.

Power is supplied at all times:

- through 15A fuse (No. 39 , located in the fusible link and fuse box)
- to daytime light control unit terminal ② and
- to lighting switch terminal ⑤.

Power is also supplied at all times:

- through 15A fuse (No. 40 , located in the fusible link and fuse box)
- to daytime light control unit terminal ③ and
- to lighting switch terminal ⑧.

With the ignition switch in the ON or START position, power is supplied:

- through 7.5A fuse (No. 7 , located in the fuse block [HEC])
- to daytime light control unit terminal ⑫.

Ground is supplied to daytime light control unit terminal ⑨ through body grounds M43 , M44 and M60 .

HEADLAMP OPERATION

Low beam operation

When the lighting switch is moved to the 2ND position and placed in LOW ("B") position (low beam operation), power is supplied:

- from lighting switch terminal ⑦
- to RH headlamp terminal ②.

Ground is supplied to RH headlamp terminal ③ through body grounds E13 and E25 .

Also, when the lighting switch is moved to the 2ND position and placed in LOW ("B") position (low beam operation), power is supplied:

- from lighting switch terminal ⑩
- to LH headlamp terminal ②.

Ground is supplied:

- to LH headlamp terminal ③
- from daytime light control unit terminal ⑦
- through daytime light control unit terminal ⑨
- through body grounds M43 , M44 and M60 .

With power and ground supplied, the low beam headlamps illuminate.

High beam operation/Flash-to-pass operation

When the lighting switch is moved to the 2ND position and placed in HIGH ("A") or Pass ("C") position, power is supplied:

- from lighting switch terminal ⑥
- to RH headlamp terminal ①, and
- from lighting switch terminal ⑨
- to daytime light control unit terminal ⑤
- through daytime light control unit terminal ⑥
- to LH headlamp terminal ①.

Ground is supplied in the same manner as low beam operation.

With power and ground supplied, the high beam headlamps illuminate.

HEADLAMP

System Description (For Canada) (Cont'd)

DAYTIME LIGHT OPERATION

With the engine running and the lighting switch in the OFF position, power is supplied:

- to daytime light control unit terminal ③
- through daytime light control unit terminal ⑥
- to LH headlamp terminal ①
- through LH headlamp terminal ③
- to daytime light control unit terminal ⑦
- through daytime light control unit terminal ⑧
- to RH headlamp terminal ①.

Ground is supplied to RH headlamp terminal ③ through body grounds (E13) and (E25).

Because the high beam headlamps are now wired in series, they operate at half illumination.

Operation (Daytime light system for Canada)

The headlamps' high beams automatically turn on after starting the engine with the lighting switch in "OFF" or "1st" position. Lighting switch operations other than the above are the same as conventional light systems.

Engine		With engine stopped									With engine running								
Lighting switch		OFF			1ST			2ND			OFF			1ST			2ND		
		A	B	C	A	B	C	A	B	C	A	B	C	A	B	C	A	B	C
Headlamp	High beam	X	X	○	X	X	○	○	X	○	△*	△*	○	△*	△*	○	○	X	○
	Low beam	X	X	X	X	X	X	X	○	X	X	X	X	X	X	X	X	○	X
Front side marker and tail lamp		X	X	X	○	○	○	○	○	○	X	X	X	○	○	○	○	○	○
License and instrument illumination lamp		X	X	X	○	○	○	○	○	○	X	X	X	○	○	○	○	○	○

○: Lamp "ON"

X: Lamp "OFF"

△: Lamp dims


□: Added functions

*: When starting the engine with the parking brake released, the daytime light will come ON.

When starting the engine with the parking brake applied, the daytime light won't come ON.

HEADLAMP

Schematic (For Canada)





AEL589

HEADLAMP

Wiring Diagram (For Canada) -DTRL-

EL-DTRL-01






Refer to last page (Foldout page).

(M16), (E101)
(M3)

HEADLAMP Wiring Diagram (For Canada) -DTRL- (Cont'd)

EL-DTRL-02






Refer to last page (Foldout page).
(M16) . (E101)

HEADLAMP

Wiring Diagram (For Canada) -DTRL-

(Cont'd)

EL-DTRL-03



Refer to last page (Foldout page).

M16, E101

HEADLAMP

Trouble Diagnoses (For Canada)

DAYTIME LIGHT CONTROL UNIT INSPECTION TABLE

(Data are reference values.)

Ter- minal No.	Item	Condition	Judgement standard
1	Start signal	 When turning ignition switch to "ST"	Battery positive voltage
		 When turning ignition switch to "ON" from "ST"	1V or less
		 When turning ignition switch to "OFF"	1V or less
2	Power source	 When turning ignition switch to "ON"	Battery positive voltage
		 When turning ignition switch to "OFF"	Battery positive voltage
3	Power source	 When turning ignition switch to "ON"	Battery positive voltage
		 When turning ignition switch to "OFF"	Battery positive voltage
4	Lighting switch (Lo beam)	When turning lighting switch to "HEAD" (2nd position)	Battery positive voltage
5	Lighting switch (Hi beam)	When turning lighting switch to "HI BEAM"	Battery positive voltage
		When turning lighting switch to "FLASH TO PASS"	Battery positive voltage
6	LH hi beam	When turning lighting switch to "HI BEAM"	Battery positive voltage
		  When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) CAUTION: Block wheels and ensure selector lever is in "N" or "P" position.	Battery positive voltage
7	LH headlamp control (ground)	When lighting switch is turned to "HEAD"	1V or less
		  When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) CAUTION: Block wheels and ensure selector lever is in "N" or "P" position.	Approx. half battery voltage
8	RH hi beam	When turning lighting switch to "HI BEAM"	Battery positive voltage
		  When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) CAUTION: Block wheels and ensure selector lever is in "N" or "P" position.	Approx. half battery voltage

HEADLAMP

Trouble Diagnoses (For Canada) (Cont'd)

Ter- minal No.	Item	Condition		Judgement standard
9	Ground		—	—
10	Parking brake switch		When parking brake is released	Battery positive voltage
			When parking brake is set	1.5V or less
11	Generator		When turning ignition switch to "ON"	1V or less
			When engine is running	Battery positive voltage
			When turning ignition switch to "OFF"	1V or less
12	Power source		When turning ignition switch to "ON"	Battery positive voltage
			When turning ignition switch to "ST"	Battery positive voltage
			When turning ignition switch to "OFF"	1V or less

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX

Bulb Replacement



The headlamp is a semi-sealed beam type which uses a replaceable halogen bulb. The bulb can be replaced from the engine compartment side without removing the headlamp body.

- **Grasp only the plastic base when handling the bulb. Never touch the glass envelope.**

1. Disconnect the battery cable.
2. If removing the right-hand (passenger side) headlamp bulb, it is necessary to first reposition the engine coolant reservoir.
3. Disconnect the electrical connector from the bulb.
4. Push down spring retainer.
5. Pull out the headlamp bulb and socket as an assembly. Do not shake or rotate the bulb when removing it. Do not handle the glass envelope.

CAUTION:

Do not leave headlamp reflector without bulb for a long period of time. Dust, moisture, smoke, etc. entering headlamp body may affect the performance of the headlamp. Remove headlamp bulb from the headlamp reflector just before a replacement bulb is installed.



Aiming Adjustment

When performing headlamp aiming adjustment, use an aiming machine, aiming wall screen or headlamp tester. Aimers should be in good repair, calibrated and operated according to their operation manuals. Before performing aiming adjustment, make sure of the following:

- Keep all tires inflated to correct pressure.
- Place vehicle on level ground.
- See that vehicle is unloaded (except for full levels of coolant, engine oil and fuel, and spare tire, jack, and tools). Have the driver or equivalent weight placed in driver's seat.


LOW BEAM

1. Turn headlamp low beam "ON"
2. Use adjusting screws to perform aiming adjustment.

- **Adjust headlamps so that upper edge and left edge of high intensity zone are within the acceptable range as shown at left.**
- Dotted lines in illustration show center of headlamp.

"H": Horizontal center line of headlamp





"W_L": Distance between each headlamp center



EXTERIOR LAMP

Back-up Lamp/Wiring Diagram -BACK/L-

EL-BACK/L-01



Refer to last page (Foldout page).
M16, E101



EXTERIOR LAMP

NOTES

EXTERIOR LAMP

License, Tail and Stop Lamps/Wiring Diagram -TAIL/L-




EL-TAIL/L-01



EXTERIOR LAMP

License, Tail and Stop Lamps/Wiring Diagram -TAIL/L- (Cont'd)

EL-TAIL/L-02



Refer to last page (Foldout page).

M3

Front Fog Lamp/System Description

Power is supplied at all times to front fog lamp relay terminal ③ through:

- 15A fuse (No. ③⑤ , located in the fusible link and fuse box).

With the lighting switch in the 2ND position and LOW ("B") position, power is supplied:

- through 15A fuse (No. ③⑨ , located in the fusible link and fuse box)
- to lighting switch terminal ⑤
- through terminal ⑦ of the lighting switch
- to front fog lamp relay terminal ①.

Fog lamp operation

The front fog lamp switch is built into the combination switch. The lighting switch must be in the 2ND position and LOW ("B") position for fog lamp operation.

With the front fog lamp switch in the ON position:

- ground is supplied to front fog lamp relay terminal ② through the front fog lamp switch and body grounds ①③ and ①⑤.

The front fog lamp relay is energized and power is supplied:

- from front fog lamp relay terminal ⑤
- to terminal ① of each front fog lamp.

Ground is supplied to terminal ② of each front fog lamp through body grounds ①③ and ①⑤.

With power and ground supplied, the front fog lamps illuminate.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA



EL

IDX

EXTERIOR LAMP

Front Fog Lamp/Wiring Diagram -F/FOG-

EL-F/FOG-01



Turn Signal and Hazard Warning Lamps/System Description*

TURN SIGNAL OPERATION

With the hazard switch in the OFF position and the ignition switch in the ON or START position, power is supplied:

- through 7.5A fuse (No. 11, located in the fuse block [HEC])
- to hazard switch terminal ②
- through terminal ① of the hazard switch
- to combination flasher unit terminal ①
- through terminal ③ of the combination flasher unit
- to turn signal switch terminal ①.

Ground is supplied to combination flasher unit terminal ② through body grounds (M43), (M44) and (M60).

LH turn

When the turn signal switch is moved to the LH position, power is supplied from turn signal switch terminal ③ to:

- front turn signal lamp LH terminal ③
- rear combination lamp LH terminal ②, and
- combination meter terminal ⑩ (17).

Ground is supplied to the front turn signal lamp LH terminal ② through body grounds (E13) and (E25).

Ground is supplied to the rear combination lamp LH terminal ④ through body grounds (T9) and (T10).

Ground is supplied to combination meter terminal 27 (28) through body grounds (M43), (M44) and (M60).

With power and grounds supplied, the combination flasher unit controls the flashing of the LH turn signal lamps.

RH turn

When the turn signal switch is moved to the RH position, power is supplied from turn signal switch terminal ② to:

- front turn signal lamp RH terminal ③
- rear combination lamp RH terminal ②, and
- combination meter terminal 26 (27).

Ground is supplied to the front turn signal lamp RH terminal ② through body grounds (E13) and (E25).

Ground is supplied to the rear combination lamp RH terminal ④ through body grounds (T9) and (T10).

Ground is supplied to combination meter terminal 27 (28) through body grounds (M43), (M44) and (M60).

With power and grounds supplied, the combination flasher unit controls the flashing of the RH turn signal lamps.

HAZARD LAMP OPERATION

Power is supplied at all times to hazard switch terminal ③ through:

- 10A fuse (No. 15, located in the fuse block [HEC]).

With the hazard switch in the ON position, power is supplied:

- through terminal ① of the hazard switch
- to combination flasher unit terminal ①
- through terminal ③ of the combination flasher unit
- to hazard switch terminal ④.

Ground is supplied to combination flasher unit terminal ② through body grounds (M43), (M44) and (M60).

Power is supplied through terminal ⑤ of the hazard switch to:

- front turn signal lamp LH terminal ③
- rear combination lamp LH terminal ②, and
- combination meter terminal ⑩ (17).

Power is supplied through terminal ⑥ of the hazard switch to:

- front turn signal lamp RH terminal ③
- rear combination lamp RH terminal ②, and
- combination meter terminal 26 (27).

Ground is supplied to terminal ② of the front turn signal lamps through body grounds (E13) and (E25).

Ground is supplied to terminal ④ of the rear combination lamps through body grounds (T9) and (T10).

Ground is supplied to combination meter terminal 27 (28) through body grounds (M43), (M44) and (M60).

With power and ground supplied, the combination flasher unit controls the flashing of the hazard warning lamps.

*: Terminal numbers in () are for models without tachometer.

EXTERIOR LAMP

Turn Signal and Hazard Warning Lamps/System Description* (Cont'd)

WITH MULTI-REMOTE CONTROL SYSTEM

Power is supplied at all times:

- through 10A fuse (No. 15 , located in the fuse block [HEC])
- to multi-remote control relay-1 terminals ①, ⑥ and ③
- to multi-remote control relay-2 terminal ①.

Ground is supplied to multi-remote control relays-1, -2 terminal ②, when the multi-remote control system is triggered, through the smart entrance control unit.

Refer to EL-155 "MULTI-REMOTE CONTROL SYSTEM".

The multi-remote control relays-1, -2 are energized.

Power is disconnected to the turn signal switch.

Power is supplied through terminal ⑤ of the multi-remote control relay-1:

- to front turn signal lamp LH terminal ③
- to rear combination lamp LH terminal ②
- to combination meter terminal ⑩ (17).

Power is supplied through terminal ⑦ of the multi-remote control relay-1:

- to front turn signal lamp RH terminal ③
- to rear combination lamp RH terminal ②
- to combination meter terminal ⑩ (27).

Ground is supplied to terminal ② of each front turn signal lamp through body grounds E13 and E25 .

Ground is supplied to terminal ④ of the rear combination lamps through body grounds T9 and T10 .

Ground is supplied to combination meter terminal 27 (28) through body grounds M43 , M44 and M60 .

With power and ground supplied, the smart entrance control unit controls the flashing of the hazard warning lamps.



*: Terminal numbers in () are for models without tachometer.

NOTES

- GI
- MA
- EM
- LC
- EC
- FE
- CL
- MT
- AT
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL**
- IDX



Turn Signal and Hazard Warning Lamps/Wiring Diagram -TURN-

EL-TURN-01



Turn Signal and Hazard Warning Lamps/Wiring Diagram –TURN– (Cont'd)

EL-TURN-02




EXTERIOR LAMP

Turn Signal and Hazard Warning Lamps/Trouble Diagnoses

Symptom	Possible cause	Repair order
Turn signal and hazard warning lamps do not operate.	1. Hazard switch 2. Combination flasher unit 3. Open in combination flasher unit circuit	1. Check hazard switch. 2. Refer to combination flasher unit check. 3. Check wiring to combination flasher unit for open circuit.
Turn signal lamps do not operate but hazard warning lamps operate.	1. 7.5A fuse 2. Hazard switch 3. Turn signal switch 4. Open in turn signal switch circuit	1. Check 7.5A fuse (No. 11), located in fuse block [HEC]. Turn ignition switch ON and verify battery positive voltage is present at terminal ② of hazard switch. 2. Check hazard switch. 3. Check turn signal switch. 4. Check LB/G wire between combination flasher unit and turn signal switch for open circuit.
Hazard warning lamps do not operate but turn signal lamps operate.	1. 10A fuse 2. Hazard switch 3. Open in hazard switch circuit	1. Check 10A fuse (No. 15), located in fuse block [HEC]. Verify battery positive voltage is present at terminal ③ of hazard switch. 2. Check hazard switch. 3. Check LG/B wire between combination flasher unit and hazard switch for open circuit.
Front turn signal lamp LH or RH does not operate.	1. Bulb 2. Grounds (E13) and (E25)	1. Check bulb. 2. Check grounds (E13) and (E25).
Rear turn signal lamp LH or RH does not operate.	1. Bulb 2. Grounds (T9) and (T10)	1. Check bulb. 2. Check grounds (T9) and (T10).
LH and RH turn indicators do not operate.	1. Ground	1. Check grounds (M43), (M44) and (M60).
LH or RH turn indicator does not operate.	1. Bulb	1. Check bulb in combination meter.

EXTERIOR LAMP



Combination Flasher Unit Check

- Before checking, ensure that bulbs meet specifications.
- Connect a battery and test lamp to the combination flasher unit, as shown. Combination flasher unit is properly functioning if it blinks when power is supplied to the circuit.

Bulb Specifications

	Wattage (12 volt)	Bulb No.
Headlamp (Semi-sealed beam)		
High/Low	65/45	9004
Front combination lamp	27/8	1157NA
Front fog lamp	35	H3 (Special)
Rear combination lamp		
Turn signal	27	1156
Stop/Tail	27/8	1157
Back-up (SENTRA)	13	912
Back-up (200SX)	27	1156
License plate lamp	5	168
High-mounted stop lamp	13	912
Trunk lid-mounted stop lamp	13	912
Interior lamp	8	
Trunk room lamp	3.4	158

INTERIOR LAMP

Illumination/System Description

Power is supplied at all times:

- through 10A fuse (No. 36 , located in the fusible link and fuse box)
- to lighting switch terminal ⑪.

The lighting switch must be in the 1ST or 2ND position for illumination.

The illumination control switch is a thumbwheel that controls the amount of current to the illumination system. As the amount of current increases, the illumination becomes brighter.

The following chart shows the power and ground connector terminals for the components included in the illumination system.

Component	Power terminal	Ground terminal
Radio	⑧	⑦
Fan switch	①	②
A/T device indicator*	③	⑥
Hazard switch	⑦	⑧
Main power window and door lock switch*	③	④
Combination meter	④① (⑱)**	③⑨ (⑬)**
ASCD main switch*	⑤	⑥
Rear window defogger switch	⑤	⑥
Illumination control switch	①	② and ③

* If equipped.

** Terminal numbers in () are for models without tachometer.

The ground for all of the components is controlled through terminals ② and ③ of the illumination control switch and body grounds (M43), (M44) and (M60).

INTERIOR LAMP

NOTES

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA


EL

IDX

INTERIOR LAMP

Illumination/Wiring Diagram -ILL-

EL-ILL-01



(M6) W



(M7) W




(M28) W



(M29) W



(M36) W



(M47) W



(E111) W



(E105) W



Refer to last page (Foldout page).

(M3)

Illumination/Wiring Diagram -ILL- (Cont'd)

Illumination/Wiring Diagram -ILL- (Cont'd)

EL-ILL-02



INTERIOR LAMP

Interior and Trunk Room Lamps/System Description

Power is supplied at all times:

- through 7.5A fuse (No. 20 , located in the fuse block [HEC])
- to interior lamp terminal ①
- to trunk room lamp terminal ①.

Models with multi-remote control system

Power is supplied at all times:

- through 25A fusible link (letter f , located in the fusible link and fuse box)
- to circuit breaker terminal ①
- through circuit breaker terminal ②
- to smart entrance control unit terminal ① for multi-remote control system.

Ground is supplied to smart entrance control unit terminal ⑩ through body grounds M43 , M44 and M60 .

INTERIOR LAMP

Switch operation

With the interior lamp switch in the ON position, ground is supplied through screw terminal on interior lamp assembly to body to turn interior lamp ON.

When a door switch is set to OPEN (door is open) with the interior lamp switch in the DOOR position, ground is supplied:

- to interior lamp terminal ②
- through front door switch LH terminal ② or
- through any other door switch terminal ①.

The interior lamp will not illuminate if the interior lamp switch is in the OFF position.

Interior lamp control by multi-remote control system

The smart entrance control unit receives a remote control signal from multi-remote controller to turn interior lamp ON when the doors are unlocked. Ground is then supplied:

- to interior lamp terminal ②
- through smart entrance control unit terminal ⑨,
- through smart entrance control unit terminal ⑩ and
- through body grounds M43 , M44 and M60 .

With power and ground supplied, the interior lamp turns ON.

TRUNK ROOM LAMP

When the trunk room lamp switch is set to OPEN (trunk is opened), ground is supplied:

- to trunk room lamp terminal ②
- through trunk room switch terminal ①,
- through trunk room lamp switch terminal ② and
- through body grounds T9 and T10 .

With power and ground supplied, the trunk room lamp turns ON.

INTERIOR LAMP

NOTES

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA


EL

IDX


INTERIOR LAMP

Interior and Trunk Room Lamps/Wiring Diagram -INT/L-

EL-INT/L-01



Refer to last page (Foldout page).



System Description

With the ignition switch in the ON or START position, power is supplied:

- through 10A fuse (No. 8 , located in the fuse block [HEC])
- to combination meter terminal 41 for the water temperature gauge,
- to combination meter terminal 22 for the tachometer and speedometer
- to combination meter terminal 10 for the fuel gauge.

Ground is supplied:

- to combination meter terminal 28
- through body grounds M43, M44 and M60.

The water temperature gauge indicates the engine coolant temperature. The reading on the gauge is based on the resistance of the thermal transmitter.

As the temperature of the coolant increases, the resistance of the thermal transmitter decreases. A variable ground is supplied to terminal 42 of the combination meter for the water temperature gauge. The needle on the gauge moves from "C" to "H".

The tachometer indicates engine speed in revolutions per minute (rpm).

The tachometer is regulated by a signal:

- from terminal 3 of the ECM (ECCS control module)
- to combination meter terminal 29 for the tachometer.

The fuel gauge indicates the approximate fuel level in the fuel tank.

The fuel gauge is regulated by a variable ground signal supplied:

- to combination meter terminal 14 for the fuel gauge
- from terminal 1 of the fuel tank gauge unit
- through terminal 3 of the fuel tank gauge unit
- through body grounds B14 and B17.

The vehicle speed sensor provides a voltage signal to the combination meter for the speedometer.



The voltage is supplied:

- to combination meter terminals 30 and 24 for the speedometer
- from terminals 1 and 2 of the vehicle speed sensor.

The speedometer converts the voltage into the vehicle speed displayed.

METERS AND GAUGES/WITH TACHOMETER

Combination Meter





AEL622

METERS AND GAUGES/WITH TACHOMETER




Speedometer, Tachometer, Temp. and Fuel Gauges/Wiring Diagram –METER–

EL-METER-01





Refer to last page (Foldout page).

M3
M16, E101
F24, F25
GA, SR









Inspection/Fuel Gauge and Water Temperature Gauge






Inspection/Tachometer





Inspection/Speedometer and Vehicle Speed Sensor

SYMPTOM: Speedometer stays at 0 km/h (0 MPH).



System Description

With the ignition switch in the ON or START position, power is supplied:

- through 10A fuse (No. ⑧ , located in the fuse block [HEC])
- to combination meter terminal ③④ for the water temperature gauge, fuel gauge and speedometer.

Ground is supplied:

- to combination meter terminal ③⑤
- through body grounds ④④③, ④④④ and ④⑥⑤.

The water temperature gauge indicates the engine coolant temperature. The reading on the gauge is based on the resistance of the thermal transmitter.

As the temperature of the coolant increases, the resistance of the thermal transmitter decreases. A variable ground is supplied to terminal ②⑨ of the combination meter for the water temperature gauge. The needle on the gauge moves from "C" to "H".

The fuel gauge indicates the approximate fuel level in the fuel tank.

The fuel gauge is regulated by a variable ground signal supplied:

- to combination meter terminal ②④ for the fuel gauge
- from terminal ① of the fuel tank gauge unit
- through terminal ③ of the fuel tank gauge unit
- through body grounds ④①④ and ④①⑦.

The vehicle speed sensor provides a voltage signal to the combination meter for the speedometer.



The voltage is supplied:

- to combination meter terminals ②③ and ②② for the speedometer
- from terminals ① and ② of the vehicle speed sensor.

The speedometer converts the voltage into the vehicle speed displayed.

METERS AND GAUGES/WITHOUT TACHOMETER



Combination Meter



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Speedometer, Temp. and Fuel Gauges/Wiring Diagram –METER–




EL-METER-02




Refer to last page (Foldout page).

M3
M16, E101
F24

METERS AND GAUGES/WITHOUT TACHOMETER













Inspection/Fuel Gauge and Water Temperature Gauge



Inspection/Speedometer and Vehicle Speed Sensor

SYMPTOM: Speedometer stays at 0 km/h (0 MPH).






Fuel Tank Gauge Unit Check

- For removal, refer to FE section ("Fuel Pump and Gauge", "FUEL SYSTEM").


Check the resistance between terminals ① and ③.

Ohmmeter		Float position mm (in)			Resistance value (Ω)
(+)	(-)				
①	③	A	Full	35.8 (1.409)	Approx. 4.5 - 6
		B	1/2	85.9 (3.382)	Approx. 31.5 - 33.5
		C	Empty	128.8 (5.071)	Approx. 80 - 83



Fuel Warning Lamp Sensor Check


- It will take a short time for the bulb to light.



Thermal Transmitter Check

Check the resistance between the terminals of thermal transmitter and body ground.


Water temperature	Resistance
60°C (140°F)	Approx. 70 - 90 Ω
100°C (212°F)	Approx. 21 - 24 Ω



Oil Pressure Switch Check

	Oil pressure kPa (kg/cm ² , psi)	Continuity
Engine start	More than 10 - 20 (0.1 - 0.2, 1.4 - 2.8)	NO
Engine stop	Less than 10 - 20 (0.1 - 0.2, 1.4 - 2.8)	YES

Check the continuity between the terminals of oil pressure switch and body ground.



Vehicle Speed Sensor Signal Check

1. Remove vehicle speed sensor from transaxle.
2. Turn vehicle speed sensor pinion quickly and measure voltage across terminals ① and ②.

Warning Lamps/System Description*

If equipped with theft warning system, power is supplied at all times:

- through 7.5A fuse (No. 24 , located in the fuse block [HEC])
- to combination meter terminal 37 for the security lamp.

Ground for the security lamp is supplied depending on the system conditions:

- to combination meter terminal 36
- from terminal 2 of the smart entrance control unit.

With the ignition switch in the ON or START position, power is supplied:

- through 10A fuse (No. 8 , located in the fuse block [HEC])
- to combination meter terminal 10 (34) for the air bag warning lamp
- to combination meter terminal 22 (14) and
- to combination meter terminal 41.

Ground is supplied for each of the warning lamps through different terminals of the combination meter.

For details of power and ground terminals for the warning lamps in the combination meter, refer to "Combination Meter", "METERS AND GAUGES/WITH TACHOMETER" or "METERS AND GAUGES/WITHOUT TACHOMETER".

*: Terminal numbers in () are for models without tachometer.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA


EL

IDX

WARNING LAMPS AND CHIME

Warning Lamps/Schematic

MODELS WITH TACHOMETER




AEL592-A

WARNING LAMPS AND CHIME

Warning Lamps/Schematic (Cont'd)




MODELS WITHOUT TACHOMETER



WARNING LAMPS AND CHIME

Warning Lamps/Wiring Diagram –WARN– (Cont'd)

EL-WARN-02



Refer to last page (Foldout page).



M16, **E101**, **M37**

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
DX

WARNING LAMPS AND CHIME

Warning Lamps/Wiring Diagram -WARN- (Cont'd)

EL-WARN-03





Refer to last page (Foldout page).

M16, E101
F24: GA
F25: SR
B107

Warning Lamps/Wiring Diagram –WARN– (Cont'd)

 : For U.S.A.
 : For Canada
 : Models with ABS





(M16), (E101)
(F24)
(B107)

WARNING LAMPS AND CHIME

Warning Lamps/Wiring Diagram -WARN- (Cont'd)

EL-WARN-06



Refer to last page (Foldout page).
(M16, E101)

Warning Chime/System Description

MODELS WITH POWER DOOR LOCKS

The warning chime is controlled by the smart entrance control unit.

Power is supplied at all times:

- through 7.5A fuse (No. 24 , located in the fuse block [HEC])
- to warning chime terminal ③
- to key switch terminal ①.

Power is supplied at all times:

- through 10A fuse (No. 36 , located in the fusible link and fuse box)
- to lighting switch terminal ⑪.

Power is supplied at all times:

- through 25A fusible link (letter f , located in the fusible link and fuse box)
- to circuit breaker terminal ①
- through circuit breaker terminal ②
- to smart entrance control unit terminal ①.

With the ignition switch in the ON or START position, power is supplied:

- through 7.5A fuse (No. 7 , located in the fuse block [HEC])
- to smart entrance control unit terminal ⑪.

Ground is supplied to smart entrance control unit terminal ⑩ through body grounds M43 , M44 and M60 .

When a signal, or combination of signals, is received by the smart entrance control unit, ground is supplied:

- through smart entrance control unit terminal ②③
- to warning chime terminal ①.

With power and ground supplied, the warning chime will sound.

Ignition key warning chime

With the key in the ignition switch in the OFF or ACC position, and the driver's door open, the warning chime will sound. A battery positive voltage is supplied:

- from key switch terminal ②
- to smart entrance control unit terminal ②④.

Ground is supplied:

- to smart entrance control unit terminal ①⑤
- from front door switch LH terminal ①.

Front door switch LH terminal ③ is grounded through body grounds B14 and B17 .

Light warning chime

With ignition switch OFF, or ACC driver's door open, and lighting switch in 1ST or 2ND position, the warning chime will sound. A battery positive voltage is supplied:

- from lighting switch terminal ⑫
- to smart entrance control unit terminal ②⑤

Ground is supplied:

- to smart entrance control unit terminal ①⑤
- from front door switch LH terminal ①.

Front door switch LH terminal ③ is grounded through body grounds B14 and B17 .

Seat belt warning chime

With ignition switch turned ON and seat belt unfastened (seat belt switch ON), warning chime will sound for approximately 6 seconds.

Ground is supplied:

- to smart entrance control unit terminal ②①
- from seat belt switch terminal ①.

Seat belt switch terminal ② is grounded through body grounds B14 and B17 .

MODELS WITHOUT POWER DOOR LOCKS

The warning chime is controlled by the warning chime unit.

Power is supplied at all times:

- through 7.5A fuse (No. 24 , located in the fuse block [HEC])
- to key switch terminal ①.

WARNING LAMPS AND CHIME

Warning Chime/System Description (Cont'd)

Power is supplied at all times:

- through 10A fuse (No. 36), located in the fusible link and fuse box)
- to lighting switch terminal ⑪.

With the ignition switch in the ON or START position, power is supplied:

- through 7.5A fuse (No. 7), located in the fuse block [HEC])
- to warning chime unit terminal ①.

Ground is supplied to warning chime unit terminal ⑧ through body grounds M43, M44 and M60.

When a signal, or combination of signals, is received by the warning chime unit, the warning chime will sound.

Ignition key warning chime

With the key in the ignition switch in the OFF or ACC position, and the driver's door open, the warning chime will sound. A battery positive voltage is supplied:

- from key switch terminal ②
- to warning chime unit terminal ⑤.

Ground is supplied:

- to warning chime unit terminal ⑦
- from front door switch LH terminal ①.

Front door switch LH terminal ③ is grounded through body grounds B14 and B17.

Light warning chime

With ignition switch OFF or ACC, driver's door open, and lighting switch in 1ST or 2ND position, warning chime will sound. A battery positive voltage is supplied:

- from lighting switch terminal ⑫
- to warning chime unit terminal ④.

Ground is supplied:

- to warning chime unit terminal ⑦
- from front door switch LH terminal ①.

Front door switch LH terminal ③ is grounded through body grounds B14 and B17.

Seat belt warning chime

With ignition switch turned ON and seat belt unfastened (seat belt switch ON), warning chime will sound for approximately 6 seconds.

Ground is supplied:

- to warning chime unit terminal ②
- from seat belt switch terminal ①.

Seat belt switch terminal ② is grounded through body grounds B14 and B17.

GI

MA

EM

IC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

ET

HA



EL

IDX

WARNING LAMPS AND CHIME

Warning Chime/Wiring Diagram –CHIME–

MODELS WITH POWER DOOR LOCKS





WARNING LAMPS AND CHIME

Warning Chime/Wiring Diagram –CHIME– (Cont'd)

MODELS WITHOUT POWER DOOR LOCKS

EL-CHIME-02



Refer to last page (Foldout page).

M3
M16, E101

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

WARNING LAMPS AND CHIME

Warning Chime/Trouble Diagnoses

SYMPTOM CHART

Models with power door locks

PROCEDURE	Preliminary Check			Main Power Supply and Ground Circuit Check	Diagnostic Procedure		
REFERENCE PAGE	EL-105	EL-105	EL-105	EL-107	EL-108	EL-110	EL-112
SYMPTOM	Preliminary check 1	Preliminary check 2	Preliminary check 3	Main power supply and Ground circuit	Diagnostic Procedure 1	Diagnostic Procedure 2	Diagnostic Procedure 3
Light warning chime does not activate.	○			○	○		
Ignition key warning chime does not activate.		○		○		○	
Seat belt warning chime does not activate.			○	○			○

Models without power door locks

PROCEDURE	Preliminary Check			Main Power Supply and Ground Circuit Check	Diagnostic Procedure		
REFERENCE PAGE	EL-106	EL-106	EL-106	EL-107	EL-109	EL-111	EL-112
SYMPTOM	Preliminary check 1	Preliminary check 2	Preliminary check 3	Main power supply and Ground circuit	Diagnostic Procedure 1	Diagnostic Procedure 2	Diagnostic Procedure 3
Light warning chime does not activate.	○			○	○		
Ignition key warning chime does not activate.		○		○		○	
Seat belt warning chime does not activate.			○	○			○

WARNING LAMPS AND CHIME


Warning Chime/Trouble Diagnoses (Cont'd)

PRELIMINARY CHECK

Models with power door locks


Preliminary check 1

- Light warning chime does not activate.




Preliminary check 2

- Ignition key warning chime does not activate.



Preliminary check 3

- Seat belt warning chime does not activate.



GI
MA
EM
LG
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX


WARNING LAMPS AND CHIME

Warning Chime/Trouble Diagnoses (Cont'd)

Models without power door locks


Preliminary check 1

- Light warning chime does not activate.




Preliminary check 2

- Ignition key warning chime does not activate.



Preliminary check 3

- Seat belt warning chime does not activate.



WARNING LAMPS AND CHIME

Warning Chime/Trouble Diagnoses (Cont'd)

MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK

Main power supply

• Models with power door locks

Terminals	Battery voltage existence condition		
	Ignition switch position		
	OFF	ACC	ON
⑪ - ⑩	No	No	Yes
① - ⑩	Yes	Yes	Yes

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST





RS

BT

HA

EL

IDX



• Models without power door locks

Terminals	Battery voltage existence condition		
	Ignition switch position		
	OFF	ACC	ON
① - ⑧	No	No	Yes

Ground circuit

• Models with power door locks

Terminals	Continuity
⑩ - Ground	Yes

• Models without power door locks

Terminals	Continuity
⑧ - Ground	Yes

WARNING LAMPS AND CHIME






Warning Chime/Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1

SYMPTOM: Light warning chime does not activate.

- Perform "Preliminary check 1" before referring to the following flow chart.




Models with power door locks



WARNING LAMPS AND CHIME

Warning Chime/Trouble Diagnoses (Cont'd)

Models without power door locks



GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
ET
HA
EL
IDX

WARNING LAMPS AND CHIME






Warning Chime/Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 2

SYMPTOM: Ignition key warning chime does not activate.

- Perform "Preliminary check 2" before referring to the following flow chart.



Models with power door locks



WARNING LAMPS AND CHIME

Warning Chime/Trouble Diagnoses (Cont'd)

Models without power door locks



Step 2

DOOR SWITCH INPUT SIGNAL CHECK.

Check continuity between warning chime unit harness terminals ⑦ and ⑧.

Condition of driver's door	Continuity
LH door is closed.	No
LH door is open.	Yes

NG

- Check door switch. (Refer to EL-223.)
- Check harness continuity between warning chime unit harness terminal ⑦ and LH door switch harness terminal ①. **Continuity should exist.**
- Check harness continuity between LH door switch harness terminal ③ and body ground. **Continuity should exist.**

OK

Step 1

IGNITION KEY SWITCH INPUT SIGNAL CHECK.

Measure voltage between warning chime unit harness terminals ⑤ and ⑧.

Condition	Voltage [V]
Key is inserted.	Approx. 12
Key is pulled.	0

NG

- Check ignition key switch.
- Check harness continuity between warning chime unit harness terminal ⑤ and key switch harness terminal ②. **Continuity should exist.**
- Measure voltage between key switch harness terminal ① and body ground. **Battery voltage should exist.**

OK

Replace warning chime unit.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX

WARNING LAMPS AND CHIME





Warning Chime/Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 3

SYMPTOM: Seat belt warning chime does not activate.

- Perform "Preliminary check 3" before referring to the following flow chart.

Models with power door locks



Step 2

SEAT BELT SWITCH INPUT SIGNAL CHECK.

Check continuity between control unit harness terminals (21) and (10).

Condition	Continuity
Unfastened	Yes
Fastened	No

NG

- Check seat belt switch.
- Check harness continuity between control unit harness terminal (21) and seat belt switch harness terminal (1).

Continuity should exist.

- Check harness continuity between seat belt switch harness terminal (2) and body ground.

Continuity should exist.

OK

Step 1

WARNING CHIME POWER SUPPLY CHECK.

Measure voltage between warning chime harness terminal (3) and body ground. Battery voltage should exist.

NG

Check 7.5A fuse 24, harness and connector.

OK

WARNING CHIME OUTPUT SIGNAL CHECK.

Check continuity between warning chime harness terminal (1) and control unit harness terminal (23). Continuity should exist.

NG

Repair harness or connectors.

OK

WARNING CHIME CHECK. Refer to EL-113.

NG

Replace warning chime.

OK

Replace control unit.

Models without power door locks

SEAT BELT SWITCH INPUT SIGNAL CHECK.

Check continuity between warning chime unit harness terminals (2) and (8).

Condition	Continuity
Unfastened	Yes
Fastened	No

NG

- Check seat belt switch.
- Check harness continuity between warning chime unit harness terminal (2) and seat belt switch harness terminal (1).

Continuity should exist.


- Check harness continuity between seat belt switch harness terminal (2) and body ground.

Continuity should exist.

OK

Replace warning chime unit.




WARNING LAMPS AND CHIME



Diode Check

- Check continuity using an ohmmeter.
- Diode is functioning properly if test results are as shown in the figure at left.

NOTE: Specification may vary depending on the type of tester. Before performing this inspection, be sure to refer to the instruction manual for the tester being used.



Warning Chime Check

Supply battery voltage to warning chime as shown in the illustration.

Warning chime should operate.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX

System Description

WIPER OPERATION

The wiper switch is controlled by a lever built into the combination switch.

There are three wiper switch positions:

- LO speed
- HI speed
- INT (with Intermittent)

With the ignition switch in the ACC or ON position, power is supplied:

- through 20A fuse (No. 19, located in the fuse block [HEC])
- to wiper motor terminal ⑥
- to wiper amplifier terminal ⑤ (with intermittent).

Ground is supplied to wiper amplifier terminal ③ through body grounds M43, M44 and M60 (with intermittent).

Low and high speed wiper operation

Ground is supplied to wiper switch terminal ⑰ through body grounds E13 and E25.

When the wiper switch is placed in the LO position, ground is supplied:

- through terminal ⑭ of the wiper switch
- to wiper motor terminal ②.

With power and ground supplied, the wiper motor operates at low speed.

When the wiper switch is placed in the HI position, ground is supplied:

- through terminal ⑯ of the wiper switch
- to wiper motor terminal ①.

With power and ground supplied, the wiper motor operates at high speed.

Auto stop operation (with intermittent)

With wiper switch turned OFF, wiper motor will continue to operate until wiper arms reach windshield base.

When wiper arms are not located at base of windshield with wiper switch OFF, ground is provided:

- from terminal ⑭ of the wiper switch
- to wiper motor terminal ②, in order to continue wiper motor operation at low speed.

Ground is also supplied:

- through terminal ⑬ of the wiper switch
- to wiper amplifier terminal ②
- through terminal ⑦ of the wiper amplifier
- to wiper motor terminal ⑤
- through terminal ④ of the wiper motor, and
- through body grounds M43, M44 and M60.

When wiper arms reach base of windshield, wiper motor terminals ⑤ and ⑥ are connected instead of terminals ⑤ and ④. Wiper motor will then stop wiper arms at the PARK position.

Auto stop operation (without intermittent)

With wiper switch turned OFF, wiper motor will continue to operate until wiper arms reach windshield base.

When wiper arms are not located at base of windshield with wiper switch OFF, ground is provided:

- from terminal ⑭ of the wiper switch
- to wiper motor terminal ②, in order to continue wiper motor operation at low speed.

Ground is also supplied:

- through terminal ⑬ of the wiper switch
- to wiper motor terminal ⑤
- through terminal ④ of the wiper motor, and
- through body grounds M43, M44 and M60.

When wiper arms reach base of windshield, wiper motor terminals ⑤ and ⑥ are connected instead of terminals ⑤ and ④. Wiper motor will then stop wiper arms at the PARK position.

Intermittent operation

The wiper motor operates the wiper arms one time at low speed at an interval of approximately 7 seconds. This feature is controlled by the intermittent wiper amplifier.

When the wiper switch is placed in the INT position, ground is supplied:

- to wiper amplifier terminal ①

WIPER AND WASHER

System Description (Cont'd)

- from wiper switch terminal ⑮
- through body grounds ①③ and ①②⑤, and
- to wiper motor terminal ②
- through the wiper switch terminal ⑭
- to wiper switch terminal ⑬
- through wiper amplifier terminal ②
- to wiper amplifier terminal ③
- through body grounds ④③, ④④ and ④⑥.

WASHER OPERATION

With the ignition switch in the ACC or ON position, power is supplied:

- through 20A fuse (No. ①⑨, located in the fuse block [HEC])
- to washer motor terminal ①.

When the lever is pulled to the WASH position, ground is supplied:

- to washer motor terminal ②, and
- to wiper amplifier terminal ⑥ (with intermittent)
- from terminal ①⑧ of the wiper switch
- through terminal ①⑦ of the wiper switch, and
- through body grounds ①③ and ①②⑤.

With power and ground supplied, the washer motor operates.

If equipped with intermittent wipers, the wiper motor is activated when the lever is pulled to WASH for 1 second or more. The motor operates at low for approximately 3 seconds. This feature is controlled by the wiper amplifier in the same manner as the intermittent operation.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT




HA

EL

IDX

Wiring Diagram -WIPER- MODELS WITH INTERMITTENT WIPERS

EL-WIPER -01




Refer to last page (Foldout page).

M16, E101
M3

WIPER AND WASHER

Wiring Diagram -WIPER- (Cont'd)

EL-WIPER -02






3	2	1	(M64)
7	6	5	W

WIPER AND WASHER

Wiring Diagram -WIPER- (Cont'd)





MODELS WITHOUT INTERMITTENT WIPERS

EL-WIPER -03



Refer to last page (Foldout page).


M16, E101
M3



Trouble Diagnoses

DIAGNOSTIC PROCEDURE 1

SYMPTOM: Intermittent wiper does not operate.





WIPER AND WASHER

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 2

SYMPTOM: Wiper and washer activate individually but not in combination.



A

WASHER SWITCH INPUT SIGNAL CHECK.

1. Turn ignition switch to "ACC".
2. Measure voltage between wiper amp. harness terminals ⑥ and ③.

Condition of washer switch	Voltage [V]
OFF	Approx. 12
ON	0

NG

Check harness continuity between wiper amp. harness terminal ⑥ and wiper switch harness terminal ⑱.

OK

B

WIPER AMP. OUTPUT SIGNAL CHECK.

Measure voltage between wiper amp. harness terminals ② and ③ after operating washer switch.

0V for approx. 3 seconds after washer has operated.

NG

Check wiper switch.

OK

Replace wiper amp.

Wiper Installation and Adjustment

1. Turn ignition ON.
2. Prior to wiper arm installation, turn on wiper switch and then turn it "OFF". Allow wiper to operate until its Auto Stop position is reached before turning ignition OFF.
3. Lift the blade up and then set it down onto glass surface. Set the blade center to clearance "L" just before tightening nut.
4. Eject washer fluid. Turn on wiper switch to operate wiper motor and then turn it "OFF".
5. Ensure that wiper blades stop within clearance "L".


Clearance "L": 27 - 41 mm (1.06 - 1.61 in)

- Tighten windshield wiper arm nuts to specified torque.


Windshield wiper:

⌚: 21 - 26 N·m (2.1 - 2.7 kg-m, 15 - 20 ft-lb)

Windshield wiper and washer




AEL624



SEL024J


- Before reinstalling wiper arm, clean up the pivot area as illustrated. This will reduce possibility of wiper arm looseness.



Washer Nozzle Adjustment

- Adjust washer nozzle with suitable tool as shown in the figure at left.

Adjustable range: $\pm 10^\circ$



System Description

Power is supplied at all times:

- from 25A fusible link (letter **f** , located in the fusible link and fuse box)
- to circuit breaker terminal **①**
- through circuit breaker terminal **②**
- to power window relay terminal **③**.

With the ignition switch in ON or START position, power is supplied:

- from 7.5A fuse (No. **7** , located in the fuse block [HEC])
- to power window relay terminal **①**.

Ground is supplied to power window relay terminal **②**:

- through body grounds **M43** , **M44** and **M60**.

The power window relay is energized and power is supplied:

- through terminal **⑤** of the power window relay
- to main power window and door lock switch terminal **①**
- to power window switch (front RH) terminal **⑤**
- to power window switch (rear LH) terminal **⑤**, and
- to power window switch (rear RH) terminal **⑤**.

Ground is supplied

- to main power window and door lock switch terminal **⑤**
- through body grounds **M43** , **M44** and **M60**.

MANUAL OPERATION

Front door LH

WINDOW UP

When the main power window switch front LH is pressed in the UP position, power is supplied:

- to front power window motor LH terminal **②**
- through main power window and door lock switch terminal **⑬**.

Ground is supplied:

- to front power window motor LH terminal **①**
- through main power window and door lock switch terminal **⑮**.

Then, the motor raises the window until the switch is released.

WINDOW DOWN

When the main power window switch front LH is pressed in the DOWN position, power is supplied:

- to front power window motor LH terminal **①**
- through main power window and door lock switch terminal **⑮**.

Ground is supplied:

- to front power window motor LH terminal **②**
- through main power window and door lock switch terminal **⑬**.

Then, the motor lowers the window until the switch is released.

Except front LH door

FRONT DOOR RH

NOTE:

Figures in parentheses () refer to terminal Nos. arranged in order when the UP or DOWN section of power window switch is pressed.

Operation by main switch

Power is supplied:

- through main power window and door lock switch terminal **(⑭, ⑬)**
- to power window switch (front RH) terminal **(③, ④)**.

The subsequent operations are the same as those outlined under "Operation by sub-switches".

Operation by sub-switches

Power is supplied:

- through power window switch (front RH) terminal **(①, ②)**
- to power window motor (front RH) terminal **(②, ①)**.

Ground is supplied:

- to power window motor (front RH) terminal **(①, ②)**

G1

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX

POWER WINDOW

System Description (Cont'd)

- through power window switch (front RH) terminal (②, ①)
- to power window switch (front RH) terminal (④, ③)
- through main power window and door lock switch terminal (⑬, ⑭)
- to main power window and door lock switch terminal (⑤)
- through body grounds (M43), (M44) and (M60).

Then, the motor raises or lowers the window until the switch is released.

REAR DOOR LH

NOTE:

Figures in parentheses () refer to terminal Nos. arranged in order when the UP or DOWN section of power window switch is pressed.

Operation by main switch

Power is supplied:

- through main power window and door lock switch terminal (⑫, ⑪)
- to power window switch (rear LH) terminal (③, ④).

The subsequent operations are the same as those outlined under "Operation by sub-switches".

Operation by sub-switches

Power is supplied:

- through power window switch (rear LH) terminal (①, ②)
- to power window motor (rear LH) terminal (②, ①).

Ground is supplied:

- to front power window motor (rear LH) terminal (①, ②)
- through power window switch (rear LH) terminal (②, ①)
- to power window switch (rear LH) terminal (④, ③)
- through main power window and door lock switch terminal (⑪, ⑫)
- to main power window and door lock switch terminal (⑤)
- through body grounds (M43), (M44) and (M60).

Then, the motor raises or lowers the window until the switch is released.

REAR DOOR RH

NOTE:

Figures in parentheses () refer to terminal Nos. arranged in order when the UP or DOWN section of power window switch is pressed.

Operation by main switch

Power is supplied:

- through main power window and door lock switch terminal (⑩, ⑨)
- to power window switch (rear RH) terminal (③, ④).

The subsequent operations are the same as those outlined under "Operation by sub-switches".

Operation by sub-switches

Power is supplied:

- through power window switch (rear RH) terminal (①, ②)
- to power window motor (rear RH) terminal (②, ①).

Ground is supplied:

- to front power window motor (rear RH) terminal (①, ②)
- through power window switch (rear RH) terminal (②, ①)
- to power window switch (rear RH) terminal (④, ③)
- through main power window and door lock switch terminal (⑨, ⑩)
- to main power window and door lock switch terminal (⑤)
- through body grounds (M43), (M44) and (M60).

Then, the motor raises or lowers the window until the switch is released.

AUTO FEATURE

The AUTO feature enables the driver to lower the driver's window without holding the window switch down.

The AUTO feature only operates on the driver's window downward movement.

When the main power window switch (front LH) is pressed and released in the AUTO position, ground signal is supplied:

- to front power window motor LH terminal ②
- through main power window and door lock switch terminal ⑯.

POWER WINDOW

System Description (Cont'd)

Power is supplied:

- to front power window motor LH terminal ①
 - through main power window and door lock switch terminal ⑮.
- Then, the front door LH window will travel to the fully open position.

LOCK FEATURE

The power window lock is designed to lock-out window operation to all windows except the front door LH window.

Pressing the lock switch to the lock position disconnects the ground from the main power window and door lock switch. This prevents the power window motors from operating.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT


HA

EL


IDX

POWER WINDOW


Component Layout



Rear door



Front door





NOTES

- GI
- MA
- EM
- LC
- EC
- FE
- CL
- MT
- AT
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL**
- IDX

Wiring Diagram -WINDOW-

EL-WINDOW-01






Refer to last page (Foldout page).

M16, E101
M3

POWER WINDOW

Wiring Diagram -WINDOW- (Cont'd)

EL-WINDOW-02



POWER WINDOW

Trouble Diagnoses

Symptom	Possible causes	Repair order
None of the power windows can be operated from any switch.	7.5A fuse and 25A fusible link and circuit breaker. - Grounds (M43), (M44) and (M60). - Power window relay. - Open/short in main power window and door lock switch circuit.	- Check 7.5A fuse (No. 7), located in fuse block [HEC]) and 25A fusible link (letter f), located in the fusible link and fuse box) and the circuit breaker. Turn ignition switch ON and verify battery positive voltage is present at terminal ① of main power window switch and terminal ⑤ of any other switches. - Check grounds (M43), (M44) and (M60). - Check power window relay. - Check L/W wire between power window relay and main power window door lock switch for open/short circuit.
Driver side power window cannot be operated but other windows can be operated.	- Driver side (front LH) power window motor circuit. - Driver side (front LH) power window motor.	- Check driver side (front LH) power window motor circuit. - Check driver side (front LH) power window motor.
One or more passenger power windows cannot be operated.	- Power window switches (front RH, rear LH and RH). - Power window motors (front RH, rear LH and RH). - Main power window and door lock switch. - Power window circuits.	- Check power window switches (front RH, rear LH and RH). - Check power window motors (front RH, rear LH and RH). - Check main power window and door lock switch. - Check wires between main power window and door lock switch and power window switches and motors for open/short circuits.
One or more passenger power windows cannot be operated by main switch but can be operated by passenger's switches.	Main power window and door lock switch.	Check main power window and door lock switch.

System Description

Power is supplied at all times:

- through 25A fusible link (Letter **f** , located in the fusible link and fuse box)
- to circuit breaker terminal ①
- through circuit breaker terminal ②
- to smart entrance control unit terminal ①.

Ground is supplied to smart entrance control unit terminal ⑩ through body grounds **M43** , **M44** and **M60** .

INPUT

When the door lock & unlock switch LH is in LOCK position, ground signal is supplied:

- to smart entrance control unit terminal ⑩
- through door lock & unlock switch LH terminal ⑦
- to door lock & unlock switch LH terminal ⑤
- through body grounds **M43** , **M44** and **M60** .

When the door lock & unlock switch RH is in LOCK position, ground signal is supplied:

- to smart entrance control unit terminal ⑩
- through door lock & unlock switch RH terminal ①
- to door lock & unlock switch RH terminal ②
- through body grounds **M43** , **M44** and **M60** .

When the door lock & unlock switch LH is in UNLOCK position, ground signal is supplied:

- to smart entrance control unit terminal ⑩
- through door lock & unlock switch LH terminal ⑧
- to door lock & unlock switch LH terminal ⑤
- through body grounds **M43** , **M44** and **M60** .

When the door lock & unlock switch RH is in UNLOCK position, ground signal is supplied:

- to smart entrance control unit terminal ⑩
- through door lock & unlock switch RH terminal ③
- to door lock & unlock switch RH terminal ②
- through body grounds **M43** , **M44** and **M60** .

OUTPUT

Unlock

Power is supplied:

- from smart entrance control unit terminal ③
- to front door lock actuator LH terminal ①
- from smart entrance control unit terminal ②
- to all other door lock actuators terminal ①.

Ground is supplied:

- from smart entrance control unit terminal ④,
- to all door lock actuators terminal ③.

With power and ground supplied, the door lock actuators move to the unlocked position.

Lock

Power is supplied:

- from smart entrance control unit terminal ④
- to all door lock actuators terminal ③.

Ground is supplied:

- from smart entrance control unit terminal ③
- to front door lock actuator LH terminal ①
- from smart entrance control unit terminal ②.
- to all other door lock actuators terminal ①.

With power and ground supplied, the door lock actuators move to the locked position.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT


HA

EL

IDX

POWER DOOR LOCK

Schematic





AEL594

POWER DOOR LOCK

Wiring Diagram -D/LOCK-

EL-D/LOCK-01





Refer to last page (Foldout page).

M16, E101
M3
M37

POWER DOOR LOCK

Wiring Diagram -D/LOCK- (Cont'd)

EL-D/LOCK-02




Refer to last page (Foldout page).
(M37)

POWER DOOR LOCK


Wiring Diagram -D/LOCK- (Cont'd)

EL-D/LOCK-03

RE: Models with multi-remote control system



POWER DOOR LOCK




Trouble Diagnoses

MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK


Main power supply for smart entrance control unit (SECU)

Terminals	Battery voltage existence
① - Ground (GND)	Yes




Main power supply while ignition switch is "ON" or "START" position

Terminals	Battery voltage existence
⑪ - Ground	Yes



Ground circuit for smart entrance control unit

Terminals	Continuity
⑩ - Ground	Yes



ELECTRICAL COMPONENTS INSPECTION

Power door lock motor


Door lock condition	Terminals	
	⊕	⊖
Unlocked → Locked	③	①
Locked → Unlocked	①	③

POWER DOOR LOCK

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE

SYMPTOM: Power door locks cannot be operated by door lock/unlock switches.




A

CHECK SIGNAL OF DOOR LOCK/UNLOCK SWITCH.

Door lock/unlock switch (LH or RH) operation	Terminals	Voltage (V)
Lock	(18) - GND	12 → 0 → 12
Unlock	(19) - GND	12 → 0 → 12

OK → **(A)** (Go to next page.)

NG



B C

CHECK HARNESS CONTINUITY.

1. Disconnect control unit connector.
2. Check continuity.

B Door lock/unlock switch LH


Operation	Terminals	Continuity
Lock	(18) - (5)	Yes
Unlock	(19) - (5)	

C Door lock/unlock switch RH

Operation	Terminals	Continuity
Lock	(18) - (2)	Yes
Unlock	(19) - (2)	

OK → Repair ground harness of door lock/unlock switch.

NG



D E

CHECK DOOR LOCK/UNLOCK SWITCHES.

1. Disconnect door lock/unlock switch.
2. Check continuity.

D Door lock/unlock switch LH

Operation	Terminals	Continuity
Lock	(7) - (5)	Yes
Unlock	(8) - (5)	



E Door lock/unlock switch RH

Operation	Terminals	Continuity
Lock	(1) - (2)	Yes
Unlock	(3) - (2)	

OK → Repair harness between door lock/unlock switch and control unit connector.




NG

Replace door lock/unlock switch.



POWER DOOR LOCK

Trouble Diagnoses (Cont'd)



F G

CHECK DOOR LOCK ACTUATOR CIRCUIT.

Check voltage for door lock motor.

F Front door lock actuator LH

Door lock/unlock switch operation	Terminals		Voltage (V)
	⊕	⊖	
Lock	④	③	Battery voltage
Unlock	③	④	

NG

Replace smart entrance control unit.

G All other door lock actuators

Door lock/unlock switch operation	Terminals		Voltage (V)
	⊕	⊖	
Lock	④	②	Battery voltage
Unlock	②	④	

OK

CHECK VOLTAGE FOR DOOR LOCK MOTOR.

Door lock/unlock switch operation	Terminals		Voltage (V)
	⊕	⊖	
Lock	③	①	Battery voltage
Unlock	①	③	

NG

Repair harness between control unit connector and door lock actuator.

OK

Go to power door lock motor in ELECTRICAL COMPONENTS INSPECTION. (See page EL-136.)

NG


Replace defective power door lock motor.

OK


Check system again.

Wiring Diagram –MIRROR–

EL-MIRROR-01



Refer to last page (Foldout page).



System Description

POWER

Power is supplied to the sunroof motor assembly by the sunroof relay, or power window relay, if equipped. When the ignition switch is turned ON the relay is energized. The power circuit is protected by the circuit breaker. The sunroof motor assembly has an independent ground circuit.

TILT AND SLIDE OPERATION

The sunroof is controlled by the sunroof switch. With sunroof in closed position, depressing UP/CLOSE switch will tilt rear of sunroof up. The sunroof will stop when the switch is released, or when the sunroof reaches its maximum tilt position.






The sunroof will tilt down when in tilt up position and DOWN/OPEN switch is depressed. The sunroof will stop when switch is released, or when sunroof is fully closed.

With sunroof in closed position, pressing DOWN/OPEN switch will cause sunroof to slide open. The sunroof will slide open until switch is released or until it is all the way open. The sunroof will close when in open position, and UP/CLOSE switch is depressed. The sunroof will slide until switch is released, or when sunroof is fully closed.

All automatic operations in sunroof are controlled by internal limit switches located in sunroof motor assembly.

Wiring Diagram -SROOF-

EL-SROOF-01



Refer to last page (Foldout page).

(M18) (E101)
(M3)

EL

IDX

Wiring Diagram –HORN–



(M16), (E101)
(M3)



System Description

If equipped with power door locks the rear defogger system is controlled by the smart entrance control unit. If not equipped with power door locks the rear defogger system is controlled by the rear window defogger timer. The rear window defogger operates for approximately 15 minutes.

Power is supplied at all times:

- through 20A fuse (No. ④ , located in the fuse block [HEC])
- to rear window defogger relay terminal ③ and
- through 20A fuse (No. ⑤ , located in the fuse block [HEC])
- to rear window defogger relay terminal ⑥.

With the ignition switch in the ON or START position, power is supplied:

- through 7.5A fuse (No. ⑦ , located in the fuse block [HEC])
- to rear window defogger relay terminal ① and
- to smart entrance control unit terminal ⑪ (models with power door lock), or
- to rear window defogger timer terminal ① (models without power door lock).

Ground is supplied to terminal ② of the rear window defogger switch through body grounds M43 , M44 and M60 .

When the rear window defogger switch is activated, ground is supplied:

- through terminal ① of the rear window defogger switch
- to smart entrance control unit terminal ⑫ (models with power door lock) or
- to rear window defogger timer terminal ③ (models without power door lock).

Terminal ③⑥ of the smart entrance control unit (models with power door lock) or terminal ② of the rear window defogger timer (models without power door lock) then supplies ground to the rear window defogger relay terminal ②.

With power and ground supplied, the rear window defogger relay is energized.

Power is supplied:

- through terminals ⑤ and ⑦ of the rear window defogger relay
- to rear window defogger terminal ①.

The rear window defogger has an independent ground.

With power and ground supplied, the rear window defogger filaments heat and defog the rear window.

When the system is activated, the rear window defogger indicator illuminates in the rear window defogger switch.

Power is supplied:

- to terminal ③ of the rear window defogger switch
- from terminal ⑦ of the rear window defogger relay.

Terminal ④ of the rear window defogger switch is grounded through body grounds M43 , M44 and M60 .

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA


EL

IDX

REAR WINDOW DEFOGGER


Wiring Diagram -DEF-

EL-DEF-01



Refer to last page (Foldout page).


(M3)



REAR WINDOW DEFOGGER

Wiring Diagram -DEF- (Cont'd)

EL-DEF-02



4	3	(M38) W
2	1	

Refer to last page (Foldout page).

(M37)





REAR WINDOW DEFOGGER

Trouble Diagnoses

DIAGNOSTIC PROCEDURE

SYMPTOM: Rear defogger does not activate, or does not go off after activating.

Models with power door lock



REAR WINDOW DEFOGGER OUTPUT SIGNAL CHECK.

Measure voltage between control unit harness terminals (36) and (10).

Condition	Voltage [V]
Rear defogger switch is "OFF".	Approx. 12
Rear defogger switch is "ON".	0

OK

- Check rear window defogger relay. (Refer to EL-148.)
- Check rear window defogger circuit.
- Check rear window defogger filament. (Refer to EL-148.)

NG

REAR WINDOW DEFOGGER SWITCH INPUT SIGNAL CHECK.

Check continuity between control unit harness terminal (20) and body ground.

Condition of defogger switch	Continuity
Rear defogger switch is pushed.	Yes
Rear defogger switch is released.	No

NG

- Check rear window defogger switch. (Refer to EL-148.)
- Check continuity between control unit harness terminal (20) and rear window defogger switch harness terminal (1). **Continuity should exist.**
- Check continuity between rear window defogger switch harness terminal (2) and body ground. **Continuity should exist.**

OK

IGNITION INPUT SIGNAL CHECK.

Check voltage between control unit harness terminal (11) and body ground.

Condition	Voltage [V]
Ignition switch is "ON".	Approx. 12
Ignition switch is "OFF".	0

NG

Repair harness or connectors.

OK

CONTROL UNIT GROUND CIRCUIT CHECK.

Check continuity between control unit harness terminal (10) and body ground. **Continuity should exist.**

NG

Repair harness or connectors.





OK

Replace control unit.

REAR WINDOW DEFOGGER

Trouble Diagnoses (Cont'd)

Models without power door lock



A

REAR WINDOW DEFOGGER OUTPUT SIGNAL CHECK.
Measure voltage between rear window defogger timer harness terminals ② and ④.

Condition	Voltage [V]
Rear defogger switch is "OFF".	Approx. 12
Rear defogger switch is "ON".	0

- OK
- Check rear window defogger relay. (Refer to EL-148.)
 - Check rear window defogger circuit.
 - Check rear window defogger filament. (Refer to EL-148.)

B

REAR WINDOW DEFOGGER SWITCH INPUT SIGNAL CHECK.
Check continuity between rear window defogger timer harness terminal ③ and body ground.

Condition of defogger switch	Continuity
Rear defogger switch is pushed.	Yes
Rear defogger switch is released.	No

- NG
- Check rear window defogger switch. (Refer to EL-148.)
 - Check continuity between rear window defogger timer harness terminal ③ and rear window defogger switch harness terminal ①. **Continuity should exist.**
 - Check continuity between rear window defogger switch harness terminal ② and body ground. **Continuity should exist.**

C

IGNITION INPUT SIGNAL CHECK.
Check voltage between rear window defogger timer harness terminal ① and body ground.

Condition	Voltage [V]
Ignition switch is "ON".	Approx. 12
Ignition switch is "OFF".	0

- NG
- Repair harness or connectors.

D

CONTROL UNIT GROUND CIRCUIT CHECK.
Check continuity between rear window defogger timer harness terminal ④ and body ground. **Continuity should exist.**

- NG
- Repair harness or connectors.

OK

Replace control unit.


REAR WINDOW DEFOGGER

Trouble Diagnoses (Cont'd)

ELECTRICAL COMPONENTS INSPECTION

Rear window defogger relay


Check continuity between terminals ③ and ⑤, ⑥ and ⑦.



Condition	Continuity
12V direct current supply between terminals ① and ②	Yes
No current supply	No

Rear window defogger switch



Check continuity between terminals when rear window defogger switch is pushed and released.



Terminals	Condition	Continuity
① - ②	Rear window defogger switch is pushed	Yes
	Rear window defogger switch is released	No

Filament Check



- When measuring voltage, wrap tin foil around the top of the negative probe. Press the foil against the wire with your finger. This action will prevent damage to the element.



- Attach probe circuit tester (in volt range) to middle portion of each filament.

REAR WINDOW DEFOGGER

Filament Check (Cont'd)



2. If a filament is burned out, circuit tester registers 0 or 12 volts.

3. To locate burned out point, move probe to left and right along filament. Tester needle swings abruptly at the burned point.

Filament Repair

REPAIR EQUIPMENT


1. Conductive silver composition (Dupont No. 4817 or equivalent)
2. Ruler 30 cm (11.8 in) long
3. Drawing pen
4. Heat gun
5. Alcohol
6. Cloth

REPAIR PROCEDURE

1. Wipe broken heat wire and its surrounding area clean with a cloth dampened in alcohol.
2. Apply a small amount of conductive silver composition to tip of drawing pen.



Shake silver composition container before use.

3. Place ruler on glass along broken line. Deposit conductive silver composition on break with drawing pen. Slightly overlap existing heat wire on both sides [preferably 5 mm (0.20 in)] of the break.



REAR WINDOW DEFOGGER

Filament Repair (Cont'd)



4. After repair has been completed, check repaired wire for continuity. This check should be conducted 10 minutes after silver composition is deposited.

Do not touch repaired area while test is being conducted.

5. Apply a constant stream of hot air directly to the repaired area for approximately 20 minutes with a heat gun. A minimum distance of 3 cm (1.2 in) should be kept between repaired area and hot air outlet. If a heat gun is not available, let the repaired area dry for 24 hours.

System Description

Refer to Owner's Manual for audio system operating instructions.

Power is supplied at all times:

- through 7.5A fuse (No. 24 , located in the fuse block [HEC])
- to radio/radio and cassette player terminal ⑥.

With the ignition switch in the ACC or ON position, power is supplied:

- through 15A fuse (No. 10 , located in the fuse block [HEC])
- to radio/radio and cassette player terminal ⑩.

Ground is supplied through the case of the radio/radio and cassette player.

When the system is on, audio signals are supplied:

- through radio/radio and cassette player terminals ①, ②, ③, ④, ⑬, ⑭, ⑮ and ⑯
- to the front and rear speakers.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT






HA

EL

IDX

Wiring Diagram -AUDIO-

EL-AUDIO-01



Refer to last page (Foldout page).

M3

Trouble Diagnoses

Symptom	Possible causes	Repair order
Radio inoperative (no digital display and no sound from speakers).	15A fuse - Poor radio case ground - Radio	- Check 15A fuse (No. 10 , located in fuse block [HEC]). Turn ignition switch ON and verify battery positive voltage is present at terminal 10 of radio. - Check radio case ground. - Remove radio for repair.
Radio controls are operational, but no sound is heard from any speaker.	- Radio output - Radio	- Check radio output voltages. - Remove radio for repair.
Radio presets are lost when ignition switch is turned OFF.	7.5A fuse - Radio	- Check 7.5A fuse (No. 24 , located in fuse block [HEC]) and verify battery positive voltage is present at terminal 6 of radio. - Remove radio for repair.
Rear speakers are inoperative.	- Radio output - Radio	- Check radio output voltages. - Remove radio for repair.
Front speakers are inoperative.	- Radio output - Radio	- Check radio output voltages. - Remove radio for repair.
Individual speaker is noisy or inoperative.	- Speaker - Radio output - Speaker circuit - Radio	- Check speaker. - Check radio output voltages. - Check wires for open or short between radio and speaker. - Remove radio for repair.
AM stations are weak or noisy (FM stations OK).	- Antenna - Poor radio ground - Radio	- Check antenna. - Check radio ground. - Remove radio for repair.
FM stations are weak or noisy (AM stations OK).	- Antenna - Radio	- Check antenna. - Remove radio for repair.
Radio generates noise in AM and FM modes with engine running.	- Poor radio ground - Loose or missing ground bonding straps. - Ignition condenser - Generator - Ignition coil or secondary wiring - Radio	- Check radio ground. - Check ground bonding straps. - Replace ignition condenser. - Check generator. - Check ignition coil and secondary wiring. - Remove radio for repair.
Radio generates noise in AM and FM modes with accessories on (switch pops and motor noise).	- Poor radio ground - Antenna - Accessory ground - Faulty accessory	- Check radio ground. - Check antenna. - Check accessory ground. - Replace accessory.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX

AUDIO

Trouble Diagnoses (Cont'd)

SPEAKER INSPECTION

1. Disconnect speaker harness connector.
2. Measure the resistance between speaker terminals ① and ②.
 - The resistance should be 2-4 Ω .
3. Using jumper wires, momentarily connect a 9V battery between speaker terminals ① and ②.
 - A momentary hum or pop should be heard.

ANTENNA INSPECTION

Using a jumper wire, clip an auxiliary ground between antenna and body.

- If reception improves, check antenna ground (at body surface).
- If reception does not improve, check main feeder cable for short circuit or open circuit.

RADIO INSPECTION

All voltage inspections are made with:

- Ignition switch ON or ACC
- Radio ON
- Radio connected (If removed for inspection, supply a ground to the case using a jumper wire.)

Radio voltages

Terminal	Voltage (V)
1	5 - 7.5
2	5 - 7.5
3	5 - 7.5
4	5 - 7.5
6	10.8 - 15.6
7	—
8	—
9	—
10	10.8 - 15.6
11	—
12	—
13	5 - 7.5
14	5 - 7.5
15	5 - 7.5
16	5 - 7.5

System Description

Power is supplied at all times:

- from 25A fusible link (letter **f** , located in the fusible link and fuse box)
- to circuit breaker terminal ①
- through circuit breaker terminal ②
- to smart entrance control unit terminal ①.

Power is supplied at all times:

- from 7.5A fuse (No. 20 , located in the fuse block [HEC])
- to interior lamp terminal ①.

Power is supplied at all times:

- from 7.5A fuse (No. 24 , located in the fuse block [HEC])
- to key switch terminal ①.

Power is supplied at all times:

- from 10A fuse (No. 15 , located in the fuse block [HEC])
- to multi-remote control relay-1 terminal ①
- to multi-remote control relay-1 terminal ⑥
- to multi-remote control relay-1 terminal ③
- to multi-remote control relay-2 terminal ①.

With the ignition switch in the ACC or ON position, power is supplied:

- from 7.5A fuse (No. 10 , located in the fuse block [HEC])
- to smart entrance control unit terminal 17.

Terminal ⑩ of the smart entrance control unit is grounded through body grounds **M43** , **M44** and **M60** .

INPUTS

When the key switch is ON (ignition key is inserted in key cylinder), power is supplied:

- through key switch terminal ②
- to smart entrance control unit terminal 24.

When any door switch is OPEN, ground is supplied:

- to smart entrance control unit terminal ⑩
- through front door switch LH terminal ②, or
- through any other door switch terminal ①.

When the front door lock actuator LH (door unlock sensor) is UNLOCKED, ground is supplied:

- to smart entrance control unit terminal ⑫
- through front door lock actuator LH (door unlock sensor) terminal ④
- to front door lock actuator LH (door unlock sensor) terminal ②
- through body grounds **M43** , **M44** and **M60** .

When the front door lock actuator RH (door unlock sensor) is UNLOCKED, ground is supplied:

- to smart entrance control unit terminal ⑬
- through front door lock actuator RH (door unlock sensor) terminal ④
- to front door lock actuator RH (door unlock sensor) terminal ②
- through body grounds **M43** , **M44** and **M60** .

When either rear door lock actuator (door unlock sensor) is UNLOCKED, ground is supplied:

- to smart entrance control unit terminal ⑭
- through either rear door lock actuator (door unlock sensor) terminal ④
- to either rear door lock actuator (door unlock sensor) terminal ②
- through body grounds **B14** and **B17** .

Remote controller signal is input:

- through window antenna
- to smart entrance control unit terminal 37.

The multi-remote control system controls operation of the:

- power door lock
- interior lamp
- panic alarm
- hazard lamp
- ID code entry.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX

OPERATING PROCEDURE

Power door lock operation

When the following input signals are both supplied:

- key switch OFF (when ignition key is not inserted in key cylinder);
- door switches CLOSED (when all the doors are closed); smart entrance control unit locks all the doors with input of LOCK signal from remote controller. When key switch is OFF (when ignition key is not inserted in key cylinder), smart entrance control unit unlocks the doors with input of UNLOCK signal from remote controller.

Refer to "POWER DOOR LOCK" (EL-131) and "THEFT WARNING SYSTEM" (EL-193).

Interior lamp operation

When the following input signals are both supplied:

- key switch OFF (when ignition key is not inserted in key cylinder);
- door switches CLOSED (when all the doors are closed); multi-remote control system turns on interior lamp (for 30 seconds) with input of UNLOCK signal from remote controller. For detailed description, refer to "Interior and Trunk Room Lamps/System Description" (EL-74).

Panic alarm operation

When key switch is OFF (when ignition key is not inserted in key cylinder), the multi-remote control system turns on and off horn and headlamps intermittently with the input of a PANIC ALARM signal from the remote controller.

For detailed description, refer to "System Description", "THEFT WARNING SYSTEM" (EL-193).

Hazard lamp operation

When the following input signals are all supplied:

- key switch OFF (when ignition key is not inserted in key cylinder);
- door switches CLOSED (when all the doors are closed)
- door lock actuator (door unlock sensor) LOCKED (when all the doors are locked);

multi-remote control system outputs the following ground signals with input of LOCK signal from remote controller:

- to multi-remote control relay-1 terminal ②
- to multi-remote control relay-2 terminal ②
- through smart entrance control unit terminal ⑦.

As a result, multi-remote control relay-1 and multi-remote control relay-2 are energized and hazard warning lamps flash on and off.

For detailed description refer to "Turn Signal and Hazard Warning Lamps/System Description" (EL-63).

NOTES

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL




IDX

MULTI-REMOTE CONTROL SYSTEM

Wiring Diagram -MULTI-

EL-MULTI-01

FD : 4-Door models



Refer to last page (Foldout page).



M3

MULTI-REMOTE CONTROL SYSTEM

Wiring Diagram -MULTI- (Cont'd)

EL-MULTI-02


GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
DX





MULTI-REMOTE CONTROL SYSTEM

Wiring Diagram -MULTI- (Cont'd)

EL-MULTI-03





Refer to last page (Foldout page).
(M37)



MULTI-REMOTE CONTROL SYSTEM
Wiring Diagram -MULTI- (Cont'd)

EL-MULTI-04




Refer to last page (Foldout page).
(M16), (E101)
(M3)
(M37)

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

MULTI-REMOTE CONTROL SYSTEM

Schematic



MULTI-REMOTE CONTROL SYSTEM

Input/Output Operation Signal


SMART ENTRANCE CONTROL UNIT

Terminal No.	Connections	Operated condition	Voltage (V) (Approximate values)
1	Power source (C/B)	—	12V
2	Passenger and rear door lock actuators	Door lock & unlock switch	Unlocked 12V
3	Driver door lock actuator		Free 0V
4	All door lock actuators	Door lock & unlock switch	Locked 12V
			Free 0V
7	Multi-remote control relay -1, -2	When doors are locked using remote controller	12V → 0V
8	Theft warning relay	When panic alarm is operated using remote controller	12V → 0V
9	Interior lamp	When interior lamp is operated using remote controller. (Lamp switch in "DOOR" position)	12V → 0V
10	Ground	—	—
11	Ignition switch (ON)	"ON" position	12V
12	Driver door unlock sensor	Driver door: Locked → Unlocked	12V → 0V
13	Passenger door unlock sensor	Passenger door: Locked → Unlocked	12V → 0V
14	Rear door unlock sensors	Either rear door: Locked → Unlocked	12V → 0V
15	Driver door switch	OFF (Closed) → ON (Open)	12V → 0V
16	All door switches	OFF (Closed) → ON (Open)	12V → 0V
17	Ignition switch (ACC)	"ACC" position	12V
18	Door lock & unlock switches	Neutral → Locks	12V → 0V
19	Door lock & unlock switches	Neutral → Unlocks	12V → 0V
20	Rear window defogger switch	OFF → ON	12V → 0V
21	Seat belt switch	Unfasten → Fasten	0V → 12V
23	Warning chime	OFF → ON	12V → 0V
24	Ignition key switch (Insert)	IGN key inserted → IGN key removed from IGN key cylinder	12V → 0V
25	Headlamp switch (1ST)	1ST, 2ND positions: ON → OFF	12V → 0V
26	Trunk switch	ON (Open) → OFF (Closed)	0V → 12V
27	Trunk key unlock switch	OFF (Neutral) → ON (Unlocked)	12V → 0V
28	Door key cylinders tamper switch	OFF → ON	12V → 0V
29	Hood open signal	ON (Open) → OFF (Closed)	0V → 12V
30	Door key cylinder lock switch	OFF (Neutral) → ON (Locked)	12V → 0V
31	Door key cylinder lock switch	OFF (Neutral) → ON (Unlocked)	12V → 0V
32	Theft warning relay (Starter cut)	OFF → ON	12V → 0V
33	Theft warning indicator	Goes off → Illuminates	12V → 0V
36	Rear defogger relay	OFF → ON	12V → 0V
37	Multi-remote antenna	—	—


Trouble Diagnoses

TROUBLE SYMPTOM

- All functions of remote control system do not operate.



- Some functions of multi-remote controller do not operate.




Note: The multi-remote control system does not activate with the ignition key inserted in the ignition key cylinder.

MULTI-REMOTE CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1

Check remote controller battery.



A

CHECK REMOTE CONTROLLER BATTERY.

Remove battery and measure voltage across battery positive and negative terminals $\oplus$ and $\ominus$.

Measuring terminal		Standard value
$\oplus$	$\ominus$	
Battery positive terminal $\oplus$	Battery negative terminal $\ominus$	3V or more

Note:

Remote controller does not function if battery is not set correctly.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST


RS

BT

HA

EL

IDX



DIAGNOSTIC PROCEDURE 2

All remote controls do not function even if remote controller is operated properly.

A

CHECK MAIN POWER SUPPLY AND GROUND CIRCUIT.

1. Remove key from ignition.
 2. Disconnect connector from control unit.
- Check voltage across control unit terminal ① and GND.
- Battery voltage should exist.**

NG

Check power supply harness.

OK

B

CHECK GROUND CONTINUITY.

Check continuity between terminal ⑩ and GND.

Continuity should exist.

NG

Check GND harness.

OK

C

CHECK ANTENNA CIRCUIT.

Disconnect 1-pin connector from control unit.

Check continuity between terminal on 1-pin harness connector and filament on the rear window.

Continuity should exist.



NG

Check antenna circuit. (Refer to "Filament Repair", "REAR WINDOW DEFOGGER", EL-149.)

OK









A

(Go to next page.)



MULTI-REMOTE CONTROL SYSTEM

Trouble Diagnoses (Cont'd)







MULTI-REMOTE CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 3

Hazard indicator does not flash twice when pressing lock button of remote controller. Everything else functions.




MULTI-REMOTE CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4

Interior lamp does not turn on for 30 seconds when pressing unlock button of remote controller. Everything else functions.



A

CHECK INTERIOR LAMP CIRCUIT.

When interior lamp switch is in "DOOR" position, check voltage across control unit terminal ⑨ and GND.

Does battery voltage exist?

No

Repair harness between control unit connector and interior lamp connector.

Yes

CHECK VOLTAGE.

Push unlock button of remote controller and check voltage across control unit terminal ⑨ and GND.

Is voltage approx. 0V?

No

Replace smart entrance control unit.

Yes

Check system again.

Replacing Remote Controller or Control Unit

If the remote controller or the control unit needs to be replaced or if an additional remote controller needs to be set, enter the identity (ID) code manually.

ID Code Entry Procedure

To enter the ID code, follow this procedure:

“Setting mode”:

Three steps must be followed to establish the “setting mode”.

1. Close and lock all doors.
2. Insert and remove the key from the ignition more than six times within 10 seconds. (The hazard warning lamp will then flash twice.)
- **At this time, the original ID codes are eliminated.**
3. Turn ignition key to “ACC” position.

ID code entry:

4. Push the lock button on the new remote controller once.
- **At this time, the new ID code is entered. (The hazard warning lamp will then flash twice.)**
5. To enter additional remote controllers (including the original) unlock, then lock, the driver's door with the door lock/unlock switch LH (in main power window switch).
6. Push lock button on the new additional remote controller once.
7. This ID code entry enable state and setting mode remains until the driver's door is opened.

NOTE

- If the same ID code already exists in memory, the entry is canceled, and no ID code will be entered.
- Entry of maximum four ID codes is allowed and any attempt to enter more will be ignored.
- Any ID codes entered after termination of the “setting” mode will not be accepted. Additionally, remote control signals will be inhibited when an ID code has not been entered during “setting” mode.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX

System Description*

Refer to Owner's Manual for ASCD operating instructions.

When the ignition switch is in the ON or START position, power is supplied:

- through 7.5A fuse (No. 7), located in the fuse block [HEC]
- to ASCD main switch terminal ① and
- to ASCD hold relay terminal ⑤.

When ASCD main switch is in the ON position, power is supplied:

- from terminal ② of the ASCD main switch
- to ASCD control unit terminal ④ and
- from terminal ③ of the ASCD main switch
- to ASCD hold relay terminal ①.

Ground is supplied:

- to ASCD hold relay terminal ②
- through body grounds M43, M44 and M60.

With power and ground supplied, the ASCD hold relay is activated, and power is supplied:

- from terminal ③ of the ASCD hold relay
- to ASCD control unit terminal ④ and
- to ASCD clutch pedal position switch terminal ① (M/T models) or
- to inhibitor relay terminal ③ (A/T models).

Power remains supplied to ASCD control unit terminal ④ when the ASCD main switch is released to the N (neutral) position.

Ground is supplied:

- to ASCD control unit terminal ③
- through body grounds M43, M44 and M60.

Inputs

At this point, the system is ready to activate or deactivate, based on inputs from the following:

- speedometer in the combination meter
- stop lamp switch
- ASCD steering switch
- inhibitor relay (A/T models)
- ASCD clutch pedal position switch (M/T models)
- ASCD cancel switch.

A vehicle speed input is supplied:

- to ASCD control unit terminal ⑦
- from terminal ②③ (21) of the combination meter.

Power is supplied at all times:

- through 15A fuse (No. 14), located in the fuse block [HEC]
- to stop lamp switch terminal ①.

When the brake pedal is depressed, power is supplied:

- from terminal ② of the stop lamp switch
- to ASCD control unit terminal ⑪.

Power is supplied at all times:

- through 10A fuse (No. 42), located in the fusible link and fuse box)
- to horn relay terminal ②
- through terminal ① of the horn relay
- to ASCD steering switch terminal ⑫.

When the SET/COAST button is depressed, power is supplied:

- from terminal ⑭ of the ASCD steering switch
- to ASCD control unit terminal ②.

When the RESUME/ACCEL button is depressed, power is supplied:

- from terminal ⑬ of the ASCD steering switch
- to ASCD control unit terminal ①.

When the CANCEL button is depressed, power is supplied:

- to ASCD control unit terminals ① and ②.

When the system is activated, power is supplied:

- to ASCD control unit terminal ⑤.

*: Terminal numbers in () are for models without tachometer.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

System Description* (Cont'd)

Power is interrupted when:

- the shift lever is placed in "P" or "N" (A/T models)
- the clutch pedal is depressed (M/T models) or
- the brake pedal is depressed.

Outputs

The ASCD actuator controls the throttle drum via the ASCD wire based on inputs from the ASCD control unit. The ASCD actuator consists of a vacuum motor, an air valve, and a release valve.

Power is supplied:

- from terminal ⑧ of the ASCD control unit
- to ASCD actuator terminal ①.

Ground is supplied to the vacuum motor:

- from terminal ⑨ of the ASCD control unit
- to ASCD actuator terminal ④.

Ground is supplied to the air valve:

- from terminal ⑩ of the ASCD control unit
- to ASCD actuator terminal ②.

Ground is supplied to the release valve:

- from terminal ⑭ of the ASCD control unit
- to ASCD actuator terminal ③.

When the system is activated, power is supplied:

- from terminal ⑬ of the ASCD control unit
- to combination meter terminal ②⑤ (②⑥) and
- to A/T control unit terminal ③⑦ (A/T models with SR engine).

Ground is supplied:

- to combination meter terminal ②⑦ (②⑧)
- through body grounds M43, M44 and M60.

With power and ground supplied, the CRUISE indicator illuminates.

When the RESUME/ACCEL button is depressed, a signal is sent:

- from terminal ⑫ of the ASCD control unit
- to A/T control unit terminal ④⑩ (A/T models with SR engine), or.
- to A/T control valve terminal ② (A/T models with GA engine).

When this occurs, overdrive is cancelled.

*: Terminal numbers in () are for models without tachometer.

GI

MA

EW

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT



HA

EL

IDX


AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Component Parts and Harness Connector Location



AUTOMATIC SPEED CONTROL DEVICE (ASCD)


Schematic



AUTOMATIC SPEED CONTROL DEVICE (ASCD)


Wiring Diagram -ASCD-

EL-ASCD-01



Refer to last page (Foldout page).


(M3)



AUTOMATIC SPEED CONTROL DEVICE (ASCD)


Wiring Diagram -ASCD- (Cont'd)

EL-ASCD-02



Refer to last page (Foldout page).



(M16) , (E101)



AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram -ASCD- (Cont'd)




EL-ASCD-03



AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram -ASCD- (Cont'd)

EL-ASCD-04



Refer to last page (Foldout page).

(M16), (E101)
(M3)


EL

IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)


Wiring Diagram -ASCD- (Cont'd)

EL-ASCD-05



Refer to last page (Foldout page).

(M16) , (E101)





AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram -ASCD- (Cont'd)

MODELS WITH TACHOMETER

EL-ASCD-06



Refer to last page (Foldout page).

M16, E101
M3
M8

EL

IDX





AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram -ASCD- (Cont'd)

MODELS WITHOUT TACHOMETER

EL-ASCD-07

(A) : A/T models



Refer to last page (Foldout page).

(M16), (E101)
(M3)

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses

SYMPTOM CHART

PROCEDURE	Diagnostic Procedure								—	Electrical Components Inspection						
REFERENCE PAGE	EL-182	EL-184	EL-184	EL-184	EL-185	EL-186	EL-187	EL-188	EL-189	EL-190	EL-191	EL-191	EL-191	EL-191	EL-191	EL-192
SYMPTOM	Diagnostic Procedure 1	Diagnostic Procedure 2	Diagnostic Procedure 3	Diagnostic Procedure 4	Diagnostic Procedure 5	Diagnostic Procedure 6	Diagnostic Procedure 7	Diagnostic Procedure 8	ASCD Wire Adjustment	ASCD actuator/ASCD pump	ASCD main switch	ASCD steering switch	ASCD cancel switch and stop lamp switch	Clutch pedal position switch (M/T models)	Inhibitor switch (A/T models)	Vehicle speed sensor
ASCD control unit cannot be set properly.	○									○	○	○	○	○	○	○
Engine hunts.		○							○	○						
Large difference between set speed and actual vehicle speed.			○						○	○						
Deceleration is greatest immediately after ASCD has been set.				○					○	○						
ACCEL switch will not operate.	○				○							○				
RESUME switch will not operate.	○					○						○	○	○		
Set speed cannot be cancelled.							○		○	○			○	○		
"CRUISE" indicator lamp blinks.								○		○		○	○			

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL




IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1

SYMPTOM: ASCD control cannot be set.



Turn ASCD main switch "OFF" and "ON" to make sure indicator illuminates.

NG

A **CHECK POWER SUPPLY FOR ASCD MAIN SWITCH.**

1. Disconnect switch harness connector.
2. Does approx. 12 volts exist between switch harness terminal ① and body ground?

No

Check fuse and harness.

Yes

Check ASCD main switch. Refer to EL-191. Check ASCD hold relay.

B **CHECK POWER SUPPLY CIRCUIT FOR ASCD CONTROL UNIT.**

1. Turn ASCD main switch "ON".
 2. Check voltage between ASCD control unit harness terminals ④ and ③.
- Battery positive voltage should exist.

NG

Check continuity between ASCD control unit harness terminal ④ and ASCD hold relay terminal ③.

OK

C **CHECK CUT-OFF CIRCUIT FOR ASCD CONTROL UNIT.**

Check voltage between ASCD control unit harness terminals ⑤ and ③. Battery positive voltage should exist.

NG

Check ASCD cancel switch, ASCD clutch pedal position switch (M/T models) and inhibitor switch (A/T models). Refer to EL-191. Check inhibitor relay (A/T models).





OK

Ⓐ

(Go to next page)

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)




AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)


DIAGNOSTIC PROCEDURE 2

SYMPTOM: Engine hunts.




DIAGNOSTIC PROCEDURE 3

SYMPTOM: Large difference between set vehicle speed and actual speed.



DIAGNOSTIC PROCEDURE 4

SYMPTOM: Deceleration is greatest immediately after ASCD has been set.






AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 5

SYMPTOM: ACCEL switch will not operate.



Check constant-speed function for operating using SET/COAST switch.

NG

Perform "DIAGNOSTIC PROCEDURE 1". Refer to EL-182.

OK

A

CHECK ACCEL SIGNAL.

Check voltage between ASCD control unit harness terminals ① and ③ after turning on and holding RESUME/ACCEL switch.

Battery positive voltage should exist.

NG

Check ASCD steering switch. Refer to EL-191.

OK

B

Check voltage between ASCD control unit harness terminals ① and ③ after releasing RESUME/ACCEL switch.

Voltage is 0V.

NG

Check ASCD steering switch. Refer to EL-191.

OK

C

CHECK IF ACCEL IS NOW FUNCTIONING.

Does vehicle accelerate when RESUME/ACCEL switch is turned on?

No

Replace ASCD control unit.

Yes

Does vehicle maintain the new (faster) speed when RESUME/ACCEL switch is released?

No

Replace ASCD control unit.

Yes

System is OK.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL


IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 6

SYMPTOM: RESUME switch will not operate.




Check constant-speed function for operation using SET/COAST switch.

NG

Perform "DIAGNOSTIC PROCEDURE 1". Refer to EL-182.

OK



CHECK RESUME SIGNAL.

Check voltage between ASCD control unit harness terminals ① and ③ after turning on and holding RESUME/ACCEL switch.

Battery positive voltage should exist.

NG

Check ASCD steering switch. Refer to EL-191.

OK

B


Check voltage between ASCD control unit harness terminals ① and ③ after releasing RESUME/ACCEL switch.

Voltage is 0V.

NG

Check ASCD steering switch. Refer to EL-191.

OK



CHECK IF RESUME IS NOW FUNCTIONING.

Set vehicle speed at 80 km/h (50 MPH) by turning on SET/COAST switch.

OK

D

While cruising at set speed, depress and release brake pedal.

OK

Does speed control disengage and "CRUISE" lamp turn off?

No

Check stop lamp switch, ASCD cancel switch and ASCD clutch pedal position switch (M/T models). Refer to EL-191.

Yes

E

Above 48 km/h (30 MPH), press and release RESUME/ACCEL switch.

OK



Does vehicle return to previously set speed [80 km/h (50 MPH)]?

No

Replace ASCD control unit.

Yes

System is OK.




AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 7

SYMPTOM: Set speed cannot be cancelled.



A


CHECK ASCD CANCEL, CLUTCH PEDAL POSITION, INHIBITOR SWITCH CIRCUIT.

1. Turn ASCD main switch on.
2. Check voltage between ASCD control unit harness terminals (5) and (3).

NG → Check ASCD cancel, clutch pedal position, and inhibitor switch. Refer to EL-191.

Conditions			Voltage [V]
	ASCD cancel switch	Depressed	0
		Released	Approx. 12
M/T	ASCD clutch pedal position switch	Depressed	0
		Released	Approx. 12
A/T	A/T shift lever position is at any position except N or P.		Approx. 12
	A/T shift lever position is at N or P.		0

OK



B

CHECK STOP LAMP SWITCH CIRCUIT.

Check voltage between ASCD control unit harness terminals (11) and (3).

NG → Check stop lamp switch. Refer to EL-191.

Condition		Voltage [V]
Stop lamp switch	Depressed	Approx. 12
	Released	0

OK

Check ASCD wire moves smoothly.

NG → Replace ASCD wire.

OK

Check ASCD actuator/ASCD pump. Refer to EL-190.

NG → Replace ASCD actuator assembly.

OK



Replace ASCD control unit.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)


DIAGNOSTIC PROCEDURE 8

SYMPTOM: "CRUISE" indicator lamp blinks.



AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd) ASCD WIRE ADJUSTMENT



CAUTION:

- Be careful not to twist ASCD wire when removing it.
- Do not overly tighten ASCD wire during adjustment.

Confirm that accelerator wire is properly adjusted.

- For accelerator cable adjustment, refer to FE section ("Adjusting Accelerator Cable", "ACCELERATOR CONTROL SYSTEM").

Adjust the ASCD wire as follows:

1. Loosen lock nut and tighten adjusting nut until throttle drum starts to move.
 2. From that position turn back adjusting nut 0.5 to 1 turn, and secure lock nut.
(This prevents a delay in the operation of the ASCD.)
- For ASCD cancel switch adjustment, refer to BR and CL sections ("Adjustment", "BRAKE PEDAL AND BRACKET" and "Adjusting Clutch Pedal", "INSPECTION AND ADJUSTMENT", respectively).


AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

ELECTRICAL COMPONENTS INSPECTION

ASCD actuator/ASCD pump

1. Disconnect ASCD actuator/ASCD pump connector.
2. Check ASCD actuator/ASCD pump operations as shown.




A

CHECK ASCD PUMP MOTOR.
Does motor start when 12V D.C. is applied across ① and ④?

NO

Replace ASCD actuator assembly.

YES



B

CHECK ASCD ACTUATOR OPERATION.
Is ASCD wire pulled when 12V D.C. is applied across ①, ②, ③ and ④?

NO

Replace ASCD actuator assembly.

YES (Wire is pulled.)

C

CHECK ASCD ACTUATOR OPERATION.
Does ASCD wire returns to original position 50 to 60 seconds after disconnecting lead from ④?

NO

Replace ASCD actuator assembly.

YES (Wire does not return.)

D


CHECK ASCD ACTUATOR OPERATION.
Disconnect lead from ① to see if ASCD wire returns immediately.

NG

Replace ASCD actuator assembly.

OK (Wire returns.)

ASCD actuator/ASCD pump are OK.




AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

ASCD main switch


Check continuity between terminals by pushing switch to each position.



Switch position	Terminal					
	1	2	3	4	5	6
ON	○	○	○	○		
N		○	○	○	ILL. ○	
OFF						


ASCD steering switch

Check continuity between terminals by pushing each button.



Button	Terminal		
	3	5	4
SET/COAST	○	○	
RESUME/ACCEL	○		○
CANCEL	○	▶	
	○	▶	○


ASCD cancel switch and stop lamp switch



Condition	Continuity	
	ASCD cancel switch	Stop lamp switch
When brake pedal is depressed	No	Yes
When brake pedal is released	Yes	No

Check each switch after adjusting brake pedal — refer to BR section ("Adjustment", "BRAKE PEDAL AND BRACKET").


ASCD clutch pedal position switch (For M/T models)



Condition	Continuity
When clutch pedal is depressed	No
When clutch pedal is released	Yes

Check switch after adjusting clutch pedal — refer to CL section ("Adjusting Clutch Pedal", "INSPECTION AND ADJUSTMENT").

Inhibitor switch (For A/T models)




Shift lever position	Terminal	
	1	2
"P"	○	○
"N"	○	○
Except "N" or "P"		

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

Vehicle speed sensor


- 1 Remove vehicle speed sensor from transaxle.
- 2 Turn vehicle speed sensor pinion quickly and measure voltage across terminals ② and ①.



THEFT WARNING SYSTEM

System Description

1. Operation flow



2. Setting the theft warning system

Initial condition

- (1) Close all doors.
- (2) Close hood and trunk lid.
- (3) Pull key out of ignition.

Disarmed phase

The theft warning system is in the disarmed phase when any door(s), hood or trunk lid is open and the ignition key is not in the "ACC" or "ON" position. The security indicator lamp blinks every 0.5 second. When the ignition key is turned to the "ACC" or "ON" position, the security indicator lamp turns off.

Pre-armed phase and armed phase

The theft warning system turns into the "pre-armed" phase when hood, trunk lid and all doors are closed and locked by key or multi-remote controller. (The security indicator lamp illuminates.)

After about 30 seconds, the system automatically shifts into the "armed" phase (the system is set). (The security indicator lamp blinks every 2.4 seconds.)

3. Canceling the set theft warning system

When the following (a) or (b) operation is performed, the armed phase is canceled.

- (a) Unlock the doors or the trunk lid with the key.
- (b) Unlock the doors or the trunk lid with the multi-remote controller.

4. Activating the alarm operation of the theft warning system

Make sure the system is in the armed phase. (The security indicator lamp blinks every 2.4 seconds.)

When any of the following operations (a), (b) and (c) is performed, the system sounds the horns and flashes the headlamps for about 2.5 minutes. After 2.5 minutes the security indicator lamp will turn off. (At the same time, the system disconnects the starting system circuit.)

The starting system is kept dead even after the alarm turns off.

- (a) Engine hood is opened without using the hood opener.
- (b) Door is unlocked or trunk lid is opened without using key or multi-remote controller.
- (c) Key cylinder is pulled out from either front door or the trunk lid.

THEFT WARNING SYSTEM

System Description (Cont'd)

Refer to Owner's Manual for theft warning system operating instructions.

Power is supplied at all times:

- through 30A fusible link (letter **f**), located in the fusible link and fuse box)
- to ignition switch terminal ①.

With the ignition switch in the ON or START position, power is supplied:

- through 10A fuse (No. **21**, located in the fuse block [HEC])
- to theft warning relay terminals ① and ③ (A/T models)
- to theft warning relay terminal ① (M/T models for U.S.A. and Canada).

With the ignition switch in the START position, power is supplied:

- from terminal ⑤ of the ignition switch
- to clutch interlock relay terminal ③ (M/T models for U.S.A.) or
- to theft warning relay terminal ③ (M/T models for Canada)
- to inhibitor relay terminal ⑥ (A/T models).

With the ignition switch in the START position, power is supplied:

- through 7.5A fuse (No. **26**, located in the fuse block [HEC])
- to theft warning relay terminal ③ (M/T models for U.S.A.).

Power is supplied at all times:

- through 7.5A fuse (No. **43**, located in the fusible link and fuse box)
- to horn relay-2 terminals ① and ③.

Power is supplied at all times:

- through 25A fusible link (letter **f**), located in the fusible link and fuse box)
- to circuit breaker terminal ①
- through circuit breaker terminal ②
- to smart entrance control unit terminal ①.

Power is supplied at all times:

- through 15A fuses (No. **39** and **40**, located in the fusible link and fuse box)
- to theft warning lamp relay terminals ③ and ⑥.

Power is supplied at all times:

- through 10A fuse (No. **42**, located in the fusible link and fuse box)
- to horn relay terminal ②.

Power is supplied at all times:

- through 7.5A fuse (No. **24**, located in the fuse block [HEC])
- to security indicator lamp terminal ③⑦
- to key switch terminal ①.

With the ignition switch in the ON or START position, power is supplied:

- through 7.5A fuse (No. **7**, located in the fuse block [HEC])
- to smart entrance control unit terminal ⑪.

With the ignition switch in the ACC or ON position, power is supplied:

- through 15A fuse (No. **10**, located in the fuse block [HEC])
- to smart entrance control unit terminal ⑰.

Ground is supplied:

- to smart entrance control unit terminal ⑩
- through body grounds **(M43)**, **(M44)** and **(M60)**.

THEFT WARNING SYSTEM ACTIVATION (Without key or remote controller used to lock doors)

The operation of the theft warning system is controlled by the doors, hood and trunk lid.

To activate the theft warning system, the ignition key must be removed, doors, hood and trunk closed, and the doors locked.

When a door is open, smart entrance control unit terminal ⑰ receives a ground signal from door switches.

When a door is unlocked, smart entrance control unit terminal ⑫, ⑬ or ⑭ receives a ground signal:

- from terminal ④ of all the door unlock sensors
- through body grounds **(M43)**, **(M44)** and **(M60)**.

When the hood is open, smart entrance control unit terminal ②⑨ receives a ground signal:

- from terminal ① of the hood switch
- through body grounds **(E13)** and **(E25)**.

When the trunk lid is open, smart entrance control unit terminal ②⑥ receives a ground signal:

- from terminal ① of the trunk room lamp switch

THEFT WARNING SYSTEM

System Description (Cont'd)

- through body grounds (T9) and (T10).

If none of the described conditions exist, the theft warning system will activate automatically.

THEFT WARNING SYSTEM ACTIVATION (With key or remote controller used to lock doors)

If the key or remote controller is used to lock doors, terminal (30) receives a ground signal:

- from terminal (1) of the door key cylinder switch LH
- from terminal (2) of the door key cylinder switch RH
- through body grounds (M43), (M44) and (M60).

If this signal is received by the smart entrance control unit, the theft warning system will activate automatically.

With the theft warning system activated, smart entrance control unit terminal (33) supplies ground to the security indicator lamp.

THEFT WARNING SYSTEM OPERATION

The theft warning system is triggered by:

- opening a door or the trunk lid without using the key
- opening the hood
- tampering with the key cylinder in the door.

Once the theft warning system has been activated, it will be triggered if the smart entrance control unit receives a ground signal at terminal (15), (16), (26) or (29). Also, when a door key tamper signal is received at the smart entrance control unit, the system will be triggered. The headlamps flash and the horn sounds intermittently, and the starting system is interrupted.

When a door key cylinder switch has been tampered with, smart entrance control unit terminal (28) receives a ground signal:

- from terminal (3) of the front LH or RH key cylinder switch
- through body grounds (M43), (M44) and (M60).

If the theft warning system is triggered, ground is supplied:

- from terminal (32) of the smart entrance control unit
- to theft warning relay terminal (2).

With power and ground supplied, power to the clutch interlock relay (M/T models for U.S.A.), inhibitor relay (A/T models) or starter motor (M/T models for Canada) is interrupted. The starter motor will not crank and the engine will not start.

When the theft warning system is triggered, ground is supplied intermittently:

- from terminal (8) of the smart entrance control unit
- to theft warning lamp relay terminal (2) and
- to horn relay-2 terminal (2).

The headlamps flash and the horn sounds intermittently.

The alarm automatically turns off after 2 or 3 minutes but will reactivate if the vehicle is tampered with again.

THEFT WARNING SYSTEM DEACTIVATION

To deactivate the theft warning system, a door or the trunk lid must be unlocked with the key or remote controller.

When the key is used to unlock a door, smart entrance control unit terminal (31) receives a ground signal:

- from terminal (2) of the LH key cylinder switch
- from terminal (1) of the RH key cylinder switch.

When the key is used to unlock the trunk lid, smart entrance control unit terminal (27) receives a ground signal from terminal (1) of the trunk key cylinder switch.

When the smart entrance control unit receives either one of these signals, the theft warning system is deactivated.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX

THEFT WARNING SYSTEM

System Description (Cont'd)

PANIC ALARM OPERATION

Multi-remote control system may or may not operate theft warning system (horn and headlamps) as required.







When the multi-remote control system is triggered, ground is supplied intermittently:

- from smart entrance control unit terminal ⑧
- to theft warning lamp relay terminal ② and
- to horn relay-2 terminal ②.

The headlamp flashes and the horn sounds intermittently:


The alarm automatically turns off after 30 seconds or when smart entrance control unit receives any signal from multi-remote controller.

Component Parts and Harness Connector Location



THEFT WARNING SYSTEM


Schematic



AEL597

THEFT WARNING SYSTEM


Wiring Diagram -THEFT-



THEFT WARNING SYSTEM

Wiring Diagram -THEFT- (Cont'd)

EL-THEFT-02



Refer to last page (Foldout page).


(M37)

THEFT WARNING SYSTEM



Wiring Diagram -THEFT- (Cont'd)

EL-THEFT-03

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX





Refer to last page (Foldout page).
(M37)



Wiring Diagram -THEFT- (Cont'd)

EL-THEFT-04



Refer to last page (Foldout page).



(M16), (E101)



THEFT WARNING SYSTEM


Wiring Diagram -THEFT- (Cont'd)

EL-THEFT-05






Wiring Diagram –THEFT– (Cont'd)

EL-THEFT-06



Refer to last page (Foldout page).

(M16), (E101)





THEFT WARNING SYSTEM

Wiring Diagram -THEFT- (Cont'd)

A/T MODELS

EL-THEFT-07




Refer to last page (Foldout page).

(M16, E101)
(M37)

THEFT WARNING SYSTEM


Wiring Diagram -THEFT- (Cont'd)

M/T MODELS



Refer to last page (Foldout page).

(M16) (E101)
(M37)




Trouble Diagnoses

SYSTEM OPERATION CHECK

The system operation is canceled by turning ignition switch to "ACC" at any step in the following:


- A step between START and ARMED, or
- In the ARMED phase

in the following flow chart.




THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)



THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)



CI
 MA
 EM
 LC
 EC
 FE
 CL
 WT
 AT
 FA
 RA
 BR
 ST
 RS
 ET
 HA
 EL
 IDX


THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

POWER SUPPLY AND GROUND CIRCUIT CHECK


Main power supply circuit check

Terminals	Ignition switch position		
	OFF	ACC	ON
① - ⑩	Battery voltage	Battery voltage	Battery voltage




Power supply circuit check for system cancel

Terminals	Ignition switch position		
	OFF	ACC	ON
⑩ - ⑩	0V	Battery voltage	Battery voltage



Ground circuit check

Terminals	Continuity
⑩ - Ground	Yes



THEFT WARNING SYSTEM




Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1

SYMPTOM:

- Indicator lamp does not blink or
- Indicator lamp remains blinking every second.

Diagnostic procedure 1-(1)



A

DOOR SWITCH INPUT SIGNAL CHECK.
Check continuity between control unit harness terminals (16) and (10).

Condition	Continuity between (16) and (10)
LH door is closed.	No
LH door is opened.	Yes

Condition	Continuity between (16) and (10)
RH door is closed.	No
RH door is opened.	Yes

Condition	Continuity between (16) and (10)
Rear LH, RH door is closed.	No
Rear LH, RH door is opened.	Yes

Door switch check.
Refer to "Electrical Components Inspection" (EL-223).

B

DOOR SWITCH CIRCUIT CHECK.
• Check harness continuity between control unit harness terminal (16) and door switch harness terminal.
Continuity should exist.

C

CHECK CONTINUITY.
Check harness continuity between door switch harness terminal and body ground. (Before checking harness continuity, control unit harness connector should be disconnected.)
Continuity should not exist.

Check the connections at each connector.

OK → Go to Diagnostic Procedure 2 (EL-215).

NG → Replace door switch.



NG → Repair harness or connectors.

NG → Repair harness. (Short circuit exists between control unit harness terminal (16) and door switch harness terminals.)

THEFT WARNING SYSTEM


Trouble Diagnoses (Cont'd)

Diagnostic procedure 1-(2)



OK → Go to Diagnostic Procedure 2 (EL-215).



NG



NG → Adjust installation of hood switch or hood.



NG → Replace hood switch.

OK



NG → Repair harness or connectors.

OK





NG → Repair harness.
(Short circuit exists between control unit harness terminal ②⑨ and hood switch harness terminal ①.)



THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)


Diagnostic procedure 1-(3)





OK → Go to Diagnostic Procedure 2 (EL-215).



NG → Replace trunk room lamp switch.



NG → Repair harness or connectors.



NG → Repair harness. (Short circuit exists between control unit harness terminal (26) and trunk room lamp switch harness terminal (1).)

Check the connections at each connector.

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA




EL

IDX

THEFT WARNING SYSTEM







Trouble Diagnoses (Cont'd)

Diagnostic procedure 1-(4)




THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)



DIAGNOSTIC PROCEDURE 2

SYMPTOM: • Indicator lamp does not blink or
• Indicator lamp remains "ON".






THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 3

SYMPTOM: Indicator lamp does not come on.



A DOOR UNLOCK SENSOR INPUT SIGNAL CHECK.

Check continuity between control unit harness terminals (12) or (13) or (14) and (10).

Condition	Continuity between (12) and (10)
LH door is locked.	No
LH door is unlocked.	Yes

Condition	Continuity between (13) and (10)
RH door is locked.	No
RH door is unlocked.	Yes

Condition	Continuity between (14) and (10)
LH, RH door is locked.	No
LH, RH door is unlocked.	Yes

OK → Go to Diagnostic Procedure 2 (EL-215).

OK

Replace control unit.

NG

Door unlock sensor check. Refer to "Electrical Components Inspection" (EL-224).

NG → Replace door lock actuator.

OK

B DOOR UNLOCK SENSOR CIRCUIT CHECK.

- Check harness continuity between control unit harness terminal (12), (13) or (14) and door actuator terminal (4).
 - Check harness continuity between door lock actuator harness terminal (2) and body ground.
- Continuity should exist.**

NG → Repair harness or connectors.

OK

C CHECK CONTINUITY.

Check harness continuity between door lock actuator harness terminal (4) and body ground. (Before checking harness continuity, control unit harness connector should be disconnected.)

Continuity should not exist.

NG → Repair harness. (Short circuit exists between control unit harness terminal (12), (13) or (14) and door lock actuator harness terminal (4).)

OK





Check the connections at each connector.

THEFT WARNING SYSTEM


Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4

SYMPTOM: Indicator lamp does not come on.



SYMPTOM: Alarm does not operate.



A
(Go to next page)



Replace horns.

NG

Replace control unit.

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)




CI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
DX

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 6

SYMPTOM: • **STARTER MOTOR** can be operated. (Starter killed phase) or
• **STARTER MOTOR** cannot be operated after the theft warning system is deactivated.



A

STARTER MOTOR KILL OUTPUT SIGNAL CHECK.

Check voltage between control unit harness terminals (32) and (10).

Condition	Voltage
Except starter killed phase	Approx. 12V
Starter killed phase	0V

NG

Check the following.

- Harness continuity between control unit harness terminal (32) and theft warning relay harness terminal (2).
- Harness continuity between theft warning relay harness terminal (1) and fuse.
- Theft warning relay. Refer to "Electrical Components Inspection" (EL-225).

OK

Replace control unit.

OK

Theft warning relay check.
Refer to "Electrical Components Inspection" (EL-225).

OK

NG

Replace relay.


Check the connections at each connector.

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 7

SYMPTOM: Alarm does not stop even if stop signal is given.



A

DOOR KEY CYLINDER SWITCH INPUT SIGNAL CHECK (UNLOCK SIGNAL).
Check continuity between control unit harness terminals (31) and (10).

Key position	Continuity
Neutral/Unlock	No
Between Neutral and Unlock	Yes

NG

Door key cylinder switch check.
Refer to "Electrical Components Inspection" (EL-224).

NG

OK — Alarm output signal check
Go to Diagnostic Procedure 5. (EL-218).

B

DOOR KEY CYLINDER SWITCH CIRCUIT CHECK.

- Check harness continuity between control unit harness terminal (31) and door key cylinder switch terminal (1) or (2).
- Check harness continuity between door key cylinder switch terminal (4) and body ground.

Continuity should exist.

OK

C

CHECK CONTINUITY.

Check harness continuity between door key cylinder switch terminals (1) or (2) and body ground.
(Before checking harness continuity, control unit harness connector should be disconnected.)



Continuity should not exist.

OK

Check the connections at each connector.

NG

Repair harness.
(Short circuit exists between control unit harness terminal (31) and door key cylinder switch terminal (1) or (2).)







THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 8

SYMPTOM: Alarm does not stop even if stop signal is given.



THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

ELECTRICAL COMPONENTS INSPECTION

Door switches

Check continuity between terminals when door switch is pushed and released.

Terminal No.	Condition	Continuity
RH: ① - body ground	Door switch is pushed.	No
LH: ② - body ground	Door switch is pushed.	No
Rear RH, LH: ① - body ground	Door switch is released.	Yes

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST


RS

BT


HA

EL

IDX



AEL771




AEL772

Hood switch

Check continuity between terminals when hood switch is pushed and released.

Terminal No.	Condition	Continuity
① - ②	Hood switch is pushed.	No
① - ②	Hood switch is released.	Yes



AEL773

Trunk room lamp switch

Check continuity between terminals when trunk lid is closed and opened.

Terminal No.	Condition	Continuity
① - ②	Trunk lid is closed.	No
① - ②	Trunk lid is opened.	Yes


THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

Key cylinder tamper switch, door lock switch and door unlock switch


• Door key cylinder switch

	Terminal No.	Condition	Continuity
Tamper switch	③ - ④	Key cylinder is installed.	No
		Key cylinder is removed.	Yes
Door lock switch	RH: ② - ④ LH: ① - ④	Key position is neutral or lock.	No
		Key position is between neutral and lock.	Yes
Door unlock switch	RH: ① - ④ LH: ② - ④	Key position is neutral or unlock.	No
		Key position is between neutral and unlock.	Yes




• Trunk lid key cylinder switch (unlock switch)

Terminal No.	Condition	Continuity
① - ③	Key position is neutral.	No
	Key position is unlock.	Yes




• Door lock actuator (Door unlock sensor)

Terminal No.	Condition	Continuity
④ - ②	Door is locked.	No
	Door is unlocked.	Yes



Horns

Supply horn terminal with battery voltage and check horn operation.




THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

Theft warning lamp relay

Check continuity between terminals ③ and ⑤, ⑥ and ⑦.

Condition	Continuity
12V direct current supply between terminals ① and ②	Yes
No current supply	No




SEC202B

Theft warning relay

Check continuity between terminals ③ and ④.

Condition	Continuity
12V direct current supply between terminals ① and ②	No
No current supply	Yes




SEL360T

Horn relay

Check continuity between terminals ② and ③.

Condition	Continuity
12V direct current supply between terminals ① and ②	Yes
No current supply	No




SEL550T

Horn relay-2

Check continuity between terminals ③ and ⑤, ⑥ and ⑦.

Condition	Continuity
12V direct current supply between terminals ① and ②	Yes
No current supply	No



SEC202B

GI

MA

EW

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT




HA

EL

IDX


LOCATION OF ELECTRICAL UNITS

Engine Compartment



LOCATION OF ELECTRICAL UNITS

Passenger Compartment



GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX

HARNESS LAYOUT

How To Read Harness Layout

Example:

E2 E1 GY/2: Brake fluid level switch

Connector color/Cavity

Connector number

Grid reference

The following Harness Layouts use a map style grid to help locate connectors on the drawings:

- Engine Room Harness (Engine Compartment)
- Main Harness
- Body Harness

To use the grid reference

- 1) Find the desired connector number on the connector list.
- 2) Find the grid reference.
- 3) On the drawing, find the crossing of the grid reference letter column and number row.
- 4) Find the connector number in the crossing zone.
- 5) Follow the line (if used) to the connector.

CONNECTOR SYMBOL


Main symbol of connector (In Harness Layout) are indicated below.

Connector type	Water proof type		Standard type	
	Male	Female	Male	Female
• Cavity: Less than 4 • Relay connector				
• Cavity: From 5 to 8				
• Cavity: More than 9				
• Ground: terminal etc.				


HARNESS LAYOUT

Outline

2-DOOR



4-DOOR




HARNESS LAYOUT

Engine Room Harness

PASSENGER COMPARTMENT

- * E101 SMJ : To M16
- E102 W/2 : Circuit breaker
- E103 W/6 : Joint connector-3
- E104 B/2 : Fuse block (HEC)
- * E105 W/16 : Fuse block (HEC)
- E106 W/6 : Fuse block (HEC)
- * E107 W/6 : Ignition switch
- E108 W/2 : Key switch
- E109 L/8 : Wiper switch
- E110 W/6 : Turn signal switch
- E111 W/8 : Lighting switch
- E112 B/2 : Front fog lamp switch



* : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection.


NOTES

- GI
- MA
- EM
- LC
- EC
- FE
- CL
- MT
- AT
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL**
- IDX

HARNESS LAYOUT

Engine Room Harness (Cont'd)


ENGINE COMPARTMENT



AEL784-A

HARNESS LAYOUT


Engine Room Harness (Cont'd)



* : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection.

HARNESS LAYOUT


Main Harness



AEL785-A

HARNESS LAYOUT

Main Harness (Cont'd)




* : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection.

HARNESS LAYOUT

2-DOOR


Body Harness



HARNESS LAYOUT

Body Harness (Cont'd)


4-DOOR



Engine Control Harness

GA ENGINE

- * (F1) GY/3 : Front heated oxygen sensor
(Except Non-California models with M/T)
- * (F2) B/1 : Front oxygen sensor
(Non-California models with M/T)
- * (F3) GY/2 : Crankshaft position sensor
- * (F4) GY/2 : Distributor GY/6
- * (F6) GY/2 : Resistor
- * (F7) BR/4 : Mass air flow sensor
- * (F8) GY/2 : Intake air temperature sensor
- * (F9) BR/5 : IACV-AAC and FICD solenoid valve
- * (F10) BR/3 : Throttle position sensor
- * (F11) GY/2 : EGR temperature sensor
- * (F12) — : Engine ground
- * (F13) W/12 : To (M46)
- * (F14) L/4 : ECCS relay
- * (F15) G/2 : EGR valve and EVAP canister purge control solenoid valve
- * (F16) B/2 : Injector No. 1
- * (F17) B/2 : Injector No. 2
- * (F18) B/2 : Injector No. 3
- * (F19) B/2 : Injector No. 4
- * (F20) GY/2 : Engine coolant temperature sensor
- * (F21) GY/2 : To knock sensor
- * (F22) B/2 : Valve timing control solenoid valve
- * (F23) — : Engine ground
- * (F24) SMJ : ECM (ECCS control module)
- * (F25) GY/3 : Rear heated oxygen sensor (Models for California)
- * (F26) W/4 : To (M34)
- * (F27) W/16 : To (M33)
- * (F28) GY/6 : Joint connector - 1
- * (F29) GY/6 : Joint connector - 2



* : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection.


AEL146A

HARNESS LAYOUT

Engine Control Harness (Cont'd)

SR ENGINE

- * (F1) GY/3 : Front heated oxygen sensor
- * (F3) GY/2 : Crankshaft position sensor
- * (F4) GY/2 : Distributor
- GY/6
- * (F5) GY/5 : To (E23)
- * (F6) GY/2 : Resistor
- * (F7) BR/4 : Mass air flow sensor
- * (F8) GY/2 : Intake air temperature sensor
- * (F9) BR/8 : To terminal cord assembly (A/T models)
- * (F10) BR/3 : Throttle position sensor (M/T models)
- * (F11) GY/2 : EGR temperature sensor
- * (F12) — : Engine ground
- * (F13) W/12 : To (M46)
- * (F14) L/4 : ECCS relay
- * (F15) GY/3 : Revolution sensor (A/T models)
- * (F16) GY/3 : Throttle position sensor (A/T models)
- * (F17) GY/4 : Throttle position switch (A/T models)
- * (F18) — : Engine ground
- * (F19) BR/2 : IACV-AAC valve
- * (F20) GY/2 : IAC-FICD solenoid valve
- GY/8 : To (F51)
- GY/2 : IACV-air regulator
- GY/6 : Joint connector-1
- GY/6 : Joint connector-2
- SMJ : ECM (ECCS control module)
- W/4 : To (M34)
- W/16 : To (M33)
- W/16 : To (M36)
- GY/8 : To (F21)
- B/2 : Injector No. 1
- B/2 : Injector No. 2
- B/2 : Injector No. 3
- B/2 : Injector No. 4
- B/2 : Knock sensor





* : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection.

GI
MA
EM
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Engine Harness No. 2 and Generator Harness

GA ENGINE



Body ground

* : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection.

+ Harness routing for models with M/T


HARNESS LAYOUT

Engine Harness No. 2 and Generator Harness (Cont'd)

SR ENGINE

Generator harness

- (A1) GY/3 : To (E30)
- (A2) GY/1 : To (E31)
- (A3) GY/1 : To (E29)
- (A4) — : Body ground
- (A5) — : Generator
- W/2
- (A6) B/1 : A/C compressor




GI
MA
EW
LC
EC
FE
CL
MT
AT
FA
RA
BR
ST
RS
BT
HA
EL
IDX

HARNESS LAYOUT

Room Lamp Harness

2-DOOR


- (R1) W/4 : To (M18)
- (R2) W/1 : Sun roof assembly
- (R4) W/2 : Interior lamp



AEL808


4-DOOR

- (R1) W/4 : To (M18)
- (R2) W/1 : Sun roof assembly
- (R4) W/2 : Interior lamp



AEL809

Air Bag Harness



- (Z1) W/12 : To (M32)
- (Z2) W/6 : Air bag module LH
- (Z3) W/2 : Air bag module RH
- (Z4) Y/24 : Air bag diagnosis sensor unit

GI

MA

EM

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX



HARNESS LAYOUT

Tail Harness

2-DOOR

- | | |
|------------------------------------|--|
| (T1) W/8 : To (B19) | (T6) W/3 : Trunk lid key cylinder switch |
| (T2) W/2 : Back-up lamp LH | (T7) W/2 : Back-up lamp RH |
| (T3) BR/2 : License lamp | (T8) W/4 : Rear combination lamp LH |
| (T4) B/2 : Trunk room lamp switch | (T9) — : Body ground |
| (T5) BR/2 : High mounted stop lamp | (T10) — : Body ground |
| | (T11) W/4 : Rear combination lamp RH |

Body ground





AEL806

4-DOOR

- | | |
|--|--------------------------------------|
| (T1) W/8 : To (B19) | (T7) W/2 : Back-up lamp RH |
| (T2) W/2 : Back-up lamp LH | (T8) W/4 : Rear combination lamp LH |
| (T3) BR/2 : License lamp | (T9) — : Body ground |
| (T4) B/2 : Trunk room lamp switch | (T10) — : Body ground |
| (T5) W/2 : High mounted stop lamp | (T11) W/4 : Rear combination lamp RH |
| (T6) W/3 : Trunk lid key cylinder switch | |

Body ground




AEL807


HARNESS LAYOUT

LEFT

Front Door Harness (2-Door)




RIGHT




HARNESS LAYOUT

LEFT

Front Door Harness (4-Door)




RIGHT




HARNESS LAYOUT

LEFT

Rear Door Harness (4-Door)



RIGHT



CI

MA

EN

LC

EC

FE

CL

MT

AT

FA

RA

BR

ST

RS

BT

HA

EL

IDX

HARNESS LAYOUT



↓
(Whole page added)

Body Harness No. 2


- ⑥103 — : Body ground
- ⑥108 BR/2 : Rear wheel sensor LH
- ⑥110 GY/2 : Rear wheel sensor RH

- ⑥104 GY/2 : Front wheel sensor RH
- ⑥105 W/18 : To ⑥109
- ⑥106 — : Body ground
- ⑥107 SMJ : ABS control unit

- ⑥101 W/6 : Wiper motor
- ⑥102 W/2 : Power steering oil pressure switch
- ⑥103 GY/8 : ABS control actuator
- ⑥104 B/6 : ABS relay unit



Body ground



Body ground