

REPAIR PRO



Fix it like a Pro

How to use this Service Manual

In the bookmarks to the left you will find different segments of this manual:

Service Manual

This is the standard manual for this vehicle. Use this segment as your major point of reference and information.

Supplementary Service Manual (if available)

These segments are updates and additions to the standard service manual. They are added as needed when certain changes are made to the model. Be sure to check these for additional information that may be lacking from the regular service manual.

HOW TO USE THIS MANUAL

CONSTRUCTION OF THIS MANUAL

This manual consists of chapters for the main categories of subjects. (See “Illustrated symbols”)

- 1st title ①: This is a chapter with its symbol on the upper right of each page.
- 2nd title ②: This title appears on the upper of each page on the left of the chapter symbol. (For the chapter “Periodic inspection and adjustment” the 3rd title appears.)
- 3rd title ③: This is a final title.

MANUAL FORMAT

All of the procedures in this manual are organized in a sequential, step-by-step format. The information has been compiled to provide the mechanic with an easy to read, handy reference that contains comprehensive explanations of all disassembly, repair, assembly, and inspections.


A set of particularly important procedure ④ is placed between a line of asterisks “*” with each procedure preceded by “●”.


IMPORTANT FEATURES

- Data and a special tool are framed in a box preceded by a relevant symbol ⑤.
- An encircled numeral ⑥ indicates a part name, and an encircled alphabetical letter data or an alignment mark ⑦, the others being indicated by an alphabetical letter in a box ⑧.
- A condition of a faulty component will precede an arrow symbol ⑨ and the course of action will follow it.

EXPLODED DIAGRAM

Each chapter provides exploded diagrams before each disassembly section for ease in identifying correct disassembly and assembly procedures.



①	GEN INFO 		②	SPEC 	
③	INSP ADJ 		④	ENG 	
⑤	CARB 		⑥	DRIV 	
⑦	CHAS 		⑧	ELEC 	
⑨	TRBL SHTG 		⑩		
⑪			⑫		
⑬			⑭		
⑮			⑯		
⑰		⑱		⑲	
⑳		㉑		㉒	
㉓			㉔	New	

ILLUSTRATED SYMBOLS

(Refer to the illustration)

Illustrated symbols ① to ⑨ are designed as thumb tabs to indicate the chapter's number and content.

- ① General information
- ② Specifications
- ③ Periodic inspection and adjustment
- ④ Engine
- ⑤ Carburetion
- ⑥ Drive train
- ⑦ Chassis
- ⑧ Electrical
- ⑨ Troubleshooting

Illustrated symbols ⑩ to ⑯ are used to identify the specifications appearing in the text.


- ⑩ Filling fluid
- ⑪ Lubricant
- ⑫ Special tool
- ⑬ Tightening
- ⑭ Wear limit, clearance
- ⑮ Engine speed
- ⑯ Ω , V, A

Illustrated symbols ⑰ to ㉔ in the exploded diagram indicate grade of lubricant and location of lubrication point.

- ⑰ Apply engine oil
- ⑱ Apply gear oil
- ⑲ Apply molybdenum disulfide oil
- ⑳ Apply wheel bearing grease
- ㉑ Apply lightweight lithium-soap base grease
- ㉒ Apply molybdenum disulfide grease
- ㉓ Apply locking agent (LOCTITE®)
- ㉔ Use new one

CONTENTS

GENERAL INFORMATION	1
MACHINE IDENTIFICATION	1
VEHICLE IDENTIFICATION NUMBER	1
MODEL LABEL	1
 SPECIFICATIONS	2
GENERAL SPECIFICATIONS	2
MAINTENANCE SPECIFICATIONS	5
ENGINE	5
CHASSIS	10
ELECTRICAL	12
 PERIODIC INSPECTION AND ADJUSTMENT	14
INTRODUCTION	14
PERIODIC MAINTENANCE/LUBRICATION	14
ENGINE.....	16
SPARK ARRESTER CLEANING.....	16




GENERAL INFORMATION

MACHINE IDENTIFICATION

VEHICLE IDENTIFICATION NUMBER

The vehicle identification number ① is stamped into the left side of the frame.



MODEL LABEL

The model label ① is affixed to the frame. This information will be needed to order spare parts.



SPECIFICATIONS

GENERAL SPECIFICATIONS

Model	YFA1M(C)
Model code:	3FAR (Except for California) 3FAP (For California)
Dimension:	
Overall length	1,640 mm (64.6 in)
Overall width	965 mm (38.0 in)
Overall height	980 mm (38.6 in)
Seat height	690 mm (27.2 in)
Wheelbase	1,080 mm (42.5 in)
Minimum ground clearance	145 mm (5.7 in)
Minimum turning radius	2,900 mm (114.2 in)
Basic weight:	
With oil and full fuel tank	144 kg (318 lb)
Engine:	
Engine type	Air cooled 4-stroke, SOHC
Cylinder arrangement	Forward incline single cylinder
Displacement	124 cm ³
Bore × stroke	49 × 66 mm (1.93 × 2.60 in)
Compression ratio	9.0 : 1
Compression pressure	850 kPa (8.5 kg/cm ² , 121 psi)
Starting system	Electric starter
Lubrication system:	
Type	Wet sump
Engine oil type	API service SE, SF type or higher
Oil quantity:	
Engine oil	
Periodic oil change	1.25 L (1.10 Imp qt, 1.32 US qt)
Total amount	1.45 L (1.28 Imp qt, 1.53 US qt)
Transmission oil	0.60 L (0.53 Imp qt, 0.63 US qt)
Air filter:	
Type	Wet type element
Fuel:	
Type	Regular gasoline
Fuel tank capacity	7.0 L (1.54 Imp gal, 1.85 US gal)
Reserve amount	1.3 L (0.28 Imp gal, 0.34 US gal)




Model	YFA1M(C)
Carburetor: Type/quantity Manufacturer	VM18SH/1 MIKUNI
Spark plug: Type (manufacturer) Spark plug gap	C7HSA (NGK), U22FS-U (DENSO) 0.6 ~ 0.7 mm (0.024 ~ 0.028 in)
Transmission: Primary reduction system Primary reduction ratio Secondary reduction system Secondary reduction ratio Clutch type Transmission type Operation Single speed automatic Reverse ratio	Helical gear/spur gear 43/14 × 40/17 (7.226) Chain drive 32/12 (2.666) Dry, centrifugal automatic Single speed automatic (V-belt) Centrifugal automatic type 2.303 ~ 0.821 : 1 49/14 × 49/15 × 40/17 (26.902)
Chassis: Frame type Caster angle Camber angle Kingpin angle Trail Tread Front Rear Toe-in	Steel tube frame 6° 1.5° 10.5° 15 mm (0.59 in) 695 mm (27.36 in) 710 mm (27.95 in) 0 ~ 10.0 mm (0 ~ 0.39 in)
Tire: Type Size Front Rear Manufacturer (type) Front Rear	Tubeless AT20 × 7- 8 AT22 × 10- 8 DUNLOP (KT536A) DUNLOP (KT537A)
Tire pressure (cold tire): Maximum load-except motorcycle Minimum Front Rear Maximum Front Rear	100 kg (221 lb) 17 kPa (0.17 kg/cm ² , 2.4 psi) 22 kPa (0.22 kg/cm ² , 3.1 psi) 23 kPa (0.23 kg/cm ² , 3.3 psi) 28 kPa (0.28 kg/cm ² , 4.0 psi)

GENERAL SPECIFICATIONS**SPEC**



Model	YFA1M(C)
Brake: Front brake type Front brake operation Rear brake type Rear brake operation	Drum brake Right hand operation Drum brake Left hand operation
Suspension: Front Rear	Swing axle Swingarm
Shock absorber: Front Rear	Coil spring/oil damper Coil spring/oil damper
Wheel travel: Front Rear	70 mm (2.76 in) 80 mm (3.15 in)
Electrical: Ignition system Generator system Battery capacity Battery type Headlight type Headlight bulb type Bulb wattage (quantity) Headlight Taillight Neutral indicator light Reverse indicator light	C.D.I. C.D.I. magneto 12 V 12 AH 12N12C-4A-2 Bulb type Incandescence 12 V 25 W/25 W (1) 12 V 3.8 W (1) 12 V 3.4 W (1) 12 V 3.4 W (1)







MAINTENANCE SPECIFICATIONS ENGINE

Model	YFA1M(C)
Cylinder head: Warp limit 	0.03 mm (0.0012 in) * Lines indicate straightedge measurement.
Cylinder: Bore size <Wear limit> Measuring point	48.99 ~ 49.03 mm (1.9287 ~ 1.9303 in) <49.15 mm (1.9350 in)> 45 mm (1.7717 in)
Camshaft: Drive method Cam dimensions Intake "A" "B" "C" Exhaust "A" "B" "C" Camshaft runout limit	Chain drive (left) 26.17 ~ 26.27 mm (1.0303 ~ 1.0342 in) 21.06 ~ 21.16 mm (0.8292 ~ 0.8331 in) 5.16 ~ 5.28 mm (0.2031 ~ 0.2078 in) 26.17 ~ 26.27 mm (1.0303 ~ 1.0342 in) 21.06 ~ 21.17 mm (0.8292 ~ 0.8331 in) 5.16 ~ 5.28 mm (0.2031 ~ 0.2078 in) 0.03 mm (0.0012 in)
Timing chain: Type No. of links Adjustment method	DID 25 92 links Automatic
Rocker arm/rocker arm shaft: Inside diameter (rocker arm) Outside diameter (shaft) Arm-to-shaft clearance	10.000 ~ 10.015 mm (0.3937 ~ 0.3943 in) 9.981 ~ 9.991 mm (0.3930 ~ 0.3933 in) 0.009 ~ 0.034 mm (0.0004 ~ 0.0013 in)
Valve, valve seat, valve guide: Valve clearance (cold) Intake Exhaust Valve dimensions "A" head diameter Intake Exhaust "B" face width Intake Exhaust	 0.08 ~ 0.12 mm (0.0031 ~ 0.0047 in) 0.10 ~ 0.14 mm (0.0039 ~ 0.0055 in) 25.9 ~ 26.1 mm (1.0197 ~ 1.0276 in) 21.9 ~ 22.1 mm (0.8622 ~ 0.8701 in) 1.4 ~ 3.0 mm (0.0551 ~ 0.1181 in) 1.7 ~ 2.8 mm (0.0669 ~ 0.1102 in)




Model		YFA1M(C)
"C" seat width Intake Exhaust  "D" margin thickness Intake Exhaust  Outside diameter (valve stem) Intake Exhaust Inside diameter (valve guide) Intake Exhaust Stem-to-guide clearance Intake Exhaust Valve seat width Intake Exhaust		0.9 ~ 1.1 mm (0.0354 ~ 0.0433 in) 0.9 ~ 1.1 mm (0.0354 ~ 0.0433 in) 0.4 ~ 0.8 mm (0.0157 ~ 0.0315 in) 0.8 ~ 1.2 mm (0.0315 ~ 0.0472 in) 4.975 ~ 4.990 mm (0.1959 ~ 0.1965 in) 4.960 ~ 4.975 mm (0.1953 ~ 0.1959 in) 5.000 ~ 5.012 mm (0.1969 ~ 0.1973 in) 5.000 ~ 5.012 mm (0.1969 ~ 0.1973 in) 0.010 ~ 0.037 mm (0.0004 ~ 0.0015 in) 0.025 ~ 0.052 mm (0.0010 ~ 0.0020 in) 0.9 ~ 1.1 mm (0.0354 ~ 0.0433 in) 0.9 ~ 1.1 mm (0.0354 ~ 0.0433 in)
Valve spring: Free length Intake Exhaust Set length (valve closed) Intake Exhaust Compressed pressure (installed) Intake Exhaust Direction of winding (top view)		30.35 mm (1.1949 in) 30.35 mm (1.1949 in) 25.7 mm (1.0118 in) 25.7 mm (1.0118 in) 92.2 ~ 109.8 N (9.40 ~ 11.20 kg, 20.7 ~ 24.7 lb) 92.2 ~ 109.8 N (9.40 ~ 11.20 kg, 20.7 ~ 24.7 lb)
		Intake Exhaust
		Clockwise Clockwise
		 



Model	YFA1M(C)
Piston: Piston size "D" Measuring point "H"  Piston-to-cylinder clearance <Wear limit> Piston off-set Piston off-set direction Inside diameter (piston pin bore) Outside diameter (piston pin)	48.96 ~ 49.00 mm (1.9276 ~ 1.9291 in) 6 mm (0.362 in) From bottom of the piston. 0.020 ~ 0.040 mm (0.0008 ~ 0.0016 in) <0.15 mm (0.0060 in)> 0.5 mm (0.0197 in) Intake side 13.002 ~ 13.013 mm (0.5119 ~ 0.5123 in) 12.996 ~ 13.000 mm (0.5117 ~ 0.5118 in)
Piston ring: Type Top ring 2nd ring Dimension (B × T) Top ring  2nd ring  Oil ring  End gap (installed) Top ring 2nd ring Oil ring Side clearance Top ring 2nd ring	Barrel Taper 1.0 × 2.0 mm (0.0394 × 0.0787 in) 1.0 × 2.0 mm (0.0394 × 0.0787 in) 2.0 × 2.2 mm (0.0787 × 0.0866 in) 0.15 ~ 0.30 mm (0.0059 ~ 0.0118 in) 0.15 ~ 0.30 mm (0.0059 ~ 0.0118 in) 0.20 ~ 0.80 mm (0.0079 ~ 0.0315 in) 0.03 ~ 0.07 mm (0.0012 ~ 0.0028 in) 0.02 ~ 0.06 mm (0.0008 ~ 0.0024 in)



Model	YFA1M(C)
Crankshaft: Crank width "A" Runout limit "C" Big end side clearance "D" Big end radial clearance "E" Small end free play "F" 	44.95 ~ 45.00 mm (1.7697 ~ 1.7717 in) 0.03 mm (0.0012 in) 0.05 ~ 0.45 mm (0.0020 ~ 0.0177 in) 0.010 ~ 0.025 mm (0.0004 ~ 0.0010 in) 0.80 ~ 1.00 mm (0.0315 ~ 0.0394 in)
Ballancer: Drive method	Gear
Automatic centrifugal clutch: Clutch shoe thickness <Wear limit> Free length (clutch spring) Clutch-in revolution Clutch-stall revolution	3.5 mm (0.1378 in) <2.0 mm (0.0787 in)> 27.5 mm (1.0827 in) 2,300 ~ 2,600 r/min 3,400 ~ 3,800 r/min
Transmission: Runout limit Main axle Drive axle	0.08 mm (0.0031 in) 0.08 mm (0.0031 in)
Shifter: Type	Cam drum and guide bar
Air filter oil grade:	Air cooled 2-stroke engine oil
Carburetor: I.D. mark Main jet (M.J.) Main air jet (M.A.J.) Jet needle (J.N.) Needle jet (N.J.) Cutaway (C.A.) Pilot air jet (P.A.J.) Pilot outlet (P.O.) Pilot jet (P.J.) Bypass 1 (B.P.1) Pilot screw (P.S.) Valve seat size (V.S.) Starter jet (G.S.) Float height (F.H.) Fuel level (F.L.)	3FA01 (Except for California) 3FAP10 (For California) #82.5 (Except for California) #77.5 (For California) 1.3 4H36-3 (Except for California) 4HPY-46 (For California) N-6 (Except for California) 0-1M (For California) 2.5 #130 0.7 #12.5 1.1 2 1/2 1.8 #45 21.8 mm (0.86 in) 4.0 ~ 6.0 mm (0.1575 ~ 0.2362 in) With special tool

MAINTENANCE SPECIFICATIONS**SPEC**

Model	YFA1M(C)
Engine idling speed	1,650 ~ 1,750 r/min
Intake vacuum	26.7 kPa (200 mmHg, 7.88 inHg)
Oil pump:	
Type	Trochoid type
Tip clearance	0.15 mm (0.0059 in)
Side clearance	0.06 ~ 0.10 mm (0.0024 ~ 0.0039 in)



CHASSIS

Model	YFA1M(C)
Suspension: Suspension travel Front Rear Free length (spring) Front Rear Spring rate Front Rear Stroke Front Rear Optional spring Front Rear	41 mm (1.61 in) 60 mm (2.36 in) 148 mm (5.83 in) 205 mm (8.07 in) 29.4 N/mm (2.94 kg/mm, 167.9 lb/in) 36.3 N/mm (3.63 kg/mm, 207.3 lb/in) 0 ~ 41.0 mm (0 ~ 1.61 in) 0 ~ 60.0 mm (0 ~ 2.36 in) No No
Wheel: Wheel type Front Rear Rim size Front Rear Rim material Front Rear Rim runout limit Front Vertical Lateral Rear Vertical Lateral	Panel wheel Panel wheel 8 × 5.5 AT 8 × 8.0 AT Steel Steel 2.0 mm (0.08 in) 2.0 mm (0.08 in) 2.0 mm (0.08 in) 2.0 mm (0.08 in)
Drive chain: Type/manufacture Number of links Chain slack	520V-6/DAIDO 74 links 30 mm (1.18 in)



Model	YFA1M(C)
Front brake (drum brake): Type Inside diameter (brake drum) <Wear limit> Lining thickness <Wear limit> Free length (shoe spring)	Leading, trailing 110 mm (4.33 in) <111 mm (4.37 in)> 4.0 mm (0.16 in) <2.0 mm (0.08 in)> 34.5 mm (1.36 in)
Rear brake (drum brake): Type Inside diameter (brake drum) <Wear limit> Lining thickness <Wear limit> Free length (shoe spring)	Leading, trailing 130 mm (5.12 in) <131 mm (5.16 in)> 4.0 mm (0.16 in) <2.0 mm (0.08 in)> 36.5 mm (1.44 in)
Brake lever: Free play Front brake Rear brake	 10 ~ 12 mm (0.39 ~ 0.47 in) at lever pivot 5 ~ 8 mm (0.20 ~ 0.31 in) at lever pivot



ELECTRICAL

Model	YFA1M(C)
Voltage:	12 V
Ignition system: Ignition timing (B.T.D.C.) Advanced timing (B.T.D.C.) Advancer type	7° at 1,700 r/min 27° at 5,000 r/min Electrical type
C.D.I.: Magneto model/manufacture Pickup coil resistance (lead color) Source coil resistance (lead color) Lighting coil resistance (lead color) C.D.I. unit model/manufacture	F3FA/YAMAHA 248 ~ 372 Ω at 20°C (68°F) (Red-Gray) 264 ~ 396 Ω at 20°C (68°F) (Brown-Green) 0.56 ~ 0.84 Ω at 20°C (68°F) (White-Brack) 0.32 ~ 0.48 Ω at 20°C (68°F) (Yellow-Brack) 3FA1/YAMAHA
Ignition coil: Model/manufacture Primary coil resistance Secondary coil resistance	2JN/YAMAHA 0.184 ~ 0.276 Ω at 20°C (68°F) 6.32 ~ 9.48 k Ω at 20°C (68°F)
Spark plug cap: Type Resistance	Resin type 10 k Ω at 20°C (68°F)
Rectifier/regulator: Model/manufacture Regulator type No load regulated voltage (DC) No load regulated voltage (AC) Rectifier capacity (DC) Rectifier capacity (AC) Withstand voltage	EHU-01TR31A/MATSUSHITA Semi conductor short circuit type 14.0 ~ 15.0 V 13.0 ~ 14.0 V 8 A 8 A 200 V
Battery: Specified gravity	1.280
Electric starting system: Type Starter motor Model/manufacture Output Armature coil resistance Overall length (brush) <Limit> Brush spring pressure Commutator diameter	Constant mesh type 3FA1/YAMAHA 0.4 kw 0.019 ~ 0.023 Ω at 20°C (68°F) 10.0 mm (0.39 in) <3.5 mm (0.14 in)> 5.52 ~ 8.28 N (19.87 ~ 29.80 oz) 22.0 mm (0.87 in)

MAINTENANCE SPECIFICATIONS**SPEC**

Model	YFA1M(C)
<Wear limit>	<21.0 mm (0.83 in)>
Mica undercut	1.5 mm (0.06 in)
Starter relay	
Mode/manufacture	MS5D-611/JIDECO
Amperage rating	100 A
Coil resistance	3.87 ~ 4.37 Ω at 20°C (68°F)
Starting circuit cut off relay	
Model/manufacture	ACA1211-9/MATSUSHITA
Coil resistance	72 ~ 88 Ω at 20°C (68°F)
Diode	No
Circuit breaker:	
Type	Fuse
Amperage for individual circuit	
Main	5 A

PERIODIC INSPECTION AND ADJUSTMENT

INTRODUCTION

This chapter includes all information necessary to perform recommended inspections and adjustments. These preventive maintenance procedures, if followed, will ensure more reliable vehicle operation and a longer service life. The need for costly overhaul work will be greatly reduced. This information applies to vehicles already in service as well as new vehicles that are being prepared for sale. All service technicians should be familiar with this entire chapter.

PERIODIC MAINTENANCE/LUBRICATION

ITEM	ROUTINE	INITIAL			EVERY	
		1 month	3 months	6 months	6 months	1 year
Valves*	• Check valve clearance. • Adjust if necessary.	○		○	○	○
Spark plug	• Check condition. • Adjust gap and clean. • Replace if necessary.	○	○	○	○	○
Air filter element (for engine and V-belt compartment)	• Clean. • Replace if necessary.	Every 20 ~ 40 hours (More often in wet or dusty areas.)				
Carburetor*	• Check idle speed/starter operation. • Adjust if necessary.		○	○	○	○
Cylinder head cover breather system*	• Check breather hose for cracks or damage. • Replace if necessary.			○	○	○
Exhaust system*	• Check leakage. • Retighten if necessary. • Replace gasket if necessary.			○	○	○
Spark arrester	• Clean.			○	○	○
Fuel line*	• Check fuel hose for cracks or damage. • Replace if necessary.			○	○	○
Engine oil	• Replace (warm engine before draining).	○		○	○	○
Oil strainer*	• Clean. • Replace if necessary.	○		○		○
Drive chain	• Check and adjust slack/alignment/clean/lube.	○	○	○	○	○
Transmission oil	• Check oil level/oil leakage. • Replace every 12 months.	○				○
Brake*	• Check operation. • Adjust if necessary.	○	○	○	○	○
V-belt*	• Check operation. • Replace if damage or excessive wear.	○				○
Wheels*	• Check balance/damage/runout. • Replace if necessary.	○		○	○	○
Wheel bearings*	• Check bearing assembly for looseness/damage. • Replace if damaged.	○		○	○	○
Steering system*	• Check operation. • Replace if damaged. • Check toe-in. • Adjust if necessary.	○	○	○	○	○


PERIODIC MAINTENANCE/LUBRICATION



ITEM	ROUTINE	INITIAL			EVERY	
		1 month	3 months	6 months	6 months	1 year
Knuckle shafts/ Steering shaft*	• Lubricate every 6 months.**			○	○	○
Fittings and Fasteners*	• Check all chassis fittings and fasteners. • Correct if necessary.	○	○	○	○	○
Battery*	• Check specific gravity. • Check breather hose for proper operation. • Correct if necessary.	○	○	○	○	○

*: It is recommended that these items be serviced by a Yamaha dealer.

**: Lithium soap base grease.



ENGINE

SPARK ARRESTER CLEANING

1.Remove the bolt ①.

NOTE:

Make sure to not loose the washer ② when removing the bolt.

2.Remove the tailpipe ③ by pulling it out of the muffler.

3.Tap the tailpipe lightly with a soft-face hammer or suitable tool, then use a wire brush to remove any carbon deposits from the spark arrester portion of the tailpipe and the inner contact surfaces of the muffler.

4.Insert the tailpipe ③ into the muffler and align the bolt holes.

5.Install the bolt ① and tighten it.


NOTE:

Make sure to install the washer ② when installing the bolt.

⚠ WARNING

Always let the exhaust system cool before performing this operation.

Do not start the engine when cleaning the spark arrester or exhaust system.

①	GEN INFO 	②	SPEC 		
③	INSP ADJ 	④	ENG 		
⑤	COOL 	⑥	CARB 		
⑦	DRIV 	⑧	CHAS 		
⑨	ELEC 	⑩	TRBL SHTG 		
⑪		⑫			
⑬		⑭			
⑮		⑯			
⑰		⑱			
⑲		⑳		㉑	
㉒		㉓		㉔	

ILLUSTRATED SYMBOLS (Refer to the illustration)

Illustrated symbols ① to ⑩ are designed as thumb tabs to indicate the chapter's number and content.

- ① General information
- ② Specifications
- ③ Periodic inspection and adjustment
- ④ Engine
- ⑤ Cooling system
- ⑥ Carburetion
- ⑦ Drive train
- ⑧ Chassis
- ⑨ Electrical
- ⑩ Troubleshooting

Illustrated symbols ⑪ to ⑰ are used to identify the specifications appearing in the text.

- ⑪ Filling fluid
- ⑫ Lubricant
- ⑬ Special tool
- ⑭ Tightening
- ⑮ Wear limit, clearance
- ⑯ Engine speed
- ⑰ Ω , V, A

Illustrated symbols ⑱ to ㉔ in the exploded diagram indicate grade of lubricant and location of lubrication point.

- ⑱ Apply locking agent (LOCTITE®)
- ⑲ Apply engine oil
- ⑳ Apply gear oil
- ㉑ Apply molybdenum disulfide oil
- ㉒ Apply wheel bearing grease
- ㉓ Apply lightweight lithium-soap base grease
- ㉔ Apply molybdenum disulfide grease

INDEX

GENERAL INFORMATION	
	GEN INFO 1
SPECIFICATIONS	
	SPEC 2
PERIODIC INSPECTION AND ADJUSTMENT	
	INSP ADJ 3
ENGINE OVERHAUL	
	ENG 4
CARBURETION	
	CARB 5
CHASSIS	
	CHAS 6
ELECTRICAL	
	ELEC 7
TROUBLESHOOTING	?
	TRBL SHTG 8

CONTENTS

CHAPTER 1. GENERAL INFORMATION

MACHINE IDENTIFICATION	1-1
VEHICLE IDENTIFICATION NUMBER	1-1
FRAME SERIAL NUMBER	1-1
ENGINE SERIAL NUMBER	1-1
IMPORTANT INFORMATION	1-2
PREPARATION FOR REMOVAL	1-2
ALL REPLACEMENT PARTS	1-2
GASKETS, OIL SEALS, AND O-RINGS	1-2
LOCK WASHERS/PLATES AND COTTER PINS	1-3
BEARINGS AND OIL SEALS	1-3
CIRCLIPS	1-3
SPECIAL TOOLS	1-4
FOR TUNE UP	1-4
FOR ENGINE SERVICE	1-5
FOR CHASSIS SERVICE	1-8
FOR ELECTRICAL COMPONENTS	1-8

CHAPTER 2. SPECIFICATIONS

GENERAL SPECIFICATIONS	2-1
MAINTENANCE SPECIFICATIONS	2-4
ENGINE	2-4
CHASSIS	2-10
ELECTRICAL	2-13
GENERAL TORQUE SPECIFICATIONS	2-15
DEFINITION OF UNITS	2-15
LUBRICATION POINTS AND LUBRICANT TYPE	2-16
ENGINE	2-16
CHASSIS	2-16
LUBRICATION DIAGRAM	2-17
CABLE ROUTING	2-18

CHAPTER 3. PERIODIC INSPECTION AND ADJUSTMENT

INTRODUCTION	3-1
PERIODIC MAINTENANCE/LUBRICATION INTERVALS	3-1
FENDERS	3-2
REMOVAL	3-2
INSTALLATION	3-4
ENGINE	3-5
VALVE CLEARANCE ADJUSTMENT	3-5
TIMING CHAIN ADJUSTMENT	3-7
IDLING SPEED ADJUSTMENT	3-8
THROTTLE CABLE FREE PLAY ADJUSTMENT	3-9
SPARK PLUG INSPECTION	3-9
IGNITION TIMING CHECK	3-10
COMPRESSION PRESSURE MEASUREMENT	3-12
ENGINE OIL LEVEL INSPECTION	3-13
ENGINE OIL REPLACEMENT	3-14
TRANSMISSION OIL LEVEL INSPECTION	3-15
TRANSMISSION OIL REPLACEMENT	3-16
AIR FILTER CLEANING	3-17
CARBURETOR JOINT INSPECTION	3-20
FUEL LINE INSPECTION	3-20
CRANKCASE BREATHER HOSE INSPECTION	3-21
EXHAUST SYSTEM INSPECTION	3-21
V-BELT INSPECTION	3-22
CHASSIS	3-23
FRONT BRAKE ADJUSTMENT	3-23
REAR BRAKE ADJUSTMENT	3-23
BRAKE SHOE INSPECTION	3-25
DRIVE CHAIN SLACK ADJUSTMENT	3-25
DRIVE CHAIN LUBRICATION	3-27
STEERING SYSTEM INSPECTION	3-27
TOE-IN ADJUSTMENT	3-28
TIRE INSPECTION	3-29
WHEEL INSPECTION	3-32
CABLE INSPECTION AND LUBRICATION	3-32
LEVER LUBRICATION	3-33
FRONT SUSPENSION LUBRICATION	3-33
STEERING COLUMN LUBRICATION	3-33
REAR SUSPENSION LUBRICATION	3-33
ELECTRICAL	3-34
BATTERY INSPECTION	3-34
FUSE INSPECTION	3-34
HEADLIGHT BEAM ADJUSTMENT	3-37
HEADLIGHT BULB REPLACEMENT	3-38

**GEN
INFO****1****SPEC****2****INSP
ADJ****3****ENG****4****CARB****5****CHAS****6****ELEC****7****?****TRBL
SHTG****8**

CHAPTER 4 ENGINE OVERHAUL

ENGINE REMOVAL	4-1
ENGINE OIL	4-1
TRANSMISSION OIL	4-1
FENDERS	4-1
CARBURETOR	4-1
MUFFLER	4-2
STARTING MOTOR	4-3
LEADS AND HOSES	4-3
ENGINE REMOVAL	4-3
 ENGINE DISASSEMBLY	 4-5
CYLINDER HEAD, CYLINDER AND PISTON	4-5
PRIMARY SHEAVE AND SECONDARY SHEAVE	4-7
ELECTRIC STARTING DRIVE	4-9
SHIFT LEVER	4-10
CDI MAGNETO	4-10
OIL PUMP	4-11
TIMING CHAIN	4-12
CRANKCASE (RIGHT)	4-12
SHIFTER AND TRANSMISSION	4-13
CRANKSHAFT AND BALANCER	4-14
CAMSHAFT, ROCKER ARM AND VALVE	4-14
 INSPECTION AND REPAIR	 4-17
CYLINDER HEAD	4-17
VALVE SEAT	4-18
VALVE AND VALVE GUIDE	4-21
CAMSHAFT	4-22
ROCKER ARM AND ROCKER ARM SHAFT	4-23
VALVE SPRING	4-24
TIMING CHAIN, CHAIN GUIDE AND SPROCKET	4-24
CYLINDER AND PISTON	4-25
PISTON RING	4-27
PISTON PIN	4-27
CRANKSHAFT AND CONNECTING ROD	4-28
ELECTRIC STARTER DRIVES	4-29
CLUTCH	4-30
TRANSMISSION AND SHIFTER	4-31
PRIMARY SHEAVE AND SECONDARY SHEAVE	4-32
V-BELT	4-33
OIL PUMP AND STRAINER	4-34
OIL DELIVERY PIPE	4-34
CRANKCASE	4-35
BEARINGS AND OIL SEALS	4-35
CIRCLIPS AND WASHERS	4-35

ENGINE ASSEMBLY AND ADJUSTMENT	4-36
CAMSHAFT, ROCKER ARM AND VALVE	4-36
CRANKSHAFT AND BALANCER	4-37
SHIFTER AND TRANSMISSION	4-37
CRANKCASE (RIGHT)	4-38
TIMING CHAIN	4-43
OIL PUMP	4-43
CDI MAGNETO	4-43
SHIFT LEVER	4-44
ELECTRIC STARTING DRIVE	4-45
PRIMARY SHEAVE AND SECONDARY SHEAVE	4-45
CYLINDER HEAD, CYLINDER AND PISTON	4-47
REMounting ENGINE	4-55

CHAPTER 5. CARBURETION

CARBURETOR	5-1
SECTIONAL VIEW	5-2
REMOVAL	5-3
DISASSEMBLY	5-4
INSPECTION	5-5
ASSEMBLY	5-7
INSTALLATION	5-7
FLOAT HEIGHT ADJUSTMENT	5-8
FUEL LEVEL ADJUSTMENT	5-9

CHAPTER 6. CHASSIS

FRONT WHEEL	6-1
REMOVAL	6-2
INSPECTION	6-3
INSTALLATION	6-5
REAR WHEEL	6-8
REMOVAL	6-9
INSPECTION	6-12
INSTALLATION	6-15
FRONT SUSPENSION	6-18
REMOVAL	6-19
INSPECTION	6-20
INSTALLATION	6-21



**GEN
INFO** **1**



SPEC **2**



**INSP
ADJ** **3**




ENG **4**



CARB **5**



CHAS **6**



ELEC **7**



**TRBL
SHTG** **8**

STEERING SYSTEM	6-23
REMOVAL	6-24
INSPECTION	6-26
INSTALLATION	6-28
SWINGARM	6-30
REMOVAL	6-31
INSPECTION	6-33
INSTALLATION	6-34
DRIVE CHAIN AND SPROCKET	6-35
REMOVAL	6-35
INSPECTION	6-35
INSTALLATION	6-37

CHAPTER 7. ELECTRICAL

YFA1(W) CIRCUIT DIAGRAM	7-1
COLOR CODE	7-2
ELECTRICAL COMPONENTS	7-3
CHECKING OF SWITCHES	7-4
SWITCH CONNECTION AS SHOWN IN MANUAL	7-4
CHECKING SWITCH FOR TERMINAL CONNECTION	7-4
CHECKING OF BULBS (FOR HEADLIGHT, TAIL/BRAKE LIGHT, FLASHER LIGHT, METER LIGHT, ETC.)	7-7
KINDS OF BULBS	7-7
CHECKING BULB CONDITION	7-7
IGNITION SYSTEM	7-9
CIRCUIT DIAGRAM	7-9
TROUBLESHOOTING	7-11
ELECTRIC STARTING SYSTEM	7-19
CIRCUIT DIAGRAM	7-19
TROUBLESHOOTING	7-21
STARTING MOTOR	7-25
CHARGING SYSTEM	7-31
CIRCUIT DIAGRAM	7-31
TROUBLESHOOTING	7-33
LIGHTING SYSTEM	7-37
CIRCUIT DIAGRAM	7-37
TROUBLESHOOTING	7-39

SIGNAL SYSTEM	7-43
CIRCUIT DIAGRAM	7-43
TROUBLESHOOTING	7-45
SIGNAL SYSTEM CHECK	7-47

CHAPTER 8. TROUBLESHOOTING

STARTING FAILURE/HARD STARTING	8-1
FUEL SYSTEM	8-1
ELECTRICAL SYSTEM	8-2
COMPRESSION SYSTEM	8-2
POOR IDLE SPEED PERFORMANCE	8-3
FUEL SYSTEM	8-3
POOR MEDIUM AND HIGH SPEED PERFORMANCE	8-3
FUEL SYSTEM	8-3
ELECTRICAL SYSTEM	8-4
COMPRESSION SYSTEM	8-4
FAULTY GEAR SHIFTING	8-5
HARD SHIFTING	8-5
SELECT LEVER DOES NOT MOVE	8-5
JUMP-OUT GEAR	8-5
FAULTY AUTOMATIC TRANSMISSION (V-BELT TYPE)	8-6
MACHINE DOES NOT MOVE WHILE ENGINE IS OPERATING	8-6
CLUTCH-OUT FAILURE	8-6
POOR STANDING START (LOW CLIMBING ABILITY)	8-6
POOR ACCELERATION (POOR HIGH SPEED)	8-6
FAULTY BRAKE	8-7
POOR BRAKING EFFECT	8-7
SHOCK ABSORBER MALFUNCTION	8-7
MALFUNCTION	8-7
OVERHEATING	8-7
OVERHEATING	8-7
INSTABLE HANDLING	8-8
INSTABLE HANDLING	8-8
FAULTY SIGNAL AND LIGHTING SYSTEM	8-9
HEADLIGHT DARK	8-9
BULB BURNT OUT	8-9



**GEN
INFO** **1**



SPEC **2**



**INSP
ADJ** **3**




ENG **4**



CARB **5**



CHAS **6**




ELEC **7**



**TRBL
SHTG** **8**

GENERAL INFORMATION



MACHINE IDENTIFICATION

VEHICLE IDENTIFICATION NUMBER (FOR USA, CDN AND AUS)

The vehicle identification number ① is stamped into the left side of the frame.


NOTE: _____

The vehicle identification number is used to identify your machine and may be used to register your machine with the licensing authority in your state.

Starting Serial Number:

JY43FAW0 * KC000101 (USA, AUS)

JY43FAN0 * KC031101 (CDN)



FRAME SERIAL NUMBER

(EXCEPT FOR USA, CDN AND AUS)


The frame serial number ① is stamped into the left side of frame.

NOTE: _____

The first three digits of these numbers are for model identifications; the remaining digits are the unit production number.

Starting Serial Number:

3FA-031101



ENGINE SERIAL NUMBER

The engine serial number ① is stamped into the right side of the engine.

NOTE: _____

The first three digits of these numbers are for model identifications; the remaining digits are the unit production number.

Starting Serial Number:

3FA-000101 (USA, AUS)

3FA-031101 (CDN, CH, F, NL, S, DK)

NOTE: _____

Designs and specifications are subject to change without notice.

IMPORTANT INFORMATION

PREPARATION FOR REMOVAL


1. Remove all dirt, mud, dust and foreign material before removal and disassembly.
2. Use proper tools and cleaning equipment. Refer to "CHAPTER 1. GENERAL INFORMATION-SPECIAL TOOLS" section.
3. When disassembling the machine, keep mated parts together. This includes gears, cylinder, piston and other parts that have been "mated" through normal wear. Mated parts must be reused as an assembly or replaced.
4. During the machine disassembly, clean all parts and place them in trays in the order of disassembly. This will speed up assembly time and help assure that all parts are correctly reinstalled.
5. Keep away from fire.

ALL REPLACEMENT PARTS

1. We recommended to use Yamaha genuine parts for all replacements. Use oil and/or grease recommended by Yamaha for assembly and adjustment. Other brands may be similar in function and appearance, but inferior in quality.

GASKETS, OIL SEALS, AND O-RINGS


1. All gaskets, seals, and O-rings should be replaced when an engine is overhauled. All gasket surfaces, oil seal lips, and O-rings must be cleaned.
2. Properly oil all mating parts and bearings during reassembly. Apply grease to the oil seal lips.



LOCK WASHERS/PLATES AND COTTER PINS

1. All lock washers/plates ① and cotter pins must be replaced when they are removed. Lock tab(s) should be bent along the bolt or nut flat(s) after the bolt or nut has been properly tightened.

1





BEARINGS AND OIL SEALS

1. Install the bearing(s) ① and oil seal(s) ② with their manufacturer's marks or numbers facing outward. (In other words, the stamped letters must be on the side exposed to view.) When installing oil seal(s), apply a light coating of light-weight lithium base grease to the seal lip(s). Oil the bearings liberally when installing.

⚠ WARNING:


Do not use compressed air to spin the bearings dry. This causes damage to the bearing surfaces and may cause the bearing to explode.



CIRCLIPS

1. All circlips should be inspected carefully before reassembly. Always replace piston pin clips after one use. Replace distorted circlips. When installing a circlip ①, make sure that the sharp edged corner ② is positioned opposite to the thrust ③ it receives. See the sectional view.

④ Shaft



1

SPECIAL TOOLS


The proper special tools are necessary for complete and accurate tune-up and assembly. Using the correct special tool will help prevent damage caused by the use of improper tools or improvised techniques.

FOR TUNE UP**1. Inductive Tachometer**

P/N YU-08036

P/N 90890-03113


This tool is needed for detecting engine rpm.

**2. Fuel Level Gauge**

P/N YM-01312-A

P/N 90890-01312


This gauge is used to measure the fuel level in the float chamber.

**3. Valve Adjusting Tool**

P/N YM-08035

P/N 90890-01311


This tool is necessary for adjusting the valve clearance.


**4. Timing Light**

P/N YM-33277

P/N 90890-03109


This tool is necessary for checking timing.





5. Compression Gauge
P/N YU-33223
P/N 90890-03081


This gauge is used to measure engine compression.



FOR ENGINE SERVICE


1. Rotor Holder
P/N YU-01235
P/N 90890-01235

This tool is used to hold the flywheel magneto when removing or installing the flywheel magneto securing nut.




2. Piston Pin Puller
P/N YU-01304
P/N 90890-01304

This tool is used to remove the piston pin.




3. Sheave Holder
P/N YU-01880
P/N 90890-01701

This tool is used when holding the clutch hub.




4. Locknut Wrench
P/N YM-4045-A
P/N 90890-01348

This tool is used to remove and install the secondary sheave nut.




5. Spring Holder
P/N YS-28891
P/N 90890-01337

This tool is used to compress the clutch spring.




6. Universal Puller
P/N YU-33270
P/N 90890-01362

This tool is used to remove the CDI rotor.




7. Crankcase Separating Tool
P/N YU-01135
P/N 90890-01135

This tool is used to separate the crankcase.




8. Slide Hammer Set
P/N YU-01083
P/N 90890-01084, 90890-01085

These tools are used to remove and install the rocker arm shafts.




9. Valve Spring Compressor — ①
P/N YM-04019
P/N 90890-04019
Adapter — ②
P/N YM-4108
P/N 90890-04108

These tools are used to remove and install the valve assemblies.




10. Valve Seat Cutter
P/N YM-91043

These tools are used to resurface the valve seat.




11. Valve Guide Remover
P/N YM-4097
P/N 90890-04097

This tool is needed to install the valve guides properly.




12. Valve Guide Installer
P/N YM-4098
P/N 90890-04098

This tool is needed to install the valve guides properly.




13. Valve Guide Reamer
P/N YM-4099
P/N 90890-04099

This tool is used to rebores the new valve guide.




14. Sealant (Quick Gasket®)
P/N ACC-11001-05-01
P/N 90890-85505

This sealant (Bond) is used for crankcase mating surfaces, etc.

1**FOR CHASSIS SERVICE**


1. Rear Axle Nut Wrench
P/N YM-37132
P/N 90890-01419

This tool is used to loosen and tighten the rear axle nut.

**FOR ELECTRICAL COMPONENTS**

1. Dynamic Coil Tester
P/N YU-34487
P/N 90890-03144

This instrument is necessary for checking the ignition system components.



2. Pocket Tester
P/N YU-03112
P/N 90890-03112

This instrument is invaluable for checking the electrical system.



SPECIFICATIONS

GENERAL SPECIFICATIONS

Model	YFA1 (W)
Model Code Number	3FA
Engine Starting Number	3FA-000101 (USA, AUS)
Vehicle Identification Number	3FA-031101 (CDN, CH, F, NL, S, DK)
Frame Starting Number	JY43FAW0 * KC000101 (USA, AUS)
	JY43FAN0 * KC031101 (CDN)
	3FA-031101 (CH, F, NL, S, DK)
Dimension:	
Overall Length	1,640 mm (64.6 in)
Overall Width	965 mm (38.0 in)
Overall Height	980 mm (38.6 in)
Seat Height	690 mm (27.2 in)
Wheelbase	1,080 mm (42.5 in)
Minimum Ground Clearance	145 mm (5.7 in)
Basic Weight:	
With Oil and Full Fuel Tank	144 kg (317 lb)
Minimum Turning Radius	2,900 mm (114.2 in)
Engine:	
Engine Type	Air Cooled 4-Stroke, SOHC
Cylinder Arrangement	Forward Inclinde Single Cylinder
Displacement	124 cm ³
Bore x Stroke	49 x 66 mm (1.93 x 2.60 in)
Compression Ratio	9.0 : 1
Compression Pressure	850 kPa (8.5 kg/cm ² , 120 psi)
Starting System	Electric Starter
Lubrication system:	
Type	Wet Sump
Engine Oil Type	
Transmission Oil Type	Yamalube 4 (10W30 or 20W40), SAE10W 30 Type SE or SAE 20W40 Type SE *Yamalube 4 (10W30 and 20W40) are for USA and CDN.

2

GENERAL SPECIFICATIONS










Model	YFA1 (W)
Oil Quantity: Engine Oil Periodic Oil Change Total Amount Transmission Oil	1.25 L (1.10 Imp qt, 1.32 US qt) 1.45 L (1.28 Imp qt, 1.53 US qt) 0.60 L (0.53 Imp qt, 0.63 US qt)
Air Filter: Type	Wet Type Element
Fuel: Type Fuel Tank Capacity Reserve Amount	Regular Gasoline 7.0 L (1.54 Imp gal, 1.85 US gal) 1.3 L (0.28 Imp gal, 0.34 US gal)
Carburetor: Type/Quantity Manufacturer	VM18SH/1 pc. MIKUNI
Spark Plug: Type (Manufacturer) Spark Plug Gap	C7HSA (NGK), U22FS-U (ND) (USA, AUS) CR7HS (NGK) (CDN, CH, F, NL, S, DK) 0.6 ~ 0.7 mm (0.024 ~ 0.028 in)
Transmission: Primary Reduction System Primary Reduction Ratio Secondary Reduction System Secondary Reduction Ratio Clutch Type Transmission Type Operation Single Speed Automatic Reverse Ratio	Helical Gear 43/14 x 40/17 (7.226) Chain Drive 32/12 (2.666) Dry, Centrifugal Automatic Single Speed Automatic (V-Belt) Centrifugal Automatic Type 2.303 ~ 0.821 (2.3 ~ 0.82) x 49/14 x 49/15 x 40/17 (61.874 ~ 22.059)
Chassis: Frame Type Caster Angle Camber Trail Tread Front Rear Toe-in	Steel Tube Frame 6° 1.5° 15 mm (0.59 in) 695 mm (27.4 in) 710 mm (28.0 in) 0.0 ~ 10.0 mm (0.0 ~ 0.4 in)
Tire: Type Size Front Rear Manufacturer (Type) Front Rear Wear Limit	Tubeless AT20 x 7 – 8 AT22 x 10 – 8 DUNLOP (KT536) DUNLOP (KT537) 3.0 mm (0.12 in)



Model	YFA1 (W)
Tire Pressure (Cold Tire): Recommended Front Rear Minimum Front Rear Maximum Front Rear	20 kPa (0.20 kg/cm ² , 2.8 psi) 25 kPa (0.25 kg/cm ² , 3.5 psi) 17 kPa (0.17 kg/cm ² , 2.4 psi) 22 kPa (0.22 kg/cm ² , 3.1 psi) 23 kPa (0.23 kg/cm ² , 3.3 psi) 28 kPa (0.28 kg/cm ² , 4.0 psi)
Brake: Front Brake Type Front Brake Operation Rear Brake Type Rear Brake Operation	Drum Brake Right Hand Operation Drum Brake Left Hand Operation
Suspension: Front Rear	Swing Axle Swingarm
Shock Absorber: Front Rear	Coil Spring/Oil Damper Coil Spring/Oil Damper
Wheel Travel: Front Rear	70 mm (2.76 in) 80 mm (3.15 in)
Electrical: Ignition System Generator System Battery Capacity Battery Type Headlight Type Bulb Wattage (Quantity) Headlight Tail/Brake Light Neutral Indicator Light Reverse Indicator Light	CDI A.C. Magneto Generator 12V 12AH 12N12C-4A-1 Bulb Type 12V 25W/25W (1 pc.) 12V 3.8W (1 pc.) (USA, AUS, CH, F, NL, S, DK) 12V 7.5W (1 pc.) (CDN) 12V 3.4W (1 pc.) 12V 3.4W (1 pc.)

ENGINE

2

Model		YFA1 (W)	
“C” Seat Width Intake Exhaust  “D” Margin Thickness Intake Exhaust  Outside Diameter (Valve Stem) Intake Exhaust Inside Diameter (Valve Guide) Intake Exhaust Stem-to-Guide Clearance Intake Exhaust Stem Runout Limit Valve Seat Width Intake Exhaust		0.9 ~ 1.1 mm (0.035 ~ 0.043 in) 0.9 ~ 1.1 mm (0.035 ~ 0.043 in) 0.4 ~ 0.8 mm (0.016 ~ 0.031 in) 0.8 ~ 1.2 mm (0.031 ~ 0.047 in) 4.975 ~ 4.990 mm (0.196 in) 4.960 ~ 4.975 mm (0.195 ~ 0.196 in) 5.000 ~ 5.012 mm (0.197 in) 5.000 ~ 5.012 mm (0.197 in) 0.010 ~ 0.037 mm (0.004 ~ 0.0014 in) 0.025 ~ 0.052 mm (0.0010 ~ 0.0020 in) 0.01 mm (0.0004 in) 0.9 ~ 1.1 mm (0.035 ~ 0.043 in) 0.9 ~ 1.1 mm (0.035 ~ 0.043 in)	
		Valve Spring: Free Length Intake Exhaust Set Length (Valve Closed) Intake Exhaust Compressed Pressure (Installed) Intake Exhaust Tilt Limit Intake Exhaust 	
		28.63 mm (1.127 in) 28.63 mm (1.127 in) 24.9 mm (0.980 in) 24.9 mm (0.980 in) 8.8 ~ 10.8 kg at 24.9 mm (19.4 ~ 23.8 lb at 0.980 in) 8.8 ~ 10.8 kg at 24.9 mm (19.4 ~ 23.8 lb at 0.980 in) 2.5° or 1.2 mm (0.047 in) 2.5° or 1.2 mm (0.047 in)	
		Intake	Exhaust
		Clockwise	Clockwise
			
Direction of Winding (Top View)		Intake	Exhaust
		Clockwise	Clockwise
			



Model	YFA1 (W)
Piston: Piston Size "D" Measuring Point "H" Piston-to-Cylinder Clearance < Wear Limit > Over Size 2nd 4th Piston Off-Set Piston Off-Set Direction Inside Diameter (Piston Pin Bore) Outside Diameter (Piston Pin) Piston Pin-to-Piston Clearance < Limit >	48.96 ~ 49.00 mm (1.927 ~ 1.929 in) 6 mm (0.24 in) From bottom of the piston. 0.020 ~ 0.040 mm (0.0008 ~ 0.0016 in) < 0.15 mm (0.006 in) > 49.5 mm (1.95 in) 50.0 mm (1.97 in) 0.5 mm (0.02 in) Intake side 13.002 ~ 13.013 mm (0.512 in) 12.996 ~ 13.000 mm (0.512 in) 0.002 ~ 0.017 mm (0.0001 ~ 0.0006 in) < 0.07 mm (0.003 in) >
Piston Ring: Dimension (B x T) Top Ring Second Ring Oil Ring End Gap (Installed) Top Ring Second Ring Oil Ring Side Clearance Top Ring Second Ring	1.0 x 2.0 mm (0.039 x 0.079 in) 1.0 x 2.0 mm (0.039 x 0.079 in) 2.0 x 2.2 mm (0.079 x 0.087 in) 0.15 ~ 0.30 mm (0.006 ~ 0.012 in) 0.15 ~ 0.30 mm (0.006 ~ 0.012 in) 0.30 ~ 0.90 mm (0.012 ~ 0.036 in) 0.03 ~ 0.07 mm (0.0012 ~ 0.0027 in) 0.02 ~ 0.06 mm (0.0008 ~ 0.0024 in)
Connecting Rod: Length	111.95 ~ 112.05 mm (4.407 ~ 4.411 in)
Crankshaft: Crank Width "A" Runout Limit "C" Big End Side Clearance "D" Small End Free Play "F" 	44.95 ~ 45.00 mm (1.770 ~ 1.772 in) 0.03 mm (0.0012 in) 0.05 ~ 0.45 mm (0.0020 ~ 0.0177 in) 0.80 ~ 1.00 mm (0.031 ~ 0.039 in)



Model	YFA1 (W)
Ballancer: Drive Method	Gear
Automatic Centrifugal Clutch: Clutch Shoe Thickness < Wear Limit > Free Length (Clutch Spring) Free Length (Sliding Sheave Spring) Compressed Pressure of Sliding Sheave Spring (Installed) Inside Diameter (Clutch Housing) Clutch-In Revolution Clutch-Stall Revolution	3.5 mm (0.138 in) < 2.0 mm (0.079 in) > 27.5 mm (1.083 in) 79.6 mm (3.134 in) 27.2 kg (60.0 lb) at 52.1 mm (2.051 in) 119.9 ~ 120.1 mm (4.720 ~ 4.728 in) 2,300 ~ 2,600 r/min 3,400 ~ 3,800 r/min
V-Belt: Width < Wear Limit >	20.1 mm (0.791 in) 18.1 mm (0.712 in)
Transmission: Runout Limit Main Axle Drive Axle	0.08 mm (0.003 in) 0.08 mm (0.003 in)
Shifter: Type Runout Limit (Guide Bar) Shift Fork Thickness	Cam Drum and Guide Bar 0.03 mm (0.0012 in) 4.76 ~ 4.89 mm (0.184 ~ 0.192 in)
Air Filter Oil Grade:	Foam-Air-Filter Oil or SAE 10W30
Carburetor: I.D. Mark Main jet (M.J.) Main Air Jet (M.A.J.) Jet Needle (J.N.) Needle Jet (N.J.) Cutaway (C.A.) Pilot Air Jet (P.A.J.) Pilot Outlet (P.O.) Pilot Jet (P.J.) Pilot Screw (P.S.) Valve Seat Size (V.S.) Starter Jet (G.S.) Float Height (F.H.) Fuel Level (F.L.) Engine Idling Speed	3FA00 # 82.5 φ 1.3 4H36-3/5 N-6 2.5 # 130 φ 0.7 # 12.5 2 and 1/2 turns out 1.8 # 45 21.8 ~ 22.8 mm (0.858 ~ 0.898 in) 2.0 ~ 4.0 mm (0.08 ~ 0.16 in) With Special Tool 1,650 ~ 1,750 r/min




Model	YFA1 (W)
Oil Pump:	
Type	Trochoid Type
Tip Clearance	0.15 mm (0.006 in)
Side Clearance	0.06 ~ 0.10 mm (0.002 ~ 0.004 in)

Lubrication Chart:

← : Pressured feed

⇐ : Splashed





Tightening torque:

Parts to be tightened	Thread size	Tightening torque			Remarks
		Nm	m • kg	ft • lb	
Cylinder head cover and cylinder head	M6 x 1.0	7	0.7	5.1	
Spark plug	M10 x 1.0	13	1.3	9.4	
Stud bolt (exhaust manifold)	M6 x 1.0	7	0.7	5.1	
Bearing retainer (camshaft) and cylinder head	M6 x 1.0	12	1.2	8.7	
Cylinder head and cylinder	M8 x 1.25	22	2.2	16	
Locknut (valve clearance adjuster)	M5 x 0.8	7	0.7	5.1	
Cylinder head and cylinder	M6 x 1.0	10	1.0	7.2	
Cam sprocket and camshaft	M8 x 1.25	26	2.6	19	
Timing chain tensioner and cylinder	M6 x 1.0	10	1.0	7.2	
Plug (timing chain tensioner)	M8 x 1.25	7	0.7	5.1	
Intake manifold and cylinder head	M6 x 1.0	12	1.2	8.7	
Intake manifold and carburetor	M6 x 1.0	10	1.0	7.2	
Muffler and cylinder head	M6 x 1.0	10	1.0	7.2	
Protector and muffler	M6 x 1.0	8	0.8	5.8	
Muffler and frame	M8 x 1.25	27	2.7	19	
Air filter case cover and air filter case	M5 x 0.8	4	0.4	2.9	
Air filter and air filter case cover	M6 x 1.0	7	0.7	5.1	
Drain plug (for engine oil)	M35 x 1.5	32	3.2	23	
Drain plug (for transmission oil)	M14 x 1.5	23	2.3	17	
Filler plug (for transmission oil)	M14 x 1.5	23	2.3	17	
Checking screw (for transmission oil)	M8 x 1.25	16	1.6	11	
Air duct	M6 x 1.0	7	0.7	5.1	
Crankcase cover (left) and crankcase	M6 x 1.0	7	0.7	5.1	
Crankcase cover (right) and crankcase	M6 x 1.0	7	0.7	5.1	
Chain case cover and crankcase	M6 x 1.0	7	0.7	5.1	
Crankcase (left) and crankcase (right)	M6 x 1.0	7	0.7	5.1	
Oil pump and crankcase	M6 x 1.0	7	0.7	5.1	
Shift lever and shift shaft	M6 x 1.0	10	1.0	7.2	
Shift lever guide and crankcase	M6 x 1.0	10	1.0	7.2	
Shift lever switch and crankcase	M5 x 0.8	6	0.6	4.3	
Plug (shift cam stopper)	M14 x 1.5	10	1.0	7.2	
Lever (shift lever switch) and crankcase	M6 x 1.0	10	1.0	7.2	
Drive sprocket and drive axle	M20 x 1.5	75	7.5	54	Lock washer
Bearing housing (drive axle bearing) and crankcase	M6 x 1.0	10	1.0	7.2	Lock washer
Bearing retainer (drive axle bearing)	M55 x 1.5	60	6.0	43	Lock washer
Primary fixed sheave and crankshaft	M12 x 1.0	55	5.5	40	
Cover (primary fixed sheave) and housing (primary fixed sheave)	M4 x 0.7	3	0.3	2.2	
Bearing retainer (primary drive axle)	M6 x 1.0	7	0.7	5.1	Lock washer
Clutch housing and primary drive axle	M14 x 1.5	60	6.0	43	
Clutch assembly	M36 x 1.5	90	9.0	65	
Main jet		2	0.2	1.4	
Pilot jet		1	0.1	0.7	
Needle jet		3	0.3	2.2	
Bulb seat holder		1	0.1	0.7	
Starter plunger		3	0.3	2.2	
Float chamber		2	0.2	1.4	
CDI magneto	M12 x 1.25	70	7.0	51	
Stator assembly	M6 x 1.0	7	0.7	5.1	



CHASSIS

Model	YFA1 (W)
Suspension: Suspension Travel Front Rear Free Length (Spring) Front Rear Spring Rate Front Rear Stroke Front Rear Optional Spring Front Rear	41 mm (1.614 in) 60 mm (2.362 in) 148 mm (5.827 in) 205 mm (8.071 in) 30 N/mm (3.0 kg/mm, 165.2 lb/in) 37 N/mm (3.7 kg/mm, 203.8 lb/in) 0.0 ~ 41mm (0.0 ~ 1.614 in) 0.0 ~ 60mm (0.0 ~ 2.362 in) No No
Wheel: Wheel Type Front Rear Rim Size Front Rear Rim Material Front Rear Rim Runout Limit Front Vertical Lateral Rear Vertical Lateral	Panel Wheel Panel Wheel 8 x 5.5 AT 8 x 8.0 AT Steel Steel 2.0 mm (0.08 in) 2.0 mm (0.08 in) 2.0 mm (0.08 in) 2.0 mm (0.08 in)
Drive Chain: Type/Manufacturer Number of Links Chain Slack 10-Link Length Limit	520V-S/DAIDO 74 Links 30 mm (1.18 in) 150.1 mm (5.909 in)
Front Brake (Drum Brake): Type Inside Diameter (Brake Drum) < Wear Limit > Lining Thickness < Wear Limit > Free Length (Shoe Spring)	Leading, Trailing 110 mm (4.33 in) < 111 mm (4.37 in) > 4.0 mm (0.16 in) < 2.0 mm (0.08 in) > 34.5 mm (1.36 in)



Model	YFA1 (W)
Rear Brake (Drum Brake): Type Inside Diameter (Brake Drum) < Wear Limit > Lining Thickness < Wear Limit > Free Length (Shoe Spring)	Leading, Trailing 130 mm (5.12 in) < 131 mm (5.16 in) > 4.0 mm (0.16 in) < 2.0 mm (0.08 in) > 36.5 mm (1.44 in)
Brake Lever: Free Play Front Brake Rear Brake	10 ~ 12 mm (0.39 ~ 0.47 in) At lever pivot. 5 ~ 8 mm (0.20 ~ 0.31 in) At lever pivot.



Tightening torque:

Parts to be tightened	Thread size	Tightening torque			Remarks
		Nm	m · kg	ft · lb	
Engine stay (front) and frame	M8 x 1.25	33	3.3	24	
Engine (front) and engine stay	M10 x 1.25	42	4.2	30	
Engine (rear — upper) and engine stay	M10 x 1.25	42	4.2	30	
Engine (rear — lower) and engine stay	M10 x 1.25	42	4.2	30	
Pivot shaft and frame	M12 x 1.25	80	8.0	58	
Swingarm and lower guard	M8 x 1.25	23	2.3	17	
Rear shock absorber and frame	M10 x 1.25	45	4.5	32	
Front arm and frame	M10 x 1.25	32	3.2	23	
Front shock absorber and front arm	M10 x 1.25	45	4.5	32	
Front shock absorber and frame	M10 x 1.25	45	4.5	32	
Tie-rod and steering column	M10 x 1.25	25	2.5	18	
Tie-rod and knuckle arm	M10 x 1.25	25	2.5	18	
Locknut (tie-rod)	M10 x 1.25	30	3.0	22	
Steering column and frame	M10 x 1.25	30	3.0	22	
Bracket (steering column) and frame	M8 x 1.25	23	2.3	17	Lock washer
Steering column and handlebar holder	M8 x 1.25	20	2.0	14	
Front arm and steering knuckle	M10 x 1.25	30	3.0	22	
Front wheel hub and wheel panel	M10 x 1.25	55	5.5	40	
Front wheel hub and steering knuckle	M14 x 1.5	70	7.0	50	
Camshaft lever (front brake) and camshaft	M6 x 1.0	9	0.9	6.5	
Rear axle and ring nut	M33 x 1.5				See "NOTE"
Rear wheel hub and wheel panel	M10 x 1.25	55	5.5	4.0	
Rear wheel hub and rear axle	M14 x 1.5	120	12.0	85	
Swingarm (rear) and hub					
Upper	M12 x 1.25	85	8.5	61	
Lower	M10 x 1.25	60	6.0	43	
Brake drum (rear brake) and boss	M8 x 1.25	21	2.1	15	Lock washer
Driven sprocket and hub	M10 x 1.25	62	6.2	45	
Camshaft lever (rear brake) and camshaft	M6 x 1.0	9	0.9	6.5	
Locknut (drive chain slack adjuster)	M8 x 1.25	16	1.6	11	
Locknut (lock bolt)	M8 x 1.25	16	1.6	11	
Bracket (foot board) and frame	M8 x 1.25	33	3.3	24	
Fuel cock and fuel tank	M6 x 1.0	5	0.5	3.6	
Front bumper and frame	M8 x 1.25	23	2.3	17	
Rear bumper and frame	M8 x 1.25	23	2.3	17	
Tensioner (drive chain) and frame	M8 x 1.25	20	2.0	14	

NOTE:

Apply locking agent (LOCTITE®) to nuts threads.

1. Tighten the nut (inside) to 55 Nm (5.5 m · kg, 40 ft · lb) while holding the rear axle.
2. Hold the nut (inside) and tighten the nut (outside) to 190 Nm (19.0 m · kg, 140 ft · lb).
3. Hold the nut (outside) and tighten back the nut (inside) to 240 Nm (24.0 m · kg, 170 ft · lb).



ELECTRICAL

Model	YFA1 (W)
Voltage:	12V
Ignition System: Ignition Timing (B.T.D.C.) Advanced Timing (B.T.D.C.) Advancer Type	7° at 1,700 r/min 27° at 5,000 r/min Electrical Type
Ignition timing (B.T.D.C.) Engine Speed (x 1000 r/min) 7 ± 1.6° at 1,700 r/min 2,430 ± 370 r/min at 9° 3,640 ± 450 r/min at 23° 27 ± 3° at 5,000 r/min	
C.D.I.: Magneto Model/Manufacturer Pickup Coil Resistance (Lead Color) Source Coil Resistance (Lead Color) C.D.I. Unit Model/Manufacturer	F3FA/YAMAHA 280 ~ 420 Ω at 20°C (68°F) (Red-Gray) 310 ~ 400 Ω at 20°C (68°F) (Brown-Green) 3FA1/YAMAHA
Ignition Coil: Model/Manufacturer Minimum Spark Gap Primary Coil Resistance Secondary Coil Resistance	3FA1/YAMAHA 6.0 mm (0.24 in) 0.56 ~ 0.84 Ω at 20°C (68°F) 5.7 ~ 8.5kΩ at 20°C (68°F)
Spark Plug Cap: Type Resistance	Rubber Type 8 ~ 12kΩ at 20°C (68°F)
Charging System: Type Magneto Model/Manufacturer Charging Coil Resistance (Lead Color) Charging Current Day (Minimum) (Maximum) Night (Minimum) (Maximum)	A.C. Magneto Generator F3FA/YAMAHA 0.56 ~ 0.84 Ω at 20°C (68°F) (White-Black) 0.8A at 3,000 r/min 1.3A at 8,000 r/min 0.6A at 3,000 r/min 1.1A at 8,000 r/min




Model	YFA1 (W)
Lighting Coil Resistance (Lead Color)	0.32 ~ 0.48 Ω at 20°C (68°F) (Yellow-Black)
Lighting Voltage (Minimum)	12.0V at 3,000 r/min
(Maximum)	14.8V at 8,000 r/min
Rectifier/Regulator:	
Model/Manufacturer	TR31/MATSUSHITA
Regulator Type	Semi Conductor Short Circuit Type
No Load Regulated Voltage	14.0 ~ 15.0V
Rectifier Capacity	4.0A
Withstand Voltage	240V
Battery:	
Specified Gravity	1.280
Electric Starting System:	
Starter Motor	
Model/Manufacturer	3FA1/YAMAHA
Output	0.4kw
Armature Coil Resistance	0.016 ~ 0.024 Ω at 20°C (68°F)
Overall Length (Brush)	10.0 mm (0.39 in)
< Limit >	< 3.5 mm (0.14 in) >
Brush Spring Pressure	560 ~ 840 g
Commutator Diameter	22.0 mm (0.87 in)
< Wear Limit >	< 21.0 mm (0.83 in) >
Mica Undercut	1.5 mm (0.06 in)
Starter Relay	
Model/Manufacturer	MS5D-191/HITACHI
Amperage Rating	100A
Coil Resistance	3.87 ~ 4.73 Ω at 20°C (68°F)
Starting Circuit Cut Off Relay	
Model/Manufacturer	ACA1211-9/MATSUSHITA
Coil Resistance	72 ~ 88 Ω at 20°C (68°F)
Diode	Yes
Circuit Breaker:	
Type	Fuse
Amperage for Individual Circuit	
Main	5A

GENERAL TORQUE SPECIFICATIONS

This chart specifies torque for standard fasteners with standard I.S.O. pitch threads. Torque specifications for special components or assemblies are included in the applicable sections of this book. To avoid warpage, tighten multifastener assemblies in a crisscross fashion, in progressive stages, until full torque is reached. Unless otherwise specified, torque specifications call for clean, dry threads. Components should be at room temperature.

A (Nut)	B (Bolt)	General torque specifications		
		Nm	m·kg	ft·lb
10mm	6mm	6	0.6	4.3
12mm	8mm	15	1.5	11
14mm	10mm	30	3.0	22
17mm	12mm	55	5.5	40
19mm	14mm	85	8.5	61
22mm	16mm	130	13.0	94



A: Distance across flats
B: Outside thread diameter

DEFINITION OF UNITS


Unit	Read	Definition	Measure
mm	millimeter	10^{-3} meter	Length
cm	centimeter	10^{-2} meter	Length
kg	kilogram	10^3 gram	Weight
N	Newton	$1 \text{ kg} \times \text{m/sec}^2$	Force
Nm	Newton meter	$\text{N} \times \text{m}$	Torque
m·kg	Meter kilogram	$\text{m} \times \text{kg}$	Torque
Pa	Pascal	N/m^2	Pressure
N/mn	Newton per millimeter	N/mn	Spring rate
L	Liter	—	Volume or Capacity
cm^3	Cubic centimeter	—	
r/min	Rotation per minute	—	Engine Speed

LUBRICATION POINTS AND LUBRICANT TYPE

ENGINE


Lubrication Points	Lubricant Type
Bearing retainer (all)	
Oil seal lips (all)	
O-rings (all)	
Valve stem and valve guide	
Oil seal (valve stem end)	
Rocker arm shaft and rocker arm	
Cam (camshaft)	
Crank pin	
Piston, piston rings and piston pin	
Rotor and rotor housing (oil pump)	
Weights (primary sliding sheave)	
Torque cams (secondary sliding sheave) and grooves	
O-rings (secondary sliding sheave)	BEL-LAY Assembly Lube®
Oil seals (secondary sliding sheave)	BEL-LAY Assembly Lube®
Ball (shift cam stopper)	
Guide bar (shift fork)	
Crankcase mating surfaces	Sealant (Quick Gasket)® Yamaha Bond No. 4

CHASSIS

Lubrication Points	Lubricant Type
Oil seal lips (all)	
O-rings (all)	
Pivoting points (steering knuckle)	
Cam shafts (front brake)	
Pivoting points (front arm)	
Bushes (steering column)	
Brake cable ends (at lever side)	
Throttle cable end (at lever side)	
Cam shafts (rear brake)	
Pivoting points (swingarm)	
Shaft (rear shock absorber — lower)	



LUBRICATION DIAGRAM





2



CABLE ROUTING

- ① Throttle cable
- ② Front brake cable
- ③ Rear brake cable
- ④ Brake switch lead
- ⑤ Band
- ⑥ Breather hose
- ⑦ Handlebar switch lead
- ⑧ Main switch
- ⑨ CDI unit

- A Pass leads in front of the brake cable and connect them inside the headlight body.
- B Pass the brake cables through the cable guide.
- C Pass the inlet and outlet hoses between the brake cables.






- ① Throttle cable
- ② Ignition coil
- ③ Breather hose (transmission case)
- ④ Starter relay
- ⑤ Fuse holder
- ⑥ Starting circuit cut-off relay
- ⑦ Reverse relay
- ⑧ Taillight
- ⑨ Battery breather hose

- ⑩ Over flow hose
- ⑪ Shift lever switch
- ⑫ Neutral switch lead
- ⑬ Clamp
- ⑭ Band
- ⑮ CDI magneto lead
- ⑯ Starting motor
- ⑰ Rectifier/regulator


- A Pass the breather hose through the guides.
- B Pass the over flow hose between the engine and swing arm.
- C Hold the clamp and ground lead to the crankcase with a screw.





- ① Front brake cable (right)
- ② Front brake cable (left)
- ③ Rear brake cable
- ④ Over flow hose
- ⑤ Breather hose (crankcase)
- ⑥ Fuel hose
- ⑦ Outlet hose
- ⑧ Inlet hose
- ⑨ Guide


- A Pass the brake cable inside the swingarm.
- B Pass the over flow hose left side of the engine stay.
- C Pass the breather hose through the hole of handlebar cover and then between the steering column and fuel tank.





- ① CDI unit
- ② Starter cable
- ③ Throttle cable
- ④ Breather hose (crankcase)
- ⑤ Battery negative lead
- ⑥ Battery positive lead
- ⑦ Ignition coil
- ⑧ Band

- A Pass the breather hose between the throttle cable and starter cable.



PERIODIC INSPECTION AND ADJUSTMENT

INTRODUCTION

This chapter includes all information necessary to perform recommended inspections and adjustments. These preventive maintenance procedures, if followed, will ensure more reliable vehicle operation and a longer service life. The need for costly overhaul work will be greatly reduced. This information applies to vehicles already in service as well as new vehicles that are being prepared for sale. All service technicians should be familiar with this entire chapter.

PERIODIC MAINTENANCE/LUBRICATION INTERVALS

Item	Remarks	Initial			Every	
		1 month	3 months	6 months	6 months	1 year
Valve(s) *	Check valve clearance. Adjust if necessary.	○		○	○	○
Spark plug(s)	Check condition. Clean or replace if necessary.	○	○	○	○	○
Air filter element (for engine and V-belt compartment)	Clean. Replace if necessary.		○	○	○	○
Carburetor *	Check idle speed/starter operation. Adjust if necessary.		○	○	○	○
Fuel line *	Check fuel hose for cracks or damage. Replace if necessary.			○	○	○
Engine oil	Replace (Warm engine before draining).	○		○	○	○
Oil strainer *	Clean. Replace if necessary.	○				○
Transmission oil	Check oil leakage. Replace every 12 months.	○				○
Brake *	Check operation. Adjust if necessary.	○	○	○	○	○
V-belt *	Check operation/replace if damage or excessive wear.	○				○
Wheels *	Check balance/damage/runout. Repair if necessary.	○		○	○	○
Wheel bearings *	Check bearings assembly for looseness/damage. Replace if damaged.	○		○	○	○
Steering system *	Check operation/replace if damage. Check toe-in/adjust if necessary.	○	○	○	○	○
Knuckle shafts *	Lubricate every 6 months. ***			○	○	○
Fittings/Fasteners *	Check all chassis fittings and fasteners. Correct if necessary.	○	○	○	○	○
Battery *	Check specific gravity. Check breather pipe for proper operation. Correct if necessary.	○	○	○	○	○

* It is recommended that these items be serviced by a Yamaha dealer.

*** Lithium soap base grease.




FENDERS

REMOVAL


1. Remove:
 - Seat

NOTE:

Pull the lock lever ① backward, then pull up the seat at the rear.




2. Disconnect:
 - Breather hose ① (fuel tank)
3. Remove:
 - Tank cap ②




4. Remove:
 - Cover ① (center)

NOTE:

Put on the fuel tank cap after removing the cover (center) to prevent dust, mud, etc. from entering the fuel tank.




5. Remove:
 - Cover ① (front)




6. Disconnect:
 - Inlet hose ① (air duct)
 - Outlet hose ② (air duct)

NOTE:

Cover the holes of the air duct with a clean rag after disconnecting the hoses to prevent dust, mud, etc. from entering the V-belt compartment.




7. Remove:
- Front fender ①




8. Remove:
- Battery band ①
9. Disconnect:
- Battery positive lead ②
 - Battery negative lead ③
 - Breather hose ④

CAUTION:


Disconnect the negative lead first, and then disconnect the positive lead.



10. Remove:
- Battery ①
 - Battery seat ②




11. Loosen:
- Screw ① (carburetor joint)
12. Disconnect:
- Breather hose ② (crankcase)



13. Remove:
- Rear fender ①

NOTE:

Cover the carburetor with a clean rug after disconnecting carburetor joint to prevent dust, mud, etc. from entering the carburetor.

**INSTALLATION**

Reverse the "REMOVAL" procedure. Note the following points.

1. Install:
 - Rear fender

NOTE:

Pass the battery positive lead and battery negative lead through the holes of the rear fender.

2. Install:
 - Battery


CAUTION:

- Connect the positive lead first, and then connect the negative lead.
- Make sure that the battery leads are connected properly. Reversing leads can seriously damage the electrical system.

3. Connect:
 - Inlet hose (air duct)
 - Outlet hose (air duct)

NOTE:

- Pass through the both hoses inside the frame. Refer to the "CABLE ROUTING" section in the CHAPTER 2.
- Align the notch ① of the hose with the projection ② of the air duct.




Screw (clamp):
7 Nm (0.7 m · kg, 5.1 ft. · lb)

4. Install:
 - Seat

NOTE:

Insert the lobes of the seat front into the receptacles of the frame, then push down the seat at the rear.



ENGINE

VALVE CLEARANCE ADJUSTMENT


NOTE:

- The valve clearance should be adjusted when the engine is cool to the touch.
- Check and adjust the valve clearance when the piston is at Top Dead Center (T.D.C.) on compression stroke.

1. Remove:


- Seat
- Cover (front)
- Cover (center)
- Front fender

Refer to the "FENDERS" section for removal.




2. Remove:

- Foot board ① (right)




3. Remove:

- Plug ①
- Plug ②



4. Remove:

- Tappet cover ① (intake)
- Tappet cover ② (exhaust)



5. Check:

- Valve clearance
- Out of specification → Adjust.




Valve clearance (cold):

Intake valve

0.08 ~ 0.12 mm (0.003 ~ 0.005 in)

Exhaust valve

0.10 ~ 0.14 mm (0.004 ~ 0.006 in)





Checking steps:

- Turn the crankshaft counterclockwise with a wrench.
- Align the TDC mark ① with the stationary pointer ②.
- Measure the valve clearance by using a feeler gauge.

6. Adjust:

- Valve clearance



Adjustment steps:

- Loosen the locknut ①.
- Insert the feeler gauge ② between the adjuster end and the valve end.
- Turn the adjuster ③ in or out with the Valve adjusting tool ④ until specified clearance is obtained.

Turning in	Valve clearance is decreased.
Turning out	Valve clearance is increased.



Valve adjusting tool:

P/N YM-08035, 90890-01311


- Hold the adjuster to prevent it from moving and thoroughly tighten the locknut.



Locknut:


7 Nm (0.7 m · kg, 5.1 ft · lb)

- Measure the valve clearance.
- If the valve clearance is incorrect, repeat above steps until the specified clearance is obtained.




7. Install:

- Tappet cover ① (intake)
- Tappet cover ② (exhaust)



8. Install:

- Plug ①
- Plug ②



9. Install:

- Foot board ① (right)

10. Install:

- Front fender
- Cover (center)
- Cover (front)
- Seat

Refer to the "FENDERS" section for installation.

TIMING CHAIN ADJUSTMENT

Adjustment free.

3

IDLING SPEED ADJUSTMENT

1. Start the engine and let it warm up for several minutes.
2. Attach:
 - Inductive tachometer
(to the spark plug lead)



Inductive tachometer:
 P/N YU-08036, 90890-03113

3. Check:
 - Engine idling speed
Out of specification → Adjust.



Engine idling speed:
 1,650 ~ 1,750 r/min

4. Adjust:
 - Engine idling speed

Adjustment steps:

- Turn in the pilot screw ① until it is lightly seated.
- Turn out the pilot screw for the specified number of turns.

Pilot screw:
2 and 1/2 turns out



- Turn the throttle stop screw ② in or out until specified idling speed is obtained.

Turning in	Idling speed becomes higher.
Turning out	Idling speed becomes lower.

5. Adjust:
 - Throttle cable free play
Refer to the "THROTTLE CABLE FREE PLAY ADJUSTMENT" section.



Free play:
 1.0 ~ 4.0 mm (0.04 ~ 0.16 in)






THROTTLE CABLE FREE PLAY ADJUSTMENT

NOTE:

Engine idling speed should be adjusted properly,
before adjusting the throttle cable free play.




1. Check:

- Throttle cable free play (a)
Out of specification → Adjust.



Throttle cable free play:
1.0 ~ 4.0 mm (0.04 ~ 0.16 in)
at throttle lever end.

3



2. Adjust:

- Throttle cable free play

Adjustment Steps:

- Loosen the locknut (1).
- Turn the adjuster (2) in or out until the specified free play is obtained.

Turning in	Free play is increased.
Turning out	Free play is decreased.

- Tighten the locknut.

⚠ WARNING:

After adjusting, turn the handlebar to right and left and make sure that the engine idling does not run faster.

SPARK PLUG INSPECTION

1. Remove:

- Spark plug


2. Inspect:

- Spark plug type
Incorrect → Replace.

Standard spark plug:

**C7HSA (NGK), U22FS-U (ND) (USA,
AUS), CR7HS (NGK) (CDN, CH, F, NL,
S, DK)**

IGNITION TIMING CHECK




3. Inspect:

- Electrode ①
Wear/Damage → Replace.
- Insulator ②
Abnormal color → Replace.
Normal color is a medium-to-light tan color.

4. Clean the spark plug with a spark plug cleaner or a wire brush.


5. Measure:

- Plug gap (a)
Use a wire gauge or feeler gauge.
Out of specification → Replace.



6. Tighten:

- Spark plug



NOTE:

- Before installing a spark plug, clean the gasket surface and plug surface.
- If a torque wrench is not available when you are installing a spark plug, a good estimate of the correct torque is 1/4 to 1/2 turns part finger tight. Have the spark plug torqued to the correct value as soon as possible with a torque wrench.


IGNITION TIMING CHECK

NOTE:


Engine idling speed and throttle cable free play should be adjusted properly before checking the ignition timing.

IGNITION TIMING CHECK

INSP
ADJ




1. Remove:
 - Foot board ① (right)



2. Remove:
 - Plug ①
3. Attach:
 - Timing light
 - Inductive tachometer (to the spark plug lead).



Timing light:
P/N YM-33277, 90890-03109
Inductive tachometer:
P/N YU-08036, 90890-03113



4. Check:
 - Ignition timing

Checking steps:

- Warm up the engine and keep it at the specified speed.



Engine speed:
1,650 ~ 1,750 r/min

- Visually check the stationary pointer ① to verify it is within the required firing range ② indicated on the flywheel.
Incorrect firing range → check flywheel and/or pickup assembly (tightness damage).

5. Install:
 - Plug
 - Foot board (right)

3

COMPRESSION PRESSURE MEASUREMENT


NOTE: _____
Insufficient compression pressure will result in performance loss.

1. Check:
 - Valve clearance
Out of specification → Adjust.
Refer to the "VALVE CLEARANCE ADJUSTMENT" section.
2. Start the engine and let it warm up for several minutes.
3. Stop the engine.
4. Remove:
 - Spark plug

5. Attach:
 - Compression gauge ①



Compression gauge:
P/N YU-33223, 90890-03081



6. Measure
 - Compression pressure

Above the maximum pressure → Inspect cylinder head, valve surfaces, and piston crown for carbon deposits.

Below the minimum pressure → Squirt a few drops of oil into affected cylinder and cylinder and measure again.
Follow the table below.



Compression pressure (with oil introduced into cylinder)	
Reading	Diagnosis
Higher than without oil	Worn or damaged piston
Same as without oil	Defective ring(s), valves, cylinder head gasket or piston is possible.

Compression pressure (at sea level):
850 kPa (8.5 kg/cm² , 120 psi)


Measurement steps:

- Crank over the engine with the throttle wide-open until the compression reading on the gauge stabilizes.

⚠ WARNING:

When cranking the engine, ground the spark plug lead to prevent from sparking.

3



ENGINE OIL LEVEL INSPECTION

1. Place the machine on a level surface.
2. Inspect:


• Oil level

Oil level should be between maximum ① and minimum ② marks.

Oil level low → Add oil to proper level.

NOTE:

Do not screw the dipstick ③ . Insert the dipstick lightly when inspecting the oil level.



Recommended oil:
Follow the left chart.

NOTE:

For USA only.

Recommended oil classification:

API Service "SE", "SF" type or equivalent (e.g. "SF-SE", "SF-SE-CC", "SF-SE-SD" etc).

⚠ CAUTION:

Do not allow foreign material to enter the crankcase.

3. Start the engine and let it warm up for several minutes.
4. Stop the engine and inspect the oil level once again.

NOTE:


Wait a few minutes until level settles before inspecting the oil level.

⚠ WARNING:

Never attempt to remove the dipstick just after high speed operation. The heated oil could spout out, causing danger. Wait until the oil cools down.

ENGINE OIL REPLACEMENT

1. Start the engine and let it warm up for several minutes.
2. Stop the engine and place an oil pan under the engine.

**3. Remove:**

- Dipstick
- Drain plug ①
- O-ring ②
- Compression spring ③
- Oil strainer ④

Drain the crankcase of its oil.

⚠ CAUTION:

When removing the drain plug, the compression spring, oil strainer, and o-ring will fall off. Take care not to lose these parts.

4. Inspect:

- Oil strainer
 - O-ring
- Damage → Replace.

5. Install:

- Oil strainer
- Compression spring
- O-ring
- Drain plug



Drain plug:
32 Nm (3.2 m · kg, 23 ft · lb)

3



6. Fill:

- Crankcase



Oil quantity:
1.25 L (1.10 imp qt, 1.32 usqt)

Refer to the "ENGINE OIL LEVEL INSPECTION" section.



TRANSMISSION OIL LEVEL INSPECTION

- Place the machine on a level place.
- Remove:
 - Checking screw ①

3. Inspect:

- Oil level (a)
- Oil level should be up to bottom brim ① of hole.
- Oil level low → Add oil to proper level.



Recommended oil:
Yamalube 4 (10W30 or 20W40),
SAE 10W30 Type SE or SAE
20W40 Type SE

**NOTE:**

For USA only.

Recommended oil classification:

API Service "SE", "SF" type or equivalent (e.g. "SF-SE", "SF-SE-CC", "SF-SE-SD" etc).

CAUTION:

Do not allow foreign material to enter the transmission case.

WARNING:

Never attempt to remove the checking screw just after high speed operation. The heated oil could spout out, causing danger wait until the oil cools down.

4. Install:

- Checking screw
- Oil filler bolt



Checking screw :


16 Nm (1.6 m · kg, 11 ft · lb)

Oil filter bolt:

23 Nm (2.3 m · kg, 17 ft · lb)

NOTE:

Check the gasket (checking screw). If damaged, replace it with a new one.

**TRANSMISSION OIL REPLACEMENT**

1. Place an open pan under the transmission case.
2. Remove:
 - Oil filler bolt ①
 - Drain plug ②
 Drain the transmission case of its oil.
3. Install:
 - Drain plug



Drain plug:

23 Nm (2.3 m · kg, 17 ft · lb)

NOTE:

Check the gasket (drain plug). If damaged, replace it with a new one.

4. Fill

- Transmission case



Oil quantity:
0.60 L (0.53 imp qt, 0.63 us qt)

Refer to the "TRANSMISSION OIL LEVEL INSPECTION" section.


5. Install:

- Oil filler bolt



Oil filler bolt:
23 Nm (2.3 m · kg, 17 ft · lb)

3




AIR FILTER CLEANING

For Engine:

NOTE:

There is a check hose ① at the bottom of the air filter case. If dust and/or water collects in this hose, clean the air filter element and air filter case.




1. Remove:

- Seat

Refer to the "FENDERS" section for removal.

2. Disconnect:

- Breather hose ① (crankcase)




3. Loosen:

- Screw ① (carburetor joint)

4. Remove:

- Cover ② (air filter case)

3



5. Remove:

- Air filter element ①
- Element guide ②

NOTE:


Each time filter element maintenance is performed, check the air inlet to the filter case for obstructions. Check the air cleaner joint rubber to the carburetor and manifold fittings for an air-tight seal. Tighten all fittings thoroughly to avoid the possibility of unfiltered air entering the engine.

⚠ CAUTION:

Never operate the engine with the air filter element removed. This will allow unfiltered air to enter, causing rapid wear and possible engine damage. Additionally, operation without the filter element will affect carburetor jetting with subsequent poor performance and possible engine overheating.

6. Inspect:

- Air filter element
- Damage → Replace.



7. Clean:

- Air filter element

Cleaning steps:

- Wash the element gently, but thoroughly in solvent ①.

⚠ WARNING:

Use parts cleaning solvent only. Never use gasoline or low flash point solvents which may lead to a fire or explosion.


- Squeeze the excess solvent out of the element and let dry.

⚠ CAUTION:

Do not twist or wring out the foam element. This could damage the foam material.

- Apply the engine oil ②.
- Squeeze out the excess oil.

NOTE: _____
The element should be wet but not dripping.



8. Install:
- Element guide
 - Air filter element

CAUTION: _____

Install the washer ① with its bent fringe upward as shown.



Screw (air filter element):
7 Nm (0.7 m · kg, 5.1 ft · lb)

9. Install:
- Cover (air filter case)



Screw (cover):
4 Nm (0.4 m · kg, 2.9 ft · lb)


10. Tighten:
- Screw (carburetor joint)
11. Connect:
- Breather hose (crankcase)
12. Install:
- Seat
- Refer to the "FENDER" section for installation.

For V-Belt Compartment:

1. Remove:
- Cover (front)

Refer to the "FENDERS" section for removal.

CARBURETOR JOINT INSPECTION/ FUEL LINE INSPECTION




2. Remove:
 - Cover ① (air filter case)
 - Air filter element ②
3. Inspect:
 - Air filter element
 - Damage → Replace.

4. Clean:
 - Air filter element

Cleaning steps:


- Tap the element lightly to remove most of the dust and dirt.
- Blow out the remaining dirt with compressed air.

5. Install:
 - Air filter element
 - Cover (air filter case)
6. Install:
 - Cover (front)



CARBURETOR JOINT INSPECTION

1. Inspect:
 - Carburetor joint ①
 - Crack/Damage → Replace.
 - Refer to the "CARBURETOR" section in the CHAPTER 5 for replacement.



FUEL LINE INSPECTION

1. Inspect:
 - Fuel hose ①
 - Crack/Damage → Replace.




CRANKCASE BREATHER HOSE INSPECTION

1. Remove:

- Seat
- Cover (center)
- Cover (front)
- Front fender

Refer to the "FENDERS" section for removal.



2. Inspect:

- Crankcase breather hose ①
- Crack/Damage → Replace

3. Install:

- Front fender
- Cover (front)
- Cover (center)
- Seat

3

EXHAUST SYSTEM INSPECTION


1. Remove:

- Seat
- Cover (center)
- Cover (front)
- Front fender
- Rear fender

Refer to the "FENDERS" section for removal.

2. Inspect:

- Muffler
- Cracks/Damage → Replace.
- Gasket
- Exhaust gas leaks → Replace.



Nut ① (exhaust pipe):
10 Nm (1.0 m · kg, 7.2 ft · lb)

Bolt ② (muffler):
27 Nm (2.7 m · kg, 19 ft · lb)

3. Install:

- Rear fender
- Front fender
- Cover (front)
- Cover (center)
- Seat

V-BELT INSPECTION


1. Remove:

- Seat
- Cover (center)
- Cover (front)
- Front fender

Refer to the "FENDERS" section for removal.


2. Remove:

- Foot board ① (left)




3. Remove:

- Bracket ① (foot board)




4. Remove:


- Air duct ①
- Crankcase cover ② (left)



5. Inspect:

- V-belt ①
Crack/Wear/Scaling/Chipping → Replace.
Oil or grease adhered to the V-belt → Check the primary and secondary sheaves. Refer to the "INSPECTION AND REPAIR" section in the CHAPTER 4.





6. Measure:

- V-belt width (a)
Out of specification → Replace.



V-belt width:
20.1 mm (0.791 in)
< Wear limit >:
< 18.1 mm (0.712 in) >

7. Install:

- Crankcase cover (left)
- Air duct
- Bracket (foot board)





Bolt (crankcase cover):
7 Nm (0.7 m · kg, 5.1 ft · lb)
Bolt (air duct):
7 Nm (0.7 m · kg, 5.1 ft · lb)
Bolt (bracket):
33 Nm (3.3 m · kg, 24 ft · lb)

8. Install:

- Front fender
- Cover (fender)
- Cover (center)
- Seat

3



CHASSIS

FRONT BRAKE ADJUSTMENT

1. Check:

- Brake lever free play (a)
Out of specification → Adjust.



Free play:
10 ~ 12 mm (0.4 ~ 0.5 in)
at brake lever pivot.


2. Adjust:

- Brake lever free play

Adjustment steps:

- Loosen the locknuts ①.
- Turn the adjusters ② in or out until the specified free play is obtained.

REAR BRAKE ADJUSTMENT



Turning in	Free play is increased.
------------	-------------------------

Turning out	Free play is decreased.
-------------	-------------------------

NOTE:


The difference between both clearances (① and ②) should be 2 mm (0.08 in) or less when front brake is applied.

- Tighten the locknuts.

⚠ CAUTION:

Make sure that the brake does not drag after adjusting.

3




REAR BRAKE ADJUSTMENT

1. Check:

- Brake lever free play ①
Out of specification → Adjust.



Free play:
5 ~ 8 mm (0.2 ~ 0.3 in)
at brake lever pivot.



2. Adjust:

- Brake lever free play

Adjustment steps:

- Turn the adjuster ① in or out until the specified free play is obtained.

Turning in	Free play is decreased.
------------	-------------------------



Turning out	Free play is increased.
-------------	-------------------------

⚠ CAUTION:

Make sure that the brake does not drag after adjusting.

BRAKE SHOE INSPECTION/ DRIVE'CHAIN SLACK ADJUSTMENT

INSP
ADJ



BRAKE SHOE INSPECTION

1. Apply the brake (front brake or rear brake).
2. Inspect:
 - Brake shoeWear indicator ① reaches the wear limit line ② → Replace shoes as a set.

A Front brake

B Rear brake

3

DRIVE CHAIN SLACK ADJUSTMENT

NOTE: _____

Before checking and/or adjusting, rotate the rear wheels several revolutions and check slack at several points to find the tightest point. Check and/or adjust the chain slack with the rear wheels in this "tightest" position.

CAUTION: _____

Too little of chain slack will overload the engine and other vital parts; keep the slack within the specified limits.


1. Place the machine on a level place.

NOTE: _____

Wheels should be on the ground without the rider on it.


2. Check:

- Drive chain slack (a)
- Out of specification → Adjust.




Drive chain slack:
Approximately 30 mm (1.18 in)

DRIVE CHAIN SLACK ADJUSTMENT



3. Loosen:

- Locknut ① (hub locknut)
- Hub lockbolt ②
- Bolt ③ (hub)



4. Adjust:

- Drive chain slack

Adjustment steps:

- Loosen the locknut ① (adjuster).
- Turn the adjuster ② in or out until the specified slack is obtained.

Turning in	Slack is decreased.
------------	---------------------

Turning out	Slack is increased.
-------------	---------------------

⚠ CAUTION:

If the adjuster measures less than 27 mm (1.06 in), replace the drive chain and both sprockets.

- Tighten the bolts (hub) to the specification, while pushing up or down on the chain to zero slack.



Bolt (hub):

Upper

85 Nm (8.5 m · kg, 61 ft · lb)

Lower

60 Nm (6.0 m · kg, 43 ft · lb)

- Tighten the locknut (adjuster).



Locknut (adjuster):

16 Nm (1.6 m · kg, 11 ft · lb)

5. Tighten:


- Locknut (hub lockbolt)



Locknut (hub lockbolt):

16 Nm (1.6 m · kg, 11 ft · lb)

3



DRIVE CHAIN LUBRICATION



The chain consists of many parts which work against each other. If the chain is not maintained properly, it will wear out rapidly, therefore, from the habit of periodically servicing the chain. This service is especially necessary when riding in dusty conditions.

This machine has a drive chain with small rubber O-rings between the chain plates. Steam cleaning, high-pressure washes, and certain solvents can damage these O-rings. Use only kerosene to clean the drive chain. Wipe it dry, and thoroughly lubricate it with SAE 30 ~ 50W motor oil. Do not use any other lubricants on the drive chain. They may contain solvents that could damage the O-rings.




Recommended lubricant:
SAE 30 ~ 50 Motor Oil

3





STEERING SYSTEM INSPECTION

1. Place the machine on a level place.
2. Check:
 - Steering column bushings and bearings
Move the handlebar up and down, and/or back and forth.
Excessive play → Replace the steering column bushings and or bearings.
Refer to the "STEERING SYSTEM" section in the CHAPTER 6.
3. Check:
 - Tie-rod ends
Turn the handlebar to the left and/or right until it stops completely, then slightly move the handlebar from left to right.
Tie-rod end ① has any vertical play → Replace the tie-rod end(s).
Refer to the "STEERING SYSTEM" section in the CHAPTER 6.



4. Raise the front end of the machine so that there is no weight on the front wheels.
5. Check:
 - Ball joints and/or wheel bearings
Move the wheels laterally back and forth. Excessive free play → Replace the front arms and/or wheel bearings.
 Refer to the "FRONT SUSPENSION" and "FRONT WHEEL" section in the CHAPTER 6.

3



TOE-IN ADJUSTMENT

1. Place the machine on a level place.
2. Measure:
 - Toe-in
Out of specification → Adjust.

Toe-in measurement steps:


- Mark both front tire tread centers.
- Raise the front end of the machine so that there is no weight on the front tires.
- Fix the handlebar straight ahead.
- Measure the width **A** between the marks.
- Rotate the front tires 180 degrees until the marks come exactly opposite.
- Measure the width **B** between the marks.
- Calculate the toe-in using the formula given below.

$$\text{Toe-in} = \text{B} - \text{A}$$



Toe-in:
0 ~ 10 mm (0 ~ 0.39 in)

- If the toe-in is incorrect, adjust the toe-in.



3. Adjust:

- Toe-in

Adjustment steps:

- Mark both tie-rod ends.
This reference point will be needed during adjustment.
- Loosen the locknuts (tie-rod end) ① of both tie-rods.
- The same number of turns should be given to both tie-rods ② right and left until the specified toe-in is obtained, so that the lengths of the rods will be kept the same.
- Tighten the rod end locknuts of both tie-rods.



Locknut (rod end):
30 Nm (3.0 m · kg, 22 ft · lb)

⚠ WARNING:

- Be sure that both tie-rods are turned the same amount. If not, the machine will drift right or left even though the handlebar is positioned straight which may lead to mis-handling and accident.
- After setting the toe-in to specification, run the machine slowly for some distance with hands placed lightly on the handlebar and check that the handlebar responds correctly. If not, turn either the right or left tie-rod within the toe-in specification.

3

TIRE INSPECTION

⚠ WARNING:

This model is equipped with low pressure tires. It is important that they be inflated correctly and maintained at the proper pressures.

• TIRE CHARACTERISTICS

- 1) Tire characteristics influence the handling of ATV's. The tires listed below have been approved by Yamaha Motor Co., Ltd. for this model. If other tire combinations are used, they can adversely affect your machine's handling characteristics and are therefore not recommended.


	Manufacturer	Size	Type
Front	Dunlop	AT20 x 7-8	KT536
Rear	Dunlop	AT22 x 10-8	KT537

• TIRE PRESSURE

- 1) Recommend tire pressure
 Front 20 kPa (0.20 kg/cm², 2.8 psi)
 Rear 25 kPa (0.25 kg/cm², 3.6 psi)
- 2) Tire pressure below the minimum specified could cause the tire to dislodge from the rim under severe riding conditions.
 The following are minimums:
 Front 17 kPa (0.17 kg/cm², 2.4 psi)
 Rear 22 kPa (0.22 kg/cm², 3.1 psi)
- 3) Use no more than
 Front 250 kPa (2.5 kg/cm², 36 psi)
 Rear 250 kPa (2.5 kg/cm², 36 psi)
 When seating the tire beads. Higher pressures may cause the tire to burst.
 Inflate the tires very slowly and carefully.
 Fast inflation could cause the tire to burst.

1. Measure:

- Tire pressure (cold tire pressure)
 Out of specification → Adjust.

**NOTE:**

The low-pressure tire gauge ① is included in the standard equipment.

If dust or the like is stuck to this gauge, it does not provide correct readings. Therefore, make two measurements on the tire pressure and get the second reading.

Cold tire pressure	Front	Rear
Standard	20 kPa (0.2 kg/cm ² , 2.8 psi)	25 kPa (0.25 kg/cm ² , 3.6 psi)
Minimum	17 kPa (0.17 kg/cm ² , 2.4 psi)	22 kPa (0.22 kg/cm ² , 3.1 psi)
Maximum	23 kPa (0.23 kg/cm ² , 3.2 psi)	28 kPa (0.28 kg/cm ² , 4.0 psi)

⚠ WARNING:

Uneven or improper tire pressure may adversely affect the handling of this machine and may cause loss of control.

- Maintain proper tire pressures.
- Set tire pressures when the tires are cold.
- Tire pressures must be equal in both front tires and equal in both rear tires.

2. Inspect:


- Tire surfaces
Wear/Damage → Replace.



Tire wear limit ②:
Front and rear: 3.0 mm (0.12 in)

⚠ WARNING:

It is dangerous to ride with a wornout tire. When a tire wear is out of specification, replace the tire immediately.



WHEEL INSPECTION

1. Inspect:

- Wheels

Damage/Bends → Replace.

NOTE: _____

Always balance the wheel when a tire or wheel has been changed or replaced.

⚠ WARNING: _____

- Never attempt even small repairs to the wheel.
- Ride conservatively after installing a tire to allow it to seat itself properly on the rim.

3

CABLE INSPECTION AND LUBRICATION

⚠ WARNING: _____

Damaged cable sheath may cause corrosion and interfere with the cable movement. An unsafe condition may result so replace such cable as soon as possible.

1. Inspect:

- Cable sheath

Damage → Replace.

2. Check:

- Cable operation

Unsmooth operation → Lubricate or replace.



Recommended lubricant:
SAE 10W30 Motor Oil

NOTE: _____

Hold cable end high and apply several drops of lubricant to cable.

3. Apply:

- Lithium soap base grease
(onto end of the cable)







LEVER LUBRICATION

1. Lubricate the pivoting parts of each lever.



Recommended lubricant:
SAE 10W30 Motor Oil



FRONT SUSPENSION LUBRICATION

1. Inject grease into the nipples ① using a grease gun until slight over flow is observed from the thrust covers.



Lightweight lithium-soap
base grease

3

NOTE:

Wipe off the excess grease.

STEERING COLUMN LUBRICATION

1. Inject grease into the nipple ① using a grease gun.



Lightweight lithium-soap
base grease

NOTE:

Wipe off the excess grease.

REAR SUSPENSION LUBRICATION

1. Inject grease into the nipple ① using a grease gun.



Lightweight lithium-soap
base grease

NOTE:


Wipe off the excess grease.

ELECTRICAL**BATTERY INSPECTION**

1. Remove:

- Seat

Refer to the "FENDERS" section for removal.



2. Inspect:

- Fluid level

Fluid level should be between upper ① and lower ② level marks.

Incorrect → Refill.

⚠ CAUTION:

Refill with distilled water only; tap water contains minerals harmful to a battery.

3. Inspect:

- Battery terminal

Dirty terminal → Clean with wire brush.

Poor connection → Correct.

NOTE:

After cleaning the terminals, apply grease lightly to the terminals.

4. Inspect:


- Breather hose

Obstruction → Remove.

Damage → Replace.

⚠ CAUTION:


When inspecting the battery, be sure the breather hose is routed correctly. If the breather hose touches the frame or exits in such a way as to cause battery electrolyte or gas to exit onto the frame, structural and cosmetic damage to the machine can occur.



5. Connect:

- Breather hose ①

Be sure the hose is properly attached and routed.



6. Check:

- Specific gravity

Less than 1.280 → Recharge battery.

Charging current: 1.2 amps/10 hrs
Specific gravity: 1.280 at 20° C (68° F)

Replace the battery if:

- Battery voltage will not rise to a specific value or bubbles fail to rise even after many hours of charging.
- Sulfation of one or more cells occurs, as indicated by the plates turning white, or an accumulation of material exists in the bottom of the cell.
- Specific gravity readings after a long, slow charge indicate one cell to be lower than the rest.
- Warpage or buckling of plates or insulators is evident.

⚠ CAUTION:

Always charge a new battery before using it to ensure maximum performance.

**⚠ WARNING:**

Battery electrolyte is dangerous; it contains sulfuric acid and therefore is poisonous and highly caustic.

Always follow these preventive measures:

- Avoid bodily contact with electrolyte as it can cause severe burns or permanent eye injury.
- Wear protective eye gear when handling or working near batteries.

Antidote (EXTERNAL):

- SKIN – Flush with water.
- EYES – Flush with water for 15 minutes and get immediate medical attention.

Antidote (INTERNAL):

- Drink large quantities of water or milk follow with milk of magnesia, beaten egg, or vegetable oil. Get immediate medical attention.


Batteries also generate explosive hydrogen gas, therefore you should always follow these preventive measures:

- Charge batteries in a well-ventilated area.
- Keep batteries away from fire, sparks, or open flames (e.g., welding equipment, lighted cigarettes, etc.)
- DO NOT SMOKE When charging or handling batteries.

KEEP BATTERIES AND ELECTROLYTE OUT OF REACH OF CHILDREN.

7. Install:

- Seat




FUSE INSPECTION

⚠ CAUTION:

Don't forget to turn off the main switch when checking or replacing the fuse. Otherwise, it may cause accidental shortcircuiting.

1. Remove:

- Fuse ①



2. Inspect:

- Fuse

Inspection steps:

- Connect the pocket tester ($\Omega \times 1$) to the fuse and check it for continuity.



Pocket tester:

P/N YU-03113, 90890-03112

- If the tester is indicated at ∞ . The fuse is blown, replace it.

3

3. Replace:


- Blown fuse

Replacement steps:

- Turn off ignition.
- Install a new fuse of proper amperage.
- Turn on switches to verify operation of electrical device.
- If fuse blows immediately again, check electrical circuit.

⚠ WARNING:

Never use a fuse with a rating other than specified, or other material in place of a fuse. An improper fuse may cause damage to the electrical system and possibly cause a fire, or the lighting and/or ignition may cease to function.




HEADLIGHT BEAM ADJUSTMENT

1. Adjust:

- Headlight beam (vertical)


To raise the beam, loosen the adjusting screw ⑪ and pull it toward you. To lower the beam, push it away from you. After adjusting, retighten it.



HEADLIGHT BULB REPLACEMENT

1. Remove:

- Bolts ① (headlight unit)



2. Remove:

- Bulb holder ①
- Bulb

NOTE:

Turn the bulb holder counterclockwise and remove the defective bulb.

⚠ WARNING:

Keep flammable products and your hands away from the bulb while it is on, it will be hot. Do not touch the bulb until it cools down.

3. Install:

- Bulb (new)
- Secure the new bulb with the bulb holder.

⚠ CAUTION:

Avoid touching glass part of bulb. Also keep it free from oil otherwise, transparency of glass, bulb life and illuminous flux will be adversely affected. If oil gets on bulb, clean it with a cloth moistened thoroughly with alcohol or lacquer thinner.

4. Install:

- Bolt (headlight unit)



ENGINE OVERHAUL

ENGINE REMOVAL

NOTE: _____

It is not necessary to remove the engine in order to remove the following components:

- Cylinder head
 - Cylinder
 - Pinion/Piston ring
 - Camshaft/Rocker arm/Valve
 - Centrifugal clutch
 - Primary sheave
 - Secondary sheave
 - V-belt
 - Starter clutch
 - Oil pump
 - CDI magneto
-

ENGINE OIL

1. Drain:

- Engine oil

Refer to the "ENGINE OIL REPLACEMENT" section in the CHAPTER 3.

TRANSMISSION OIL

1. Drain:

- Transmission oil

Refer to the "TRANSMISSION OIL REPLACEMENT" section in the CHAPTER 3.

FENDERS

1. Remove:

- Seat
- Cover (front)
- Cover (center)
- Front fender
- Rear fender


Refer to the "FENDERS" section in the CHAPTER 3.

CARBURETOR

1. Remove:


- Carburetor

Refer to the "CARBURETOR — REMOVAL" section in the CHAPTER 5.

**MUFFLER**


1. Remove:

- Fuel tank ①




2. Remove:

- Air duct ①




3. Remove:


- Starter cable ① (with bracket)



4. Remove:


- Muffler ①



**STARTING MOTOR**


1. Remove:

- Starting motor ①

**LEADS AND HOSES**


1. Disconnect:

- CDI magneto leads ①




2. Disconnect:

- Neutral switch lead ①
- Select lever switch lead ②
- Ground lead ③




3. Disconnect:

- Breather hose ① (transmission case)

**ENGINE REMOVAL**

1. Apply:

- Parking brake




2. Straighten:

- Lock washer tab ①

3. Remove:


- Nut ②
- Lock washer ③
- Drive sprocket ④



4. Remove:


- Mounting bolt ① (front)
- Engine bracket ②

4



5. Remove:

- Mounting bolt ① (rear-lower)
- Mounting bolt ② (rear-upper)



6. Remove:

- Engine assembly
(to the right side of the machine)




ENGINE DISASSEMBLY

CYLINDER HEAD, CYLINDER AND PISTON

NOTE:

With the engine mounted, the cylinder head, cylinder, and piston can be maintained by removing the following parts.

- Seat
- Cover (front)
- Cover (center)
- Front fender
- Rear fender
- Muffler



1. Remove:


- Cylinder head cover ①
- Spark plug ②
- Tappet cover ③ (intake)
- Tappet cover ④ (exhaust)
- O-rings ⑤ (Tappet covers)
- O-ring ⑥ (Cylinder head cover)

2. Loosen:

- Plug ① (timing chain tensioner)


3. Remove:


- Timing chain tensioner ②



4. Remove:


- Plug ①
- Plug ②





5. Remove:


- Baffle plate ①



NOTE:

Loosen the bolt (baffle plate) while holding the nut (CDI magneto) with a wrench.

4




6. Remove:

- Cam sprocket ①

NOTE:

Fasten a safety wire ② to the timing chain to prevent it from falling into the crankcase.




7. Remove:

- Cylinder head ①
- Gasket ② (cylinder head)
- Dowel pins ③
- Chain guide ④ (exhaust)
- Cylinder ⑤
- Gasket ⑥ (cylinder)
- Dowel pins ⑦

NOTE:

Loosen each bolt 1/4 turn, and remove them after all bolts are loosened.



8. Remove:

- Piston pin clip ①
- Piston pin ②
- Piston ③
- Piston rings ④

NOTE:

- Before removing the piston pin circlip, cover the crankcase with a clean rag to prevent the circlip from falling into the crankcase cavity.
- Before removing the piston pin, deburr the clip grooved and pin hole area. If the piston pin groove is deburred and the piston pin is still difficult to remove, use Piston Pin Puller.



Piston Pin Puller:
P/N YU-01304, 90890-01304

⚠ CAUTION:

Do not use a hammer to drive the piston pin out.

4

PRIMARY SHEAVE AND SECONDARY SHEAVE


NOTE:


With the engine mounted, the primary sheave and secondary sheave can be maintained by removing the following parts.

- Seat
- Cover (front)
- Cover (center)
- Front fender
- Foot board (left)
- Bracket (foot board)

1. Remove:

- Crankcase cover ① (left)
- Dowel pins ②
- Gasket ③ (crankcase cover)






2. Remove:


- Primary fixed sheave ①
- Collar ②
- Primary sliding sheave ③
- V-belt ④

NOTE:

- Before loosening the nut (primary sheave), straighten the lock washer tab.
- Loosen the nut (primary sheave) while holding the nut (CDI Magneto) with a wrench.



4



3. Remove:


- Clutch housing ①
- Secondary sheave assembly (with clutch shoes) ②

NOTE:

Loosen the nut (clutch housing) while holding the clutch housing with the sheave holder ③.



Sheave holder:
P/N YS-01880, 90890-01701




4. Loosen:

- Nut ① (secondary sheave)

NOTE:

Loosen the nut (secondary sheave) by the locknut wrench ② while holding the clutch shoes with the sheave holder ③.






Sheave holder:
P/N YS-01880, 90890-01701

Locknut wrench:
P/N YM-4045-A, 90890-01348

CAUTION:

Do not remove the nut yet.





5. Remove:

- Clutch shoes ①
- Sliding sheave spring ②
- Spring seat ③
- Guide pins ④
- Collars ⑤
- Secondary sliding sheave ⑥
- Secondary fixed sheave ⑦

NOTE:

Before removing the nut (secondary sheave assembly), compress the sliding sheave spring with the spring holder ⑧ and then, remove the nut.




Spring holder:
P/N YS-28891, 90890-01337

ELECTRIC STARTING DRIVE

NOTE:


With the engine mounted, the starter clutch and gears can be maintained by removing the following parts.

- Seat
- Cover (center)
- Cover (front)
- Front fender
- Foot board (left)
- Bracket (foot board)
- Crankcase cover (left)
- Primary sheave
- V-belt



1. Remove:

- Starter idle gear ①
- Shaft ② (starter idle gear)
- Starter clutch ③
- Starter wheel gear ④


**SHIFT LEVER**

1. Move the shift lever to "N" position.

2. Remove:

- Bolts ① (shift lever guide)
- Shift lever ②

4




3. Remove:

- Shift lever switch ①
- Lever ②
- Torsion spring ③

CDI MAGNETO**NOTE:**


With the engine mounted, the CDI magneto can be maintained by removing the following parts.

- Seat
- Cover (front)
- Cover (center)
- Front fender




1. Remove:

- Crankcase cover ①
- Dowel pins ②
- Gasket ③



2. Remove:

- Nut ① (CDI magneto)
- Washer ②
- Collar ③
- Rotor ④ (CDI magneto)
- Starter assembly ⑤
- Woodruff key ⑥
- Gasket ⑦




NOTE:

Loosen the nut (CDI magneto) while holding the CDI rotor with the rotor holder ⑧.



Rotor holder:

P/N YU-01235, 90890-01235



NOTE:

Remove the rotor by the rotor puller ⑨.



Rotor puller:


P/N YU-33270, 90890-01362

OIL PUMP

NOTE:


With the engine mounted, the oil pump can be maintained by removing the following parts.

- Seat
- Cover (front)
- Cover (center)
- Front fender
- CDI magneto




1. Remove:

- Oil pump gear ①
- Oil pump ②
- Gasket ③ (oil pump)

**TIMING CHAIN**


1. Remove:

- Cover ①



2. Remove:

- Timing chain ①
- Chain guide ② (intake)
- O-rings ③

**CRANKCASE (RIGHT)**

1. Remove:


- Collar ①
- Chain cover ②



2. Remove:

- Crankcase (right)
- Dowel pins

NOTE:

Loosen each bolt 1/4 turn, and remove them after all bolts are loosened.



**Removal steps:**

- Attach the Crankcase separating tool ①.

**Crankcase separating tool:**

P/N YU-01135, 90890-01135

NOTE:

Fully tighten the tool holding bolts, but make sure the tool body is parallel with the case. If necessary, one screw may be backed out slightly to level tool body.

- As pressure is applied, alternately tap on the front engine mounting boss and drive axle. Then, remove the crankcase (right).


NOTE:

If the crankcase will not come off, use the lever guides ② for removal.


CAUTION:

- Be sure not to give damages to the mating surface.
- Use soft hammer to tap on the case half. Tap only on reinforced portions of case. Do not tap on gasket mating surface. Work slowly and carefully. Make sure the case halves separate evenly. If one end "hangs", take pressure off the push screw, realign, and start over. If the cases do not separate, check for a remaining case screw or fitting. Do not force.

4


**SHIFTER AND TRANSMISSION****1. Remove:**

- Plug ① (shift cam stopper)
- Spring ②
- Shift cam stopper ③



2. Remove:


- Shift shaft ①
- Shift cam ②
- Guide bar ③
- Shift fork ④



3. Remove:


- Drive axle ①
- Counter axle ②
- Main axle ③

4



4. Remove:

- Oil seal ①
- Circlip ②
- Screw ③ (with washer)
- Primary drive axle ④



CRANKSHAFT AND BALANCER

1. Remove:

- Crankshaft ①
- Balancer ②


Tap the crankshaft lightly with a soft hammer.

CAMSHAFT, ROCKER ARM AND VALVE

NOTE:


With the engine mounted, the camshaft, rocker arm and valve can be maintained by removing the following parts.

- Seat
- Cover (front)
- Cover (center)
- Front fender
- Fuel tank
- Exhaust pipe



1. Remove:

- Bearing retainer ①



2. Remove:

- Rocker arm shaft ①
- Rocker arm ②
- Camshaft ③



Use the slide hammer.



Slide hammer:

P/N YU-01083

90890-01084, 90890-01085



3. Check:

- Valve sealing

Leakage at valve seat → Inspect the valve face, valve seat and valve seat width.


Refer to the "INSPECTION AND REPAIR – VALVE SEAT" section.

NOTE:

Before removing the internal parts (valve, valve spring, spring seat, etc.) of the cylinder head, the valve sealing should be checked.

Valve seal checking steps:

- Supply a clean solvent ① into the intake and exhaust ports.
- Check the valve sealing. There should be no leakage at the valve seats ②.




4. Remove:

- Valve cotter ①
- Spring retainer ②
- Valve spring ③
- Oil seal ④
- Spring seat ⑤
- Valve ⑥


NOTE:

Compress the valve spring to remove the valve cotters by the Valve spring compressor ⑦.



Valve spring compressor:
P/N YM-04019, 90890-04019

Adapter:
P/N YM-4108, 90890-04108



INSPECTION AND REPAIR

CYLINDER HEAD

1. Eliminate:

- Carbon deposit
(from combustion chamber)
Use rounded scraper ①.


NOTE:

Do not use a sharp instrument and avoid damaging or scratching:

- Spark plug threads
- Valve seat

2. Inspect:

- Cylinder head
Scratches/Damage → Replace.




3. Measure:

- Warpage
Out of specification → Resurface.



Cylinder head warpage:
Less than 0.03 mm (0.0012 in)



4. Resurface:

- Cylinder head

Resurfacement steps:

Place a 400 ~ 600 grit wet sandpaper on the surface plate, and resurface the head using a figure-eight sanding pattern.


NOTE:

Rotate the head several times to avoid removing too much material from one side.



VALVE SEAT

1. Eliminate:
 - Carbon deposit
(from valve face and valve seat)
2. Inspect:
 - Valve seat
Pitting/Wear → Reface the valve seat.



3. Measure:
 - Valve seat width (a)
Out of specification → Reface valve seat.



Valve seat width:


Intake:

0.9 ~ 1.1 mm (0.035 ~ 0.043 in)

Exhaust

0.9 ~ 1.1 mm (0.035 ~ 0.043 in)

4




Measurement steps:

- Apply the Mechanic's bluing dye (Dykem) ① to the valve face.
- Install the valve into the cylinder head.
- Press the valve through the valve guide and onto the valve seat to make a clear pattern.
- Measure the valve seat width. Wherever the valve seat and valve face made contact, bluing will have been removed.
- If the valve seat width is too wide, too narrow, or seat has not centered, the valve seat must be refaced.

4. Reface:


- Valve seat
Use a 30°, 45° and 60° Valve Seat Cutter ①.



Valve seat cutter:
P/N YM-91043

⚠ CAUTION:


When twisting cutter, keep an even downward pressure (4 ~ 5 kg) to prevent chatter marks.



Cut sections as follows

Section	Cutter
A	30°
B	45°
C	60°

A



Refacing steps:

- A** Valve face indicates that valve seat is centered on valve face but is too wide.

Valve seat cutter set		Desired result
Use lightly	30° cutter	To reduce valve seat width to 1.0 mm (0.039 in).
	60° cutter	

- B** Valve seat is in the middle of the valve face but too narrow.

Valve seat cutter set		Desired result
Use	45° cutter	To achieve a uniform valve seat width of 1.0 mm (0.039 in).


- C** Valve seat is too narrow and right up near valve margin.

Valve seat cutter set		Desired result
Use	30° cutter, first	To center the seat and to achieve its width of 1.0 mm (0.039 in).
	45° cutter	


- D** Valve seat is too narrow and is located down near the bottom edge of the valve face.

Valve seat cutter set		Desired result
Use	60° cutter, first	To center the seat and increase its width.
	45° cutter	

C



D








5. Lap:

- Valve face
- Valve seat

NOTE: _____

After refacing the valve seat or replacing the valve and valve guide, the valve seat and valve face should be lapped.

4**Lapping steps:**

- Apply a coarse lapping compound to the valve face.

CAUTION: _____

Be sure no compound enters the gap between the valve stem and guide.

- Apply a molybdenum disulfide oil to the valve stem.
- Install the valve into the cylinder head.
- Turn the valve until the valve face and valve seat are evenly polished, then clean off all compound.

NOTE: _____


To obtain the best lapping results, lightly tap the valve seat while rotating the valve back and forth between your hands.

- Apply a fine lapping compound to the valve face and repeat the above steps.

NOTE: _____

Be sure to clean off all compound from the valve face and valve seat after every lapping operation.

- Apply the Mechanic's bluing dye (Dykem) to the valve face.
- Install the valve into the cylinder head.
- Press the valve through the valve guide and onto the valve seat to make a clear pattern.
- Measure the valve seat width again.
If the valve seat width is out of specification, reface and lap the valve seat.



VALVE AND VALVE GUIDE

1. Measure:

- Stem-to-guide clearance

Stem-to-guide clearance =
Valve guide inside diameter (a) –
Valve stem diameter (b)

Out of specification → Replace valve guide.






Stem-to-guide clearance:

Intake 0.010 ~ 0.037 mm
(0.0004 ~ 0.0014 in)
< Limit: 0.06 mm (0.002 in) >
Exhaust 0.025 ~ 0.052 mm
(0.0010 ~ 0.0020 in)
< Limit: 0.08 mm (0.003 in) >

2. Replace:

- Valve guide



Replacement steps:

NOTE:

Heat the cylinder head in an oven to 100°C (212°F) to ease guide removal and installation and to maintain correct interference fit.

- Remove the valve guide using the Valve guide remover (1).
- Install the valve guide (new) using the Valve guide installer (2) and Valve guide remover (1).
- After installing the valve guide, bore the valve guide using the Valve guide reamer (3) to obtain proper stem-to-guide clearance.



Valve guide remover:

P/N YM-04097, 90890-04097

Valve guide installer:

P/N YM-04098, 90890-04098

Valve guide reamer:

P/N YM-04099, 90890-04099

NOTE:

Reface the valve seat after replacing the valve guide.




3. Eliminate:

- Carbon deposit (from valve face)

4. Inspect:

- Valve face
Pitting/Wear → Grind the face.
- Valve stem end
Mushroom shape or diameter larger than rest of stem → Replace.



5. Measure:

- Margin thickness (a)
Out of specification → Replace.


**Margin thickness:****Intake**

0.4 ~ 0.8 mm (0.016 ~ 0.031 in)

Exhaust

0.8 ~ 1.2 mm (0.031 ~ 0.047 in)

4



6. Measure:

- Runout (valve stem)
Out of specification → Replace.






**Runout:****Less than 0.01 mm (0.0004 in)****NOTE:**

- Always replace the guide if the valve is replaced.
- Always replace the oil seal if the valve is removed.

CAMSHAFT

1. Inspect:

- Cam lobes
Pitting/Scratches/Blue discoloration → Replace.



2. Measure:

- Cam lobes length (a) and (b).
- Out of specification → Replace.



Cam lobe length:

Intake

- (a) 26.17 ~ 26.27 mm
(1.030 ~ 1.034 in)
- (b) 21.06 ~ 21.17 mm
(0.829 ~ 0.833 in)

Exhaust

- (a) 26.17 ~ 26.27 mm
(1.030 ~ 1.034 in)
- (b) 21.06 ~ 21.17 mm
(0.829 ~ 0.833 in)

ROCKER ARM AND ROCKER ARM SHAFT

1. Inspect:

- Rocker arm shaft
Blue discoloration/Grooves → Replace, then inspect lubrication system.

2. Inspect:

- Bore (rocker arm shaft) ①
- Cam lobe contact surface ②
- Adjuster surface ③
Wear/Pitting/Scratches/Blue discoloration
→ Replace, then inspect lubrication system.

3. Measure:

- Arm-to-shaft clearance
Out of specification → Replace as a set.

Arm-to-shaft clearance =

Bore size (rocker arm shaft) (a) –

Outside diameter (rocker arm shaft) (b)




Arm-to-shaft clearance:

0.009 ~ 0.034 mm

(0.0003 ~ 0.0013 in)

< Limit: 0.10 mm (0.004 in) >


**VALVE SPRING**

1. Measure:

- Free length (a) (valve spring)
Out of specification → Replace.



Free length (valve spring):
28.63 mm (1.127 in)



2. Measure:


- Compressed force (a) (valve spring)
Out of specification → Replace.

(b) Installed length



Compressed force (valve spring):
8.8 ~ 10.8 kg (19.4 ~ 23.8 lb)
at 24.9 mm (0.980 in)

4




3. Measure:

- Spring Tilt (a)
Out of specification → Replace.




Spring tilt:
Less than 1.2 mm (0.047 in)

**TIMING CHAIN, CHAIN GUIDE AND SPROCKET**

1. Inspect:

- Timing chain
Stiff/Cracks → Replace timing
Chain and sprocket as a set.




2. Inspect:

- Sprocket
Wear/Damage → Replace sprocket and
timing chain as a set.


- ① 1/4 tooth
- ② Correct
- ③ Roller
- ④ Sprocket

343-014



3. Inspect:

- Chain guide ① (exhaust side)
 - Chain guide ② (intake side)
- Wear/Damage → Replace.




CYLINDER AND PISTON

1. Eliminate:

- Carbon deposits
(from the piston crown and ring grooves)

2. Inspect:

- Piston wall
- Wear/Scratches/Damage → Replace.



3. Eliminate:

- Score marks and lacquer deposits
From the sides of piston.
- Use a 600 ~ 800 grit wet sandpaper.


NOTE:

Sand in a crisscross pattern. Do not sand excessively.

4

4. Inspect:

- Cylinder wall
- Wear/Scratches → Rebore or replace.



5. Measure:


- Piston-to-cylinder clearance

Piston-to-cylinder clearance measurement steps:

First steps

- Measure the cylinder bore "C" with a cylinder bore gauge.

① 45 mm (1.77 in) from the cylinder top



4

NOTE:

Measure the cylinder bore "C" in parallel to and at right angles to the crankshaft. Then, find the average of the measurements.

**Cylinder Bore "C":**

49.030 ~ 49.045 mm (1.930 in)

<Limit: 49.15 mm (1.935 in)>

$$C = \frac{X + Y}{2}$$

- If out of the specification, rebore or replace the cylinder, and the piston and piston rings as a set.

2nd steps

- Measure the piston skirt diameter "P" with a micrometer.

⑥ 6 mm (0.24 in) from the piston bottom edge

**Piston skirt diameter "P":**

48.96 ~ 49.00 mm

(1.927 ~ 1.929 in)

- If out of the specification, replace the piston and piston rings as a set.

3rd steps

- Find the piston-to-cylinder clearance with following formula.

$$\text{Piston-to-cylinder clearance} = \text{Cylinder bore "C"} - \text{Piston skirt diameter "P"}$$


**Piston-to-cylinder clearance:**

0.020 ~ 0.040 mm

(0.0008 ~ 0.0016 in)

<Limit: 0.15 mm (0.006 in)>

- If out of the specification, rebore or replace the cylinder, and replace the piston and piston rings as a set.

**PISTON RING**

1. Measure:

- Side clearance

Out of specification → Replace piston, and rings as a set.

NOTE:

Clean carbon from piston ring grooves and rings before measuring side clearance.

**Side clearance:****Top ring**

0.03 ~ 0.07 mm
(0.0012 ~ 0.0027 in)

2nd ring

0.02 ~ 0.06 mm
(0.0008 ~ 0.0024 in)

2. Position:

- Piston ring (into the cylinder)

NOTE:

Push the ring with the piston crown so that the ring will be at a right angle to cylinder bore.

(a) : 20 mm (0.8 in)

3. Measure:

- End gap

Out of specification → Replace.

NOTE:

You cannot measure end gap on expander spacer of oil control ring. If oil control ring rails show excessive gap, replace all three rings.

**End Gap:****Top ring**


0.15 ~ 0.30 mm (0.006 ~ 0.012 in)

2nd ring

0.15 ~ 0.30 mm (0.006 ~ 0.012 in)

Oil ring


0.30 ~ 0.90 mm (0.012 ~ 0.036 in)

**PISTON PIN**

1. Inspect:

- Piston pin

Blue discoloration/Grooves → Replace, then inspect lubrication system.




2. Measure:

- Outside diameter (a) (piston pin)
Out of specification → Replace.



Outside diameter (piston pin):
12.996 ~ 13.000 mm (0.512 in)



3. Measure:


- Piston pin-to-piston clearance
Out of specification → Replace piston.

Piston pin-to-piston clearance =
Bore size (piston pin) (b) –
Outside diameter (piston pin) (a)



Piston pin-to-piston clearance:
0.002 ~ 0.017 mm
(0.0001 ~ 0.0006 in)
<Limit: 0.07 mm (0.003 in)>

4



CRANKSHAFT AND CONNECTING ROD

1. Measure:

- Crank width (A)
Out of specification → Replace crankshaft.



Crank width:
44.95 ~ 45.00 mm
(1.770 ~ 1.772 in)

- Runout (B)
Out of specification → Replace crankshaft and/or bearing.



Runout:
Less than 0.03 mm (0.001 in)



- Small end free play ㉓

Out of specification → Replace big end bearing, crank pin and/or connecting rod.



Small end free play:

0.8 ~ 1.0 mm (0.031 ~ 0.039 in)


- Side clearance ㉔

Out of specification → Replace connecting rod.



Big end side clearance:

0.05 ~ 0.45 mm
(0.0020 ~ 0.0177 in)




ELECTRIC STARTER DRIVES

1. Inspect:

- Starter clutch

Push the dowel pin to arrow direction.

Unsmooth operation → Replace starter clutch assembly.




2. Inspect:

- Starter wheel gear teeth ①

- Idle gear teeth ②


Burrs/Chips/Roughness/Wear → Replace.



3. Inspect:

- Contacting surfaces

Pitting/Wear/Damage → Replace.






4. Check:

- Starter clutch operation

Clutch operation checking steps:

- Install the starter wheel gear to the starter clutch, and hold the starter clutch.
- When turning the wheel gear clockwise ① the starter clutch and the wheel gear should be engaged.
If not, the starter clutch is faulty. Replace it.
- When turning the wheel gear counterclockwise ②, the wheel gear should turn freely.
If not, the starter clutch is faulty. Replace it.

4

**CLUTCH**

1. Inspect:

- Clutch housing inner surface
Oil/Scratches → Remove.

Oil	Use a rag soaked in lacquer thinner or solvent.
Scratches	Use an emery cloth (lightly and evenly polishing).

2. Measure:

- Clutch housing inside diameter (a)
Out of specification → Replace.




Clutch housing inside diameter:
119.9 ~ 120.1 mm
(4.720 ~ 4.728 in)

3. Inspect:

- Clutch shoes
Glazed parts → Sand with coarse sandpaper.

NOTE:

After using the sandpaper, clean of the polished particles with cloth.



4. Measure:

- Clutch shoe thickness ①
- Out of specification → Replace.




Clutch shoe thickness:

3.5 mm (0.14 in)

< Wear limit >:


2.0 mm (0.08 in)



TRANSMISSION AND SHIFTER


1. Inspect:

- Shift fork cam follower ①
 - Shift fork pawl ②
- Scoring/Bends/Wear → Replace.



2. Inspect:

- Shift cam groove
 - Shift cam gear
- Wear/Damage → Replace.



3. Measure:

- Runout (guide bar)
- Out of specification → Replace.



Runout:

Less than 0.03 mm (0.0012 in)

⚠ WARNING:

Do not attempt to straighten a bent guide bar.



4. Measure:

- Runout (drive axle, main axle and counter axle)

Out of specification → Replace.




Runout:

Less than 0.08 mm (0.003 in)

⚠ WARNING:


Do not attempt to straighten a bent axle.

4




5. Inspect:

- Gear teeth
Blue discoloration/Pitting/Wear → Replace.
- Mated dogs
Rounded edges/Cracks/Missing portions
→ Replace.



6. Inspect:


- Gear ①
Damage → Replace.
- Shift shaft ②
Damage/Bends/Wear → Replace.



PRIMARY SHEAVE AND SECONDARY SHEAVE

1. Inspect:

- Primary sliding sheave ①
- Primary fixed sheave ②
- Collar ③
Wear/Cracks/Scratch/Damage → Replace.




2. Check:

- Free movement

Insert the collar into the primary sliding sheave, and check for free movement.


Stick or excessive play → Replace the sheave or collar.



3. Inspect:

- Secondary fixed sheave ①
- Secondary sliding sheave ②

Scratch/Crack/Damage → Replace as a set.




4. Inspect:

- Torque cam groove ①
- Guide pin ②
- Oil seals ③
- O-rings ④

Wear/Damage → Replace as a set.

Damage → Replace.



5. Measure:

- Compressed force ① (sliding sheave spring)
- Out of specification → Replace.
- ② Installed length.



Compressed force:
27.2 kg at 52.1 mm
(60.016 at 2.051 in)

V-BELT


1. Inspect:

- V-belt

Crack/Wear → Replace.

NOTE:

Replace the V-belt smeared with a lot of oil or grease.




2. Measure:

- V-belt width ①

Out of specification → REplace.



V-belt width:
20.1 mm (0.791 in)
< Wear limit >:
18.1 mm (0.712 in)



OIL PUMP AND STRAINER

1. Measure:


- Tip clearance ①
(between inner rotor ① and outer rotor ②)
- Side clearance ②
(between outer rotor ② and pump housing ③)

Out of specifications → Replace oil pump.



Tip clearance:
Less than 0.15 mm (0.006 in)
Side clearance:
0.06 ~ 0.10 mm (0.002 ~ 0.004 in)


4



2. Inspect:

- Oil strainer ①

Damage → Replace.



OIL DELIVERY PIPE

1. Inspect:

- Oil delivery pipe ①
Cracks/Damages → Replace.
Clog → Blow out with compressed air.
- O-rings ②
Damage → Replace.

**CRANKCASE**


1. Thoroughly wash the case halves in mild solvent.
2. Clean all the gasket mating surfaces and crankcase mating surfaces thoroughly.
3. Inspect:
 - Crankcase
Cracks/Damage → Replace.
 - Oil delivery passages
Clog → Blow out with compressed air.

BEARINGS AND OIL SEALS

1. Inspect:
 - Bearing
Clean and lubricate, then rotate inner race with finger.
Roughness → Replace.
2. Inspect:
 - Oil seals
Damage/Wear → Replace.

CIRCLIPS AND WASHERS

1. Inspect:
 - Circlips
 - Washers
Damage/Looseness/Bends → Replace.




ENGINE ASSEMBLY AND ADJUSTMENT

CAMSHAFT, ROCKER ARM AND VALVE

1. Deburr:

- Valve stem end
- Use an oil stone to smooth the stem end.



2. Apply:

- High-Quality molybdenum disulfide motor oil
- (to the valve stem and oil seal.)

3. Install:



- Valve ①
- Valve spring seat ②
- Oil seal ③
- Valve spring ④
- Spring retainer ⑤
- Valve cotters ⑥

NOTE:

Install the valve spring with widergapped coils facing upwards as shown.

⑦ Lager pitch

⑧ Smaller pitch




NOTE:

Compress the valve spring with the Valve, spring compressor ⑨ and then, install the valve cotters.



Valve spring compressor:
P/N YM-04019, 90890-04019
Adapter:
P/N YM-4108, 90890-04108




4. Apply:

- Engine oil
- (to the bearing of the camshaft)
- High-Quality molybdenum disulfide motor oil
- (to the rocker arm and shaft)

5. Install:

- Camshaft ①
- Rocker arm ②
- Rocker arm shaft ③




6. Install:

- Bearing retainer ①



Bolt (bearing retainer):
12 Nm (1.2 m·kg, 8.7 ft·lb)




CRANKSHAFT AND BALANCER

1. Remove:

- Crankshaft ①
- Balancer ②
(to the crankcase (left))

NOTE:

Align the mark on the balancer gear with the mark on the crankshaft gear.



SHIFTER AND TRANSMISSION

1. Apply:


- Lithium soap base grease
(to the oil seal lips)

2. Install:

- Primary drive axle ①
- Screw ② (with washer)
- Circlip ③
- Oil seal




Screw:
7 Nm (0.7 m·kg, 5.1 ft·lb)
Apply LOCTITE®



3. Install:

- Main axle ①
- Counter axle ②
- Drive axle ③

4




4. Install:

- Shift fork ①
- Guide bar ②
- Shift cam ③
- Shift shaft ④

NOTE:

Align the mark on the shift shaft gear with the mark on the shift shaft gear.



5. Apply:

- Lithium soap base grease (to the shift cam stopper)

6. Install:



- Shift cam stopper ①
- Spring ②
- Plug ③ (shift cam stopper)



Plug (shift cam stopper):
10 Nm (1.0 m·kg, 7.2 ft·lb)

7. Check:

- Transmission operation
Unsmooth operation → Repair.



CRANKCASE (RIGHT)

1. Apply:

- Gasket (to the mating surfaces of both case halves).



Quick gasket®:
ACC-11001-05-01
Yamaha bond No. 1215:
P/N 90890-85505

2. Install:


- Dowel pins
- Crankcase (right)



Bolt (crankcase):
7 Nm (0.7 m·kg, 5.1 ft·lb)

NOTE:

Tighten the bolts using crisscross pattern.






VALVE AND ROCKER ARM

- ① Rocker arm
- ② Rocker arm shaft
- ③ Valve cotter
- ④ Valve retainer
- ⑤ Valve spring
- ⑥ Oil seal
- ⑦ Spring seat
- ⑧ Valve

A	VALVE CLEARANCE (COLD):
	Intake: 0.08 ~ 0.12 mm (0.003 ~ 0.005 in) Exhaust: 0.10 ~ 0.14 mm (0.004 ~ 0.006 in)

B	VALVE SPRING TILT LIMIT:
	Inner spring: 2.5° or 1.2 mm (0.047 in) Outer spring: 2.5° or 1.2 mm (0.047 in)

C	STEM RUNOUT LIMIT: 0.01 mm (0.0004 in)
D	VALVE SEAT WIDTH: 0.9 ~ 1.1 mm (0.035 ~ 0.043 in)






CAMSHAFT AND TIMING CHAIN

- ① Camshaft
- ② Bearing retainer
- ③ Collar
- ④ Chain guide (exhaust)
- ⑤ Cam sprocket
- ⑥ Baffle plate
- ⑦ Timing chain
- ⑧ Chain guide (intake)
- ⑨ Timing chain tensioner

A


CAMSHAFT RUNOUT LIMIT:
0.03 mm (0.0012 in)





TRANSMISSION

- | | |
|--------------------|-----------------------|
| ① Drive sprocket | ⑥ Reverse wheel gear |
| ② Chain case cover | ⑦ Clutch dog |
| ③ Bearing housing | ⑧ Primary driven gear |
| ④ Drive axle | ⑨ Counter axle |
| ⑤ Main axle | ⑩ Reverse pinion gear |








SHIFTER

- ① Select lever
- ② Select lever guide
- ③ Shift shaft
- ④ Shift cam
- ⑤ Ball (Shift cam stopper)
- ⑥ Guide bar
- ⑦ Shift fork


4





TIMING CHAIN

1. Apply:
 - Lithium soap base grease (to the o-rings)
2. Install:
 - O-rings ①
 - Chain guide ② (intake)
 - Timing chain ③
3. Install:
 - Cover ①




OIL PUMP

1. Apply:
 - Engine oil (to the oil pump)
2. Install:
 - Gasket ① (oil pump)
 - Oil pump ②
 - Oil pump gear ③




Bolts (oil pump):
7 Nm (0.7 m·kg, 5.1 ft·lb)




CDI MAGNETO

1. Install:
 - Gasket ①
 - Woodruff key ②
 - Stator assembly ③
 - Rotor ④ (CDI magneto)
 - Collar ⑤
 - Washer ⑥
 - Nut ⑦ (CDI magneto)



Bolts (stator assembly):
7 Nm (0.7 m·kg, 5.1 ft·lb)

Nut (CDI magneto):
70 Nm (7.0 m·kg, 51 ft·lb)




NOTE:

- When installing the C.D.I. rotor, make sure the woodruff key is properly seated in the keyway of the crankshaft. Apply a light coating of lithium soap base grease to the tapered portion of the crankshaft end.
- Tighten the nut (CDI rotor) while holding the CDI rotor by the rotor holder ⑧.




Rotor holder:
P/N YU-01235, 90890-01235



2. Install:

- Gasket ①
- Dowel pins ②
- Crankcase cover ③



SHIFT LEVER

1. Install:

- Torsion spring ①
- Lever ②




Bolt (lever):
10 Nm (1.0 m·kg, 7.2 ft·lb)
Apply LOCTITE®

2. Install:

- Shift lever ③
- Shift lever guide ④




Bolt (shift lever):
10 Nm (1.0 m·kg, 7.2 ft·lb)
Bolts (shift lever guide):
10 Nm (1.0 m·kg, 7.2 ft·lb)



NOTE:

Align the mark on the shift lever with the mark on the shift shaft.


Shift the transmission into neutral and then, tighten the bolts (guide).



3. Install the shift lever switch (5) with its tip touching the lever (6).



Screws (Shift Lever Switch):
6Nm (0.6m-kg, 4.3 ft-lb)



ELECTRIC STARTING DRIVE


1. Install:

- Starter wheel gear (1)
- Starter clutch (2)
- Shaft (3) (starter idle gear)
- Starter idle gear (4)

PRIMARY SHEAVE AND SECONDARY SHEAVE

1. Apply:

- BEL-LAY Assembly Lube®
(to the o-rings and oil seals of the secondary sliding sheave)
- Molybdenum disulfide grease
(to the guide pins)




2. Install:


- Secondary fixed sheave (1)
- Secondary sliding sheave (2)
- Collars (3)
- Guide pins (4)
- Spring seat (5)
- Sliding sheave spring (6)
- Clutch shoes (7)

NOTE:

Before installing the nut (secondary sheave assembly), compress the sliding sheave spring with the spring holder (8) and then, install the nut.



Spring holder:
P/N YS-28891, 90890-01337



3. Tighten:

- Nut ① (secondary sheave)



Nut (secondary sheave):
90 Nm (9.0 m·kg, 65 ft·lb)


NOTE:

Tighten the nut (secondary sheave) by the locknut wrench ② while holding the clutch shoes with the sheave holder ③.



Sheave holder:
P/N YS-01880, 90890-01701
Locknut wrench:
P/N YM-4045-A, 90890-01348

4



4. Install:


- Secondary sheave assembly (with clutch shoes) ①
- Clutch housing ②



Nut (clutch housing):
60 Nm (6.0 m·kg, 43 ft·lb)

NOTE:

Tighten the nut (clutch housing) while holding the clutch housing with the sheave holder ③.




Sheave holder:
P/N YS-01880, 90890-01701


5. Install:

- V-belt ①
- Primary sliding sheave ②
- Collar ③
- Primary fixed sheave ④

NOTE:

The V-belt should be installed with the allow mark facing the direction of travel.






Nut (primary sheave):
55 Nm (5.5 m·kg, 40 ft·lb)

NOTE:

- Tighten the nut (primary sheave) while holding the nut (CDI rotor) with a wrench.
- After tightening the nut (primary sheave), bend the lock washer tab along the nut flats.




6. Install:

- Gasket ① (crankcase cover)
- Dowel pins ②
- Crankcase cover ③ (left)



Bolts (crankcase cover):
7 Nm (0.7 m·kg, 5.1 ft·lb)



CYLINDER HEAD, CYLINDER AND PISTON

1. Apply:

- Engine oil
(to the piston pin and piston rings)

2. Install:

- Piston rings ①
- Piston ②
- Piston pin ③
- Piston pin clip ④


NOTE:

- The arrow on the piston must point to the front of the engine.
- Before installing the piston pin clip, cover the crankcase with a clean towel or rag so you will not accidentally drop the pin clip and material into the crankcase.



WARNING:

Always use a new piston pin clip.




2. Offset the piston ring end gaps as shown.

NOTE:

Be sure to check the manufacturer's marks or numbers stamped on the rings are on the top side of the rings.

- ① Top ring
- ② Oil ring (lower rail)
- ③ Oil ring (upper rail)
- ④ 2nd ring

4




3. Install:

- Dowel pins ①
- Gasket ② (cylinder)
- Cylinder ③
- Chain guide ④ (exhaust)
- Dowel pins ⑤
- Gasket ⑥ (cylinder)

NOTE:

- Install the cylinder with one hand while compressing the piston rings with the other hand.
- Tie the timing chain with a piece of mechanics wire and feed it through the chain opening.










4. Install:

- Cylinder head ①
- Cam sprocket ②



Bolts (cylinder head (M8)):
22 Nm (2.2 m·kg, 16 ft·lb)
Bolts (cylinder head (M6)):
10 Nm (1.0 m·kg, 7.2 ft·lb)

**Installing steps:**

- Rotate the camshaft as shown.
- Pull the timing chain up and rotate the crankshaft until the TDC mark ③ on the CDI rotor is aligned with the stationary pointer ④.
- Install the cam sprocket to the timing chain with the mark ⑤ on the cam sprocket at twelve o'clock position.
- Pass the timing chain with cam sprocket through the cylinder head.
- Install the cam sprocket onto the camshaft.

NOTE:

When the mark on the cam sprocket is aligned with the mark on the cylinder head, the TDC mark on the CDI rotor should be aligned with the stationary pointer.

4

NOTE:

The numbers in the photo designate the cylinder head tightening sequence.

5. Install:


- Baffle plate ①



Bolt (baffle plate):
26 Nm (2.6 m·kg, 19 ft·lb)


NOTE:

Tighten the bolt (baffle plate) while holding the nut (CDI rotor) with a wrench.



6. Install:

- Plug ①
- Plug ②



7. Install:


- Timing chain tensioner ①
- Plug 2 (timing chain tensioner)



Bolts (timing chain tensioner):
10 Nm (1.0 m·kg, 7.2 ft·lb)

Plug (timing chain tensioner):
7 Nm (0.7 m·kg, 5.1 ft·lb)

4



NOTE:

Before installing the chain tensioner, unhook the ratcheted ③ and push the rod ④ into the body.

8. Adjust:

- Valve clearance


Refer to the "VALVE CLEARANCE ADJUSTMENT" section in the CHAPTER 3.



Valve clearance (cold):

Intake 0.08 ~ 0.12 mm
(0.003 ~ 0.005 in)

Exhaust 0.10 ~ 0.14 mm
(0.004 ~ 0.006 in)



9. Apply:

- Lithium soap base grease
(to the o-rings)

10. Install:

- O-ring ① (cylinder head cover)
- O-rings ② (tappet covers)
- Tappet cover ③ (exhaust)
- Tappet cover ④ (intake)
- Spark plug ⑤
- Cylinder head cover ⑥

**Spark plug:****13 Nm (1.3 m·kg, 9.4 ft·lb)****Bolts (cylinder head cover):****7 Nm (0.7 m·kg, 5.1 ft·lb)**




PRIMARY SHEAVE AND SECONDARY SHEAVE

- | | |
|----------------------------|--------------------------|
| ① Clutch housing | ⑦ Primary drive axle |
| ② Clutch assembly | ⑧ Primary fixed sheave |
| ③ Sliding sheave spring | ⑨ Primary sliding sheave |
| ④ Spring seat | ⑩ Weight |
| ⑤ Secondary sliding sheave | ⑪ Slider |
| ⑥ Secondary fixed sheave | ⑫ Cam |

* Apply BEL-RAY Assembly Lube®

4






CRANKSHAFT, PISTON AND BALANCER

- ① Balancer assembly
- ② Top ring
- ③ Second ring
- ④ Oil ring
- ⑤ Piston
- ⑥ Piston pin
- ⑦ Crankshaft assembly
- ⑧ Woodruff key

A	CRANK WIDTH: 44.95 ~ 45.00 mm (1.770 ~ 1.772 in)
B	RUNOUT LIMIT: 0.03 mm (0.0012 in)
C	SMALL END FREE PLAY: 0.8 ~ 1.0 mm (0.031 ~ 0.039 in)
D	BIG END SIDE CLEARANCE: 0.05 ~ 0.45 mm (0.0020 ~ 0.0177 in)


F	PISTON RING END GAP: Top: 0.15 ~ 0.30 mm (0.006 ~ 0.012 in) 2nd: 0.15 ~ 0.30 mm (0.006 ~ 0.012 in) Oil: 0.30 ~ 0.90 mm (0.012 ~ 0.036 in)
G	PISTON RING SIDE CLEARANCE: Top: 0.03 ~ 0.07 mm (0.0012 ~ 0.0027 in) 2nd: 0.02 ~ 0.07 mm (0.0008 ~ 0.0024 in)





CYLINDER AND CYLINDER HEAD

- ① Spark plug
- ② Valve stem (exhaust)
- ③ Valve stem (intake)
- ④ Tappet cover (exhaust)
- ⑤ Tappet cover (intake)
- ⑥ Cylinder head
- ⑦ Cylinder head cover
- ⑧ Breather hose (crankcase)
- ⑨ Cylinder





REMountING ENGINE

When remounting the engine, reverse the "ENGINE REMOVAL" procedure.

Note the following points.

1. Install:

- Engine assembly



Bolts (engine stay):
33 Nm (3.3 m·kg, 24 ft·lb)

Nuts:
42 Nm (4.2 m·kg, 30 ft·lb)

2. Install:

- Drive sprocket
- Drive chain



Nut (drive sprocket):
75 Nm (7.5 m·kg, 54 ft·lb)

NOTE:

Bend the lock washer tab along the nut flates.

4

3. Adjust:

- Drive chain slack



Drive chain slack:
30 mm (1.18 in)

Refer to the "DRIVE CHAIN SLACK ADJUSTMENT" section in the CHAPTER 3.

4. Install:

- Starting motor



Bolts (starting motor):
7 Nm (0.7 m·kg, 5.1 ft·lb)
Use LOCTITE®

NOTE:

Before installing the starting motor into the crankcase, apply lithium soap base grease onto the o-ring of the starting motor.



5. Install:

- Muffler

**Bolts (muffler):****27 Nm (2.7 m·kg, 19 ft·lb)****Nuts (exhaust pipe):****10 Nm (1.0 m·kg, 7.2 ft·lb)**

6. Install:

- Air duct

**Bolts (air duct):****7 Nm (0.7 m·kg, 5.1 ft·lb)**

7. Fill:

- Transmission case

Refer to the "TRANSMISSION OIL REPLACEMENT" section in the CHAPTER 3.

- Crankcase


Refer to the "ENGINE OIL REPLACEMENT" section in the CHAPTER 3.



CARBURETION

CARBURETOR

- | | |
|-----------------------|-----------------|
| ① Jet needle | ⑨ Main jet |
| ② Throttle valve | ⑩ Pilot jet |
| ③ Carburetor body | ⑪ Pilot screw |
| ④ Starter plunger | ⑫ Float |
| ⑤ Throttle stop screw | ⑬ Float chamber |
| ⑥ Valve seat | |
| ⑦ Needle valve | |
| ⑧ Needle jet | |






SECTIONAL VIEW

- ① Pilot screw
- ② Pilot jet
- ③ Main jet
- ④ Needle jet
- ⑤ Needle valve
- ⑥ Valve seat
- ⑦ Main air jet
- ⑧ Jet needle
- ⑨ Throttle valve

← : Air
← : Fuel
← : Mixture





REMOVAL

NOTE:


The following parts can be cleaned and inspected without disassembly.

- Throttle valve
- Starter plunger
- Throttle stop screw
- Pilot screw

1. Remove:

- Seat
- Cover (front)
- Cover (center)
- Front fender

Refer to the "FENDERS" Section in the CHAPTER 3.




2. Turn the fuel cock to "OFF" position.

3. Loosen:


- Drain screw (1).

Drain the float chamber of its fuel.



4. Disconnect:

- Fuel hose (1)
- Air ventilation hose (2)
- Drain hose (3)




5. Loosen:

- Screw (1) (carburetor joint)


6. Remove:

- Bolt (2) (intake manifold)



7. Remove:


- Top cover ① (with throttle valve)
- Starter plunger ②



8. Remove:

- Intake manifold ①


5



DISASSEMBLY

1. Remove:

- Float chamber ①
- Float pin ②
- Float ③
- Needle valve ④
- Valve seat holder ⑤
- Valve seat ⑥
- Cover ⑦
- Main jet ⑧
- Needle jet ⑨
- Pilot jet ⑩
- Pilot screw ⑪
- Throttle stop screw ⑫




2. Disconnect:

- Throttle cable ①
(from throttle valve)


NOTE:

Compress the spring to disconnect the throttle cable by hand.



3. Remove:

- Spring ①
- Jet needle holder ②
- Jet needle ③
- Throttle valve ④




4. Disconnect:

- Starter cable ①
(from the starter plunger)


NOTE:

Compress the spring to disconnect the starter cable by hand.



5. Remove:

- Spring ①
- Starter plunger ②


**INSPECTION**

1. Inspect:

- Carburetor body
Crack/Damage → Replace.
Contamination → Clean.

NOTE:

Use a petroleum based solvent for cleaning. Blow out all passages and jets with compressed air.




2. Inspect:

- Valve seat ①
- Needle valve ②
Wear/Contamination → Replace.
- O-ring ③
Damage → Replace.


NOTE:

Always replace the needle valve and valve seat as a set.




3. Inspect:

- Starter plunger ①
Wear/Contamination → Replace.
- O-ring ②
Damage → Replace.



4. Inspect:


- Throttle stop screw ①
Pilot screw ②
Wear/Contamination → Replace.
- O-ring ③
Damage → Replace.



5. Inspect:

- Jet needle ①
Bends/Wear → Replace.

5




6. Inspect:

- Throttle valve ①
Wear/Damage → Replace.

7. Check:


- Free movement
Stick → Replace.

Insert the throttle valve into the carburetor body, and check for free movement.



8. Inspect:

- Float ①
Damage → Replace.



9. Inspect:

- Main jet ①
- Needle jet ②
- Pilot jet ③

Contamination → Clean.

NOTE:

Blow out the jets with compressed air.

ASSEMBLY

Reverse the "DISASSEMBLY" procedures. Note the following points.

CAUTION:

Before reassembling, wash the all parts with a clean gasoline.

1. Tighten:

- Needle jet
- Main jet
- Pilot jet
- Screw (needle valve holder)
- Screws (float chamber)



Needle jet:

3 Nm (0.3 m · kg, 2.2 ft · lb)

Main jet:

2 Nm (0.2 m · kg, 1.4 ft · lb)

Pilot jet:

1 Nm (0.1 m · kg, 0.7 ft · lb)

Screw (needle valve holder):

1 Nm (0.1 m · kg, 0.7 ft · lb)

Screws (float chamber):

2 Nm (0.2 m · kg, 1.4 ft · lb)

5

INSTALLATION

Reverse the "REMOVAL" procedures. Note the following points.

1. Install:

- Intake manifold



Nut (intake manifold):

10 Nm (1.0 m · kg, 7.2 ft · lb)




2. Install:

- Starter plunger
- Top cover (with throttle valve)

**Starter plunger:**

3 Nm (0.3 m · kg, 2.2 ft · lb)

**NOTE:**

Align the groove ① of the throttle valve with the projection ② of the carburetor body.

3. Tighten:

- Bolts (cylinder head and intake manifold)

**Bolts (cylinder head and intake manifold):**

12 Nm (1.2 m · kg, 8.7 ft · lb)

5


FLOAT HEIGHT ADJUSTMENT**NOTE:**

After the float, valve seat and needle valve are installed to the carburetor body, float height should be adjusted.

1. Hold the carburetor in an upside down position.

2. Measure:

- Float height ①
- Out of specification → Adjust.




322-033

**Float height (F.H.):**

21.8 ~ 22.8 mm (0.858 ~ 0.898 in)

**NOTE:**

- Measure the distance from the mating surface of the float chamber (gasket removed) to the top of the float.
- The float arm should be resting on the needle valve, but not compressing the needle valve.


**3. Adjust:**

- Float height

Adjustment steps:

- Inspect the valve seat and needle valve. If either is worn, replace them both.
- If both are fine, adjust the float height by bending the float tang ① on the float.
- Recheck the float height.

5

**FUEL LEVEL ADJUSTMENT**

1. Place the machine on a level place.
2. Use a garage jack under the engine to ensure that the carburetor is positioned vertically.
3. Attach the Fuel level gauge ① to the float chamber nozzle.




Fuel level gauge:
P/N YM-01312, 90890-01312

4. Loosen the drain screw ②, and warm up the engine for several minutes.
5. Measure:
 - Fuel level ①
 Out of specification → Adjust.



Fuel level:
2.0 ~ 4.0 mm (0.08 ~ 0.16 in)
below the carburetor body edge.



6. Adjust:

- Fuel level

Adjustment steps:

- Remove the carburetor.
- Inspect the valve seat and needle valve.
- If either is worn, replace them both.
- If both are fine, adjust the float height by bending the float tang ① on the float.
- Recheck the fuel level.



CHASSIS

FRONT WHEEL


- | | |
|--------------------|------------------|
| ① Camshaft lever | ⑧ Brake shoe |
| ② Wear indicator | ⑨ Bearing |
| ③ Brake shoe plate | ⑩ Wheel hub |
| ④ Oil seal | ⑪ Collar |
| ⑤ O-ring | ⑫ Oil seal |
| ⑥ Camshaft | ⑬ Wheel assembly |
| ⑦ Spring | |



TIRE AIR PRESSURE

COLD TIRE PRESSURE	FRONT	REAR
STANDARD	20 kPa (0.20 kg/cm ² , 2.8 psi)	25 kPa (0.25 kg/cm ² , 3.6 psi)
MINIMUM	17 kPa (0.17 kg/cm ² , 2.4 psi)	22 kPa (0.22 kg/cm ² , 3.1 psi)
MAXIMUM	23 kPa (0.23 kg/cm ² , 3.3 psi)	28 kPa (0.28 kg/cm ² , 4.0 psi)

A	TIRE SIZE: AT20 x 7 - 8
B	WHEEL RUNOUT LIMIT VERTICAL: 2.0 mm (0.08 in) LATERAL: 2.0 mm (0.08 in)
C	TIRE WEAR LIMIT: 3.0 mm (0.12 in)

D	BRAKE DRUM INSIDE DIAMETER: 110 mm (4.33 in) < WEAR LIMIT > : < 111 mm (4.37 in) >
E	BRAKE SHOE THICKNESS: 4.0 mm (0.16 in) < WEAR LIMIT > : < 2.0 mm (0.08 in) >



**REMOVAL**

1. Place the machine on a level place.
2. Remove:
 - Cotter pin ①



3. Loosen:
 - Nuts ① (wheel panel)
 - Nut ② (wheel hub)

NOTE: _____
 Loosen the nut while applying the front brake.


4. Elevate the front wheels by placing a suitable stand under the frame.

⚠ WARNING: _____

Support the machine securely so there is no danger of it falling over.

6


5. Remove:
 - Nuts ①
 - Front wheel ②
 - Nut ③
 - Washer ④
 - Collar ⑤
 - Wheel hub ⑥
6. Loosen:
 - Locknut
(at brake lever)
7. Tighten:
 - Adjuster
(at brake lever)
8. Disconnect:
 - Front brake cable ①
(from brake cam lever)




9. Remove:

- Brake shoes ①
- Springs ②
- Camshaft lever ③
- Wear indicator ④
- Camshaft ⑤
- Brake shoe plate ⑥
- O-rings ⑦

INSPECTION

1. Inspect:

- Wheel
Cracks/Bends/Warpage → Replace.




2. Measure:

- Wheel runout
Out of specification → Replace wheel or check bearing play.




Rim runout limits:

Vertical ①: 2.0 mm (0.08 in)
Lateral ②: 2.0 mm (0.08 in)







⚠ WARNING:

After replacing the tire, ride conservatively to allow the tire to be properly seated in the rim. Failure to do so may cause an accident resulting in machine damage and possible operator injury.



3. Inspect:

- Front wheel hub
Cracks/Damage → Replace.



4. Inspect:

- Brake drum (inner surface)
Oil → Wipe off brake drum with rag soaked in lacquer thinner or solvent.
Scratches → Polish brake drum lightly and evenly with emery cloth.

5. Measure:

- Inside diameter (brake drum) (a)
Out of specification → Replace.



Inside diameter (brake drum):
110 mm (4.33 in)
< Wear Limit >
111 mm (4.37 in)

6. Inspect:

- Bearings (1) (front wheel hub)
Bearings allow play in the wheel hub or the wheel turns roughly → Replace.
- Oil seal (2)
Wear/Damage → Replace.

Replacement steps:

- Clean the outside of the wheel hub.
- Remove the oil seal use a flat-head screw driver.

NOTE:

Place a wood block against the outer edge to protect this edge.



- Remove the bearing using a general bearing puller.
- Install the new bearing and oil seal by reversing the previous steps.

NOTE:

Use a socket (3) that matches the outside diameter of the race of the bearing and oil seal.

CAUTION:

Do not strike the center race or balls of the bearing. Contact should be made only with the outer race.



7. Inspect:

- Brake shoes

Glazed parts → Sand with coarse sandpaper.

8. Measure:

- Lining thickness (a)

Out of specification → Replace.



Lining thickness:

4.0 mm (0.16 in)

< Wear Limit >:

2.0 mm (0.08 in)

9. Inspect:

- Shoe springs (1)

Damage → Replace.

- Brake shoe plate (2)

Cracks/Damage → Replace.

- Oil seal (3)

- Brake shoe pivot pin (4)

Wear/Damage → Replace.

- Camshaft (5)

- Camshaft hole (6)

Scratches/Excessive wear → Replace.

- O-rings (7)

Damage → Replace.

- Camshaft lever (8)

Damage → Replace.

- Wear indicator (9)

Damage → Replace.

INSTALLATION

Reverse the "REMOVAL" procedures.

Note the following points.

1. Apply:

- Lithium soap base grease

(onto the o-rings, oil seal lips, pivot pin of brake shoe and camshaft)

2. Install:

- O-rings (1)

- Brake shoe plate (2)


- Camshaft (3)

- Wear indicator (4)

- Camshaft lever (5)




- Springs (6)

- Brake shoes (7)




Bolt (camshaft lever):

9 Nm (0.9 m · kg, 6.5 ft · lb)



6

**NOTE:**

- Install the camshaft to the brake shoe plate with the slot of the camshaft placing at base line of the wear indicator scale.
- Align the projection with the slot of the camshaft when installing the wear indicator to the camshaft.
- Align the cut-out of the camshaft lever with the slot of the camshaft when installing the camshaft lever to the camshaft.

3. Install:

- Brake shoe plate ①

NOTE:

Make sure that the boss on the knuckle correctly engages with the locating slot on the brake shoe plate.

4. Apply:

- Lithium soap base grease.
(onto the bearings and oil seal lips of the wheel hub).

5. Tighten:

- Nut (wheel hub)
- Nuts (wheel panel)



Nut (wheel hub):


70 Nm (7.0 m · kg, 50 ft · lb)

Nuts (wheel panel):

55 Nm (5.5 m · kg, 40 ft · lb)

⚠ WARNING:

Tapered wheel nuts ① are used for front wheels. Install the nuts with its tapered side towards the wheel.



6. Install:

- Cotter pin ① (new)

NOTE:

Do not loosen the wheel hub nut after torque tightening. If the wheel hub nut groove is not aligned with the cotter pin hole, align groove with the hole by tightening up on the wheel hub nut.

⚠ WARNING:

Always use a new cotter pin.

7. Adjust:

- Front brake cable free play

Refer to the "FRONT BRAKE ADJUSTMENT" section in the CHAPTER 3.



Brake cable free play:

10 ~ 12 mm (0.39 ~ 0.47 in)

at lever pivot.




REAR WHEEL

- | | |
|-----------------------|------------------|
| ① Rear wheel assembly | ⑫ Wear indicator |
| ② Wheel hub | ⑬ Brake cam |
| ③ Drive chain | ⑭ Bearing |
| ④ Driven sprocket | ⑮ Oil seal |
| ⑤ Sprocket hub | ⑯ Brake shoe |
| ⑥ Dust seal | ⑰ Chain puller |
| ⑦ Oil seal | ⑱ Brake drum hub |
| ⑧ Bearing | ⑲ Rear axle |
| ⑨ Collar | ⑳ Brake drum |
| ⑩ Rear axle hub | ㉑ Oil seat |
| ⑪ Brake cam lever | ㉒ Drum cover |

* Rear Axle Nut Tightening Steps:


Apply locking agent (LOCTITE®) to rear axle nuts threads.

- 1st: Tighten the inner rear axle nut.
55 Nm (5.5 m·kg, 40 ft·lb)
- 2nd: Tighten the outer rear axle nut while holding the inner rear axle nut.
190 Nm (19.0 m·kg, 140 ft·lb)
- 3rd: Loosen the inner rear axle nut while holding the outer rear axle nut.
240 Nm (24.0 m·kg, 170 ft·lb)




REMOVAL

1. Place the machine on a level place.
2. Apply:
 - Front brake
 - Parking brake





3. Loosen:
 - Rear axle nut ① (outer)
 - Rear axle nut ② (inner)

Use the nut wrench.



4. Remove
 - Cotter pin ①




5. Loosen:
 - Nuts ① (wheel panel)
 - Nuts ② (wheel hub)

(of the both rear wheels)

6. Elevate the rear wheels by placing a suitable stand under the rear of frame.

WARNING:

Support the machine securely so there is no danger of it falling over.




7. Remove:

- Nuts ① (wheel panel)
- Rear wheels ②
- Nuts ③ (wheel hub)
- Washers ④
- Wheel hubs ⑤



8. Remove:


- Rear axle nut ① (outer)
- Rear axle nut ② (inner)



9. Remove:


- Lower guard ①

6




10. Loosen:

- Adjuster ① (drive chain slack)
- Lock bolt ②




11. Loosen:

- Bolts ① (rear axle hub)




12. Remove:

- Drive chain ①
(from driven sprocket)
- Driven sprocket ②



13. Remove:

- Brake drum cover ① (outer)




14. Straighten:

- Lock washer tabs


15. Remove:

- Brake drum cover ① (inner)
- Brake drum ②






15. Disconnect:

- Rear brake cable ①
(from the camshaft lever)



17. Remove:

- Brake shoes ①



18. Remove:

- Rear axle ①
(from right side)

⚠ CAUTION:

- Never directly tap the axle end with a hammer, this will result in damage to the axle thread ① and spline ②.
- Install the wheel boss ③ and a suitable socket ④ on the axle end to prevent the thread and spline from damage.

19. Remove:

- Rear axle hub ①

INSPECTION

1. Inspect:

- Wheel

Refer to the "WHEEL INSPECTION" section in the CHAPTER 3.

2. Measure:

- Wheel runout

Refer to the "FRONT WHEEL – INSPECTION" section.



Wheel runout limit:

Vertical: 2.0 mm (0.08 in)

Lateral: 2.0 mm (0.08 in)

3. Inspect:

- Brake drum (inner surface)

Refer to the "FRONT WHEEL – INSPECTION" section.



4. Measure:

- Inside diameter (brake drum)

Refer to the "FRONT WHEEL – INSPECTION" section.



Inside diameter (brake drum):

130 mm (5.12 in)

< Wear Limit >:

131 mm (5.16 in)

5. Inspect:

- Brake shoes

Refer to the "FRONT WHEEL – INSPECTION" section.

6. Measure:

- Lining thickness

Refer to the "FRONT WHEEL – INSPECTION" section.





Lining thickness:

4.0 mm (0.16 in)

< Wear Limit >:

2.0 mm (0.08 in)



7. Inspect:

- Wheel hub ①

Cracks/Damage → Replace.

- Splines ② (wheel hub)

Wear/Damage → Replace.


8. Inspect:

- Sprocket hub ①

Cracks/Damage → Replace.


- Splines ② (sprocket hub)

Wear/Damage → Replace.



9. Inspect:

- Rear axle ①
Scratched (excessively)/Damage → Replace.
- Splines/Threads (rear axle)
Wear/Damage → Replace.



10. Measure:


- Rear axle runout ①
Out of specification → Replace.



Rear Axle Runout:
Less than 1.5 mm (0.06 in)

⚠ WARNING:

Do not attempt to straighten a bent axle.



11. Inspect:

- Bearings ① (rear axle hub)
Bearings allow play in the axle hub or the bearing turns roughly → Replace.
- Oil seals ②
Wear/Damage → Replace.
- Rear axle hub ③
Cracks/Bend/Damage → Replace.


Bearing and oil seal replacement steps:

- Clean the outside of the rear axle.
- Remove the oil seal by a flat-head screw driver.

NOTE:

Place a wood block against the outer edge to protect this edge.

- Remove the bearing by a general bearing puller.
- Install the new bearings and oils seal by reversing the previous steps.



NOTE: _____
Use a socket ④ that matches the outside diameter of the race of the bearing and oil seal.

CAUTION: _____

Do not strike the center race or balls of the bearing. Contact should be made only with the outer race.


INSTALLATION

Reverse the "REMOVAL" procedures.

Note the following points.

1. Apply:

- Lithium soap base grease
(onto the oil seal lips, bearings and bushes)




2. Install:

- Rear axle hub ①

NOTE: _____
At this time, the rear axle hub should not be tightened completely. Final tightening is done after the chain slack adjustment.

3. Install:

- Rear axle



CAUTION: _____

- Never directly tap the axle end with a hammer, this will result in damage to the axle thread ① and spline ②.
- Install the wheel boss ③ and suitable socket ④ on the right axle end to prevent the thread and spline from damage.



4. Install:


- Brake drum



Nuts (brake drum):
21 Nm (2.1 m · kg, 15 ft · lb)

⚠ WARNING:

Always use a new lock washer.



5. Bend:

- Lock washer tabs
(at brake drum)

6. Tighten:

- Nut ① (rear axle — inner)
- Nut ② (rear axle — outer)

Rear axle nuts tightening steps:

NOTE:

Before tightening the nuts, apply the LOCKTITE® to the thread portion of the rear axle.

- Tighten the nut (inner) with the nut wrench to specification while holding the rear axle.



Nut wrench:
P/N YM-37132, 90890-01419



Nut (inner) — (first tightening):
55 Nm (5.5 m · kg, 40 ft · lb)

- Hold the nut (inner) and tighten the nut (outer) with the nut wrench to specification.



Nut (outer):
190 Nm (19.0 m · kg, 140 ft · lb)

- Hold the nut (outer) and tighten back the nut (inner) with the nut wrench to specification.



Ring nut (inner) — (final tightening):
240 Nm (24.0 m · kg, 170 ft · lb)



7. Adjust:

- Drive chain slack

Refer to the "DRIVE CHAIN SLACK ADJUSTMENT" section in the CHAPTER 3.



Drive chain slack:
30 mm (1.18 in)



Bolt (rear axle hub):

Upper

85 Nm (8.5 m · kg, 61 ft · lb)

Lower

60 Nm (6.0 m · kg, 43 ft · lb)

Locknut (adjuster):

16 Nm (1.6 m · kg, 11 ft · lb)

Locknut (hub lockbolt):

16 Nm (1.6 m · kg, 11 ft · lb)

8. Install:

- Wheel hub
- Plate washer
- Nut (wheel hub)



Nut (wheel hub):

120 Nm (12 m · kg, 87 ft · lb)

9. Install:

- Cotter pins (new) ①

NOTE:

Do not loosen the axle nut after torque tightening. If the axle nut groove is not aligned with the cotter pin hole, align groove with the hole by tightening up on the axle nut.

⚠ WARNING:

Always use a new cotter pin.

10. Install:

- Rear wheel




Nut (rear wheel):

55 Nm (5.5 m · kg, 40 ft · lb)

⚠ WARNING:

Tapered wheel nuts are used for rear wheels. Install the nuts with its tapered side towards the wheel.




349-000



FRONT SUSPENSION

- | | |
|--------------------|-----------------|
| ① Shock absorber | ⑥ Grease nipple |
| ② Thrust cover | ⑦ Front arm |
| ③ Bush | ⑧ Thrust cover |
| ④ Spacer | ⑨ Bush |
| ⑤ Steering knuckle | ⑩ Spacer |





REMOVAL

1. Elevate the front wheels by placing a suitable stand under the frame.


⚠ WARNING:

Support the machine securely so there is no danger of it falling over.

2. Remove:


- Front wheel
- Wheel hub
- Brake shoe plate

Refer to "FRONT WHEEL – REMOVAL" section.




3. Remove:

- Shock absorber ①





4. Remove:

- Cotter pin ①
- Nut ②
- Tie-rod ③
(from steering knuckle)



5. Remove:

- Cotter pin ①
- Nut ②
- Washer ③
- Bolt ④
- Steering knuckle ⑤
- Covers ⑥
- Collars ⑦
- Bush ⑧



6. Check:

- Front arm free play

Inspection steps:

- Check the front arm brackets of the frame. If bent, cracked or damaged, repair or replace the frame.
- Check the tightening torque of the front arms securing nuts.





Nut (front arm):

32 Nm (3.2 m · kg, 23 ft · lb)

- Check the front arm side play **[A]** by moving it from side to side. If side play noticeable, replace the inner collar, bushings and thrust covers as a set.
- Check the front arm vertical movement **[B]** by moving it up and down. If vertical movement is tight, binding or rough, replace the inner collar, bushings and thrust covers as a set.

6




7. Remove:

- Nuts ①
- Bolts ②
- Front arm ③
- Covers ④
- Collars ⑤
- Bushes ⑥

INSPECTION


1. Inspect:

- Shock absorber rod
Bends/Damage → Replace the shock absorber assembly.
- Shock absorber
Oil leaks → Replace the shock absorber assembly.
- Spring
Fatigue → Replace the shock absorber assembly.
Move the spring up and down.



2. Inspect:

- Steering knuckle
Cracks/Pitting/Damage → Replace.




3. Inspect:

- Front arm
Cracks/Bends/Damage → Replace.

⚠ WARNING:

Do not attempt to straighten a bent arm; this may dangerously weaken the arm.



4. Inspect:


- Cover ①
- Collar ②
- Bush ③
Wear/Damage → Replace.

INSTALLATION

Reverse the "REMOVAL" procedures.
Note the following points.

1. Apply:

- Lithium soap base grease
(onto the bushes, collars and covers)




2. Install:

- Front arm
(onto the frame)



Nuts (front arm):
32 Nm (3.2 m · kg, 23 ft · lb)



3. Apply:

- Lithium soap base grease
(onto the bush, collars and covers)

4. Install:

- Steering knuckle
(onto the front arm)



Nut (steering knuckle):
30 Nm (3.0 m · kg, 22 ft · lb)

⚠ WARNING:

Always use a new cotter pin.

5. Install:

- Tie-rod
(onto the steering knuckle)



Nut (tie-rod):
25 Nm (2.5 m · kg, 18 ft · lb)

⚠ WARNING:

Always use a new cotter pin.

6. Install:

- Shock absorber



Nuts (shock absorber):
45 Nm (4.5 m · kg, 32 ft · lb)


7. Install:

- Brake shoe plate
- Wheel hub
- Front wheel

Refer to the "FRONT WHEEL – INSTALLATION" section.

STEERING SYSTEM

- | | |
|----------------------------|--------------------|
| ① Handlebar holder (upper) | ⑥ Steering bracket |
| ② Handlebar holder (lower) | ⑦ Oil seal |
| ③ Steering column | ⑧ Steering bracket |
| ④ Cable guide | ⑨ Steering knuckle |
| ⑤ Collar | ⑩ Tie-rod |






REMOVAL

1. Remove:

- Seat
- Cover (front)
- Cover (center)
- Front fender

Refer to the "FENDERS" section in the CHAPTER 3.




2. Disconnect:

- Main switch lead ①

3. Remove:

- Handlebar cover ② (with main switch)





4. Disconnect:

- Front brake cables ①
(from the brake lever)
- Rear brake cable ②
(from the brake lever)
- Brake switch ③
(from the bracket of the brake lever)

NOTE:

Disconnect the brake switch from the bracket of the brake lever while pushing the hook ④ of the brake switch with a driver.




5. Remove:

- Cover ① (throttle housing)


6. Disconnect:

- Throttle cable ②
(from the lever)




7. Remove:

- Handlebar switch ①



8. Remove:

- Headlight unit ①
- Handlebar ②




9. Remove:

- Cotter pins ①
- Nuts ②
- Tie-rods ③


NOTE:

Remove the end of the tie-rod from the steering column and steering knuckle with a general bearing puller.



10. Remove:

- Cotter pin ①
- Nut ② (steering column)
- Washer ③




11. Straighten:


- Lock washer tabs

12. Remove:

- Bolts ①
- Lock washer ②
- Cable holder ③
- Steering brackets ④
- Oil seals ⑤
- Collars ⑥
- Steering column ⑦

**INSPECTION**


1. Inspect:
 - Handlebar
 - Cracks/Bends/Damage → Replace.




2. Inspect:
 - Steering column
 - Bends/Damage → Replace.

⚠ WARNING:


Do not attempt to straighten a bent shaft; this may dangerously weaken the shaft.



3. Inspect:
 - Steering brackets ①
 - Oil seal ②
 - Wear/Damage → Replace.



4. Inspect:
 - Tie-rod
 - Bend/Damage → Replace.



5. Check:
 - Tie-rod end movement
 - Tie-rod end exists free play → Replace.
 - Tie-rod end turns roughly → Replace.
 - Tapered surface (Tie-rod end)
 - Pitting/Wear/Damage → Replace.





6. Adjust:

- Tie-rod length and rod-end angle

Adjustment steps:

(The following procedures are done on both tie-rods, right and left:)

- Loosen the locknuts ①.
- Adjust the tie-rod length ② by turning both tie-rod ends.

**Tie rod length:**

277 mm (10.9 in)

- Set the rod-end ② (knuckle arm side) in an angle where the indentation surface ③ of the tie-rod is parallel to the rod-end shaft ④, and then tighten the locknut.

Locknut (rod-end):

30 Nm (3.0 m·kg, 22 ft·lb)

- Set the other rod-end ⑤ (steering column side) in an angle as shown in figures A and B, and then tighten the locknut.

Rod-end (tie rod) angle ⑥:

164° ~ 166°

Locknut (rod-end):

30 Nm (3,0 m·kg, 22 ft·lb)

NOTE:

The threads ③ on both rod-ends must be of the same length.


- After making adjustment on both tie rods, be sure to mark them R and L for identification.

A Right-hand tie-rod

B Left-hand tie-rod

C To knuckle arm

D To steering column



7. Inspect:

- Bushings ①
- O-rings ②
- Wear/Damage → Replace.



INSTALLATION

Reverse the "REMOVAL" procedures. Note the following points.

1. Apply:
 - Lithium soap base grease
(onto the o-rings, oil seals and bushes).
2. Install:
 - Steering column



Nut (steering column end):
30 Nm (3.0 m · kg, 22 ft · lb)
Bolts (steering bracket):
23 Nm (2.3 m · kg, 17 ft · lb)

⚠ WARNING:

Always use a new cotter pin and lock washer.

3. Bend:
 - Lock washer tabs
 - Ends of cotter pin
4. Install:
 - Tie rods



Nuts:
25 Nm (2.5 m · kg, 18 ft · lb)

NOTE:

Be sure that the rod-end ① on the identification ② side is connected to the knuckle arm.

⚠ WARNING:

Always use a new cotter pin.

5. Bend:
 - Ends of cotter pin
6. Install:
 - Handlebar





Bolt (handlebar holder):
20 Nm (2.0 m · kg, 14 ft · lb)

NOTE:

Be sure the upper handlebar holder mark ① face to front.

⚠ CAUTION:

First tighten the bolts ② on the front side of the handlebar holder, and then tighten the bolts ③ on the rear side.



**7. Apply:**

- Lithium soap base grease
(onto the end of the throttle cable and end of the brake cable).


8. Adjust:

- Toe-in
Refer to the "TOE-IN ADJUSTMENT" section in the CHAPTER 3.
- Front brake
Refer to the "FRONT BRAKE ADJUSTMENT" section in the CHAPTER 3.
- Rear brake
Refer to the "REAR BRAKE ADJUSTMENT" section in the CHAPTER 3.



SWINGARM

- ① Rear shock absorber
- ② Thrust cover
- ③ Chain guard (inner)
- ④ Chain guard (outer)
- ⑤ Bush
- ⑥ Swingarm
- ⑦ Grease nipple
- ⑧ Collar
- ⑨ Lower guard



6



REMOVAL

1. Place the machine on a level place.
2. Elevate the rear wheels by placing a suitable stand under the rear of frame.


⚠ WARNING:

Support the machine securely so there is no danger of it falling over.

3. Remove:

- Rear wheels
- Rear hub (with rear axle)

Refer to the "REAR WHEEL — REMOVAL" section.




4. Remove:

- Cotter pin ①
- Washer ②
- Shaft ③


NOTE:

When removing the lower shaft, hold the swingarm so that it does not drop downwards when the shaft is removed.



5. Remove:

- Shock absorber ①



6. Check:




- Swingarm free play

Swingarm free play inspection steps:

- Check the tightening torque of the pivot shaft (swingarm) securing nut ①.



Nut (swingarm-pivot shaft):
80 Nm (8.0 m · kg, 58 ft · lb)




- Check the swingarm side play **[A]** by moving it from side to side.
If side play noticeable, check the inner collar, bearing, bushing and thrust cover, or adjust the shim.
- Check the swingarm vertical movement **[B]** by moving it up and down.
If vertical movement is tight, binding or rough, check the inner collar, bearing, bushing and thrust cover, or adjust the shim.


7. Remove:

- Swingarm **(1)**

8. Remove:

- Thrust covers **(1)**
- Chain guards **(2)**
- Bushes **(3)**
- Collar **(4)**






INSPECTION


1. Inspect:

- Shock absorber rod
Bends/Damage → Replace the shock absorber assembly.
- Shock absorber
Oil leaks → Replace the shock absorber assembly.
- Spring
Fatigue → Replace the shock absorber assembly.
Move the spring up and down.



2. Inspect:

- Swingarm
Crack/Bend/Damage → Replace.



3. Inspect:

- Pivot shaft ①
Roll the axle on a flat surface.
Bends → Replace.

⚠ WARNING:

Do not attempt to straighten a bent axle.

4. Inspect:

- Thrust cover
- Chain guard
- Collar
- Bush
Wear/Damage → Replace.



INSTALLATION

Reverse the "REMOVAL" procedure.

Note the following points.

1. Apply:

- Lithium soap base grease
(onto the collar, bushes, pivot shaft and
and thrust cover).

2. Install:

- Swingarm



Nut (pivot shaft):
80 Nm (8.0 m · kg, 58 ft · lb)

3. Install:

- Shock absorber



Nut (shock absorber – upper):
45 Nm (4.5 m · kg, 32 ft · lb)



WARNING:

Always use a new cotter pin.

4. Install:

- Rear hub
- Rear wheels

Refer to the "REAR WHEEL – INSTALLATION" section.

5. Adjust:

- Drive chain slack

Refer to the "DRIVE CHAIN SLACK ADJUSTMENT" section in the CHAPTER 3.



Drive chain slack:
30 mm (1.18 in)

DRIVE CHAIN AND SPROCKET

NOTE:




Before removing the drive chain and sprockets, drive chain slack and 10-link length of drive chain should be measured.

REMOVAL

1. Remove:
 - Rear wheels
 - Rear hub (with rear axle)

Refer to the "REAR WHEEL – REMOVAL" section.
2. Remove:
 - Swingarm

Refer to the "SWINGARM – REMOVAL" section.
3. Remove:
 - Foot board ① (right)



4. Straighten:
 - Lock washer tab
5. Remove:
 - Drive sprocket ①
 - Drive chain ②


INSPECTION

1. Measure:
 - 10-link length ② (drive chain)

Out of specification → Replace drive chain.




10-Link length limit:
150.1 mm (5.91 in)




NOTE:

- For measurement make the chain tense by finger.
- 10-link length is a measurement between the insides of the ① and ⑪ rollers as shown.
- Two or three different 10-link lengths should be measured.




2. Clean:

- Drive chain
Place it in kerosene, and brush off as much dirt as possible. Then remove the chain from the kerosene and dry the chain.



⚠ CAUTION:

This machine has a drive chain with small rubber O-rings ① between the chain plates. Steam cleaning, high-pressure washes, and certain solvent can damage these O-rings. Use only kerosene to clean the drive chain.



3. Inspect:


- O-rings ① (drive chain)
Damage → Replace drive chain.
- Rollers ②
- Side plates ③
Damage/Wear → Replace drive chain.

4. Lubricate:

- Drive chain




Drive chain lubricant:
SAE 30 ~ 50 Motor oil



5. Inspect:


- Drive chain stiffness
Stiff → Clean and lubricate or replace.



6. Inspect:

- Drive sprocket
 - Driven sprocket
- More than 1/4 teeth ① wear → Replace sprocket.
Bent teeth → Replace sprocket.

- ② Correct
- ③ Roller
- ④ Sprocket



Driven sprocket replacement steps:

- Straighten the lock washer ① tabs and remove the driven sprocket ②.
- Install a new driven sprocket and lock washers.

⚠ WARNING:

Always use a new lock washers.



Nuts (driven sprocket):
62 Nm (6.2 m · kg, 45 ft · lb)

- Bend the lock washer tabs along the nut flats.

6

INSTALLATION

Reverse the "REMOVAL" procedure.
Note the following points.

1. Install:

- Drive sprocket



Nut (drive sprocket):
75 Nm (7.5 m · kg, 54 ft · lb)

2. Install:

- Swingarm

Refer to the "SWINGARM – INSTALLATION" section.

3. Install:

- Rear hub (with rear axle)
- Rear wheels

Refer to the "REAR WHEEL – INSTALLATION" section.

4. Adjust:

- Drive chain slack

Refer to the "DRIVE CHAIN – SLACK ADJUSTMENT" section in the CHAPTER 3.




Drive chain slack:
30 mm (1.18 in)



ELECTRICAL

YFA1(W) CIRCUIT DIAGRAM





- | | |
|----------------------------------|-----------------------------|
| ① CDI unit | ⑫ Brake switch |
| ② CDI magneto | ⑬ Main switch |
| ③ Rectifier/Regulator | ⑭ "START" switch |
| ④ Ignition coil | ⑮ Shift lever switch |
| ⑤ Spark plug | ⑯ "NEUTRAL" indicator light |
| ⑥ Fuse | ⑰ "REVERSE" indicator light |
| ⑦ Starting motor | ⑱ Reverse relay |
| ⑧ Starter relay | ⑲ "LIGHTS" (Dimmer) switch |
| ⑨ Starting circuit cut-off relay | ⑳ Taillight |
| ⑩ Battery | ㉑ Headlight |
| ⑪ "ENGINE STOP" switch | ㉒ Neutral switch |

COLOR CODE

B	Black	R/W	Red/White
R	Red	B/W	Black/White
W	White	Y/R	Yellow/Red
Br	Brown	L/W	Blue/White
Y	Yellow	G/Y	Green/Yellow
G	Green	G/W	Green/White
O	Orange	G/L	Green/Blue
L	Blue		
Sb	Sky blue		
Gy	Gray		



ELECTRICAL COMPONENTS

- | | |
|----------------------------------|-----------------------|
| ① Wireharness | ⑦ Shift lever switch |
| ② Starting circuit cut-off relay | ⑧ Neutral switch |
| ③ Reverse relay | ⑨ CDI unit |
| ④ Starter relay | ⑩ Rectifier/Regulator |
| ⑤ Fuse | ⑪ Main switch |
| ⑥ Battery | ⑫ Ignition coil |

BATTERY:

CAPACITY: 12V 12AH


SPECIFIC GRAVITY: 1,280

IGNITION COIL:

PRIMARY COIL RESISTANCE

0.56 ~ 0.84 Ω at 20°C (68°F)

SECONDARY COIL RESISTANCE

5.7 ~ 8.5k Ω at 20°C (68°F)



CHECKING OF SWITCHES

Check the switches for the continuity between the terminals to determine correct connection.

Read the following for switch inspection.

SWITCH CONNECTION AS SHOWN IN MANUAL

The manual contains a connection chart as shown left showing the terminal connections of the switches (e.g., main switch, handlebar switch, brake switch, lighting switch, etc.)

The extreme left column indicates the switch positions and the top line indicates the colors of leads connected with the terminals in the switch component.

	B	B/W	R	Br	L/W	L/R
ON			○—○		○—○	
OFF	○—○					
LOCK	○—○					
P	○—○		○—○			○—○

“○—○” indicates the terminals between which there is a continuity of electricity; i.e., a closed circuit at the respective switch positions.

In this chart:

“R and Br” and “L/W and L/R” are continuous with the “ON” switch position.

“B and B/W” is continuous with the “OFF” switch position.


“B and B/W” is continuous with the “LOCK” switch position.

“B and B/W” and “R and L/R” are continuous with the “P” switch position.

CHECKING SWITCH FOR TERMINAL CONNECTION

Before checking the switch, refer to the connection chart as shown above and check for the correct terminal connection (closed circuit) by the color combination.

To explain how to check the switch, the main switch is taken for example in the following.



1. Disconnect the main switch coupler from the wireharness.

⚠ CAUTION:


Never disconnect the main switch coupler by pulling the leads. Otherwise, leads may be pulled off the terminals inside the coupler.

2. Inspect whether any lead is off the terminal inside the coupler. If it is, repair it.

NOTE:

If the coupler is clogged with mud or dust, blow it off by compressed air.

3. Use the connection chart to check the color combination for continuity (a closed circuit). In this example, the continuity is as follows.



“R and Br” and “L/W and L/R” are continuous with the “ON” switch position.

“B and B/W” is continuous with the “OFF” switch position.

“B and B/W” is continuous with the “LOCK” switch position.


“B and B/W” and “R and L/R” are continuous with the “P” switch position.

Please note that there is no continuity (an open circuit) at all for the color combinations other than the above.

4. Check the switch component for the continuity between “R and Br”.

Checking steps:

- Turn the switch key to the “ON”, “OFF”, “LOCK”, and “P” several times.
- Set the pocket tester selector to the “ $\Omega \times 1$ ”.
- Connect the tester (+) lead to the “R” lead terminal in the coupler and the (–) lead to the “Br” lead terminal.


**NOTE:**

Use thin probes for checking the continuity. Otherwise, the probes may contact other terminals inside the coupler.

- Check the continuity between "R" and "Br" at the respective switch positions of "ON" ①, "OFF" ②, "LOCK" ③, and "P" ④. There must be continuity (the tester indicating "0") at the "ON" switch position, and there must be no continuity (the tester indicating "∞") at "OFF", "LOCK", or "P". There is something wrong between "R" and "Br" if there is no continuity at the "ON" position or if there is some continuity either at the "OFF" or "LOCK" or "P".

NOTE:

Check the switch for continuity several times.



5. Next go on to checking of the continuity between "B and B/W", "L/W and L/R", and "R and L/R" at the respective switch positions, as in the same manner mentioned above.
6. If there is something wrong with any one of the combinations, replace the switch component.




CHECKING OF BULBS (FOR HEADLIGHT, TAIL/BRAKE LIGHT, FLASHER LIGHT, METER LIGHT, ETC.)

Check the bulb terminal continuity for the condition of the bulb.

KINDS OF BULBS

The bulbs used in the motorcycle are classified as shown left by the shape of the bulb socket.



Ⓐ and Ⓑ are mainly used for the headlight.

Ⓒ is mainly used for the flasher light and tail/brake light.

Ⓓ and Ⓔ are mainly used for the meter light and other indicator lights.

CHECKING BULB CONDITION

1. Remove the bulb.

NOTE:

- Bulbs of the Ⓐ and Ⓑ type uses a bulb holder. Remove the bulb holder before removing the bulb itself. Most of the bulb holders for this type can be removed by turning them counter-clockwise.
- Most of the bulbs of Ⓒ and Ⓓ type can be removed from the bulb sockets by pushing and turning them counterclockwise.
- Bulbs of the Ⓔ type can be removed from the bulb sockets by simply pulling them out.

⚠ CAUTION:

Be sure to hold the socket firmly when removing the bulb. Never pull the lead. Otherwise, the lead may be pulled off the terminal in the coupler.

⚠ WARNING:


Keep flammable products or your hands away from the headlight bulb while it is on. It will be hot. Do not touch the bulb until it cools down.



2. Check the bulb terminals for continuity.

Checking steps:

- Set the pocket tester selector to the " $\Omega \times 1$ ".
- Connect the tester leads to the respective bulb terminals. Take for example a 3-terminal bulb as shown left. First check the continuity between the ① and ② terminals by connecting the tester (+) lead to the ① terminal and the tester (–) lead to the ② terminal. Then check the continuity between the ① and ③ terminals by connecting the tester (+) lead still to the ① terminal and the tester (–) lead to the ③ terminal. If the tester shows " ∞ " in either case, replace the bulb.




3. Check the bulb socket by installing a proven bulb to it. As in the checking of bulbs, connect the pocket tester leads to the respective leads of the socket and check for continuity in the same manner as mentioned above.



IGNITION SYSTEM

CIRCUIT DIAGRAM

Below circuit diagram shows ignition circuit.







NOTE:

For the color codes, see page 7-2.

- ① CDI unit
- ② CDI magneto
- ④ Ignition coil
- ⑤ Spark plug
- ⑪ "ENGINE STOP" switch
- ⑫ Brake switch
- ⑬ Main switch
- ⑮ Shift lever switch





TROUBLESHOOTING

IF IGNITION SYSTEM SHOULD BECOME INOPERATIVE (NO SPARK OR INTERMITTENT SPARK).

Procedure

Check;

- | | |
|------------------------------|----------------------------|
| 1. Spark plug | 7. Shift lever switch |
| 2. Ignition spark gap | 8. Brake switch |
| 3. Spark plug cap resistance | 9. Pickup coil resistance |
| 4. Ignition coil resistance | 10. Source coil resistance |
| 5. "ENGINE STOP" switch | 11. Wiring connection. |
| 6. Main switch | (Entire ignition system) |

NOTE:

- Remove the following parts before troubleshooting.

- | | |
|-------------------|-----------------|
| 1) Seat | 4) Front fender |
| 2) Cover (front) | 5) Rear fender |
| 3) Cover (center) | |

- Use the following special tools in this troubleshooting.



Dynamic spark tester:
P/N. YM34487, 90890-03144



Pocket tester:
P/N. YU-03112, 90890-03112

1. Spark plug

- Check the spark plug condition.
 - Check the spark plug type.
 - Check the spark plug gap.
- Refer to the "SPARK PLUG INSPECTION" section in the CHAPTER 3.

Standard spark plug:

C7HSA (NGK), U22FS-U (ND)
..... USA, AUS
CR7HS (NGK) . . CDN, CH, F, NL, S, DK



Spark plug gap:
0.6 ~ 0.7 mm (0.024 ~ 0.028 in)

INCORRECT

Repair or replace spark plug.

CORRECT

*




2. Ignition spark gap

- Disconnect the spark plug cap from the spark plug.
- Connect the Dynamic spark tester ① as shown.

- ② Spark plug cap
- ③ Spark plug

- Turn the main switch to "ON".
- Kick the kick crank



- Check the ignition spark gap.
- Start engine, and increase spark gap until misfire occurs.



Minimum spark gap:
6.0 mm (0.24 in)

MEETS SPECIFICATION


Ignition system is good.



OUT OF SPECIFICATION
OR NO SPARK

3. Spark plug cap resistance

- Remove the spark plug cap.
- Connect the pocket tester ($\Omega \times 1k$) to the spark plug cap.



- Check the spark plug cap for specified resistance.



Spark plug cap resistance:
8 ~ 12k Ω at 20°C (68°F)

OUT OF SPECIFICATION

Spark plug cap is faulty, replace it.



MEETS
SPECIFICATION

*




4. Ignition coil resistance

- Disconnect the ignition coil lead (Orange) from the ignition coil.
- Connect the pocket tester ($\Omega \times 1$) to the ignition coil.

Tester (+) lead → Lead terminal ①

Tester (–) lead → Ignition coil base ②



- Check the primary coil for specified resistance.



Primary coil resistance:

$0.56 \sim 0.84 \Omega$ at 20°C (68°F)

(Lead terminal – Ignition coil base)
coil base)

- Disconnect the spark plug lead from the plug cap.
- Connect the Pocket tester ($\Omega \times 1\text{k}$) to the ignition coil.

Tester (+) lead → Lead terminal ①

Tester (–) lead → Spark plug lead ③

- Check the secondary coil for specified resistance.



Secondary coil resistance:

$5.7 \sim 8.5\text{k}\Omega$ at 20°C (68°F)

(Lead terminal – spark plug
lead)

OUT OF SPECIFICATION

Ignition coil is faulty, replace it.



BOTH MEET
SPECIFICATIONS



*

7



5. "ENGINE STOP" switch

- Disconnect the "ENGINE STOP" switch leads from the wireharness.
- Check the switch component for the continuity between "Black/White ① and Black ② ". Refer to the "CHECKING OF SWITCHES" section.



INCORRECT



"ENGINE STOP" switch is faulty, replace handlebar switch (Left).



CORRECT

6. Main switch

- Disconnect the main switch coupler from the wireharness.
- Check the switch component for the continuity between "Black/White ① and Black ② ". Refer to the "CHECKING OF SWITCHES" section.



INCORRECT

Main switch is faulty, replace it.




CORRECT

7



7. Shift lever switch

- Disconnect the shift lever switch leads from the wireharness.
- Check the switch component for the continuity between "Green/White ① and Black ② ". Refer to the "CHECKING OF SWITCHES" section.



INCORRECT


Shift lever switch is faulty, replace it.



CORRECT

8. Brake switch

- Disconnect the brake switch leads from the wireharness.
- Check the switch component for the continuity between "Green/Yellow ① and Black ② ". Refer to the "CHECKING OF SWITCHES" section.



INCORRECT

Brake switch is faulty, replace it.





CORRECT



9. Pickup coil resistance

- Disconnect the CDI magneto coupler from the wireharness.
- Connect the Pocket tester ($\Omega \times 100$) to the pickup coil leads.

Tester (+) lead → Red ① lead
Tester (−) lead → Gray ② lead



- Check the pickup coil for specified resistance.



Pickup coil resistance:
280 ~ 420 Ω at 20°C (68°F)
(Red – Gray)

OUT OF SPECIFICATION

Pickup coil is faulty, replace it.





MEET SPECIFICATION

10. Source coil resistance

- Disconnect the CDI magneto coupler from the wireharness.
- Connect the Pocket tester ($\Omega \times 100$) to the source coil leads.

Tester (+) lead → Brown ① lead
Tester (−) lead → Green ② lead





- Check the source coil for specified resistance.



Source coil resistance:
310 ~ 400Ω at 20°C (68°F)
(Brown – Green)

OUT OF SPECIFICATION

Source coil is faulty, replace it.



MEETS SPECIFICATION

11. Wiring connection

Check the entire ignition system for connections. Refer to the "WIRING DIAGRAM" section.

POOR CONNECTION

Correct





CORRECT

CDI unit is faulty, replace it.

**NOTE:**

For the color codes, see page 7-2.

- ⑥ Fuse
- ⑦ Starting motor
- ⑧ Starter relay
- ⑨ Starting circuit cut-off relay
- ⑩ Battery
- ⑬ Main switch
- ⑭ "START" switch
- ⑰ Neutral switch





TROUBLESHOOTING

STARTING MOTOR DOES NOT OPERATE.

Procedure (1)

Check;

1. Starting motor
2. Battery
3. Starter relay
4. Wiring connection

Procedure (2)

Check;

1. Fuse
2. Main switch
3. "START" switch
4. Starting circuit cut-off relay
5. Neutral switch
6. Wiring connection

NOTE:

- Remove the following parts before troubleshooting.

- 1) Seat
- 2) Cover (front)
- 3) Cover (center)
- 4) Front fender
- 5) Rear fender

- Use the following special tool(s) in this troubleshooting.




Pocket tester:

P/N. YU-03112, 90890-03112

Procedure (1)

1. Starting motor

- Connect the battery leads to the battery.
- Connect the terminals of the starter relay using a jumper lead ①. *
- Check starting motor operation.

STARTING MOTOR
DOES NOT OPERATE.

*

*

⚠ WARNING:

- A wire for the jumper lead must have the equivalent capacity as that of the battery lead or more, otherwise it may cause the jumper lead to be burned.
- This check is likely to produce sparks, so be sure that no flammable gas or fluid is in the vicinity.

STARTING MOTOR
OPERATES.

Go to the "Procedure (2)".

**2. Battery**

- Check the battery condition. Refer to the "BATTERY INSPECTION" section in the CHAPTER 3.

Specific gravity:
1.280 at 20°C (68°F)

INCORRECT


- Refill battery fluid.
- Clean battery terminals.
- Recharge or replace battery.



CORRECT

3. Starter relay

- Disconnect the battery lead* and starting motor lead from the starter relay.
- Disconnect the starter relay coupler from the wireharness.
- Connect the battery and Pocket tester ($\Omega \times 1$) to the starter relay as shown.



- Check the starter relay for continuity.

*

CAUTION:

Cover the battery lead end with a electrical tape to prevent sparks.

NO CONTINUITY

Starter relay is faulty, replace it.
Correct.



CONTINUITY

4. Wiring connection

- Check the entire starting system for connections. Refer to the "WIRING DIAGRAM" section.

POOR CONNECTION

Correct.



CORRECT

Starting motor is faulty, check it.
Refer to the "STARTING MOTOR" section
for check.



Procedure (2)

1. Fuse

- Check the fuse condition. Refer to the "FUSE INSPECTION" section in the CHAPTER 3.

INCORRECT



Fuse is faulty, replace it.



CORRECT

2. Main switch

- Disconnect the main switch coupler from the wireharness.
- Check the switch component for the continuity between "Red ① and Brown ②". Refer to the "CHECKING OF SWITCHES" section.



INCORRECT



Main switch is faulty, replace it.



CORRECT

3. "START" switch

- Disconnect the handlebar switch coupler from the wireharness.
- Check the switch component for the continuity between "Brown ① and Red/White ②". Refer to the "CHECKING OF SWITCHES" section.



INCORRECT

"START" switch is faulty, replace handlebar switch (left).




CORRECT

*



4. Starting circuit cut-off relay

- Disconnect the starting circuit cut-off relay from the wireharness.
- Connect the battery and Pocket tester as shown.



- Check the starting circuit cut-off relay for continuity.

NO CONTINUITY



Starting circuit cut-off relay is faulty, replace it.



CONTINUITY

5. Neutral switch

- Disconnect the neutral switch lead from the wireharness.
- Check the switch component for the continuity between "Blue ① and Ground". Refer to the "CHECKING OF SWITCH" section.



INCORRECT

Neutral switch is faulty, replace it.



CORRECT

6. Wiring connection

- Check the entire starting system for connections. Refer to the "WIRING DIAGRAM" section.

POOR CONNECTION

Correct.



CORRECT

Electric starting system is good.





STARTING MOTOR

- ① Starting motor lead
- ② O-ring
- ③ Yoke assembly
- ④ Armature coil assembly
- ⑤ Brush assembly

7 Nm (0.7 m • kg, 5.1 ft • lb)

A	MICA UNDERCUT: 1.5 mm (0.06 in)
B	COMMUTATOR DIAMETER: 22.0 mm (0.87 in) < WEAR LIMIT > < 21.0 mm (0.83 in) >
C	OVERALL LENGTH (BRUSH): 10.0 mm (0.39 in) < WEAR LIMIT > < 3.5 mm (0.14 in) >




**Removal**

1. Remove:

- Bolts ①
- Screw ② (starting motor lead)


Disassembly

- Put identifying marks ① on the brackets for reassembly as shown.




2. Remove:

- Screws ①




3. Remove:

- Bracket (rear) ①
- Yoke assembly ②
- Armature coil assembly ③
- Bracket (front) ④

**Inspection**


1. Measure:

- Brush length (each) ①
- Out of specification → Replace brush.




Brush length:
10.0 mm (0.39 in)

< Wear limit > :
< 3.5 mm (0.14 in) >



2. Inspect:

- Brush spring
Damage → Replace.




3. Inspect:

- Commutator (outer surface)
Grooved wear/Burning/scratches → Smooth out of using a sandpaper (# 500 ~ 600).

NOTE:

Sand the commutator outer surface lightly and evenly.



4. Measure:

- Commutator diameter (a)
Out of specification → Replace.



Outside diameter:

22 mm (0.87 in)

< Wear limit > :

< 21 mm (0.83 in) >

5. Measure:

- Mica undercut (a)
Out of specification → Scrape mica using a hacksaw blade.




Mica undercut:

1.5 mm (0.06 in)

NOTE:

The mica insulation of the commutator must be undercut to ensure proper operation of the commutator.




6. Measure:

- Armature coil resistance
- Out of specification → Replace.



Armature coil resistance:
 $0.016 \sim 0.024 \Omega$ at 20°C (68°F)



7. Check:


- Armature coil insulation
- Set the pocket tester selector to " $\Omega \times 1\text{K}$ " position.
 Continuity → Replace.

Assembly and Installation

Reverse the "Removal" and "Disassembly" procedures. Note the following points.

1. Apply:

- Lithium soap base grease
 (onto oil seal lips and o-rings)



2. Install:


- Brush springs
- Brushes
- Armature coil assembly
 (by means of thin screw driver)

3. Install:


- Yoke assembly

NOTE:

Install the yoke assembly with its long skirt
 (a) forward as shown.



- (a) Long skirt
- (b) Short skirt

**NOTE:**

Align identifying marks ① on the brackets as shown.

4. Install:

Starting motor



Bolts (starting motor):

7 Nm (0.7 m · kg, 5,1 ft · lb)

Use LOCTITE®


This image shows a full page of white paper with horizontal dotted lines. The lines are evenly spaced and run across the width of the page, providing a guide for handwriting practice. There are no margins, text, or other markings on the page.



CHARGING SYSTEM

CIRCUIT DIAGRAM

Below circuit diagram shows charging circuit.







NOTE: _____

For the color codes, see page 7-2.

- ② CDI magneto
- ③ Rectifier/Regulator
- ⑥ Fuse
- ⑩ Battery





TROUBLESHOOTING

THE BATTERY IS NOT CHARGED.

Procedure

Check;

- | | |
|--------------------|-----------------------------|
| 1. Fuse | 4. Charging coil resistance |
| 2. Battery | 5. Wiring connection |
| 3. Charging output | (Entire charging system) |

NOTE:

- Remove the following parts before troubleshooting.
 - 1) Seat
- Use the following special tool(s) in this troubleshooting.



Inductive tachometer:

P/N. YU-08036, 90890-03113



Pocket tester:

P/N. YU-03112, 90890-03112

1. Fuse

- Check the fuse condition. Refer to the "FUSE INSPECTION" section in the CHAPTER 3.

INCORRECT

Fuse is faulty, replace it.

CORRECT

2. Battery

- Check the battery condition. Refer to the "BATTERY INSPECTION" section in the CHAPTER 3.

INCORRECT

- Refill battery fluid.
- Clean battery terminals.
- Recharge or replace battery

Specific gravity:

1.280 at 20°C (68°F)

CORRECT

3. Charging output

- Disconnect the battery positive lead (red) from the wireharness.
- Connect the Inductive tachometer to the spark plug lead.


7



- Connect the Pocket tester (DCA-5) to the battery positive lead.

Tester (+) lead → Fuse ① lead

Tester (–) lead → Battery positive ② lead



- Turn the “LIGHT” (Dimmer) switch to “OFF” position.
- Start the engine.
- Accelerate the engine to specifications and check the charging amperage.

⚠ CAUTION:

Never disconnect the leads from the battery before stopping the engine.



Charging output amperage:
0.8A or more at 3,000 r/min
1.3A or more at 8,000 r/min

MEETS SPECIFICATION

Charging system is good.

OUT OF
SPECIFICATION



4. Charging coil resistance

- Disconnect the CDI magneto coupler from the wireharness.
- Connect the Pocket tester ($\Omega \times 1$) to the charging coil leads.

**Charging coil:**

Tester (+) lead → White lead ①

Tester (–) lead → Black lead ②



- Check the charging coil for specified resistance.

**Charging coil resistance:****0.56 ~ 0.84 Ω at 20°C (68°F)**
(White – Black)

OUT OF SPECIFICATION

Charging coil is faulty, replace it.

MEETS SPECIFICATIONS

5. Wiring connection

- Check the entire charging system for connections. Refer to the "WIRING DIAGRAM" section.

POOR CONNECTION

Correct.

CORRECT

Rectifier/Regulator is faulty, replace it.


This image shows a single page of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.



LIGHTING SYSTEM

CIRCUIT DIAGRAM



Below circuit diagram shows lighting circuit.



**NOTE:** _____

For the color codes, see page 7-2.

- ② CDI magneto
- ③ Rectifier/Regulator
- ⑱ "LIGHTS" (Dimmer) switch
- ⑳ Taillight
- ㉑ Headlight





TROUBLESHOOTING

HEADLIGHT AND/OR TAILLIGHT DOES NOT COME ON.

Procedure

Check;

1. Bulb and bulb socket (Headlight/Taillight)
2. "LIGHTS" (Dimmer) switch
3. Lighting voltage
4. Lighting coil resistance
5. Wiring connection

NOTE:

- Remove the following parts before troubleshooting.
 - 1) Seat
 - 2) Cover (front)
 - 3) Cover (center)
- Use the following special tool(s) in this troubleshooting.



Inductive tachometer:

P/N. YU-08036, 90890-03113



Pocket tester:

P/N. YU-03112, 90890-03112

1. Bulb and bulb socket (Headlight/Taillight)

- Check the bulb and bulb socket for continuity. Refer to the "CHECKING OF BULBS" section.


NO CONTINUITY

Bulb and/or bulb socket are faulty, replace.

CONTINUITY

2. "LIGHTS" (Dimmer) switch

- Disconnect the handlebar switch coupler and leads from the wireharness.
- Check the switch component for the continuity between "Yellow/Red ① and Blue ②", "Yellow/Red ① and Green ③" and "Yellow/Red ① and Yellow ④". Refer to the "CHECKING OF SWITCHES" section.



INCORRECT

"LIGHTS" (Dimmer) switch is faulty, replace handlebar switch (Left).

CORRECT

*





3. Lighting voltage

- Connect the inductive tachometer to the spark plug lead.
- Connect the Pocket tester (ACV-20) to the headlight leads.

Tester (+) lead → Green lead ①

Tester (–) lead → Black lead ②



- Turn the “LIGHTS” (Dimmer) switch to “LO” position.
- Start the engine.
- Accelerate the engine to specifications and check the lighting voltage.



Lighting output voltage:

Minimum

12.0V or more at 3,000 r/min

Maximum

14.8V or less at 8,000 r/min

MEETS SPECIFICATION



Lighting system is good.





OUT OF
SPECIFICATION

4. Lighting coil resistance

- Disconnect the CDI magneto coupler from the wireharness.
- Connect the Pocket tester ($\Omega \times 1$) to the the lighting coil leads.



Tester (+) lead → Yellow lead ①
Tester (–) lead → Black lead ②



- Check the lighting coil for specified resistance.



Lighting coil resistance:
 $0.32 \sim 0.48 \Omega$ at 20°C (68°F)
(Yellow – Black)

OUT OF SPECIFICATION

Lighting coil is faulty, replace it.

MEETS
SPECIFICATION

5. Wiring connection

- Check the entire lighting system for connections. Refer to the "WIRING DIAGRAM" section.

POOR CONNECTION

Correct.

CORRECT

Rectifier/Regulator is faulty, replace it.

— MEMO —


This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.



SIGNAL SYSTEM

CIRCUIT DIAGRAM



Below circuit diagram shows signal circuit.





NOTE: _____
For the color codes, see page 7-2.

- ⑥ Fuse
- ⑩ Battery
- ⑬ Main switch
- ⑮ Shift lever switch
- ⑯ "NEUTRAL" indicator light
- ⑰ "REVERSE" indicator light
- ⑱ Reverse relay
- ⑲ Neutral switch





TROUBLESHOOTING

- "NEUTRAL" INDICATOR LIGHT DOES NOT COME ON.
- "REVERSE" INDICATOR LIGHT DOES NOT COME ON.

Procedure

Check;

1. Fuse
2. Battery
3. Main switch
4. Wiring connection

NOTE:

- Remove the following parts before troubleshooting.
 - 1) Seat
- Use the following special tool(s) in this troubleshooting.



Pocket tester:
P/N. YU-03112, 90890-03112

1. Fuse

- Check the fuse condition. Refer to the "FUSE INSPECTION" section in the CHAPTER 3.

INCORRECT

Fuse is faulty, replace it.



CORRECT

2. Battery

- Check the battery condition. Refer to the "BATTERY INSPECTION" section in the CHAPTER 3.

INCORRECT

- Refill battery fluid.
- Clean battery terminals.
- Recharge or replace battery.

Specific gravity:
1.280 at 20°C (68°F)



CORRECT



*

7



3. Main switch

- Disconnect the main switch coupler from the wireharness.
- Check the switch component for the continuity between "Red ① and Brown ②". Refer to the "CHECKING OF SWITCHES" section.



INCORRECT

Main switch is faulty, replace it.



CORRECT

4. Wiring connection

- Check the entire signal system for connections. Refer to the "WIRING DIAGRAM" section.



CORRECT

Check condition of each circuit for signal system. Refer to "SIGNAL SYSTEM CHECK" section.

POOR CONNECTION

Correct.



SIGNAL SYSTEM CHECK

1. "NEUTRAL" indicator light does not come on.

1. Bulb and bulb socket

- Check the bulb and bulb socket for continuity. Refer to the "CHECKING OF BULBS" section.



CONTINUITY



NO CONTINUITY



Bulb and/or bulb socket are faulty, replace.

2. Neutral switch

- Disconnect the neutral switch lead from the wireharness.
- Check the switch component for the continuity between "Blue ① and Ground". Refer to the "CHECKING OF SWITCHES" section.



INCORRECT



Neutral switch is faulty, replace it.




CORRECT

3. Voltage

- Connect the Pocket tester (DC20V) to the bulb socket connector.

Tester (+) lead → Brown ① lead

Tester (−) lead → Frame ground





- Turn the main switch to "ON".
- Check for voltage (12V) on the "Brown" lead at bulb socket connector.



MEETS
SPECIFICATION (12V)

This circuit is good.

OUT OF SPECIFICATION



Wiring circuit from main switch to
bulb socket connector is faulty, repair.

2. "REVERSE" indicator light does not come on.

1. Bulb and bulb socket

- Check the bulb and bulb socket for continuity. Refer to the "CHECKING OF BULBS" section.



CONTINUITY


NO CONTINUITY



Bulb and/or bulb socket are faulty,
replace.

2. Shift lever switch

- Disconnect the shift lever switch leads from the wireharness.
- Check the switch component for the continuity between "Green/White ① and Black ② ". Refer to the "CHECKING OF SWITCHES" section.



CORRECT

INCORRECT



Select lever switch is faulty, replace it.

TROUBLESHOOTING

NOTE:

The following troubleshooting does not cover all the possible causes of trouble. It should be helpful, however, as a guide to troubleshooting. Refer to the relative procedure in this manual for inspection, adjustment and replacement of parts.

STARTING FAILURE/HARD STARTING

FUEL SYSTEM

PROBABLE CAUSE

Fuel tank	• Empty • Clogged fuel filter • Clogged fuel breather hose • Deteriorated fuel or fuel containing water or foreign material
Fuel cock	• Clogged fuel hose
Carburetor	• Deteriorated fuel, fuel containing water or foreign material • Clogged pilot jet • Clogged pilot air passage • Sucked-in air • Deformed float • Groove-worn needle valve • Improperly sealed valve seat • Improperly adjusted fuel level • Improperly set pilot jet • Clogged starter jet • Starter plunger malfunction
Air cleaner	• Clogged air filter

ELECTRICAL SYSTEM

PROBABLE CAUSE

- | | |
|---------------------|---|
| Spark plug | <ul style="list-style-type: none"> • Improper plug gap • Worn electrodes • Wire between terminals broken • Improper heat range • Faulty spark plug cap |
| Ignition coil | <ul style="list-style-type: none"> • Broken or shorted primary/secondary • Faulty spark plug lead • Broken body |
| C.D.I. unit system | <ul style="list-style-type: none"> • Faulty C.D.I. unit • Faulty source coil • Faulty pick-up coil • Broken woodruff key |
| Switches and wiring | <ul style="list-style-type: none"> • Faulty main switch • Faulty engine stop switch • Broken or shorted wiring • Faulty shift lever switch • Faulty brake switch |
| Starter motor | <ul style="list-style-type: none"> • Faulty starter motor • Faulty starter relay • Faulty starting circuit cut-off relay • Faulty battery |

COMPRESSION SYSTEM


PROBABLE CAUSE

- | | |
|----------------------------|--|
| Cylinder and cylinder head | <ul style="list-style-type: none"> • Loose spark plug • Loose cylinder head or cylinder • Broken cylinder head gasket • Broken cylinder gasket • Worn, damaged or seized cylinder |
| Piston and piston rings | <ul style="list-style-type: none"> • Improperly installed piston ring • Worn, fatigued or broken piston ring • Seized piston ring • Seized or damaged piston |
| Crankcase and crankshaft | <ul style="list-style-type: none"> • Improperly seated crankcase • Seized crankshaft |

POOR IDLE SPEED PERFORMANCE

FUEL SYSTEM


PROBABLE CAUSE



POOR MEDIUM AND HIGH SPEED PERFORMANCE


FUEL SYSTEM

PROBABLE CAUSE




ELECTRICAL SYSTEM

PROBABLE CAUSE



COMPRESSION SYSTEM


PROBABLE CAUSE



FAULTY GEAR SHIFTING


HARD SHIFTING

PROBABLE CAUSE




SHIFT LEVER DOES NOT MOVE

PROBABLE CAUSE




JAMP-OUT GEAR

PROBABLE CAUSE




FAULTY AUTOMATIC TRANSMISSION (V-BELT TYPE)

MACHINE DOES NOT MOVE WHILE ENGINE IS OPERATING.




CLUTCH-OUT FAILURE

PROBABLE CAUSE




POOR STANDING START (LOW CLIMBING ABILITY)



POOR ACCELERATION (POOR HIGH SPEED)

PROBABLE CAUSE



FAULTY BRAKE

POOR BRAKING EFFECT

└ Drum brake

PROBABLE CAUSE

- Worn brake shoe
- Worn or rusty brake drum
- Improperly adjusted brake free play
- Improper brake cam lever position
- Improper brake shoe position
- Fatigue/Damaged return spring
- Oily or greasy brake shoe
- Oil or greasy brake drum
- Broken brake cable

SHOCK ABSORBER MALFUNCTION

MALFUNCTION

PROBABLE CAUSE

- Bent or damaged damper rod
- Damaged oil seal lip
- Fatigued shock absorber spring

OVERHEATING

OVERHEATING

└ Ignition system

└ Fuel system

└ Compression system

└ Engine oil

└ Brake


PROBABLE CAUSE

- Improper spark plug gap
- Improper spark plug heat range
- Faulty C.D.I. unit
- Improper carburetor main jet (Improper setting)
- Improperly adjusted fuel height
- Clogged air cleaner element
- Heavy carbon build-up
- Incorrect oil level
- Improper oil viscosity
- Inferior oil quality
- Dragging brake

INSTABLE HANDLING

INSTABLE HANDLING

PROBABLE CAUSE



FAULTY SIGNAL AND LIGHTING SYSTEM

HEADLIGHT DARK

PROBABLE CAUSE

- Improper bulb
- Too many electric accessories
- Hard charging (Broken charging coil and/or faulty rectifier/regulator)
- Incorrect connection
- Improperly grounded
- Poor contacts (main or light switch)
- Bulb life expired

BULB BURNT OUT

PROBABLE CAUSE

- Improper bulb
- Faulty battery
- Faulty rectifier/regulator
- Improperly grounded
- Faulty main and/or light switch
- Bulb life expired

YFA1(W) WIRING DIAGRAM

