

IMPORTANT

WARNING/CAUTION/NOTE

Please read this manual and follow its instructions carefully. To emphasize special information, the words **WARNING**, **CAUTION** and **NOTE** have special meanings. Pay special attention to the messages highlighted by these signal words.

WARNING:

Indicates a potential hazard that could result in death or injury.

CAUTION:

Indicates a potential hazard that could result in vehicle damage.

NOTE:

Indicates special information to make maintenance easier or instructions clearer.

WARNING:

This service manual is intended for authorized Suzuki dealers and qualified service mechanics only. Inexperienced mechanics or mechanics without the proper tools and equipment may not be able to properly perform the services described in this manual.

Improper repair may result in injury to the mechanic and may render the vehicle unsafe for the driver and passengers.

WARNING:

For vehicles equipped with a Supplemental Restraint (Air Bag) System:

- Service on and around the air bag system components or wiring must be performed only by an authorized SUZUKI dealer. Refer to “Air Bag System Components and Wiring Location View” under “General Description” in air bag system section in order to confirm whether you are performing service on or near the air bag system components or wiring. Please observe all WARNINGS and “Service Precautions” under “On-Vehicle Service” in air bag system section before performing service on or around the air bag system components or wiring. Failure to follow WARNINGS could result in unintentional activation of the system or could render the system inoperative. Either of these two conditions may result in severe injury.
- If the air bag system and another vehicle system both need repair, Suzuki recommends that the air bag system be repaired first, to help avoid unintended air bag system activation.
- Do not modify the steering wheel, instrument panel or any other air bag system component (on or around air bag system components or wiring). Modifications can adversely affect air bag system performance and lead to injury.
- If the vehicle will be exposed to temperatures over 93°C (200°F) (for example, during a paint baking process), remove the air bag system components (air bag (inflator) modules, SDM and/or seat belt with pretensioner) beforehand to avoid component damage or unintended activation.

FOREWORD

This manual contains procedures for diagnosis, maintenance, adjustments, minor service operations, replacement of components (Service) and for disassembly and assembly of major components (Unit Repair-Overhaul).

Applicable model: RH413/RH416

The contents are classified into sections each of which is given a section number as indicated in the Table of Contents on following page. And on the first page of each individual section is an index of that section.

This manual should be kept in a handy place for ready reference of the service work.

Strict observance of the so specified items will enable one to obtain the full performance of the vehicle.

When replacing parts or servicing by disassembling, it is recommended to use SUZUKI genuine parts, tools and service materials (lubricant, sealants, etc.) as specified in each description.

All information, illustrations and specifications contained in this literature are based on the latest product information available at the time of publication approval. And used as the main subject of description is the vehicle of standard specifications among others.

Therefore, note that illustrations may differ from the vehicle being actually serviced.

The right is reserved to make changes at any time without notice.

Related Manual

Manual Name	Manual No.
RH413/RH416 Wiring Diagram Manual	99512-54G20-015

SUZUKI MOTOR CORPORATION

OVERSEAS SERVICE DEPARTMENT

TABLE OF CONTENTS

GENERAL INFORMATION	
General Information	0A
Maintenance and Lubrication	0B
HEATING AND AIR CONDITIONING	
Heater and Ventilation	1A
Air Conditioning (Optional)	1B
STEERING, SUSPENSION, WHEELS AND TIRES	3
DRIVE SHAFT AND PROPELLER SHAFT	
Front Drive Shaft	4A
Propeller Shafts	4B
Rear Drive Shaft	4C
BRAKE SYSTEM	
Brakes	5
Antilock Brake System (ABS)	5B
ENGINE	
Engine General Information and Diagnosis (M13/M16 Engines)	6
Engine Mechanical (M13 and M16 Engines)	6A1
Engine Cooling	6B
Engine Fuel	6C
Engine and Emission Control System (M13/M16 Engines)	6E1
Ignition System (Electronic Ignition System)	6F1
Cranking System	6G
Charging System	6H
Exhaust System	6K

TRANSAXLE, CLUTCH AND DIFFERENTIAL	
Manual Transaxle	7A1
Automatic Transaxle (4 A/T)	7B1
Clutch	7C1
Transfer	7D
Rear Differential	7F
ELECTRICAL SYSTEM	
Body Electrical System	8
Wiring Diagram	8A
Immobilizer Control System (if equipped)	8G
BODY SERVICE	
9	
RESTRAINT SYSTEM	
Restraint System	10
Air Bag System	10B

0A	
0B	7A1
	7B1
1A	7C1
1B	7D
	7F
3	
	8
4A	8A
4B	8G
4C	9
5	10
5B	10B
6	
6A1	
6B	
6C	
6E1	
6F1	
6G	
6H	
6K	

NOTE:

The screen toned Section 8A is in Wiring Diagram Manual mentioned in FOREWORD of this manual.

SECTION 0A

0A


GENERAL INFORMATION

CONTENTS

How To Use This Manual.....	0A-2		
Precautions.....	0A-3		
Precaution for Vehicles Equipped with a Supplemental Restraint (Air Bag) System.....	0A-3		
Diagnosis.....	0A-3		
Servicing and handling.....	0A-4		
General Precautions	0A-6		
Precautions for Catalytic Converter.....	0A-9		
Precaution for Installing Mobile Communication Equipment	0A-9		
Precaution for Vehicle Tie-Down Hooks.....	0A-10		
Precaution in Servicing Full-Time 4WD Vehicle	0A-10		
Precautions for Electrical Circuit Service	0A-11		
Electrical Circuit Inspection Procedure.....	0A-14		
Open circuit check.....	0A-14		
		Short circuit check (wire harness to ground).....	0A-16
		Intermittent and Poor Connection	0A-17
		Identification Information.....	0A-19
		Vehicle Identification Number	0A-19
		Engine Identification Number	0A-19
		Transmission Identification Number.....	0A-19
		Warning, Caution and Information Labels..	0A-20
		Vehicle Lifting Points	0A-21
		Abbreviations and Symbols May Be Used in This Manual	0A-23
		Fastener Information	0A-27
		Metric Fasteners	0A-27
		Fastener Strength Identification	0A-27
		Standard Tightening Torque	0A-27

How To Use This Manual

- 1) There is a "TABLE OF CONTENTS" on the third page of this manual, whereby you can easily find the section that offers the information you need. Also, there is a CONTENTS on the first page of each section, where the main items in that section are listed.
- 2) Each section of this manual has its own pagination. It is indicated at the top of each page along with the Section name.
- 3) The special tool usage and torque specification are given as shown in the figure.



- 6) Install oil pump. Refer to "Oil pump" in this section.
- 7) Install flywheel (for M/T vehicle) or drive plate (for A/T vehicle).
Using special tool, lock flywheel or drive plate, and tighten flywheel or drive plate bolts (1) to specified torque.


Special Tool
(A) : 09924-17810

Tightening Torque
(c) : 78 N·m (7.8 kg-m, 56.0 lb-ft)

- 4) A number of abbreviations and symbols are used in the text. For their full explanations, refer to "ABBREVIATIONS AND SYMBOLS MAY BE USED IN THIS MANUAL" in this section.
- 5) The SI, metric and foot-pound systems are used as units in this manual.
- 6) "DIAGNOSIS" are included in each section as necessary.
- 7) At the end of each section, there are descriptions of "SPECIAL TOOL", "REQUIRED SERVICE MATERIAL" and "TIGHTENING TORQUE SPECIFICATION" that should be used for the servicing work described in that section.

Precautions

Precaution for Vehicles Equipped with a Supplemental Restraint (Air Bag) System




WARNING:

- The configuration of air bag system parts are as shown in the figure. When it is necessary to service (remove, reinstall and inspect) these parts, be sure to follow procedures described in Section 10B. Failure to follow proper procedures could result in possible air bag system activation, personal injury, damage to parts or air bag system being unable to activate when necessary.
- If the air bag system and another vehicle system both need repair, SUZUKI recommends that the air bag system be repaired first, to help avoid unintended air bag system activation.
- Do not modify the steering wheel, dashboard, or any other air bag system components. Modifications can adversely affect air bag system performance and lead to injury.
- If the vehicle will be exposed to temperatures over 93°C (200°F) (for example, during a paint baking process), remove the air bag system components beforehand to avoid component damage or unintended air bag system activation.

1. Air bag wire harness (in floor harness)	5. Contact coil
2. Passenger air bag (inflator) module	6. Driver air bag (inflator) module
3. SDM	7. Side air bag (inflator) module (if equipped)
4. Seat belt pretensioner	8. Side sensor (if equipped)

Diagnosis

- When troubleshooting air bag system, be sure to follow "DIAGNOSIS" in Section 10B. Bypassing these procedures may result in extended diagnostic time, incorrect diagnosis, and incorrect parts replacement.
- Never use electrical test equipment other than that specified in this manual.




WARNING:


Never attempt to measure the resistance of the air bag (inflator) modules (driver, passenger and side) and seat belt pretensioners (driver and passenger). It is very dangerous as the electric current from the tester may deploy the air bag or activate the pretensioner.

Servicing and handling


[A]



[B]



[C]

**WARNING:**

Many of service procedures require disconnection of "AIR BAG" fuse and all air bag (inflator) module(s) from initiator circuit to avoid an accidental deployment.

Driver, Passenger and Side Air Bag (Inflator) Modules

- For handling and storage of a live air bag (inflator) module, select a place where the ambient temperature below 65°C (150°F), without high humidity and away from electric noise.
- When carrying a live air bag (inflator) module, make sure the bag opening is pointed away from you. In case of an accidental deployment, the bag will then deploy with minimal chance of injury. Never carry the air bag (inflator) module by the wires or connector on the underside of the module. When placing a live air bag (inflator) module on a bench or other surface, always face the bag up, away from the surface. The front seat back with the live air bag (inflator) module must be placed with its frontal seat cover facing up. It is also prohibited to place anything on top of the trim cover and stack air bag (inflator) modules. This is necessary so that a free space is provided to allow the air bag to expand in the unlikely event of accidental deployment. Otherwise, personal injury may result.
- Never dispose of live (undeployed) air bag (inflator) modules (driver, passenger and side). If disposal is necessary, be sure to deploy them according to deployment procedures described in Section 10B before disposal.
- The air bag (inflator) module immediately after deployment is very hot. Wait for at least half an hour to cool it off before proceeding the work.
- After an air bag (inflator) module has been deployed, the surface of the air bag may contain a powdery residue. This powder consists primarily of cornstarch (used to lubricate the bag as it inflates) and by-products of the chemical reaction. As with many service procedures, gloves and safety glasses should be worn.


[A] : ALWAYS CARRY AIR BAG (INFLATOR) MODULE WITH TRIM COVER (AIR BAG OPENING) AWAY FROM BODY.

[B] : ALWAYS PLACE AIR BAG (INFLATOR) MODULE ON WORKBENCH WITH TRIM COVER (AIR BAG OPENING) UP, AWAY FROM LOOSE OBJECTS.

[C] : ALWAYS PLACE WITH ITS FRONTAL SEAT COVER FACING UP, AWAY FROM LOOSE OBJECTS.

WARNING:**SDM**

- For handling and storage of a SDM, select a place where the ambient temperature below 65°C (150°F), without high humidity and away from electric noise.
 - During service procedures, be very careful when handling a Sensing and Diagnostic Module (SDM). Never strike or jar the SDM.
 - Never power up the air bag system when the SDM is not rigidly attached to the vehicle. All SDM and mounting bracket fasteners must be carefully torqued and the arrow must be pointing toward the front of the vehicle to ensure proper operation of the air bag system.
- The SDM could be activated when powered while not rigidly attached to the vehicle which could cause deployment and result in personal injury.

**WARNING:****Driver and Passenger Seat Belt Pretensioners
(If equipped)**

- For handling and storage of a live seat belt pretensioner, select a place where the ambient temperature below 65°C (150°F), without high humidity and away from electric noise.
- Never carry seat belt pretensioner by wire or connector of pretensioner. When placing a live seat belt pretensioner on the workbench or some place like that, be sure not to lay it with its exhaust hole (1) provided side facing down. It is also prohibited to put something on its face with an exhaust hole or to put a seat belt pretensioner on top of another. Otherwise, personal injury may result.
- Never dispose of live (inactivated) seat belt pretensioners (driver and passenger). If disposal is necessary, be sure to activate them according to activation procedures described in Section 10B before disposal.
- The seat belt pretensioner immediately after activation is very hot. Wait for at least half an hour to cool it off before proceeding the work.
- With many service procedures, gloves and safety glasses should be worn to prevent any possible irritation of the skin or eyes.

- Even when the accident was light enough not to cause air bags to activate, be sure to inspect system parts and other related parts according to instructions under “REPAIRS AND INSPECTIONS REQUIRED AFTER AN ACCIDENT” in Section 10B.
- When servicing parts other than air bag system, if shocks may be applied to air bag system component parts, remove those parts beforehand.
- When handling the air bag (inflator) modules (driver, passenger and side), seat belt pretensioners (driver and passenger), side sensors or SDM, be careful not to drop it or apply an impact to it. If an excessive impact was applied, never attempt disassembly or repair but replace it with a new one.
- When grease, cleaning agent, oil, water, etc. has got onto air bag (inflator) modules (driver, passenger and side) or seat belt pretensioners (driver and passenger), wipe off immediately with a dry cloth.


- Air bag wire harness is included in floor wire harness. Air bag wire harness branched off from floor wire harness can be identified easily as it is covered with a yellow protection tube and it has yellow connectors. Be very careful when handling it.
- When an open in air bag wire harness, damaged wire harness, connector or terminal is found, replace wire harness, connectors and terminals as an assembly.
- Do not apply power to the air bag system unless all components are connected or a diagnostic chart requests it, as this will set a diagnostic trouble code.
- Never use air bag system component parts from another vehicle.
- When using electric welding, be sure to disconnect all air bag (inflator) module connectors and pretensioner connectors from air bag wire harness respectively.
- Never expose air bag system component parts directly to hot air (drying or baking the vehicle after painting) or flames.
- WARNING/CAUTION labels are attached on each part of air bag system components. Be sure to follow the instructions.
- After vehicle is completely repaired, perform “AIR BAG DIAGNOSTIC SYSTEM CHECK” in Section 10B.

General Precautions


The WARNING and CAUTION below describe some general precautions that you should observe when servicing a vehicle. These general precautions apply to many of the service procedures described in this manual, and they will not necessarily be repeated with each procedure to which they apply.

WARNING:


- Whenever raising a vehicle for service, be sure to follow the instructions under “VEHICLE LIFTING POINTS” in this section.
- When it is necessary to do service work with the engine running, make sure that the parking brake is set fully and the transmission is in Neutral (for manual transmission vehicles) or Park (for automatic transmission vehicles). Keep hands, hair, clothing, tools, etc. away from the fan and belts when the engine is running.
- When it is necessary to run the engine indoors, make sure that the exhaust gas is forced outdoors.
- Do not perform service work in areas where combustible materials can come in contact with a hot exhaust system. When working with toxic or flammable materials (such as gasoline and refrigerant), make sure that the area you work in is well-ventilated.
- To avoid getting burned, keep away from hot metal parts such as the radiator, exhaust manifold, tail pipe, muffler, etc.
- New and used engine oil can be hazardous. Children and pets may be harmed by swallowing new or used oil. Keep new and used oil and used engine oil filters away from children and pets. Continuous contact with used engine oil has been found to cause [skin] cancer in laboratory animals. Brief contact with used oil may irritate skin. To minimize your exposure to used engine oil, wear a long-sleeve shirt and moisture-proof gloves (such as dish washing gloves) when changing engine oil. If engine oil contacts your skin, wash thoroughly with soap and water. Launder any clothing or rags if wet with oil, recycle or properly dispose of used oil and filters.
- Make sure the bonnet is fully closed and latched before driving. If it is not, it can fly up unexpectedly during driving, obstructing your view and resulting in an accident.




- Before starting any service work, cover fenders, seats and any other parts that are likely to get scratched or stained during servicing. Also, be aware that what you wear (e.g, buttons) may cause damage to the vehicle's finish.




- When performing service to electrical parts that does not require use of battery power, disconnect the negative cable of the battery.




- When removing the battery, be sure to disconnect the negative cable first and then the positive cable. When reconnecting the battery, connect the positive cable first and then the negative cable, and replace the terminal cover.



- When removing parts that are to be reused, be sure to keep them arranged in an orderly manner so that they may be reinstalled in the proper order and position.




- Whenever you use oil seals, gaskets, packing, O-rings, locking washers, split pins, self-locking nuts, and certain other parts as specified, be sure to use new ones. Also, before installing new gaskets, packing, etc., be sure to remove any residual material from the mating surfaces.



- Make sure that all parts used in reassembly are perfectly clean.
When use of a certain type of lubricant, bond or sealant is specified, be sure to use the specified type.

“A” : Sealant 99000-31150




- Be sure to use special tools when instructed.


Special Tool

(A) : 09917-98221


(B) : 09916-58210




- When disconnecting vacuum hoses, attach a tag describing the correct installation positions so that the hoses can be reinstalled correctly.




- After servicing fuel, oil, coolant, vacuum, exhaust or brake systems, check all lines related to the system for leaks.
- For vehicles equipped with fuel injection systems, never disconnect the fuel line between the fuel pump and injector without first releasing the fuel pressure, or fuel can be sprayed out under pressure.



- When performing a work that produces a heat exceeding 80°C (176°F) in the vicinity of the electrical parts, remove the heat sensitive electrical part(s) beforehand.



- Use care not to expose connectors and electrical parts to water which will be a cause of a trouble.



- Always be careful not to handle electrical parts (computer, relay, etc.) in a rough manner or drop them.

Precautions for Catalytic Converter

For vehicles equipped with a catalytic converter, use only unleaded gasoline and be careful not to let a large amount of unburned gasoline enter the converter or it can be damaged.

- Conduct a spark jump test only when necessary, make it as short as possible, and do not open the throttle.
- Conduct engine compression checks within the shortest possible time.
- Avoid situations which can result in engine misfire (e.g. starting the engine when the fuel tank is nearly empty.)

Precaution for Installing Mobile Communication Equipment

When installing mobile communication equipment such as CB (Citizens-Band)-radio or cellular-telephone, be sure to observe the following precautions.


Failure to follow cautions may adversely affect electronic control system.

- Keep the antenna as far away as possible from the vehicle's electronic control unit.
- Keep the antenna feeder more than 20 cm (7.9 in) away from electronic control unit and its wire harnesses.
- Do not run the antenna feeder parallel with other wire harnesses.
- Confirm that the antenna and feeder are correctly adjusted.

Precaution for Vehicle Tie-Down Hooks

Never use hooks (1) to tie down vehicle when vehicle is transported by land, or body may be deformed. Be sure to use hooks (2) (hooks and frame holes) then. When vehicle is shipped by sea, use hooks (1) and/or (2) to tie-down vehicle.



[A] :	Vehicle front
[B] :	Vehicle rear



Precaution in Servicing Full-Time 4WD Vehicle


This full-time 4WD vehicle can not be converted to 2WD manually.

Observe the following caution in servicing. Otherwise, front wheels drive rear wheels or vise-versa and vehicle accidents, drivetrain damage and personal injury may result.




- Never perform any of the following types of service work.
 [A] : Testing with 2-wheel chassis dynamometer, speedometer tester or brake tester.
 [B] : Driving front wheels, which are jacked up.
 [C] : Towing under the condition where either front or rear wheels can not rotate.
- When testing with 2-wheel chassis dynamometer, speedometer tester or brake tester, be sure to make the vehicle as front wheel drive by removing rear propeller shaft.
- When using On-vehicle type wheel balancing equipment (1), be sure to jack up all four wheels, off the ground completely and support vehicle with safety stands (2). Be careful of the other wheels, which will rotate at the same time.
- This vehicle should be towed under one of the following conditions :
 - With all wheels on a flatbed truck.
 - With front or rear wheels lifted and a dolly under the other wheels.


Precautions for Electrical Circuit Service




- When replacing a fuse, make sure to use a fuse of the specified capacity. Use of a fuse with a larger capacity will cause a damage to the electrical parts and a fire.




- When disconnecting and connecting coupler, make sure to turn ignition switch OFF, or electronic parts may get damaged.




- When disconnecting connectors, never pull the wiring harness. Unlock the connector lock first and then pull them apart by holding connectors themselves.




- When connecting connectors, also hold connectors and put them together until they lock securely (a click is heard).




- When installing the wiring harness, fix it with clamps so that no slack is left.




- When installing vehicle parts, be careful so that the wiring harness is not interfered with or caught by any other part.




- To avoid damage to the harness, protect its part which may contact against a part forming a sharp angle by winding tape or the like around it.




- Be careful not to touch the electrical terminals of parts which use microcomputers (e.g. electronic control unit like as ECM, PCM, P/S controller, etc). The static electricity from your body can damage these parts.
- Never connect any tester (voltmeter, ohmmeter, or whatever) to electronic control unit when its coupler is disconnected. Attempt to do it may cause damage to it.
- Never connect an ohmmeter to electronic control unit with its coupler connected to it. Attempt to do it may cause damage to electronic control unit and sensors.



- Be sure to use a specified voltmeter/ohmmeter. Otherwise, accurate measurements may not be obtained or personal injury may result. If not specified, use a voltmeter with high impedance ($M \Omega/V$ minimum) or a digital type voltmeter.
- When taking measurements at electrical connectors using a tester probe, be sure to insert the probe (2) from the wire harness side (backside) of the connector (1).



- When connecting meter probe (2) from terminal side of coupler (1) because it can't be connected from harness side, use extra care not to bend male terminal of coupler or force its female terminal open for connection. In case of such coupler as shown connect probe as shown to avoid opening female terminal. Never connect probe where male terminal is supposed to fit.
- When checking connection of terminals, check its male half for bend and female half for excessive opening and both for locking (looseness), corrosion, dust, etc.



- Before measuring voltage at each terminal, check to make sure that battery voltage is 11 V or higher. Such terminal voltage check at low battery voltage will lead to erroneous diagnosis.


Electrical Circuit Inspection Procedure

While there are various electrical circuit inspection methods, described here is a general method to check its open and short circuit by using an ohmmeter and a voltmeter.

Open circuit check


Possible causes for the open circuit are as follows. As the cause is in the connector or terminal in many cases, they need to be checked particularly carefully.

- Loose connection of connector
- Poor contact of terminal (due to dirt, corrosion or rust on it, poor contact tension, entry of foreign object etc.)
- Wire harness being open




When checking system circuits including an electronic control unit such as ECM, TCM, ABS control module, etc., it is important to perform careful check, starting with items which are easier to check.

- 1) Disconnect negative (–) cable from battery
- 2) Check each connector at both ends of the circuit being checked for loose connection. Also check lock condition of connector if equipped with connector lock.
- 3) Using a test male terminal, check both terminals of the circuit being checked for contact tension of its female terminal. Check each terminal visually for poor contact (possibly caused by dirt, corrosion, rust entry of foreign object, etc.). At the same time, check to make sure that each terminal is locked in the connector fully.




1. Check contact tension by inserting and removing just for once.




4) Using continuity check or voltage check the following procedure, check the wire harness for open circuit and poor connection with its terminals. Locate abnormality, if any.

1. Looseness of crimping
2. Open
3. Thin wire (single strand of wire)

Continuity check



1) Measure resistance between connector terminals at both ends of the circuit being checked (between A-1 and C-1 in the figure). If no continuity is indicated (infinity or over limit), that means that the circuit is open between terminals A-1 and C-1.




2) Disconnect the connector included in the circuit (connector-B in the figure) and measure resistance between terminals A-1 and B-1.

If no continuity is indicated, that means that the circuit is open between terminals A-1 and B-1. If continuity is indicated, there is an open circuit between terminals B-1 and C-1 or an abnormality in connector-B.

Voltage check

If voltage is supplied to the circuit being checked, voltage check can be used as circuit check.



1) With all connectors connected and voltage applied to the circuit being checked, measure voltage between each terminal and body ground.

a) If measurements were taken as shown in the figure and results were as listed below, it means that the circuit is open between terminals B-1 and A-1.

Voltage between

C-1 and body ground : Approx. 5 V

B-1 and body ground : Approx. 5 V

A-1 and body ground : 0 V

b) Also, if measured values were as listed below, it means that there is a resistance (abnormality) of such level that corresponds to the voltage drop in the circuit between terminals A-1 and B-1.

Voltage between

C-1 and body ground : Approx. 5 V

B-1 and body ground : Approx. 5 V


A-1 and body ground : Approx. 3 V

Short circuit check (wire harness to ground)


- 1) Disconnect negative (–) cable at battery.
- 2) Disconnect connectors at both ends of the circuit to be checked.

NOTE:

If the circuit to be checked is connected to other parts (1), disconnect all connectors of those parts. Otherwise, diagnosis will be misled.



- 3) Measure resistance between terminal at one end of circuit (A-1 terminal in the figure) and body ground. If continuity is indicated, it means that there is a short to ground between terminals A-1 and C-1 of the circuit.




- 4) Disconnect the connector included in circuit (connector B) and measure resistance between A-1 and body ground. If continuity is indicated, it means that the circuit is shorted to the ground between terminals A-1 and B-1.


1. To other parts

Intermittent and Poor Connection

Most intermittent are caused by faulty electrical connections or wiring, although a sticking relay or solenoid can occasionally be at fault. When checking it for proper connection, perform careful check of suspect circuits for :




- Poor mating of connector halves, or terminals not fully seated in the connector body (backed out).
- Dirt or corrosion on the terminals. The terminals must be clean and free of any foreign material which could impede proper terminal contact. However, cleaning the terminal with a sand paper or the like is prohibited.
- Damaged connector body, exposing the terminals to moisture and dirt, as well as not maintaining proper terminal orientation with the component or mating connector.




- Improperly formed or damaged terminals.
Check each connector terminal in problem circuits carefully to ensure good contact tension by using the corresponding mating terminal.
If contact tension is not enough, reform it to increase contact tension or replace.

- | |
|---|
| 1. Check contact tension by inserting and removing just once. |
| 2. Check each terminal for bend and proper alignment. |




- Poor terminal-to-wire connection.
Check each wire harness in problem circuits for poor connection by shaking it by hand lightly. If any abnormal condition is found, repair or replace.



- Wire insulation which is rubbed through, causing an intermittent short as the bare area touches other wiring or parts of the vehicle.
- Wiring broken inside the insulation. This condition could cause continuity check to show a good circuit, but if only 1 or 2 strands of a multi-strand-type wire are intact, resistance could be far too high.
If any abnormality is found, repair or replace.


Identification Information

Vehicle Identification Number



The number is punched on front dash panel in engine room.

Engine Identification Number




The number is punched on cylinder block.

M16 X - XXXXXX

Serial number
Engine displacement
(13:1.3 L, 16:1.6 L)
Engine type (M)


Transmission Identification Number




The automatic transmission identification number is located on transmission case.

Warning, Caution and Information Labels

The figure below shows main labels among others that are attached to vehicle component parts. When servicing and handling parts, refer to WARNING/CAUTION instructions printed on labels. If any WARNING/CAUTION label is found stained or damaged, clean or replace it as necessary.



1. Air bag label on back side of engine hood (for vehicle with air bag system)
2. Air bag label on sun visor (for vehicle with air bag system)
3. Radiator cap label
4. Engine cooling fan label
5. Steering shaft joint cover label (for vehicle with air bag system)




1. Air bag label on driver air bag (inflator) module	5. Pretensioner label on seat belt retractor
2. Air bag label on combination switch and contact coil assembly	6. Child seat label
3. Air bag label on passenger air bag (inflator) module	7. Air bag label on side air bag module
4. Air bag label on SDM	[A] : These labels are attached on vehicle equipped with air bag system only.

Vehicle Lifting Points

WARNING:


- Before applying hoist to underbody, always take vehicle balance throughout service into consideration. Vehicle balance on hoist may change depending on what part to be removed.
- Before lifting up the vehicle, check to be sure that end of hoist arm is not in contact with brake pipe, fuel pipe, bracket or any other part.
- When using frame contact hoist, apply hoist as shown (right and left at the same position). Lift up the vehicle till 4 tires are a little off the ground and make sure that the vehicle will not fall off by trying to move vehicle body in both ways. Work can be started only after this confirmation.
- Make absolutely sure to lock hoist after vehicle is hoisted up.

WHEN USING FRAME CONTACT HOIST



1. Vehicle front	6. Bolts
2. Support position for frame contact hoist and safety stand	7. Rear left tire
3. Floor jack position	[A] : 2WD vehicle
4. Embossed-mark	[B] : 4WD vehicle
5. Front left tire	

WHEN USING FLOOR JACK



WARNING:

If the vehicle to be jacked up only at the front or rear end, be sure to block the wheels on ground in order to ensure safety.
After the vehicle is jacked up, be sure to support it on stands. It is extremely dangerous to do any work on the vehicle raised on jack alone.

CAUTION:

Never apply jack against suspension parts (i.e., stabilizer, etc) or vehicle floor, or it may get deformed.


For 2WD vehicle

In raising front or rear vehicle end off the floor by jacking, be sure to put the jack against the front end of the engine mounting member (1) or rear suspension frame (2).

For 4WD vehicle

In raising front or rear vehicle end off the floor by jacking, be sure to put the jack against the jacking bracket (3) or rear differential (4).

[A] : 2WD vehicle front	[C] : 2WD vehicle rear
[B] : 4WD vehicle front	[D] : 4WD vehicle rear



To perform service with either front or rear vehicle end jacked up, be sure to place safety stands (1) under vehicle body so that vehicle body is securely supported. And then check to ensure that vehicle body does not slide on safety stands (1) and the vehicle is held stable for safety's sake.

[A] : Front
[B] : Rear
2. Bolts
3. Embossed mark



















Abbreviations and Symbols May Be Used in This Manual

ABBREVIATIONS

A	ABS	Anti-lock Brake System	E	EFE Heater	Early Fuel Evaporation Heater (Positive Temperature Coefficient, PTC Heater)
	ATDC	After Top Dead Center		EPS	Electronic Power Steering
	API	American Petroleum Institute		EVAP	Evaporative Emission
	ATF	Automatic Transmission Fluid, Automatic Transaxle Fluid		EVAP Canister	Evaporative Emission Canister (Charcoal Canister)
	ALR	Automatic Locking Retractor	F	4WD	4 Wheel Drive
	AC	Alternating Current		GEN	Generator
	A/T	Automatic Transmission, Automatic Transaxle	G	GND	Ground
	A/C	Air Conditioning		HC	Hydrocarbons
B	ABDC	After Bottom Dead Center	H	HO2S	Heated Oxygen Sensor
	A/F	Air Fuel Mixture Ratio		IAC Valve	Idle Air Control Valve (Idle Speed Control Solenoid Valve ISC Solenoid Valve)
	A-ELR	Automatic-Emergency Locking Retractor		IAT Sensor	Intake Air Temperature Sensor (Air temperature Sensor, ATS)
C	B+	Battery Positive Voltage		ICM	Immobilizer Control Module
	BTDC	Before Top Dead Center	I	IG	Ignition
	BBDC	Before Bottom Dead Center		ISC Actuator	Idle Speed Control Actuator
	CKT	Circuit		LH	Left Hand
D	CKP sensor	Crankshaft Position Sensor	L	LSPV	Load Sensing Proportioning Valve
	CMP sensor	Camshaft Position Sensor		MAF Sensor	Mass Air Flow Sensor (Air Flow Sensor, AFS, Air Flow Meter, AFM)
	CO	Carbon Monoxide		MAP Sensor	Manifold Absolute Pressure Sensor (Pressure Sensor, PS)
	CPP switch	Clutch Pedal Position Switch (Clutch Switch, Clutch Start Switch)		Max	Maximum
E	CPU	Central Processing Unit	M	MFI	Multiport Fuel Injection (Multipoint Fuel Injection)
	CRS	Child Restraint System		MIN	Minimum
	DC	Direct Current		MIL	Malfunction Indicator Lamp ("CHECK ENGINE" Light)
	DLC	Data Link Connector (Assembly Line Diag. Link, ALDL, Serial Data Link, SDL)		M/T	Manual Transmission, Manual Transaxle
F	DOHC	Double Over Head Camshaft	N	NOx	Nitrogen Oxides
	DOJ	Double Offset Joint		OBD	On-Board Diagnostic System (Self-Diagnosis Function)
	DRL	Daytime Running Light	O	O/D	Overdrive
	DTC	Diagnostic Trouble Code (Diagnostic Code)		OHC	Over Head Camshaft
G	EBCM	Electronic Brake Control Module, ABS Control Module	O2S	O2S	Oxygen Sensor
	EBD	Electronic Brake Force Distribution			
	ECM	Engine Control Module			
	ECT sensor	Engine Coolant Temperature Sensor (Water Temp. Sensor, WTS)			
H	EGR	Exhaust Gas Recirculation			
	EGRT sensor	EGR Temperature Sensor (Recirculated Exhaust Gas Temp. Sensor, REGTS)			


P	PNP	Park/Neutral Position
	P/S	Power Steering
	PSP Switch	Power Steering Pressure Switch (P/S Pressure Switch)
	PCM	Powertrain Control Module
	PCV	Positive Crankcase Ventilation
R	RH	Right Hand
S	SAE	Society of Automotive Engineers
	SDM	Sensing and Diagnostic Module (Air bag controller, Air bag control module)
	SFI	Sequential Multiport Fuel Injection
	SOHC	Single over Head Camshaft
T	TBI	Throttle Body Fuel Injection (Single-Point Fuel Injection, SPI)
	TCC	Torque Converter Clutch
	TCM	Transmission Control Module (A/T Controller, A/T Control Module)
	TP Sensor	Throttle Position Sensor
	TVV	Thermal Vacuum Valve (Thermal Vacuum Switching Valve, TVSV, Bimetal Vacuum Switching Valve, BVSV)
	TWC	Three Way Catalytic Converter (Three Way Catalyst)
	2WD	2 Wheel Drive
V	VIN	Vehicle Identification Number
	VSS	Vehicle Speed Sensor
W	WU-OC	Warm Up Oxidation Catalytic Converter
	WU-TWC	Warm Up Three Way Catalytic Converter

SYMBOLS

SYMBOL	DEFINITION	SYMBOL	DEFINITION
	Tightening torque		Apply SUZUKI BOND NO. 1216 99000-31160
	Apply oil (engine, transmission, transfer, differential)		Apply SILICONE SEALANT 99000-31120
	Apply fluid (brake, power steering or automatic transmission fluid)		Apply SEALING COMPOUND 366E 99000-31090
	Apply SUZUKI SUPER GREASE A 99000-25010		
	Apply SUZUKI SUPER GREASE C 99000-25030		Apply THREAD LOCK 1322 99000-32110
	Apply SUZUKI SUPER GREASE E 99000-25050		Apply THREAD LOCK 1333B 99000-32020
	Apply SUZUKI SUPER GREASE H 99000-25120		Apply THREAD LOCK 1342 99000-32050
	Apply SUZUKI SUPER GREASE I 99000-25210		
	Apply SUZUKI BOND NO. 1215 99000-31110		Do not reuse
	Apply SUZUKI BOND NO. 1207C 99000-31150		Note on reassembly

WIRE COLOR SYMBOLS

Symbol		Wire Color	Symbol		Wire Color
B	BLK	Black	O, Or	ORN	Orange
Bl	BLU	Blue	R	RED	Red
Br	BRN	Brown	W	WHT	White
G	GRN	Green	Y	YEL	Yellow
Gr	GRY	Gray	P	PNK	Pink
Lbl	LT BLU	Light blue	V	PPL	Violet
Lg	LT GRN	Light green			



There are two kinds of colored wire used in this vehicle. One is single-colored wire and the other is dual-colored (striped) wire.

The single-colored wire uses only one color symbol (i.e. "GRN").

The dual-colored wire uses two color symbols (i.e. "GRN/YEL").

The first symbol represents the base color of the wire ("GRN" in the figure) and the second symbol represents the color of the stripe ("YEL" in the figure).

Fastener Information

Metric Fasteners


Most of the fasteners used for this vehicle are metric. When replacing any fasteners, it is most important that replacement fasteners be the correct diameter, thread pitch and strength.

Fastener Strength Identification

Most commonly used metric fastener strength property classes are 4T, 6.8, 7T, 8.8 and radial line with the class identification embossed on the head of each bolt. Some metric nuts will be marked with punch, 6 or 8 mark strength identification on the nut face. Figure shows the different strength markings.

When replacing metric fasteners, be careful to use bolts and nuts of the same strength or greater than the original fasteners (the same number marking or higher). It is likewise important to select replacement fasteners of the correct diameter and thread pitch. Correct replacement bolts and nuts are available through the parts division.

Metric bolts : Identification class numbers or marks correspond to bolt strength (increasing numbers represent increasing strength).



1. Nut strength identification







Standard Tightening Torque

Each fastener should be tightened to the torque specified in each section of this manual. If no description or specification is provided, refer to the following tightening torque chart for the applicable torque for each fastener. When a fastener of greater strength than the original one is used, however, use the torque specified for the original fastener.

NOTE:

- For the flanged bolt, flanged nut and self-lock nut of 4T and 7T strength, add 10% to the tightening torque given in the chart below.
- The chart below is applicable only where the fastened parts are made of steel light alloy.

Tightening torque chart :

			Thread Diameter (Nominal Diameter) (mm)								
			4	5	6	8	10	12	14	16	18
Strength	A equivalent of 4T strength fastener 	N-m	1.5	3.0	5.5	13	29	45	65	105	160
		kg-m	0.15	0.30	0.55	1.3	2.9	4.5	6.5	10.5	16
		lb-ft	1.0	2.5	4.0	9.5	21.0	32.5	47.0	76.0	116.0
	A equivalent of 6.8 strength fastener without flange 	N-m	2.4	4.7	8.4	20	42	80	125	193	280
		kg-m	0.24	0.47	0.84	2.0	4.2	8.0	12.5	19.3	28
		lb-ft	2.0	3.5	6.0	14.5	30.5	58.0	90.5	139.5	202.5
	A equivalent of 6.8 strength fastener with flange 	N-m	2.4	4.9	8.8	21	44	84	133	203	298
		kg-m	0.24	0.49	0.88	2.1	4.4	8.4	13.3	20.3	29.8
		lb-ft	2.0	3.5	6.5	15.5	32.0	61.0	96.5	147.0	215.5
	A equivalent of 7T strength fastener 	N-m	2.3	4.5	10	23	50	85	135	210	240
		kg-m	0.23	0.45	1.0	2.3	5.0	8.5	13.5	21	24
		lb-ft	2.0	3.5	7.5	17.0	36.5	61.5	98.0	152.0	174.0
	A equivalent of 8.8 strength fastener without flange 	N-m	3.1	6.3	11	27	56	105	168	258	373
		kg-m	0.31	0.63	1.1	2.7	5.6	10.5	16.8	25.8	37.3
		lb-ft	2.5	4.5	8.0	19.5	40.5	76.0	121.5	187.0	270.0
	A equivalent of 8.8 strength fastener with flange 	N-m	3.2	6.5	12	29	59	113	175	270	395
		kg-m	0.32	0.65	1.2	2.9	5.9	11.3	17.5	27	39.5
		lb-ft	2.5	5.0	9.0	21.0	43.0	82.0	126.5	195.5	286.0

*: Self-lock nut

SECTION 0B

MAINTENANCE AND LUBRICATION

0B

WARNING:

For vehicles equipped with Supplemental Restraint (Air Bag) System:

- Service on and around the air bag system components or wiring must be performed only by an authorized SUZUKI dealer. Refer to “Air Bag System Components and Wiring Location View” under “General Description” in air bag system section in order to confirm whether you are performing service on or near the air bag system components or wiring. Please observe all WARNINGS and “Service Precautions” under “On-Vehicle Service” in air bag system section before performing service on or around the air bag system components or wiring. Failure to follow WARNINGS could result in unintentional activation of the system or could render the system inoperative. Either of these two conditions may result in severe injury.
- Technical service work must be started at least 90 seconds after the ignition switch is turned to the “LOCK” position and the negative cable is disconnected from the battery. Otherwise, the system may be activated by reserve energy in the Sensing and Diagnostic Module (SDM).

CONTENTS

Maintenance Schedule	0B-2	Brake.....	0B-10
Maintenance Schedule Under Normal		Brake discs and pads (front)	0B-10
Driving Conditions	0B-2	Brake drums and shoes (rear)	0B-11
Maintenance Recommended under Severe		Brake hoses and pipes.....	0B-11
Driving Conditions	0B-4	Brake fluid	0B-11
Maintenance Service.....	0B-5	Brake lever and cable	0B-11
Engine	0B-5	Chassis and Body	0B-12
Drive belt	0B-5	Clutch	0B-12
Valve lash (clearance)	0B-6	Tires / Wheels	0B-12
Engine oil and oil filter	0B-6	Suspension system.....	0B-13
Engine coolant.....	0B-8	Steering system	0B-13
Exhaust system	0B-8	Drive shaft (axle) boots / Propeller shafts	
Ignition System.....	0B-8	(4WD)	0B-14
Spark plugs	0B-8	Manual transaxle oil	0B-15
Fuel System	0B-9	Automatic transaxle fluid	0B-15
Air cleaner filter	0B-9	Transfer oil (4WD A/T) and rear	
Fuel lines and connections.....	0B-9	differential oil (4WD).....	0B-16
Fuel filter.....	0B-9	All latches, hinges and locks	0B-17
Fuel tank.....	0B-10	Power steering (P/S) system	
Emission Control System	0B-10	(if equipped)	0B-17
PCV valve.....	0B-10	Final Inspection.....	0B-18
Fuel evaporative emission control		Recommended Fluids and Lubricants.....	0B-20
system	0B-10		

Maintenance Schedule

Maintenance Schedule Under Normal Driving Conditions

NOTE:

- This interval should be judged by odometer reading or months, whichever comes first.
- This table includes service as scheduled up to 90,000 km (54,000 miles) mileage. Beyond 90,000 km (54,000 miles), carry out the same services at the same intervals respectively.

Interval		Km (x 1,000)	15	30	45	60	75	90	
		Miles (x 1,000)	9	18	27	36	45	54	
		Months	12	24	36	48	60	72	
ENGINE									
Drive belt			–	–	I	–	–	R	
Valve lash (clearance)			–	I	–	I	–	I	
Engine oil and oil filter			R	R	R	R	R	R	
Engine coolant			–	–	R	–	–	R	
Exhaust system			–	I	–	I	–	I	
IGNITION SYSTEM									
*Spark plugs	When unleaded fuel is used	Vehicle without HO2S	Nickel plug	–	R	–	R	–	R
			Iridium plug	–	–	–	R	–	–
		Vehicle with HO2S	Nickel plug	–	–	R	–	–	R
			Iridium plug	Replace every 105,000 km (63,000 miles) or 84 months					
	When leaded fuel is used, refer to “MAINTENANCE RECOMMENDED UNDER SEVERE DRIVING CONDITON” in this section.								
FUEL SYSTEM									
Air cleaner filter			Paved-road	I	I	R	I	I	R
			Dusty conditions	Refer to “MAINTENANCE RECOM-MENDED UNDER SEVERE DRIVING CON-DITIONS” in this section.					
Fuel lines and connections			–	I	–	I	–	I	
Fuel filter			Replace every 105,000 km (63,000 miles)						
Fuel tank			–	–	I	–	–	I	
EMISSION CONTROL SYSTEM									
*PCV valve		Vehicle without HO2S	–	–	I	–	–	I	
		Vehicle with HO2S	–	–	–	–	–	I	
*Fuel evaporative emission control system			–	–	–	–	–	I	

NOTE:

- “R” : Replace or change
- “I” : Inspect and correct, replace or lubricate if necessary
- For Sweden, items with * (asterisk) should be performed by odometer reading only.
- For spark plugs, replace every 50,000 km if the local law requires.
- Nickel spark plug : BKR6E-11 (NGK) or K20PR-U11 (DENSO)
- Iridium spark plug : IFR6E11 (NGK)

Interval	Km (x 1,000)	15	30	45	60	75	90
	Miles (x 1,000)	9	18	27	36	45	54
	Months	12	24	36	48	60	72
BRAKE							
Brake discs and pads (thickness, wear, damage)		I	I	I	I	I	I
Brake drums and shoes (wear, damage)		–	I	–	I	–	I
Brake hoses and pipes (leakage, damage, clamp)		–	I	–	I	–	I
Brake fluid		–	R	–	R	–	R
Brake lever and cable (damage, stroke, operation)		Inspect at first 15,000 km (9,000 miles only)					
CHASSIS AND BODY							
Clutch (fluid level, leakage)		–	I	–	I	–	I
Tires (wear, damage, rotation) /wheels (damage)		I	I	I	I	I	I
Suspension system (tightness, damage, rattle, breakage)		–	I	–	I	–	I
Steering system (tightness, damage, breakage, rattle)		–	I	–	I	–	I
Drive shaft (axle) boots/Propeller shafts (4WD)		–	–	I	–	–	I
Manual transaxle oil (leakage, level) (I : 1st 15,000 km only)		I	–	R	–	–	R
Automatic transaxle fluid	Fluid level	–	I	–	I	–	I
	Fluid change	Replace every 165,000 km (99,000 miles)					
	Fluid hose	–	I	–	I	–	I
Transfer oil (4WD A/T) (leakage, level)		I	–	I	–	I	–
Rear differential oil (4WD) (leakage, level) (R : 1st 15,000 km only)		R or I	–	I	–	I	–
All latches, hinges and locks		–	I	–	I	–	I
Power steering (if equipped)		I	I	I	I	I	I

NOTE:

- “R” : Replace or change
- “I” : Inspect and correct or replace if necessary

Maintenance Recommended under Severe Driving Conditions

If the vehicle is usually used under the conditions corresponding to any severe condition code given below, IT IS RECOMMENDED that applicable maintenance operation be performed at the particular interval as shown in the following table.

Severe condition code :

A : Repeated short trips

B : Driving on rough and/or muddy roads

C : Driving on dusty roads

D : Driving in extremely cold weather and/or salted roads

E : Repeated short trips in extremely cold weather

F : Leaded fuel use

G : -----

H : Towing a trailer (if admitted)

Severe Condition Code	Maintenance		Maintenance Operation	Maintenance Interval
- B C D - - - -	Drive belt		I	Every 15,000 km (9,000 miles) or 12 months
			R	Every 45,000 km (27,000 miles) or 36 months
A - C D E F - H	Engine oil and oil filter		R	Every 5,000 km (3,000 miles) or 4 months
- - C - - - - -	Air cleaner filter *1		I	Every 2,500 km (1,500 miles)
			R	Every 30,000 km (18,000 miles) or 24 months
A B C - E F - H	Spark plugs	Nickel spark plug	R	Every 10,000 km (6,000 miles) or 8 months
		Iridium spark plug	R	Every 30,000 km (18,000 miles) or 24 months
- B C D - - - - H	Wheel bearings		I	Every 15,000 km (9,000 miles) or 12 months
- B - D E - - - H	Drive shafts and propeller shafts (4WD)		I	Every 15,000 km (9,000 miles) or 12 months
- B - - E - - - H	Manual transaxle oil, transfer oil (4WD A/T) and differential oil (4WD)		R	Every 30,000 km (18,000 miles) or 24 months
- B - - E - - - H	Automatic transaxle fluid		R	Every 30,000 km (18,000 miles) or 24 months
	Automatic transaxle fluid hose		I	Every 15,000 km (9,000 miles) or 12 months

NOTE:

- "I" : Inspect and correct or replace if necessary
- "R" : Replace or change
- *1 : Inspect more frequently if the vehicle is used under dusty conditions.

Maintenance Service


Engine

Drive belt

WARNING:

Be sure to disconnect negative cable from battery before checking, adjusting and replacing belt.

WATER PUMP AND GENERATOR DRIVE BELT INSPECTION




Inspect belt for cracks, cuts, deformation, wear, cleanliness and tension referring to “WATER PUMP/GENERATOR DRIVE BELT TENSION INSPECTION AND ADJUSTMENT” in Section 6B.

If any faulty condition is found, adjust or replace.

WATER PUMP AND GENERATOR DRIVE BELT REPLACEMENT

Replace belt with new one referring to “WATER PUMP/GENERATOR DRIVE BELT” in Section 6B.

A/C COMPRESSOR AND/OR POWER STEERING PUMP DRIVE BELT INSPECTION (IF EQUIPPED)



Inspect belt for cracks, cuts, deformation, wear, cleanliness and tension referring to “POWER STEERING BELT CHECK” in Section 3.

If any faulty condition is found, adjust or replace.

[A] : Vehicle with power steering


[B] : Vehicle with power steering and air conditioning
--

REPLACEMENT

Replace belt with new one referring to “POWER STEERING BELT” in Section 3.

Valve lash (clearance)

INSPECTION



Inspect intake and exhaust valve lash and adjust as necessary. Refer to "VALVE LASH" in Section 6A1 for valve lash inspection and adjustment procedure.

1. Camshaft
2. Thickness gauge


Engine oil and oil filter

REPLACEMENT

WARNING:

- New and used engine oil can be hazardous. Be sure to read "WARNING" in General Precaution in Section 0A and observe what is written there.
- Step 1) - 7) outlined below must be performed with **ENGINE NOT RUNNING**. For step 8), be sure to have adequate ventilation while engine is running.


Before draining engine oil, check engine for oil leakage. If any evidence of leakage is found, make sure to correct defective part before proceeding to the following work.



- 1) Drain engine oil by removing drain plug.
- 2) After draining oil, wipe drain plug clean. Reinstall drain plug, and tighten it securely as specified below.

Tightening torque


Engine oil drain plug (a) : 50 N·m (5.0 kg-m, 36.5 lb-ft)



- 3) Loosen oil filter by using oil filter wrench (special tool).

Special tool

(A) : 09915-47330




NOTE:

Before fitting new oil filter, be sure to oil its O-ring. Use engine oil for this purpose.

- 4) Screw new filter on oil filter stand by hand until the filter O-ring contacts the mounting surface.

CAUTION:


To tighten oil filter properly, it is important to accurately identify the position at which filter O-ring first contacts the mounting surface.



- 5) Tighten the filter (1) 3/4 turn from the point of contact with the mounting surface using an oil filter wrench (2).

Tightening torque

Oil filter (b) : 14 N·m (1.4 kg·m, 10.5 lb·ft) (for reference)



- 6) Replenish oil until oil level is brought to FULL level mark on dipstick. (oil pan and oil filter capacity). The filler inlet is at the top of the cylinder head cover.

It is recommended to use engine oil of SE, SF, SG, SH or SJ grade. Select the appropriate oil viscosity according to the proper engine oil viscosity chart [A].


Engine oil specification

Oil pan capacity	About 3.6 liters (7.6/6.3 US/Imp pt.)
Oil filter capacity	About 0.2 liter (0.4/0.3 US/Imp pt.)
Others	About 0.3 liter (0.6/0.5 US/Imp pt.)
Total	About 4.1 liters (8.7/7.2 US/Imp pt.)

NOTE:

Engine oil capacity is specified. However, note that the amount of oil required when actually changing oil may somewhat differ from the data in the table depending on various conditions (temperature, viscosity, etc.)

- 7) Check oil filter and drain plug for oil leakage.



- 8) Start engine and run it for 3 minutes. Stop it and wait 5 minutes before checking oil level. Add oil, as necessary, to bring oil level to FULL level mark on dipstick.

1. Full level mark (hole)
2. Low level mark (hole)

Engine coolant

REPLACEMENT

Change engine coolant referring to “COOLING SYSTEM FLUSH AND REFILL” in Section 6B.

Exhaust system

INSPECTION

WARNING:

To avoid danger of being burned, do not touch exhaust system when it is still hot. Any service on exhaust system should be performed when it is cool.

- Check rubber mountings for damage, deterioration, and out of position.
- Check exhaust system for leakage, loose connections, dents and damages.
If bolts or nuts are loose, tighten them to specification.
- Check nearby body areas for damaged, missing, or mispositioned parts, open seams, holes, loose connections or other defects which could permit exhaust fumes to seep into the vehicle.
- Make sure that exhaust system components have enough clearance from the underbody to avoid overheating and possible damage to the floor carpet.
- Any defects should be fixed at once.

Ignition System

Spark plugs

REPLACEMENT


Replace spark plugs with new ones referring to “SPARK PLUGS” in Section 6F1.

Fuel System

Air cleaner filter

INSPECTION

- 1) Disconnect air cleaner hose from air cleaner case.
- 2) Open air cleaner case after unhooking its clamps.
- 3) Take air cleaner filter out of case.
- 4) Check that filter is not excessively dirty, damaged or oily, clean filter with compressed air from air outlet side of filter.
- 5) Install air cleaner filter and clamp case securely.
- 6) Connect air cleaner hose to air cleaner case and clamp it securely.



REPLACEMENT

Replace air cleaner filter with new one according to steps 1), 2), 3), 5) and 6) of inspection procedure.


Fuel lines and connections

INSPECTION

Visually inspect fuel lines and connections for evidence of fuel leakage, hose cracking and damage. Make sure all clamps are secure.

Repair leaky joints, if any.


Replace hoses that are suspected of being cracked.



Fuel filter

REPLACEMENT

Fuel filter (1) is installed in fuel pump assembly (2) in fuel tank. Replace fuel filter with new one, referring to "FUEL PUMP ASSEMBLY" in Section 6C for proper procedure.



Fuel tank

INSPECTION

Check fuel tank damage, cracks, fuel leakage, corrosion and tank bolts looseness.

If a problem is found, repair or replace.

Emission Control System


PCV valve

INSPECTION

Check crankcase ventilation hose and PCV hose for leaks, cracks or clog, and PCV valve for stick or clog. Refer to "PCV SYSTEM" of Section 6E1 for PCV valve checking procedure.

Fuel evaporative emission control system

INSPECTION




- 1) Visually inspect hoses for cracks, damage, or excessive bends. Inspect all clamps for damage and proper position.
- 2) Check EVAP canister for operation and clog, referring to "EVAPORATIVE EMISSION CONTROL SYSTEM" in Section 6E1.

If a malfunction is found, repair or replace.

Brake

Brake discs and pads (front)

INSPECTION




Check front disc brake pads and discs for excessive wear, damage and deflection. Replace parts as necessary. For details, refer to "BRAKE PAD" in Section 5.

Be sure to torque caliper pin bolts to specification.

Brake drums and shoes (rear)

INSPECTION




Check rear brake drums and brake linings for excessive wear and damage, while wheels and drums are removed. At the same time, check wheel cylinders for leaks. Replace these parts as necessary.

For details, refer to "BRAKE DRUM" in Section 5.

Brake hoses and pipes

INSPECTION



Perform this inspection where there is enough light and use a mirror as necessary.

- Check brake hoses and pipes for proper hookup, leaks, cracks, chafing and other damage.
- Check that hoses and pipes are clear of sharp edges and moving parts.

Repair or replace any of these parts as necessary.

CAUTION:

After replacing any brake pipe or hose, be sure to carry out air purge operation.

Brake fluid

REPLACEMENT


Change brake fluid as follows.

Drain existing fluid from brake system completely, fill system with specified fluid and carry out air purge operation.


For air purging procedure, refer to "AIR BLEEDING OF BRAKE SYSTEM" in Section 5.

Brake lever and cable

INSPECTION



- 1) Inspect brake cable for damage and smooth movement. Replace cable if it is in deteriorated condition.



- 2) Check tooth tip of each notch for damage or wear. If any damage or wear is found, replace parking lever.
- 3) Check parking brake lever for proper operation and stroke, and adjust it if necessary.

For checking and adjusting procedures, refer to "PARKING BRAKE INSPECTION AND ADJUSTMENT" in Section 5.


Parking brake lever stroke

"a" : 3 - 5 notches (with 200 N, 20 kg (44 lbs) of pull pressure)

Chassis and Body

Clutch


INSPECTION



- 1) Check system for evidence of fluid leakage.
Repair leaky point if any.
- 2) Check reservoir for fluid level referring to "CLUTCH FLUID" in Section 7C1.

Tires / Wheels

TIRES INSPECTION



- 1) Check tires for uneven or excessive wear, or damage.
If defective, replace.
Refer to "IRREGULAR AND/OR PREMATURE WEAR" and "WEAR INDICATORS" in Section 3 for details.

1. Wear indicator

- 2) Check inflating pressure of each tire and adjust pressure to specification as necessary.

NOTE:

- Tire inflation pressure should be checked when tires are cool.
- Specified tire inflation pressure should be found on tire placard or in owner's manual which came with the vehicle.


- 3) Rotate tires.

For details, refer to "TIRE ROTATION" in Section 3.

WHEEL DISCS INSPECTION

Inspect each wheel disc for dents, distortion and cracks. A disc in badly damaged condition must be replaced.


WHEEL BEARING INSPECTION




- 1) Check front wheel bearing for wear, damage, abnormal noise or rattles. For details, refer to "WHEEL DISC, NUT AND BEARING CHECK (FOR FRONT SUSPENSION)" in Section 3.
- 2) Check rear wheel bearing for wear, damage, abnormal noise or rattles. For details, refer to "WHEEL DISC, NUT AND BEARING CHECK (FOR REAR SUSPENSION)" in Section 3.

Suspension system

INSPECTION




- 1) Inspect front & rear struts for evidence of oil leakage, dents or any other damage on sleeves ; and inspect anchor ends for deterioration.
Replace defective parts, if any.
- 2) Check front and rear suspension systems for damaged, loose or missing parts ; also for parts showing signs of wear or lack of lubrication.
Repair or replace defective parts, if any.



- 3) Check front suspension arm ball joint stud dust seals for leakage, detachment, tear or any other damage.
Replace defective boot, if any.

Steering system

INSPECTION




- 1) Check steering wheel for play and rattle, holding vehicle straight on ground.

Steering wheel play

"a" : 0 – 30 mm (0 – 1.1 in.)


- 2) Check bolts and nuts for tightness and retighten them as necessary. Repair or replace defective parts, if any.



- 3) Check steering linkage for looseness and damage. Repair or replace defective parts, if any.
- 4) Check boots of steering linkage and steering gear case for damage (leak, detachment, tear, etc.). If damage is found, replace defective boot with new one.
If any dent is found on steering gear case boots, correct it to original shape by turning steering wheel to the right or left as far as it stops and holding it for a few seconds.
- 5) Check universal joints of steering shaft for rattle and damage. If rattle or damage is found, replace defective part with a new one.
- 6) Check that steering wheel can be turned fully to the right and left. Repair or replace defective parts, if any.
- 7) If equipped with power steering system, check also, in addition to above check items, that steering wheel can be turned fully to the right and left more lightly when engine is running at idle speed than when it is stopped. Repair, if found faulty.
- 8) Check wheel alignment referring to "FRONT WHEEL ALIGNMENT" and "REAR WHEEL ALIGNMENT" in Section 3.


Drive shaft (axle) boots / Propeller shafts (4WD)

DRIVE SHAFT (AXLE) BOOTS INSPECTION



Check drive shaft boots (wheel side and differential side) for leaks, detachment, tear or other damage.
Replace boot as necessary.


PROPELLER SHAFTS (4WD) INSPECTION



- 1) Check propeller shaft connecting bolts for looseness. If looseness is found, tighten to specified torque.
- 2) Check propeller shaft joints for wear, play and damage. If any defect is found, replace.
- 3) Check propeller shaft center support for biting of foreign matter, crack, abnormal noise and damage. If any defect is found, replace.

Manual transaxle oil

INSPECTION



- 1) Inspect transaxle case for evidence of oil leakage.
Repair leaky point if any.
- 2) Make sure that vehicle is placed level for oil level check.
- 3) Remove oil filler/level plug (1) of transaxle.
- 4) Check oil level.

Oil level can be checked roughly by means of filler/level plug hole. That is, if oil flows out of level plug hole or if oil level is found up to hole when level plug is removed, oil is properly filled.

If oil is found insufficient, pour specified oil up to level hole.

For specified oil, refer to "OIL CHANGE" in Section 7A1.

- 5) Install filler/level plug referring to "OIL CHANGE" in Section 7A1.

[A] : 2WD

[B] : 4WD

REPLACEMENT


Change transaxle oil referring to "OIL CHANGE" in Section 7A1.

Automatic transaxle fluid

INSPECTION

- 1) Inspect transaxle case for evidence of fluid leakage.
Repair leaky point, if any.
- 2) Make sure that vehicle is placed level for fluid level check.
- 3) Pull out dipstick and check fluid level.

For fluid level checking procedure, refer to "FLUID LEVEL CHECK" in Section 7B1 and be sure to perform it under specified conditions. If fluid level is low, replenish specified fluid.




1. Dipstick

2. FULL HOT mark

3. LOW HOT mark


REPLACEMENT



- 1) Inspect transaxle case for evidence of fluid leakage.
Repair leaky point, if any.
- 2) Make sure that vehicle is placed level.
- 3) Change fluid. For its procedure, refer to "FLUID CHANGE" in Section 7B1.

1. Drain plug


FLUID COOLER HOSE INSPECTION



Check automatic transaxle fluid cooler hose for fluid leakage, cracks, damage and deterioration.

Replace hose and/or clamp if any faulty condition is found.

Transfer oil (4WD A/T) and rear differential oil (4WD) INSPECTION



- 1) Check transfer case or differential for evidence of oil leakage.
Repair leaky point if any.
- 2) Make sure that vehicle is placed level for oil level check.
- 3) Remove level plug of transfer or differential and check oil level.

Oil level can be checked roughly by means of level plug hole. That is, if oil flows out of level plug hole or if oil level is found up to hole when level plug is removed, oil is properly filled.

If oil is found insufficient, pour specified amount of specified oil referring to "TRANSFER OIL CHANGE" in Section 7D or "DIFFERENTIAL OIL CHANGE" in Section 7F.

[A] : Transfer

[B] : Rear differential

1. Oil level/filler plug

2. Drain plug

- 4) Tighten level plug to specified torque referring to "TRANSFER OIL CHANGE" in Section 7D or "DIFFERENTIAL OIL CHANGE" in Section 7F.


REPLACEMENT

Change transfer oil and differential oil with new specified oil referring to "TRANSFER OIL CHANGE" in Section 7D or "DIFFERENTIAL OIL CHANGE" in Section 7F.

All latches, hinges and locks

INSPECTION

DOORS



Check that each door of front, rear and back doors opens and closes smoothly and locks securely when closed.

If any malfunction is found, lubricate hinge and latch or repair door lock system.

ENGINE HOOD

Check that secondary latch operates properly (check that secondary latch keeps hood from opening all the way even when pulling hood release handle inside vehicle.) Also check that hood opens and closes smoothly and properly and hood locks securely when closed.

If any malfunction is found, lubricate hinge and latch, or repair hood lock system.


Power steering (P/S) system (if equipped)

INSPECTION

- 1) Visually check power steering system for leaks or damage.
- 2) Check fluid level with engine stopped.
If it is lower than LOWER level line (2), fill fluid up to UPPER level line (1).

NOTE:

- **Fluid level should be checked when fluid is cool.**
- **Be sure to use an specified power steering fluid.**



- 3) Visually check pump drive belt for cracks and wear.
- 4) Check belt for tension, referring to "A/C COMPRESSOR AND/OR POWER STEERING PUMP DRIVE BELT INSPECTION" in this section. If necessary, have belt adjusted or replaced.

Final Inspection

WARNING:

When carrying out road tests, select a safe place where no man or no running vehicle is seen so as to prevent any accident.

SEATS

Check that seat slides fore and aft smoothly and locks securely at any position. Check that seat angle is adjusted smoothly and locked securely at any angle if equipped. Also check that reclining mechanism of front seat back allows it to be locked at any angle.

SEAT BELT

Inspect belt system including webbing, buckles, latch plates, retractors and anchors for damage or wear. Check that seat belt is securely locked. If "REPLACE BELT" label on front seat belt is visible, replace belt.

BATTERY ELECTROLYTE LEVEL CHECK

Check that the electrolyte level of all battery cells is between the upper and lower level lines on the case. If battery is equipped with built-in indicator, check battery condition by the indicator.

ACCELERATOR PEDAL OPERATION

Check that pedal operates smoothly without getting caught or interfered by any other part.

ENGINE START

Check engine start for readiness.

WARNING:

Before performing the following check, be sure to have enough room around the vehicle. Then, firmly apply both the parking brake and the regular brakes. Do not use the accelerator pedal. If the engine starts, be ready to turn off the ignition promptly. Take these precautions because the vehicle could move without warning and possibly cause personal injury or property damage.

On automatic transaxle vehicles, try to start the engine in each select lever position. The starting motor should crank only in "P" (Park) or "N" (Neutral).

On manual transaxle vehicles, place the shift lever in "Neutral," depress clutch pedal fully and try to start.

EXHAUST SYSTEM CHECK

Check for leakage, cracks or loose supports.

CLUTCH (FOR MANUAL TRANSAXLE)

Check for the following.

- Clutch is completely released when depressing clutch pedal,
- No slipping clutch occurs when releasing pedal and accelerating.
- Clutch itself is free from any abnormal condition.

GEARSHIFT OR SELECT LEVER (TRANSAXLE)

Check gear shift or select lever for smooth shifting to all positions and for good performance of transmission in any position.

With automatic transaxle equipped vehicle, also check that shift indicator indicates properly according to which position select lever is shifted to.

With automatic transaxle equipped vehicle, make sure that vehicle is at complete stop when shifting select lever to “P” range position and release all brakes.

BRAKE

Foot brake

Check the followings:

- that brake pedal has proper travel,
- that brake works properly,
- that it is free from noise,
- that vehicle does not pull to one side when brake is applied.
- and that brake do not drag.

Parking brake

Check that lever has proper travel.

WARNING:

With vehicle parked on a fairly steep slope, make sure nothing is in the way downhill to avoid any personal injury or property damage. Be prepared to apply regular brake quickly even if vehicle should start to move.

Check to ensure that parking brake is fully effective when the vehicle is stopped on the safe slope and brake lever is pulled all the way.

STEERING

- Check to ensure that steering wheel is free from instability, or abnormally heavy feeling.
- Check that the vehicle does not wander or pull to one side.

ENGINE

- Check that engine responds readily at all speeds.
- Check that engine is free from abnormal noise and abnormal vibration.

BODY, WHEELS AND POWER TRANSMITTING SYSTEM

Check that body, wheels and power transmitting system are free from abnormal noise and abnormal vibration or any other abnormal condition.

METERS AND GAUGE

Check that speedometer, odometer, fuel meter, temperature gauge, etc. are operating accurately.

LIGHTS

Check that all lights operate properly.

WINDSHIELD DEFROSTER

Periodically check that air comes out from defroster outlet when operating heater or air conditioning. Set mode control lever to defroster position and fan switch lever to “HI” position for this check.

Recommended Fluids and Lubricants

Engine oil	SE, SF, SG, SH or SJ grade (Refer to “ENGINE OIL AND OIL FILTER” in this section for engine oil viscosity.)
Engine coolant (Ethylene glycol base coolant)	“Antifreeze/Anticorrosion coolant”
Brake fluid	DOT 3
Manual transaxle oil	Refer to “M/T OIL CHANGE” in Section 7A1.
Transfer oil (4WD)	Refer to “TRANSFER OIL CHANGE” in Section 7D.
Differential oil (4WD)	Refer to “DIFFERENTIAL OIL CHANGE” in Section 7F.
Automatic transaxle fluid	An equivalent of DEXRON®-III or DEXRON®-IIE
Power steering fluid	Refer to “REQUIRED SERVICE MATERIAL (FOR POWER STEERING SYSTEM)” in Section 3.
Door hinges	Engine oil or water resistance chassis grease
Hood latch assembly	Engine oil or water resistance chassis grease
Key lock cylinder	Spray lubricant

SECTION 1A

HEATER AND VENTILATION

WARNING:

For vehicles equipped with Supplemental Restraint (Air Bag) System:

- Service on and around the air bag system components or wiring must be performed only by an authorized SUZUKI dealer. Refer to “Air Bag System Components and Wiring Location View” under “General Description” in Section 10B in order to confirm whether you are performing service on or near the air bag system components or wiring. Please observe all WARNINGS and “Service Precautions” under “On-Vehicle Service” in Section 10B before performing service on or around the air bag system components or wiring. Failure to follow WARNINGS could result in unintentional activation of the system or could render the system inoperative. Either or these two conditions may result in severe injury.
- Technical service work must be started at least 90 seconds after the ignition switch is turned to the “LOCK” position and the negative cable is disconnected from the battery. Otherwise, the system may be activated by reserve energy in the Sensing and Diagnostic Module (SDM).




NOTE:

The link mechanism of the heater varies depending on the specifications.

CONTENTS

General Description	1A-2	Heater Unit	1A-8
Wiring Circuit	1A-3	Heater Controller	1A-9
Diagnosis	1A-4	Air Inlet Actuator	1A-11
Diagnosis Table	1A-4	Blower Motor and Blower Motor High	
On-Vehicle Service	1A-5	Relays	1A-12
Blower Unit	1A-5	Center Ventilation Louver	1A-13
Blower Motor	1A-6	Side Ventilation Louver	1A-13
Blower Motor Resistor	1A-7		

General Description



1. Heater unit	5. Ventilation louver	9. Side demister air	13. Heater core
2. Blower unit	6. Ventilation air	10. Fresh air	14. Air intake selector door
3. Ventilator duct	7. Foot air	11. Recirculation air	
4. Demister nozzle	8. Windscreen demister air	12. Blower motor assembly	

Wiring Circuit


Diagnosis

Diagnosis Table

Condition	Possible Cause	Correction
Heater blower motor does not work even when fan speed selector is turned ON position.	Fuse blown	Check related fuses and check for short circuit to ground.
	Blower motor relay faulty	Check blower motor relay.
	Blower motor resistor faulty	Check blower motor resistor.
	Blower speed selector faulty	Check blower speed selector.
	Blower motor faulty	Replace blower motor.
	Wiring or grounding faulty	Repair as necessary.
Heater blower does not work when fan speed selector is turned to high speed.	Blower motor high relay faulty	Check blower motor high relay.
	Fan speed selector faulty	Check fan speed selector.
	Wiring or grounding faulty	Check wiring, grounding and repair as necessary.
Incorrect temperature output.	Control cables broken or binding	Check cables.
	Temperature selector faulty	Check temperature selector.
	Position of control cable clamp is faulty	Check and adjustment.
	Temperature selector door assembly broken	Repair temperature selector door assembly.
	Air ducts clogged	Repair air ducts.
	Heater core leaking or clogged	Replace heater core.
	Heater hoses leaking or clogged	Replace hoses.
	Thermostat faulty	Check thermostat by referring to Section 6B.
Air flow selector disagree with air outlet port.	Selector cable broken or binding	Check cable.
	Air flow selector faulty	Check air flow selector.
	Position of selector cable clamp is faulty	Check and adjustment.
	Air damper broken	Repair damper.
	Air ducts leaking or clogged	Repair air ducts.
No fresh air inlet is changed.	Fuse blown	Check related fuses and check for short circuit to ground.
	Air intake selector faulty	Check air intake selector.
	Air intake actuator faulty	Check air intake actuator.
	Air intake selector door broken	Repair air intake selector door.
	Wiring or grounding faulty	Repair or replace as necessary.

On-Vehicle Service



Blower Unit




1. Blower unit case	4. Air intake selector link	7. Blower inner case	10. Blower motor high relay
2. Blower motor assembly	5. Air intake actuator	8. Blower lower case	
3. Air intake selector door	6. Fresh air inlet duct	9. Blower motor relay	

REMOVAL

- 1) Disconnect negative (–) cable at battery.
- 2) Remove glove box.
- 3) Remove instrument panel passenger lower member (1).



- 4) Disconnect main harness connector clamp (1), air inlet actuator connector (2) and blower connector (3).
- 5) Remove blower motor relay (4) and blower motor high relay (5).



6) Remove blower unit (1) from vehicle.

INSTALLATION


Reverse removal procedure to install blower unit noting the following instruction.

- When installing each part, be careful not to catch any cable or wiring harness.

Blower Motor


REMOVAL


- 1) Disconnect negative (–) cable at battery.
- 2) Remove glove box.
- 3) Disconnect blower motor coupler (1).
- 4) Remove blower motor (2).



INSPECTION

- Check continuity between terminals as shown. If check results are no continuity, replace blower motor assembly (1).





- Check operate and current.
 - a) Fix blower motor assembly (1) by using vise.
 - b) Connect battery to blower motor assembly (1) as shown.
 - c) Check that there is smoothly operates and no noise.
 - d) Check that ammeter indicates specified current.

If measure current is incorrect, replace blower motor.

Reference:

Blower specified current at 12V

: 28 A maximum


INSTALLATION

Reverse removal procedure for installation.

Blower Motor Resistor

REMOVAL

- 1) Disconnect negative (–) cable at battery.
- 2) Disconnect blower motor resistor coupler.
- 3) Remove blower motor resistor (1).



INSPECTION


Measure each terminal-to-terminal resistance on resistor
If measured resistance is incorrect, replace blower motor resistor.

Blower motor resistor resistance

H–MH : approximately 0.4 Ω at 25°C (77°F)

H–ML : approximately 1.1 Ω at 25°C (77°F)

H–L : approximately 2.9 Ω at 25°C (77°F)




INSTALLATION

Reverse removal procedure for installation.


Heater Unit

NOTE:
Refer to “HEATER AND COOLING UNIT” in Section 1B, if vehicle is equipped with A/C system.




1. Heater core	4. Temperature selector door	7. Temperature selector link assembly	10. Foot air nozzle
2. Air resistive board	5. Air flow selector door	8. Packing	11. Air resistive side case
3. Blower motor resistor	6. Air flow selector link assembly	9. Heater case	⊗ Do not reuse.

REMOVAL



- 1) Disconnect negative (–) cable at battery.
- 2) Drain engine coolant, and disconnect heater hoses (1) from heater unit.
- 3) Remove heater unit mounting nuts (2).
- 4) Remove instrument panel referring to “INSTRUMENT PANEL” in Section 9.



- 5) Remove blower unit (1) referring to Step 4) to 6) of "REMOVAL" under "BLOWER UNIT" in this section.
- 6) Remove drain hose (2).
- 7) Remove heater unit(3).

INSTALLATION



Reverse removal procedure to install heater unit noting the following instructions.

- When installing each part, be careful not to catch any cable or wiring harness.
- Adjust heater control cable by referring to "HEATER CONTROLLER" in this section.
- Fill engine coolant to radiator.


Heater Controller

REMOVAL

- 1) Disconnect negative (–) cable at battery.
- 2) Remove steering column hole cover and glove box.
- 3) Remove center lower garnish (1) and then disconnect rear defogger switch connector and fog lamp switch connector (if equipped).



- 4) Disconnect air flow selector cable (1) and temperature selector cable (2).




- 5) Remove heater controller (1) from instrument panel, then disconnect related connector.

INSPECTION

- Check blower speed selector for each terminal to terminal continuity. If check result is not as specified, replace.


POSITION	TERMINAL				
	E	L	ML	MH	H
OFF	<input type="radio"/>				
L	<input type="radio"/>	<input type="radio"/>			
ML	<input type="radio"/>		<input type="radio"/>		
MH	<input type="radio"/>			<input type="radio"/>	
H	<input type="radio"/>				<input type="radio"/>

1. Blower speed selector
2. Terminal arrangement of fan speed selector



- Check air inlet selector for each terminal to terminal continuity. If check result is not as specified, replace.


POSITION	TERMINAL		
	a	b	c
FRESH	<input type="radio"/>	<input type="radio"/>	
RECIRCULATION	<input type="radio"/>		<input type="radio"/>




INSTALLATION

Reverse removal procedure to install heater controller noting the following instructions.

- Adjust the following items.



a) Set air flow selector (1) and temperature selector (2) as shown in figure.



b) Push air flow selector link (1) and temperature selector link (2) fully in arrow direction.

c) Fix air flow selector cable (3) and temperature selector cable (4) with clamp in position as shown in figure.


NOTE:

After installing selector cables, be sure that air flow selector and temperature selector move smoothly and stop at proper position.

Air Inlet Actuator

REMOVAL


- 1) Disconnect negative (–) cable at battery.
- 2) Remove blower unit by referring to “BLOWER UNIT” in this section.



- 3) Remove air inlet actuator (1) from blower unit (2).

INSPECTION

Check air inlet actuator as follows:



- a) Using service wire, connect battery positive terminal to “a” terminal and battery negative terminal to terminal “c”. And check that air inlet selector link operates smoothly and it stops at fresh position (1).
- b) Using service wire, connect battery positive terminal to “b” terminal and battery negative terminal to terminal “c”. And check that air inlet selector link operates smoothly and it stops at recirculation position (2).

If malfunction is found, replace it.


INSTALLATION

Reverse removal procedure for installation.

Blower Motor and Blower Motor High Relays


INSPECTION

- 1) Disconnect negative (–) cable at battery.
- 2) Remove glove box.
- 3) Remove blower motor relay (1) and blower motor high relay (2).
- 4) Check that there is no continuity between terminal “c” and “d”. If there is continuity, replace relay.
- 5) Connect battery positive (+) terminal to terminal “b” of relay. Connect battery negative (–) terminal to terminal “a” of relay. Check continuity between terminal “c” and “d”. If there is no continuity when relay is connected to the battery, replace relay.




Center Ventilation Louver

REMOVAL



1) Remove center upper garnish (1) as shown.

2. Rag




2) Remove center ventilation louver (1) from center upper garnish (2).

INSTALLATION

Reverse removal procedure for installation.


Side Ventilation Louver

REMOVAL



1) Remove side ventilation louver body (1) as shown.

2. Rag




2) Remove ventilation louver (1) from side ventilation louver body.

2. Rag

INSTALLATION

Reverse removal procedure to install side ventilation louver noting the following instruction.

- Be sure to install ventilation louver clip (1) to proper direction as shown.



SECTION 1B

AIR CONDITIONING (OPTIONAL)

WARNING:

For vehicles equipped with Supplemental Restraint (Air Bag) System :

- Service on and around the air bag system components or wiring must be performed only by an authorized SUZUKI dealer. Refer to “Air Bag System Components and Wiring Location View” under “General Description” in air bag system section in order to confirm whether you are performing service on or near the air bag system components or wiring. Please observe all WARNINGS and “Service Precautions” under “On-Vehicle Service” in air bag system section before performing service on or around the air bag system components or wiring. Failure to follow WARNINGS could result in unintentional activation of the system or could render the system inoperative. Either of these two conditions may result in severe injury.
- Technical service work must be started at least 90 seconds after the ignition switch is turned to the “LOCK” position and the negative cable is disconnected from the battery. Otherwise, the system may be activated by reserve energy in the Sensing and Diagnostic Module (SDM).

CAUTION:

The air conditioning system of this vehicle uses refrigerant HFC-134a (R-134a).

None of refrigerant, compressor oil and component parts is interchangeable between two types of A/C : one using refrigerant HFC-134a (R-134a) and the other using refrigerant CFC-12 (R-12).

Be sure to check which refrigerant is used before any service work including inspection and maintenance. For identification between these two types, refer to “REFRIGERANT TYPE” in this section.

When replenishing or changing refrigerant and compressor oil and when replacing parts, make sure that the material or the part to be used is appropriate to the A/C installed in the vehicle being serviced. Use of incorrect one will result in leakage of refrigerant, damage in parts or other faulty condition.

NOTE:

For basic servicing method of the air conditioning system that is not described in this section, refer to “AIR CONDITIONING BASIC MANUAL (Part number : 99520-02130)”.

CONTENTS

General Description	1B-3	A/C System Inspection of ECM and Its	
Sub-cool System	1B-3	Circuits	1B-15
A/C Evaporator Inlet Air Temperature		Wiring diagram	1B-15
Sensor and A/C Evaporator Outlet Air		Voltage check	1B-16
Temperature Sensor	1B-4	Refrigerant Recovery, Evacuating and	
Refrigerant Type	1B-4	Charging	1B-18
Major Components and Location	1B-5	Operation Procedure for Refrigerant	
Diagnosis	1B-6	Charging	1B-18
General Diagnosis Table	1B-6	Recovery	1B-19
Abnormal Noise Diagnosis	1B-8	Replenishing Compressor Oil	1B-19
Quickly Checking of Refrigerant Charge	1B-10	Evacuating	1B-20
Performance Diagnosis	1B-11	Evacuating procedure	1B-20
Performance diagnosis table	1B-13	Checking system for pressure leaks	1B-21
Detail diagnosis table		Charging	1B-22
(ambient temperature at 30°C (86°F))....	1B-14	Charging procedure	1B-22
Electrical Diagnosis	1B-15		

Replacement of refrigerant container in charging procedure	1B-23
Leak Test	1B-24
Liquid leak detectors	1B-24
On-vehicle Service.....	1B-25
Service Precaution.....	1B-25
Handling refrigerant HFC-134a (R-134a)	1B-25
Refrigerant Line	1B-25
Condenser Assembly	1B-26
Desiccant	1B-28
Condenser Cooling Fan	1B-28
Heater and Cooling Unit.....	1B-30
A/C Evaporator	1B-32


A/C Evaporator Inlet and Outlet Air Temperature Sensors	1B-34
Expansion Valve	1B-34
A/C Refrigerant Pressure Switch	1B-35
A/C Switch and Defroster Switch in Heater Controller	1B-36
Compressor Relay and Condenser Cooling Fan Relay	1B-36
Compressor	1B-37
Compressor Drive Belt.....	1B-37
Magnet Clutch.....	1B-38
Required Service Material.....	1B-41
Special Tool	1B-41

General Description

Sub-cool System

DESCRIPTION

In the sub-cool A/C system (condenser integrated with receiver/dryer), the condenser divided the inside into the condensation part and the sub-cooler part and located the receiver/dryer between those. In the receiver/dryer, refrigerant is separated in vapor refrigerant and liquid refrigerant. And only the liquid refrigerant is delivered to the sub-cooler part of the condenser. The refrigerant is supercooled by the sub-cooler part of the condenser.




1. Compressor	6. Expansion valve	11. Filter
2. Magnet clutch	7. A/C evaporator	12. Vapor refrigerant
3. Condenser	8. Condensation part	13. Liquid refrigerant
4. Receiver/dryer	9. Sub-cooler part	
5. Refrigerant pressure switch	10. Desiccant	

PRECAUTION FOR CHARGING

The charging refrigerant must be performed according to “CHARGING” in this section. Also, the refrigerant amount checking must be performed according to “QUICKLY CHECKING OF REFRIGERANT CHARGE” or “PERFORMANCE DIAGNOSIS” in this section.

Because, in the sub-cool system, the point at which bubbles disappear is before the stable cooling performance region. If the charging of the refrigerant is stopped at the point in which bubbles disappear, it will be in insufficient charged region. Also, overcharging causes air-conditioning ability and fuel consumption aggravation.




A/C Evaporator Inlet Air Temperature Sensor and A/C Evaporator Outlet Air Temperature Sensor

These sensors send the signals of the A/C evaporator inlet and outlet air temperatures to ECM. And, ECM controls the A/C operation as follows.


- ECM calculates the A/C ON/OFF operation temperature by comparing the A/C evaporator inlet air temperature with the A/C evaporator outlet air temperature. And, ECM controls A/C ON/OFF using the A/C ON/OFF operation temperature.
- In DEF/FOOT or DEF air flow mode, ECM turns off the A/C operation by detecting the A/C evaporator outlet temperature at less than 2.5°C (36.5°F). (The A/C operation come back at more than 4°C (39.2°F))

Refrigerant Type



Whether the A/C in the vehicle being serviced uses HFC-134a (R-134a) or CFC-12 (R-12) is indicated on compressor label (1). Also, it can be checked by the shape of the service (charge) valve (2).

Major Components and Location



1. Blower unit	7. Condenser outlet pipe	13. Fresh air	19. Sight glass
2. Compressor	8. Expansion valve	14. Recirculation air	[A]: LH model
3. Condenser assembly	9. Ventilation air	15. Heater and cooling unit	[B]: RH model
4. Receiver/dryer	10. Foot air	16. A/C refrigerant pressure switch	
5. Discharge hose	11. Defroster air	17. Low pressure charge valve	
6. Suction pipe	12. Demister air	18. High pressure charge valve	

Diagnosis

General Diagnosis Table

Condition	Possible Cause	Correction
No cool air comes out (A/C system does not operate)	No refrigerant	Perform recover, evacuation and charging.
	Fuse blown	Check related fuses, and check short circuit to ground.
	A/C switch faulty	Check A/C switch.
	Blower speed selector faulty	Check blower speed selector referring to Section 1A.
	A/C evaporator inlet or outlet air temperature sensor faulty	Check A/C evaporator inlet or outlet air temperature sensor.
	A/C refrigerant pressure switch faulty	Check A/C refrigerant pressure switch.
	Wiring or grounding faulty	Repair as necessary.
	ECT sensor faulty	Check ECT sensor referring to Section 6E1.
	ECM and/or its circuit faulty	Check ECM and its circuit referring to Section 6E1.
	Magnet clutch faulty	Check magnet clutch.
	Compressor drive belt loosen or broken	Adjust or replace drive belt.
	Compressor faulty	Check compressor.
	Compressor relay faulty	Check compressor relay.
No cool air comes out (A/C condenser cooling fan motor does not operate)	Fuse blown	Check related fuses, and check short circuit to ground.
	Wiring or grounding faulty	Repair as necessary.
	Condenser cooling fan motor relay faulty	Check condenser cooling fan motor relay.
	Condenser cooling fan motor faulty	Check condenser cooling fan motor.
	ECM and/or its circuit faulty	Check ECM and its circuit referring to Section 6E1.
No cool air comes out (Blower motor does not operate)	Fuse blown	Check related fuses, and check short circuit to ground.
	Blower motor resistor faulty	Check blower motor resistor referring to Section 1A.
	Blower speed selector faulty	Check blower speed selector referring to Section 1A.
	Wiring or grounding faulty	Repair as necessary.
	Blower motor faulty	Check blower motor referring to Section 1A.
	Blower relay faulty	Check blower relay and/or blower high relay referring to Section 1A.

Condition	Possible Cause	Correction
Cool air does not come out or insufficient cooling (A/C system normal operative)	Insufficient or excessive charge of refrigerant	Check charge of refrigerant and system for leaks.
	Condenser clogged	Check condenser.
	A/C evaporator clogged or frosted	Check A/C evaporator and A/C evaporator inlet and outlet temperature sensors.
	A/C evaporator inlet and outlet air temperature sensors faulty	Check A/C evaporator inlet and outlet temperature sensors.
	Expansion valve faulty	Check expansion valve.
	Desiccant clogged	Check desiccant.
	Compressor drive belt loosen or broken	Adjust or replace drive belt.
	Magnetic clutch faulty	Check magnetic clutch.
	Compressor faulty	Check compressor.
	Air in A/C system	Replace desiccant, and perform evacuation and charging.
	Air leaking from heater and cooling unit or air duct	Repair as necessary.
	Heater and ventilation system faulty	Check blower unit, heater controller and heater unit referring to Section 1A.
	Blower motor faulty	Check blower motor referring to Section 1A.
	Excessive compressor oil existing in A/C system	Pull out excess compressor oil in A/C system circuit, and check compressor.
Cool air does not come out only intermittently	Wiring connection faulty	Repair as necessary.
	Expansion valve faulty	Check expansion valve.
	Excessive moisture in A/C system	Replace desiccant, and perform evacuation and charging.
	Magnetic clutch faulty	Check magnetic clutch.
	Excessive charge of refrigerant	Check charge of refrigerant.
Cool air comes out only at high speed	Condenser clogged	Check condenser.
	Insufficient charge of refrigerant	Check charge of refrigerant.
	Air in A/C system	Replace desiccant, and perform evacuation and charging.
	Compressor drive belt loosen or broken	Adjust or replace drive belt.
	Compressor faulty	Check compressor.
Cool air does not come out only at high speed	Excessive charge of refrigerant	Check charge of refrigerant.
	A/C evaporator frosted	Check A/C evaporator and A/C evaporator temperature sensor.
Insufficient velocity of cooled air	A/C evaporator clogged or frosted	Check A/C evaporator and A/C evaporator temperature sensor.
	Air leaking from cooling unit or air duct	Repair as necessary.
	Blower motor faulty	Check blower motor referring to Section 1A.
	Wiring or grounding faulty	Repair as necessary.

Abnormal Noise Diagnosis

There are various types of noise, ranging from those produced in the engine compartment to those from the passenger compartment, also from rumbling noises to whistling noises.

ABNORMAL NOISE FROM COMPRESSOR

Condition	Possible Cause	Correction
During compressor operation, a rumbling noise is heard proportional to engine revolutions.	Inadequate clearance in piston area (piston or swash-plate)	Repair or replace compressor as necessary.
A loud noise is heard at a certain rpm, disproportionately to engine revolution.	Loose or faulty compressor drive belt	Adjust drive belt tension, or replace drive belt.
	Loose compressor mounting bolts	Retighten mounting bolts.
A loud rattle is heard at low engine rpm.	Loose compressor clutch plate bolt	Retighten clutch plate bolt.
		Replace compressor if it was operated in this condition for a long time.

ABNORMAL NOISE FROM MAGNETIC CLUTCH

Condition	Possible Cause	Correction
A rumbling noise is heard when compressor is not operating.	Worn or damaged bearings	Replace magnet clutch assembly.
A chattering noise is heard when compressor is engaged.	Faulty clutch clearance (excessive)	Adjust clutch clearance.
	Worn clutch friction surface	Replace magnet clutch assembly.
	Compressor oil leaked from shaft seal, contaminating the friction surface	Replace compressor body assembly.

ABNORMAL NOISE FROM TUBING

Condition	Possible Cause	Correction
A droning noise is heard inside vehicle, but not particularly noticeable in engine compartment.	Faulty tubing clamps	Reposition clamps or increase the number of clamps.
	Resonance caused by pulsation from variations in refrigerant pressure	Attach a silencer to tubing, or modify its position and length.

ABNORMAL NOISE FROM CONDENSER

Condition	Possible Cause	Correction
Considerable vibration in condenser.	Resonance from condenser bracket and body	Firmly insert a silencer between condenser bracket and body.

ABNORMAL NOISE FROM CRANKSHAFT PULLEY

Condition	Possible Cause	Correction
A large rattling noise is heard at idle or sudden acceleration.	Loosen crankshaft pulley bolt	Retighten bolt.

ABNORMAL NOISE FROM TENSION PULLEY

Condition	Possible Cause	Correction
Clattering noise is heard from pulley.	Worn or damaged bearing	Replace tension pulley.
Pulley cranks upon contact.	Cracked or loose bracket	Replace or retighten bracket.

ABNORMAL NOISE FROM A/C EVAPORATOR


Condition	Possible Cause	Correction
Whistling sound is heard from A/C evaporator.	Depending on the combination of the interior/ exterior temperatures, engine rpm and refrigerant pressure, the refrigerant flowing out of the expansion valve may, under certain conditions, make a whistling sound	At times, slightly decreasing refrigerant volume may stop this noise.
		Inspect expansion valve and replace if faulty.

ABNORMAL NOISE FROM BLOWER MOTOR

Condition	Possible Cause	Correction
Blower motor emits a chirping sound in proportion to its speed of rotation.	Worn or damaged motor brushes or commutator	Replace blower motor.
Fluttering noise or large droning noise is heard from blower motor.	Leaves or other debris introduced from fresh air inlet to blower motor	Remove debris and make sure that the screen at fresh air inlet is intact.

Quickly Checking of Refrigerant Charge

The following procedure can be used for quickly checking whether the A/C system has a proper charge of refrigerant or not.
Run engine at fast idle, and operate A/C at its maximum cooling capacity for a few minutes.



Then, look at the sight glass (1) on condenser outlet pipe (2) and compare what is observed with the symptoms listed in below.

3. Bubbles
4. A/C refrigerant pressure switch

CHECKING REFRIGERANT CHARGE


Step	Action	Yes	No
1	Are there any bubbles in sight glass?	Insufficient charge of refrigerant in A/C system. Charge proper amount of refrigerant.	Go to Step 2.
2	Is there a difference in temperature between compressor inlet pipe and compressor outlet pipe?	Go to Step 3.	Empty or nearly empty of refrigerant on A/C system. Charge proper amount of refrigerant.
3	Are any bubbles produced in sight glass for a while (not immediately), and then become clear when A/C is turned OFF?	Proper charging of refrigerant in A/C system.	Too much charge of refrigerant in A/C system. Charge proper amount of refrigerant.

NOTE:

Charge proper amount of refrigerant referring to “REFRIGERANT RECOVERY, EVACUATING AND CHARGING” in this section, if necessary.

Performance Diagnosis

- 1) Confirm that vehicle and environmental conditions are as follows.
 - Vehicle is not exposed to direct sun.
 - Ambient temperature is within 15 – 35°C (59 – 95°F).




- 2) Make sure that high pressure valve (1) and low pressure valve (2) of manifold gauge set (3) are firmly closed.
- 3) Connect high pressure charging hose (4) to high pressure service valve (5), and connect low pressure charging hose (6) to low pressure service valve (7).
- 4) Bleed the air in charging hoses (4), (6) by loosening their respective nuts on manifold gauge set (3), utilizing the refrigerant pressure. When a hissing sound is heard, immediately tighten nut.

- 5) Warm up engine to normal operating temperature (engine coolant temperature at 80 – 90°C (176 – 194°F)) and keep it at specified idle speed. (Radiator cooling fan should not be working when checking temperature.)
- 6) Set A/C switch to ON position, blower speed selector at “H” (4th position), temperature selector at “COOL”, air flow selector at “FACE” and air intake selector at “RECIRCULATION”. (Confirm that A/C compressor and condenser cooling fan are working.)


Keep all windows, doors and engine food open.

Performance diagnosis condition

Ambient temperature	15 – 35°C (59 – 95°F)
Engine rpm	Keep to 1,500 rpm.
Blower speed selector	“H” (4th position)
Temperature selector	“Cool”
Air flow selector	“Face”
Vehicle doors	All open
Air intake selector	Recirculation



- 7) With dry bulb thermometer (1) inserted into center ventilation louver and another one set near recirculation air inlet, read temperature indicated on each thermometer.




- 8) Check for each pressure of low side and high side if it is within shaded range of graph.
If each gauge reading is out of specified pressure, correct defective part referring to “PERFORMANCE DIAGNOSIS TABLE” in this section.

NOTE:
Pressure registered on gauge varies with ambient temperature. Therefore, use the graphs when determining if pressures are normal or not.

Low side and high side pressure example :

Gauges should read as follows when ambient temperature is 30°C (86°F).	
Pressure on high pressure gauge	1400 – 1750 kPa 14.0 – 17.5 kg/cm ² 199.1 – 248.9 psi
Pressure on low pressure gauge	230 – 350 kPa 2.3 – 3.5 kg/cm ² 32.7 – 49.8 psi



- 9) Check for crossing point of center ventilation louver air temperature and recirculation air inlet temperature if it is within shaded range of graph.
For example, if inlet temperature is 25°C (75°F) and center ventilation louver temperature is 8°C (46°F), their crossing point is within acceptable range as shown in graph.
If crossing point is out of acceptable range, diagnose trouble referring to “PERFORMANCE DIAGNOSIS TABLE” in this section.

Performance diagnosis table

NOTE:

If ambient temperature is approximately 30°C (86°F), it is possible to diagnose A/C system in detail referring to “DETAIL DIAGNOSIS TABLE (AMBIENT TEMPERATURE AT 30 °C (86°F))” under “PERFORMANCE DIAGNOSIS” in this section.

HIGH PRESSURE GAUGE

Condition	Possible Cause	Correction
Pressure is higher than acceptable range (“A” area)	Refrigerant overcharged	Recharge.
	Expansion valve frozen or clogged	Check expansion valve.
	Clogged refrigerant passage of high side	Clean or replace.
	Radiator or condenser cooling fan malfunction (Insufficient cooling of condenser)	Check radiator or condenser cooling fan.
	Dirty or bent condenser fins (Insufficient cooling of condenser)	Clean or repair.
	Compressor malfunction (Insufficient oil etc.)	Check compressor.
	Engine overheat	Check engine cooling system referring to Section 6B.
Pressure is lower than acceptable range (“B” area)	Insufficient refrigerant (Insufficient charge or leakage)	Check for leakage, repair if necessary and recharge.
	Expansion valve malfunction (valve opens too wide)	Check expansion valve.
	Compressor malfunction (Insufficient compression)	Check compressor.

LOW PRESSURE GAUGE

Condition	Possible Cause	Correction
Pressure is higher than acceptable range (“C” area)	Expansion valve malfunction (valve opens too wide)	Check expansion valve.
	Compressor malfunction (Insufficient compression)	Check compressor.
Pressure is lower than acceptable range (“D” area)	Insufficient refrigerant (Insufficient charge or leakage)	Check for leakage, repair if necessary and recharge.
	Expansion valve malfunction (valve opens too narrow)	Check expansion valve.
	Clogged refrigerant passage (crashed pipe)	Repair or replace.

CROSSING POINT OF CENTER VENTILATION LOUVER TEMPERATURE AND RECIRCULATION AIR INLET TEMPERATURE

Condition	Possible Cause	Correction
Crossing point is higher than acceptable range (“E” area)	Insufficient or excessive charge of refrigerant	Check refrigerant pressure.
	Dirty or bent A/C evaporator fins	Clean or repair.
	Air leakage from cooling (heater) unit or air duct	Repair or replace.
	Malfunctioning, switch over function of door in cooling (heater) unit	Repair or replace.
	Compressor malfunction	Check compressor.
Crossing point is lower than acceptable range (“F” area)	Insufficient air volume from center duct (Heater blower malfunction)	Check blower motor and fan.
	Compressor malfunction	Check compressor.


Detail diagnosis table (ambient temperature at 30°C (86°F))

Condition			Possible Cause	Correction
MANIFOLD GAUGE	MPa (kg/cm ²) (psi)	Detail		
Lo	Hi			
0.23 – 0.35 (2.3 – 3.5) (33 – 50)	1.4 – 1.75 (14 – 17.5) (200 – 249)	Normal condition	–	–
Negative pressure	0.5 – 0.6 (5 – 6) (71.2 – 85.3)	The low pressure side reads a negative pressure, and the high pressure side reads an extremely low pressure. Presence of frost around tubing to and from receiver/dryer and expansion valve.	Dust particles or water droplets are either stuck or frozen inside expansion valve, preventing the refrigerant from flowing	Clean expansion valve. Replace it if it cannot be cleaned. Replace receiver/dryer. Evacuate the A/C system and recharge with fresh refrigerant.
Normal : 0.23 – 0.35 (2.3 – 3.5) (33 – 50) ↑↓ Abnormal : Negative pressure	Normal : 1.4 – 1.75 (14 – 17.5) (200 – 249) ↑↓ Abnormal : 0.7 – 1.0 (7 – 10) (100 – 142)	During A/C operation, the low pressure side sometimes indicates negative pressure, and sometimes normal pressure. Also high pressure side reading fluctuates between the abnormal and normal pressure.	Expansion valve is frozen due to moisture in the system, and temporarily shuts off the refrigeration cycle	Replace expansion valve. Replace receiver/dryer. Evacuate A/C system and recharge with fresh refrigerant.
0.05 – 0.15 (0.5 – 1.5) (4.2 – 21.3)	0.7 – 1.0 (7 – 10) (100 – 142)	Both low and high pressure sides indicate low readings. Continuous air bubbles are visible through sight glass. Output air is slightly cold.	Insufficient refrigerant in system (Refrigerant leaking)	Using leak detector, check for leaks and repair as necessary. Recharge refrigerant to a specified amount. If the pressure reading is almost 0 when the manifold gauges are attached, check for any leaks, repair them, and evacuate the system.
0.4 – 0.6 (4 – 6) (56.9 – 85.3)		Pressure on low pressure side is high. Pressure on high pressure side is low. Both pressure becoming equal right after A/C is turned OFF.	Internal leak in compressor	Inspect compressor and repair or replace as necessary.
0.35 – 0.45 (3.5 – 4.5) (50 – 64)	2.0 – 2.5 (20 – 25) (285 – 355)	High pressure reading on both low and high pressure sides. Air bubbles are not visible even when engine rpm is lowered.	Overcharged A/C system Faulty condenser cooling operation Faulty radiator or condenser cooling fan operation	Adjust refrigerant to specified amount. Clean condenser. Inspect and repair radiator or condenser cooling fan.
		High pressure reading on both low and high pressure sides. Low pressure side tubing is not cold when touched. Air bubbles are visible through sight glass.	Presence of air in A/C system (Improperly evacuated)	Replace receiver/dryer. Inspect quantity of compressor oil and presence of contaminants in oil. Evacuate system and recharge with fresh refrigerant.
0.45 – 0.55 (4.5 – 5.5) (64 – 78)		High pressure reading on both low and high pressure sides. Large amount of frost or dew on the low pressure side tubing.	Faulty expansion valve Refrigerant flow is not regulated properly	Replace expansion valve.

Electrical Diagnosis

A/C System Inspection of ECM and Its Circuits

Wiring diagram




1. Blower motor	7. Compressor relay	13. Main fuse box	19. Defroster position switch
2. Blower motor resistor	8. Condenser cooling fan	14. ECT sensor	20. Air intake actuator
3. Blower speed selector	9. Blower fan main relay	15. Main relay	21. A/C evaporator outlet air temperature sensor
4. A/C refrigerant pressure switch	10. Blower fan high relay	16. A/C switch & air intake selector	22. A/C evaporator inlet air temperature sensor
5. Condenser cooling fan relay	11. Ignition switch	17. Recirculation position	23. ECM
6. Compressor	12. Circuit fuse box	18. Fresh position	24. Generator

Voltage check

ECM and its circuits can be checked at ECM wiring couplers by measuring voltage.

CAUTION:
ECM cannot be checked by itself. It is strictly prohibited to connect voltmeter or ohmmeter to ECM with couplers disconnected from it.




- 1) Remove ECM from vehicle by referring to “ECM (PCM) REMOVAL AND INSTALLATION” in Section 6E1.
- 2) Connect ECM couplers (1) to ECM (2).
- 3) Check voltage at each terminal of couplers connected.

NOTE:
As each terminal voltage is affected by the battery voltage, confirm that it is 11 V or more when ignition switch is ON position.

[A] : Fig. A
[B] : Fig. B
3. C20-1 or C20-2

Terminal arrangement of ECM coupler (Viewed from harness side)



ECM voltage values table for relation of A/C control

Terminal	Wire	Circuit	Measurement ground	Normal value	Condition
C20-1	BLK/ORN	ECM ground for power circuit	Ground to body (Fig A)	-0.5 – 0.5 volt	Engine running
C20-2	BLK	ECM ground for power circuit	Ground to body (Fig A)	-0.5 – 0.5 volt	Engine running
C20-10	ORN	Sensor ground for ECT sensor	Ground to body (Fig A)	-0.5 – 0.5 volt	Engine running
C20-14	LT GRN	ECT sensor input	Ground to engine (Fig B)	0.71 – 0.77 volts (298 – 320 Ω)	Engine coolant temperature at approximately 80°C (176°F) with engine running
				0.35 – 0.37 volts (135 – 144 Ω)	Engine coolant temperature at approximately 110°C (230°F) with engine running * If the temperature is more than 110°C (230°F), compressor and condenser cooling fan should be stop (come back at less than 108°C (226.4°F))
C21-1	BRN/YEL	Compressor magnet clutch relay output	Ground to engine (Fig B)	0 – 1 volt	Fulfill all the following conditions <ul style="list-style-type: none"> Blower speed selector ON A/C or defroster switch ON Engine running
				12 – 15 volts	Except the above-mentioned condition with engine running
C21-5	BLK/RED	Main power supply for ECM	Ground to engine (Fig B)	10 – 14 volts	Ignition switch ON with engine stopped
C21-6	BLK/RED	Main power supply for ECM	Ground to engine (Fig B)	10 – 14 volts	Ignition switch ON with engine stopped
C21-7	BLU/ORN	Radiator cooling fan and A/C condenser fan control pressure switch input	Ground to engine (Fig B)	-0.5 – 0.5 volt	Radiator cooling fan control pressure of A/C refrigerant pressure switch ON
				12 – 15 volts	Radiator cooling fan control pressure of A/C refrigerant pressure switch OFF
C21-9	BLU/YEL	Condenser cooling fan relay output	Ground to engine (Fig B)	0 – 1 volt	Fulfill all the following conditions <ul style="list-style-type: none"> Blower speed selector ON A/C or defroster switch ON Engine running Engine coolant temperature at more than 110°C (230°F) with engine running
				12 – 15 volts	Except the above-mentioned condition with engine running
C21-10	BRN/WHT	Main relay drive	Ground to engine (Fig B)	0.5 – 1.2 volts	Ignition switch ON with engine stopped
				10 – 14 volts	Ignition switch OFF
C21-11	YEL/WHT	A/C evaporator inlet air temperature sensor input	Ground to engine (Fig B)	2.09 – 2.17 volts (1940 – 2060 Ω)	A/C evaporator inlet air temperature at approximately 25°C (77°F) with engine running
				1.20 – 1.30 volts (2885 – 3188 Ω)	A/C evaporator inlet air temperature at approximately 18°C (64.4°F) with engine running
C21-14	WHT/BLK	A/C evaporator outlet air temperature sensor input	Ground to engine (Fig B)	2.09 – 2.17 volts (1940 – 2060 Ω)	A/C evaporator outlet air temperature at approximately 25°C (77°F) with engine running
				2.02 – 2.14 volts (6150 – 6800 Ω)	A/C evaporator outlet air temperature at approximately 2.5°C (36.5°F) with engine running
C21-16	GRN/BLK	A/C switch input	Ground to engine (Fig B)	12 – 15 volt	Fulfill all the following conditions <ul style="list-style-type: none"> Blower speed selector ON A/C or defroster switch ON Engine running
				0 – 1 volts	Except the above-mentioned condition with engine running
C21-20	ORN	Sensor ground for A/C evaporator inlet and outlet air temperature sensors	Ground to body (Fig A)	-0.5 – 0.5 volt	Engine running
G07-10	BLU/BLK	Blower speed input	Ground to engine (Fig B)	0 – 1 volt	Blower speed selector "ML", "MH" or "H" with engine running
				4 – 7 volts	Blower speed selector "L" position with engine running
				12 – 15 volts	Blower speed selector OFF with engine running

Refrigerant Recovery, Evacuating and Charging


WARNING:

- Your eyes should not be exposed to refrigerant (liquid).
Any liquid HFC-134a (R-134a) escaping by accident shows a temperature as low as approximately -6°C (32°F) below freezing point. Should liquid HFC-134a (R-134a) get into your eyes, it may cause a serious injury. To protect your eyes against such accident, it is necessary to always wear goggles. Should it occur that HFC-134a (R-134a) strikes your eyes, consult a doctor immediately.
 - Do not use your hand to rub the affected eye(s). Instead, use quantities of fresh cold water to splash it over the affected area to gradually raise temperature of such area above freezing point.
 - Obtain proper treatment as soon as possible from a doctor or eye specialist.
- Should the HFC-134a (R-134a) liquid come into contact with your skin, the affected area should be treated in the same manner as when skin is frostbitten or frozen.
- Refrigerant must not be handled near where welding or steam cleaning is performed.
- Refrigerant should be kept at a cold and dark place. It should never be stored where a high temperature is anticipated, e.g. where exposed to direct sun light, close to fire or inside vehicle (including trunk room).
- Avoid breathing fumes produced when HFC-134a (R-134a) is burned. Such fumes may be hazardous to health.

CAUTION:


Do not perform an additional refrigerant charging to A/C system. This cause it to overcharge.

Operation Procedure for Refrigerant Charging



Recovery

REFRIGERANT RECOVERY




When discharging refrigerant out of A/C system, always recover it by using refrigerant recovery and recycling equipment. Discharging refrigerant HFC-134a (R-134a) into atmosphere would cause adverse effect to environments.

NOTE:

- After recovery refrigerant from system, the amount of removed compressor oil must be measured for replenishing compressor oil.
- When handling recovery and recycling equipment, be sure to follow the instruction manual for the equipment.

Replenishing Compressor Oil




It is necessary to replenish specified amount of compressor oil to compressor (1) from compressor suction side hole (2) before evacuating and charging refrigerant.

WHEN CHARGING REFRIGERANT ONLY

When charging refrigerant without replacing any component part, replenish the same amount of measured oil when recover refrigerant (if not measure, replenish 30 cm³ (30 cc) oil).

WHEN REPLACING COMPRESSOR



Compressor oil is sealed in each new compressor by the amount required for A/C system. Therefore, when using a new compressor for replacement, drain excess oil from it by the amount calculated as follows.

“C” = “A” – “B”

“C” : Amount of oil to be drained

“A” : Amount of oil sealed in a new compressor

“B” : Amount of oil remaining in removed compressor

NOTE:

Compressor assembly supplied from factory is filled up with the following amount of oil.

Oil amount in compressor
: 100 cm³ (100 cc)

1. New compressor
2. Removed compressor

WHEN REPLACING OTHER PART

Replenish the following amount of oil to compressor.

Amount of compressor oil to be replenished

Replaced part	Amount of compressor oil
Evaporator	25 cm ³ (25 cc)
Condenser	15 cm ³ (15 cc)
Desiccant	20 cm ³ (20 cc)
Hoses	10 cm ³ (10 cc) each
Pipes	10 cm ³ (10 cc) each

Evacuating


Evacuating procedure

CAUTION:

Do not evacuate before recovering refrigerant in system.

NOTE:

Whenever opened (exposed to atmospheric air), air conditioning system must be evacuated by using a vacuum pump. The A/C system should be attached with a manifold gauge set, and should be evacuated for approximately 15 minutes.



- 1) Connect high charging hose (1) and low charging hose (2) of manifold gauge set (3) respectively as follows :
 High charging hose (1) → High pressure charging valve (4) on condenser outlet pipe
 Low charging hose (2) → Low pressure charging valve (5) on suction pipe
- 2) Attach center charging hose (6) of manifold gauge set (3) to vacuum pump (7).
- 3) Operate vacuum pump (7), and then open discharge side valve (Hi) (8) of manifold gauge set (3).
 If there is no blockage in the system, there will be an indication on high pressure gauge (9).
 In this case, open the other side valve (Lo) (10) of the set and repair the system.
- 4) Approximately 10 minutes later, low pressure gauge (11) should indicate -10 kpa (-1.0 kg/cm^2 , -760 mmHg , -14.7 psi) providing no leakage exists.

NOTE:

- If the system does not indicate -10 kpa (-1.0 kg/cm^2 , -760 mmHg , -14.7 psi), close both valves, stop vacuum pump and watch movement of low pressure gauge.
 - Increase in the gauge reading suggests existence of leakage. In this case, repair the system before continuing its evacuation.
 - If the gauge shows a stable reading (suggesting no leakage), continue evacuation.
- 5) Evacuation should be carried out for a total of at least 15 minutes.
 - 6) Continue evacuation until low pressure gauge (9) indicates -10 kpa (-1.0 kg/cm^2 , -760 mmHg , -14.7 psi) and then close both valves (8), (10).
 - 7) Stop vacuum pump (7). Disconnect center charging hose (6) from pump inlet. Now, the system is ready for charging refrigerant.

Checking system for pressure leaks

After completing the evacuation, close manifold gauge high pressure valve and low pressure valve and wait 10 minutes. Verify that low pressure gauge reading has not changed.

CAUTION:

If the gauge reading moves closer to "0", there is a leak somewhere. Inspect the tubing connections, make necessary corrections, and evacuate system once again, making sure that there are no leaks.

Charging

CAUTION:

- Always charge through low pressure side of A/C system at after the initial charging is performed from the high pressure side with the engine stopped.
- Never charge to high pressure side of A/C system with engine running.
- Do not charge while compressor is hot.
- When installing tap valve to refrigerant container to make a hole there through, carefully follow directions given by manufacturer.
- A pressure gauge should always be used before and during charging.
- The refrigerant container should be emptied of refrigerant when discarding it.
- The refrigerant container should not be heated up to 40°C (104°F) or over.
- Refrigerant container should not be reversed in direction during charging. Reversing in direction causes liquid refrigerant to enter compressor, causing troubles, such as compression of liquid refrigerant and the like.

NOTE:

The air conditioning system uses HFC-134a (R-134a).

Described here is a method to charge the air conditioning system with refrigerant from the refrigerant service container.

When charging refrigerant recovered by using the refrigerant and recycling equipment (when recycling refrigerant), follow the procedure described in the equipment manufacturer's instruction manual.

Charging procedure


Charge proper amount of refrigerant accurately in accordance with the following procedure.

Specified amount of refrigerant
: 500 ± 30 g (17.65 ± 1.05 oz)

The initial charging of the A/C system is performed from the high pressure side with the engine stopped.

And next, this method must be followed by charging from the low pressure side with the engine running.

- 1) Check to make sure that hoses are routed properly after evacuating the system.
- 2) Connect Low charging hose (1) and High charging hose (2) of the manifold gauge set (3) in position. Thus open refrigerant container valve (4) to purge the charging line.
- 3) Open the high pressure side valve (5) and charge refrigerant to system.
- 4) After a while, open the low pressure side valve (6) and close the high pressure side valve (5).



WARNING:

Make sure that high pressure side valve is closed securely.

- 5) Start engine and keep engine speed at 1500 r/min. Then, operate air conditioning at "DEF" or "DEF/FOOT" air flow mode.

- 6) Charge A/C system with refrigerant. At this time, refrigerant container (4) should be held upright.
- 7) Remove manifold gauge set as follows :

WARNING:


High pressure side is naturally under high pressure. So, care must be used to protect your eyes and skin.

- a) Close low pressure side valve of manifold gauge set. (The high pressure side valve is closed continuously during the process of charging.)
- b) Close refrigerant container valve.
- c) Stop engine.
- d) Using shop rag, remove charging hoses from service valves. This operation must be performed rapidly.
- e) Put caps on service valves.

Replacement of refrigerant container in charging procedure

When refrigerant container (1) is emptied, use the following procedure to replace it with a new refrigerant container (1).


- 1) Close low pressure valve.
- 2) Replace empty container (1) with a refrigerant container which has been charged with refrigerant. When using refrigerant container tap valve (2), use the following procedure for replacement.
 - a) Retract needle (3) and remove refrigerant container tap valve (2) by loosening its plate nut (4).
 - b) Install previously-removed refrigerant container tap valve (2) to a new refrigerant container (1).



- 3) Purge any air existing in center charging hose

When using refrigerant container tap valve, use the following procedure to purge air.

- a) Once fully tighten refrigerant container tap valve (1), and then loosen (open) plate nut (2) slightly.
- b) Open low pressure side valve (3) of manifold gauge set (4) a little.
- c) As soon as refrigerant comes out with a "hiss" through a clearance between refrigerant container and tap valve, tighten plate nut (2) as well as low pressure side valve (3).
- d) Turn handle of tap valve (1) clockwise so that its needle is screwed into the new container to make a hole for refrigerant flow.



Leak Test


Whenever a refrigerant leak is suspected in the system or any service operation has been performed which may result in disturbing lines or connections, it is advisable to test for leaks.

Common sense should be used in performing any refrigerant leak test, since the need and extent of any such test will, in general, depend upon the nature of a complaint and the type of a service performed on the system.

Liquid leak detectors

WARNING:

- To prevent explosions or fires, make sure that there are no flammables in the vicinity.
- When exposed to fire, the refrigerant turns into a poisonous gas (phosgene). Do not inhale this gas.



There are a number of fittings and places throughout the air conditioning system where a liquid leak detector solution may be used to pinpoint refrigerant leaks.

By merely applying the solution to the area in question with a swab, such as attached to the cap of a vial, bubbles will form within seconds if there is a leak.

For confined areas, such as sections of the evaporator and condenser, an electronic (refrigerant) leak detector is more practical for determining leaks.

Special tool

(A) : 09990 - 86011

On-vehicle Service

WARNING:


- When refrigerant HFC-134a (R-134a) strike your eye(s), consult a doctor immediately.
- Do not use your hand to rub affected eye(s). Instead, use quantities of fresh cold water to splash it over affected area to thus gradually raise its temperature above the freezing point.
- Obtain proper treatment as soon as possible from a doctor or eye specialist. Should liquid refrigerant HFC-134a (R-134a) get on your skin, such affected part should be treated in the same manner as when skin is frostbitten or frozen.






Service Precaution

Handling refrigerant HFC-134a (R-134a)

- Always wear goggles to protect your eyes.
- Avoid you direct contact to liquid refrigerant.
- Do not heat refrigerant container higher than 40°C (104°F).
- Do not discharge refrigerant into atmosphere.
- Do not allow liquid refrigerant to touch bright metals. Refrigerant combined with moisture is corrosive and will tarnish surfaces of bright metals including chrome.

Refrigerant Line



 1. Suction hose: Apply compressor oil (refrigerant oil) to O-ring.	 4. Expansion valve: Apply compressor oil (refrigerant oil) to O-ring.
 2. Discharge hose: Apply compressor oil (refrigerant oil) to O-ring.	 5. A/C refrigerant pressure switch: Apply compressor oil (refrigerant oil) to O-ring.
 3. Condenser outlet pipe: Apply compressor oil (refrigerant oil) to O-ring.	

- Never use heat for bending pipes. When bending a pipe, try to make its bending radius as slight as possible.
- Keep internal parts of air conditioning free from moisture and dirt. When disconnecting any line from system, install a blind plug or cap to the fitting immediately.
- When connecting hoses and pipes, apply a few drops of compressor oil (refrigerant oil) to seats of coupling nuts and O-ring.
- When tightening or loosening a fitting, use two wrenches, one for turning and the other for support.

- Tighten flared nuts by the following specified torque.

Tightening torque

8 mm pipe : 13 N·m (1.3 kg-m, 9.5 lb-ft)

12 mm pipe : 23 N·m (2.3 kg-m, 16.6 lb-ft)

14.5 mm pipe : 33 N·m (3.3 kg-m, 23.8 lb-ft)

- Route drain hose so that drained water does not make any contact to vehicle components.
- If pipes or hoses are replaced, replenish specified amount of compressor oil to compressor suction side by referring to “REPLENISHING COMPRESSOR OIL” in this section.

Condenser Assembly

CAUTION:

Be careful not to damage condenser fins. If condenser fin is bent, straighten it by using flat head screwdriver or pair of pliers.

INSPECTION

Check the following.

- Clog of condenser fins.
If, any clogs are found, condenser fins should be washed with water, and should be dried with compressed air.
- Condenser fins for leakage and breakage.
If any defects are found, repair or replace condenser.
- Condenser fittings for leakage.
If any defects are found, repair or replace condenser.


REMOVAL

- 1) Disconnect negative (–) cable at battery.
- 2) Recover refrigerant from A/C system by referring to “RECOVERY” in this section.

NOTE:

The amount of removed compressor oil must be measured for replenishing compressor oil.

- 3) Remove front bumper referring to “FRONT BUMPER” in Section 9.



- 4) Remove hood lock cross member (1) and radiator stay bolts (2).
- 5) Disconnect discharge hose (3) and condenser outlet pipe (4) from condenser (5).
- 6) Remove condenser mounting bolts (6).
- 7) Remove condenser (5).

INSTALLATION


Reverse removal procedure to install condenser noting the following instructions.

- Replenish specified amount of compressor oil to compressor suction side by referring to “REPLENISHING COMPRESSOR OIL” in this section.
- Evacuate and charge refrigerant by referring to “EVACUATING” and “CHARGING” in this section.

Desiccant

REMOVAL

- 1) Remove condenser assembly referring to "CONDENSER ASSEMBLY" in this section.
- 2) Remove circlip (1), receiver/dryer cap (2) and filter (3).



- 3) Remove desiccant.

INSTALLATION



Reverse removal procedure to install desiccant noting the following instructions.

- Do not remove desiccant from the plastic bag until just before inserting it into the receiver.
- Replenish specified amount of compressor oil to compressor suction side by referring to "REPLENISHING COMPRESSOR OIL" in this section.

Condenser Cooling Fan

INSPECTION

- 1) Check condenser cooling fan motor for continuity between terminal "a" and "b" as shown.
If there is no continuity, replace condenser cooling fan motor.




- 2) Connect battery to condenser cooling fan motor terminal "a" and "b" as shown in figure, then check that the condenser cooling fan motor operates smoothly.

Reference :

**Condenser cooling fan specified current at 12V
: 9 A maximum.**

REMOVAL




- 1) Disconnect negative (–) cable at battery.
- 2) Disconnect condenser cooling fan motor coupler.
- 3) Remove condenser cooling fan (1) from radiator (2).

INSTALLATION

Reverse removal procedure for installation.

Heater and Cooling Unit



1. A/C evaporator	7. Packing	13. Blower motor resistor	19. Expansion pipe
2. Heater core	8. Temperature selector link assembly	14. A/C evaporator under cover	20. Packing
3. Expansion valve	9. A/C evaporator inlet air temperature sensor clamp (black)	15. Lower packing	⊗ Do not reuse.
4. Temperature selector door	10. A/C evaporator outlet air temperature sensor clamp (white)	16. Foot air nozzle	
5. Air outlet selector door	11. A/C evaporator inlet air temperature sensor	17. Heater and cooling case	
6. Air outlet selector link assembly	12. A/C evaporator outlet air temperature sensor	18. Air joint duct	


CAUTION:
Be careful not to damage A/C evaporator fins. If A/C evaporator fin is bent, straighten it by using flat head screwdriver or pair of pliers.

REMOVAL


- 1) Disconnect negative (–) cable at battery.
- 2) Recover refrigerant from A/C system by referring to “RECOVERY” in this section.

NOTE:
The amount of removed compressor oil must be measured for replenishing compressor oil.


- 3) Remove instrument panel referring to “INSTRUMENT PANEL” in Section 9.



- 4) Disconnect suction hose (1) and condenser outlet hose (2) by removing attaching bolt.



- 5) Drain engine coolant and disconnect heater hoses (1) from heater unit.
6) Remove heater unit mounting nuts (2).



- 7) Remove blower unit (1) referring to steps 4) to 7) of "BLOWER UNIT" in Section 1A.
8) Disconnect A/C evaporator inlet and outlet temperature sensor couplers (2).
9) Remove heater and cooling unit drain hose (3).
10) Remove heater and cooling unit from vehicle (4).

INSTALLATION

Reverse removal procedure to install heater and cooling unit noting the following instructions.

- When installing each part, be careful not to catch any cable or wiring harness.
- Fill engine coolant to radiator.
- Replenish specified amount of compressor oil to compressor suction side by referring to "REPLENISHING COMPRESSOR OIL" in this section.
- Evacuate and charge refrigerant by referring to "EVACUATING" and "CHARGING" in this section.
- Adjust air outlet control cable and temperature control cable by referring to "HEATER CONTROLLER" in Section 1A.

A/C Evaporator

CAUTION:

Be careful not to damage A/C evaporator fins. If A/C evaporator fin is bent, straighten it by using flat head screwdriver or pair of pliers.



REMOVAL

- 1) Disconnect negative (–) cable at battery.
- 2) Recover refrigerant from A/C system by referring to “RECOVERY” in this section.


NOTE:

The amount of removed compressor oil must be measured for replenishing compressor oil.


- 3) Remove glove box.
- 4) Remove instrument panel passenger lower member (1).



- 5) Disconnect suction hose (1) and condenser outlet hose (2) by removing attaching bolt.



- 6) Unglue packing from expansion valve.
- 7) Remove expansion valve pipe (1) from expansion valve (2).
- 8) Remove expansion valve (2) from evaporator.



- 9) Disconnect A/C evaporator inlet and outlet air temperature sensor couplers (1).
- 10) Remove A/C evaporator outlet air temperature sensor (2).
- 11) Remove air joint duct (3).
- 12) Pull out A/C evaporator from heater and cooling unit (4).

INSPECTION

Check the following.


- Clog of A/C evaporator fins.
If any clogs are found, A/C evaporator fins should be washed with water, and should be dried with compressed air.
- A/C evaporator fins for leakage and breakage.
If any defects are found, repair or replace A/C evaporator.
- A/C evaporator fittings for leakage.
If any defects are found, repair or replace A/C evaporator.

INSTALLATION

Reverse removal procedure to install cooling unit noting the following instructions.

- Replenish specified amount of compressor oil to compressor suction side by referring to “REPLENISHING COMPRESSOR OIL” in this section.
- Evacuate and charge refrigerant by referring to “EVACUATING” and “CHARGING” in this section.

A/C Evaporator Inlet and Outlet Air Temperature Sensors



Check resistance between terminals for A/C evaporator inlet air temperature sensor (1) and A/C evaporator outlet air temperature sensor (2).

If check results are as not specified, replace A/C evaporator temperature sensor.

A/C evaporator inlet and outlet air temperature sensors resistance

Sensor Temperature	Resistance
0°C (32°F)	6.4 – 6.9 kΩ
25°C (77°F)	1.8 – 2.2 kΩ

Expansion Valve

INSPECTION

Refer to “PERFORMANCE DIAGNOSIS” in this section.

REMOVAL

Refer to Step 1) to 8) of “A/C EVAPORATOR” in this section.

INSTALLATION

Reverse removal procedure to install expansion valve noting the following instructions.

- Replenish specified amount of compressor oil to compressor suction side by referring to “REPLENISHING COMPRESSOR OIL” in this section.
- Evacuate and charge refrigerant by referring to “EVACUATING” and “CHARGING” in this section.

A/C Refrigerant Pressure Switch

INSPECTION


A/C control pressure switch

- 1) Run engine and A/C switch ON.
 - 2) Check continuity between “a” and “b” terminals of A/C refrigerant pressure switch (1) in normal A/C condition.
- If no continuity, replace A/C refrigerant pressure switch.

Radiator cooling fan and A/C condenser cooling fan control pressure switch

- 1) Connect manifold gauge set to charging valves.
- 2) Run engine and A/C switch ON.
- 3) Check continuity between “c” and “d” terminals of A/C refrigerant pressure switch (1) when A/C refrigerant pressure is changed, as shown in figure.

If operation is not as specified, replace A/C refrigerant pressure switch.



[A]:	A/C control pressure switch ON/OFF operation
[B]:	Radiator cooling fan and A/C condenser cooling fan control pressure switch ON/OFF operation
A:	Approx. 200 kPa (2.0 kg/cm ² , 28.5 psi)
B:	Approx. 230 kPa (2.3 kg/cm ² , 32.5 psi)
C:	Approx. 2600 kPa (26 kg/cm ² , 370 psi)
D:	Approx. 3200 kPa (32 kg/cm ² , 455 psi)
E:	Approx. 1100 kPa (11 kg/cm ² , 156 psi)
F:	Approx. 1500 kPa (15 kg/cm ² , 213 psi)

REMOVAL

- 1) Disconnect negative cable at battery.
- 2) Disconnect A/C refrigerant pressure switch connector (1).
- 3) Remove A/C refrigerant pressure switch (2) from refrigerant pipe.

CAUTION:

Be careful to distort refrigerant pipe.

INSTALLATION


Reverse removal procedure to install A/C refrigerant pressure switch noting the following instruction.

- Tighten A/C refrigerant pressure switch as specified torque.

Tightening torque

A/C refrigerant pressure switch

(a) : 11 N·m (1.1 kg-m, 8.0 lb-ft)




A/C Switch and Defroster Switch in Heater Controller

REMOVAL AND INSTALLATION

Refer to "HEATER CONTROLLER" in Section 1A.


INSPECTION



- Press A/C switch (1) and check if there is continuity between terminals "a" and "b".
- Connect battery positive terminal to terminal "c" and negative terminal to terminal "a", and then press A/C switch (1) and check if indicator lamp lights.
- Turn air flow selector (2) to defroster position and check if there is continuity between "a" and "d" terminals, "e" and "f" terminals.

Compressor Relay and Condenser Cooling Fan Relay

INSPECTION



- 1) Disconnect negative (–) cable at battery.
- 2) Remove condenser cooling fan relay (1) and compressor relay (2) from main fuse box.
- 3) Check that there is no continuity between terminal "c" and "d". If there is continuity, replace relay.
- 4) Connect battery positive (+) terminal to terminal "b" of relay. Connect battery negative (–) terminal "a" of relay. Check continuity between terminal "c" and "d". If there is no continuity when relay is connected to the battery, replace relay.


Compressor

REMOVAL

- 1) Run engine at idle speed with air conditioning ON for 10 minutes. After that stop the engine.
- 2) Disconnect negative (–) cable at battery.
- 3) Recover refrigerant from refrigeration system by referring to “RECOVERY” in this section.

NOTE:

The amount of removed compressor oil must be measured for replenishing compressor oil.



- 4) Remove compressor drive belt (1) referring to “POWER STEERING BELT” in Section 3B1.
- 5) Disconnect magnet clutch lead wire coupler (2).
- 6) Disconnect suction pipe (3) and discharge pipe (4) from compressor (5).

NOTE:

Cap open fittings immediately to keep moisture out of system.

- 7) Remove compressor mounting bolts (6), and then remove compressor (7) from its bracket.

INSPECTION


Check magnet clutch operation and specified current as follows :

- 1) Connect battery and ammeter (1) to magnet clutch, and check that magnet clutch operation with “click” sound.
- 2) Check that ammeter (1) indicates specified current.

If indicated current is without current, replace magnet clutch assembly referring to “MAGNET CLUTCH ASSEMBLY” in this section.

Reference

**Magnet clutch specified current at 12V
: 3A Max.**



INSTALLATION

Reverse removal procedure to install compressor noting the following instructions.


- If compressor is replaced, pour new compressor oil by referring to “REPLENISHING COMPRESSOR OIL” in this section.
- Evacuate and charge system by referring to “RECOVERY” in this section.
- Adjust drive belt tension by referring to “POWER STEERING BELT” in Section 3.



Compressor Drive Belt

Refer to “POWER STEERING BELT” in Section 3.

Magnet Clutch

CAUTION:
Never disassemble compressor body assembly. Performing any of these prohibited services will affect original performance of A/C system.




1. Clutch plate bolt	4. Clutch pulley	7. Compressor body assembly
2. Clutch plate	5. Shim	 Tightening torque
3. Circlip	6. Magnet clutch coil	 Do not reuse.


REMOVAL

- 1) Remove compressor from vehicle. Refer to “COMPRESSOR” in this section.
- 2) Fix armature plate (1) with special tool and remove clutch plate bolt and washer.

Special tool
(A) : 09991-06020

NOTE:
Do not reuse clutch plate bolt.






3) Using special tool, remove clutch plate (1).

Special tool

(A) : 09991-06030

4) Remove shim(s) from shaft.




5) Using special tool, remove circlip.

Special tool

(A) : 09900-06107

6) Remove magnet clutch lead wire clamp screw, and remove magnet clutch lead wire ground terminal.

7) Disconnect magnet clutch lead wire coupler.




8) Remove clutch pulley with puller.

NOTE:

- Be careful not to damage pulley when tapping magnet clutch.

1. Puller

2. Compressor



9) Remove magnet clutch coil.


Special tool

(A) : 09900-06107

INSPECTION

- Check clutch plate and clutch pulley for wear and oil soaked conditions respectively.
- Check clutch pulley bearing for noise, wear and grease leakage.

INSTALLATION



- 1) Install magnet clutch coil (2).


NOTE:

Protrusion on under side of coil ring (1) must match hole in compressor assembly (3) to prevent movement and correctly locate lead wire.

- 2) Using special tool, install snap ring as shown.

Special tool

(A) : 09900-06107



- 3) Install clutch pulley.

a) Set clutch pulley squarely over clutch installation boss.

b) Place special tool onto clutch bearing.

Ensure that edge rests only on inner race of bearing.

Special tool


(A) : 09991-06010

- c) Install snap ring.

CAUTION:

Be careful not to scratch bearing seal.


- 4) Connect magnet clutch lead wire coupler.



- 5) Adjust clearance, between clutch plate and clutch pulley by putting shim on compressor shaft.

Standard clearance between clutch plate and clutch pulley

"a" : 0.35 - 0.60 mm (0.014 - 0.020 in.)



- 6) Tighten new clutch plate bolt to specified torque.

Tightening torque

Clutch plate bolt

18 N·m (1.8 kg-m, 13.0 lb-ft)

Special tool







(A) : 09991-06020

1. Clutch plate

Required Service Material

Material	Recommended SUZUKI product (Part Number)	Use
Compressor oil	COMPRESSOR OIL (ND - OIL 8, 250 cc) 99000-27080	<ul style="list-style-type: none"> • O-ring • Each component

Special Tool

 <p>09900-06107 Snap ring pliers (Opening type)</p>	 <p>09990-06010 Manifold gauge set See NOTE below.</p>	 <p>09990 -86011 Gas leak detector</p>
 <p>09991-06010 Magnet clutch pulley installer</p>	 <p>09991-06020 Armature plate spanner</p>	 <p>09991-06030 Armature plate remover</p>

NOTE:

This kit includes the following items.

1. Manifold gauge, 2. Changing hose, 3. Quick connector, 4. Refrigerant container tap valve,
5. Refrigerant container T joint, 6. Packing set

SECTION 3

STEERING, SUSPENSION, WHEELS AND TIRES

CONTENTS

STEERING, SUSPENSION, WHEELS AND TIRES	3-3	Tightening Torque Specification	3-38
Diagnosis	3-3	Required Service Material	3-39
General Diagnosis	3-3	Special Tool	3-39
Diagnosis Table	3-3		
WHEEL ALIGNMENT	3-7	STEERING WHEEL AND COLUMN	3-40
Specifications	3-7	General Description	3-40
On-Vehicle Service	3-8	Steering Column	3-40
Front Wheel Alignment	3-8	Steering Wheel and Driver Air Bag (Inflator) Module	3-41
Preliminary checks prior to adjustment front wheel alignment	3-8	Diagnosis	3-41
Toe inspection and adjustment	3-9	Inspection and Repair Required after Accident	3-41
Steering angle check and adjustment	3-10	On-Vehicle Service	3-42
Reference information	3-10	Service Precautions	3-42
Rear Wheel Alignment	3-11	Service and diagnosis	3-42
Toe inspection and adjustment	3-11	Disabling air bag system	3-42
Reference information	3-11	Enabling air bag system	3-42
		Handling and storage	3-43
		Disposal	3-43
		Driver Air Bag (Inflator) Module	3-43
		Steering Wheel	3-45
		Centering Contact Coil	3-46
		Contact Coil and Combination Switch Assembly	3-47
		Steering Column Assembly	3-49
		Steering Lock Assembly (Ignition Switch)	3-54
		Steering Lower Shaft	3-55
		Checking Steering Column Assembly and Lower Shaft for Accident Damage	3-57
		Special Tool	3-57
POWER STEERING (P/S) SYSTEM	3-12	FRONT SUSPENSION	3-58
General Description	3-13	General Description	3-58
P/S System Description	3-13	Construction	3-58
Specifications	3-14	Diagnosis	3-59
Specification and Service Data	3-14	Diagnosis Table	3-59
Diagnosis	3-15	Stabilizer Bar and/or Bushing Check	3-59
Diagnosis Table	3-15	Strut Assembly Check	3-59
Steering Wheel Play Check	3-16	Suspension Control Arm/Steering Knuckle Check	3-60
Steering Force Check	3-17	Suspension Control Arm Bushing Check	3-60
Power Steering Fluid Level Check	3-17	Suspension Control Arm Joint Check	3-60
Power Steering Belt Check	3-17	Front Suspension Frame Check	3-61
Power Steering Belt Tension Adjustment	3-18	Front Suspension Fasteners Check	3-61
Idle Up System Check	3-18		
Fluid Leakage Check	3-19		
Hydraulic Pressure in P/S Circuit Check	3-20		
Steering Rack Boot Check	3-21		
Tie Rod End Boot Check	3-22		
Steering Shaft Joint Check	3-22		
Air Bleeding Procedure	3-22		
On-vehicle Service	3-23		
Power Steering Belt	3-23		
Tie Rod End	3-23		
Power Steering Gear Box	3-26		
Tie Rod/Rack Boot	3-29		
Power Steering Pump	3-31		

Wheel Disc, Nut and Bearing Check.....	3-61
On-vehicle Service.....	3-62
Strut Assembly.....	3-62
Stabilizer Bar and/or Bushings.....	3-65
Wheel Hub and Steering Knuckle.....	3-67
Suspension Control Arm/Bushing.....	3-73
Front Suspension Frame.....	3-76
Required Service Material.....	3-78
Special Tool.....	3-79
 REAR SUSPENSION (2WD VEHICLE)	 3-80
General Description.....	3-81
Construction.....	3-81
Diagnosis.....	3-82
Strut Assembly Check.....	3-82
Stabilizer Bar, Bushing and/or Joint Check...	3-82
Suspension Knuckle Check.....	3-83
Control Rod Check.....	3-83
Trailing Rod Check.....	3-84
Suspension Frame, Bushing and Pad Check.....	3-84
Rear Suspension Fasteners.....	3-84
Wheel Disc, Nut and Bearing Check.....	3-84
On-vehicle Service.....	3-85
Rear Strut Assembly.....	3-85
Stabilizer Bar and/or Bushings.....	3-89
Control Rod.....	3-91
Trailing Rod.....	3-93
Suspension Frame.....	3-94
Wheel Hub, Wheel Bearing and Wheel Stud.....	3-96
Knuckle.....	3-98
Tightening Torque Specifications.....	3-101
Required Service Material.....	3-101
Special Tool.....	3-102

REAR SUSPENSION (4WD VEHICLE)	3-103
General Description	3-104
Construction.....	3-104
On-vehicle Service	3-105
Rear Suspension Frame.....	3-105
Wheel Hub, Wheel Stud/Wheel Bearing Outside Inner Race.....	3-107
Knuckle, Wheel Bearing/Oil Seal.....	3-109
Tightening Torque Specifications.....	3-110
Required Service Material.....	3-111
Special Tool	3-111
 WHEELS AND TIRES	 3-112
General Description	3-112
Tires.....	3-112
Tire placard.....	3-112
Inflation of tires.....	3-112
Matched tires and wheels (steel type)	3-113
Replacement tires.....	3-113
Wheels.....	3-114
Wheel maintenance.....	3-114
Replacement wheels.....	3-114
How to measure wheel runout.....	3-114
Metric lug nuts and wheel studs.....	3-114
Specifications	3-115
Diagnosis	3-115
Diagnosis Table.....	3-115
Irregular and/or Premature Wear.....	3-115
Wear Indicators.....	3-116
Radial Tire Waddle.....	3-116
Radial Tire Lead/Pull.....	3-117
Balancing Wheels.....	3-117
General Balance Procedures.....	3-118
On-Vehicle Service	3-119
Wheel.....	3-119
Tire.....	3-120

STEERING, SUSPENSION, WHEELS AND TIRES

Diagnosis

General Diagnosis

Since the problems in steering, suspension, wheels and tires involve several systems, they must all be considered when diagnosing a complaint. To avoid using the wrong symptom, always road test the vehicle first. Proceed with the following preliminary inspection and correct any defects which are found.


- 1) Inspect tires for proper pressure and uneven wear.
- 2) Raise vehicle on a hoist and inspect front and rear suspension and steering system for loose or damaged parts.
- 3) Spin front wheels. Inspect for out-of-round tires, out-of-balance tires, bent rims, loosen and/or rough wheel bearings.

Diagnosis Table

Condition	Possible Cause	Correction
Vehicle Pulls (Leads)	Mismatched or uneven tires	Replace tire.
	Tires not adequately inflated	Adjust tire pressure.
	Broken or sagging springs	Replace spring.
	Radial tire lateral force	Replace tire.
	Disturbed wheel alignment	Check and adjust wheel alignment.
	Brake dragging in one road wheel	Repair brake.
	Loose, bent or broken front or rear suspension parts	Tighten or replace suspension parts.
Abnormal or Excessive Tire Wear	Sagging or broken spring	Replace spring.
	Tire out of balance	Adjust balance or replace tire.
	Disturbed wheel alignment	Check and adjust wheel alignment.
	Faulty strut (shock absorber)	Replace strut.
	Hard driving	Replace tire.
	Overloaded vehicle	Replace tire.
	Not rotating tire	Replace or rotate tire.
	Worn or loose wheel bearing	Replace wheel bearing.
	Wobbly wheel or tire	Replace wheel or tire.
	Tires not adequately inflated	Adjust tire pressure.
Wheel Tramp	Blister or bump on tire	Replace tire.
	Improper strut (shock absorber) action	Replace strut.
Shimmy, Shake or Vibration	Tire or wheel out of balance	Balance wheels or replace tire and/or wheel.
	Loosen wheel bearings	Replace wheel bearing.
	Worn tie rod ends	Replace tie rod end.
	Worn lower ball joints	Replace front suspension arm.
	Excessive wheel runout	Repair or replace wheel and/or tire.
	Blister or bump on tire	Replace tire.
	Excessively loaded radial runout of tire/wheel assembly	Replace tire or wheel.
	Disturbed wheel alignment	Check and adjust wheel alignment.
	Loose or worn steering linkage	Tighten or replace steering linkage.
	Loose steering gear case bolts	Tighten case bolts.

Condition	Possible Cause	Correction
Hard Steering	Tire not adequately inflated	Inflate tires to proper pressure.
	Malfunction of power steering system	Check and correct.
	Bind in tie rod end ball studs or lower ball joints	Replace tie rod end or front suspension arm.
	Disturbed front wheel alignment	Check and adjust front wheel alignment.
	Rack and pinion adjustment	Check and adjust rack and pinion torque.
	Bind in steering column	Repair or replace.
Too Much Play in Steering	Wheel bearings worn	Replace.
	Loose steering gear case bolts	Tighten.
	Rack and pinion adjustments	Check and adjust rack and pinion torque.
	Worn steering shaft joints	Replace joint.
	Worn tie rod ends or tie rod inside ball joints	Replace tie rod end or tie rod.
	Worn lower ball joints	Replace front suspension control arm.
Poor Returnability	Bind in tie rod end ball studs	Replace tie rod end.
	Bind in ball joints	Replace.
	Bind in steering column	Repair or replace.
	Poorly lubricated rack and pinion	Check, repair or lubricate rack and pinion.
	Disturbed front wheel alignment	Check and adjust front wheel alignment.
	Rack and pinion adjustment	Check and adjust rack and pinion torque.
	Tires not adequately inflated	Adjust tire pressure.
Rack and Pinion Noise (Rattle or Chuckle)	Loose steering gear case bolts	Tighten.
	Worn rack bush	Replace.
	Rack and pinion adjustment	Check and adjust rack and pinion torque.
Abnormal Noise, Front End	Worn, sticky or loose tie rod ends, lower ball joints, tie rod inside ball joints or drive shaft joints	Replace tie rod end, suspension arm, tie rod or drive shaft joint.
	Damaged struts or mountings	Repair or replace.
	Worn suspension arm bushings	Replace.
	Loose stabilizer bar	Tighten bolts or nuts, replace bushes.
	Loose wheel nuts	Tighten wheel nuts.
	Loose suspension bolts or nuts	Tighten suspension bolts or nuts.
	Broken or otherwise damaged wheel bearings	Replace.
	Broken suspension springs	Replace.
	Poorly lubricated or worn strut bearings	Replace strut bearing.

Condition	Possible Cause	Correction
Wander or Poor Steering Stability	Mismatched or uneven tires	Replace or inflate tires to proper pressure.
	Loosen ball joints and tie rod ends	Replace suspension arm or tie rod end.
	Faulty struts or mountings	Replace strut or repair mounting.
	Loose stabilizer bar	Tighten or replace stabilizer bar or bush.
	Broken or sagging springs	Replace spring.
	Rack and pinion adjustment	Check and adjust rack and pinion torque.
	Disturbed wheel alignment	Check and adjust wheel alignment.
Erratic Steering When Braking	Worn wheel bearings	Replace.
	Broken or sagging springs	Replace coil spring.
	Wheel tires are inflated unequally	Inflate tires to proper pressure.
	Disturbed wheel alignment	Check and adjust wheel alignment.
	Brakes not working in unison	Check and adjustment brake system.
	Leaking wheel cylinder or caliper	Repair or replace wheel cylinder or caliper.
	Warped discs	Replace brake disc.
	Badly worn brake linings	Replace brake shoe lining.
	Drum is out of round in some brakes	Replace brake drum.
	Defective wheel cylinders	Replace or repair wheel cylinder.
Low or Uneven Trim Height NOTE: See NOTE *1.	Broken or sagging springs	Replace.
	Over loaded	Check loading.
	Incorrect springs	Replace.
	Tires not adequately inflated	Adjust tire pressure.
Ride Too Soft	Faulty struts (shock absorber)	Replace strut.
Suspension Bottoms	Overloaded	Check loading.
	Faulty struts (shock absorber)	Replace strut.
	Incorrect, broken or sagging springs	Replace.
Body Leans or Sways in Corners	Loose stabilizer bar	Tighten stabilizer bar bolts or nuts, or replace bushes.
	Faulty struts (shock absorbers) or mountings	Replace strut or tighten mounting.
	Broken or sagging springs	Replace.
	Overloaded	Check loading.
Cupped Tires	Front struts defective	Replace.
	Worn wheel bearings	Replace.
	Excessive tire or wheel run-out	Replace tire or wheel disc.
	Worn ball joints	Replace front suspension arm.
	Tire out of balance	Adjust tire balance.




NOTE:

***1: Right-to-left trim height ("H") difference should be within 15 mm (0.6 in.) with curb weight. (same with rear side.)**

WHEEL ALIGNMENT

Specifications



Wheel alignment specifications

Item		Front	Rear
Toe ("B" – "A") (total)		0 ± 2 mm (0 ± 0.079 in.)	IN 2.6 ± 2 mm (0.1 ± 0.079 in.)
Camber "C" (Non adjustable, for reference only)	2(4)WD Vehicle	0° 10' ± 1°	0° 36' ± 1°
Caster (Non adjustable, for reference only)	2(4)WD Vehicle	2° 11' ± 2°	–
Kingpin Inclina- tion	2(4)WD Vehicle	12° 52' ± 3°	–
Side Slip Limit mm/m (in./3.3 ft)	2(4)WD Vehicle	IN 2 to OUT 1 (IN 0.079 to OUT 0.039)	IN 1.0 to IN 4.0 (IN 0.0394 to IN 0.157)
Steering angle (Turning angle)	Inside	37.5° ± 3°	–
	Outside	32.5° ± 3°	–

NOTE:

Toe value given above was measured by using a toe-in gauge.

[A]: Toe-in (Top view)	1. Center line of wheel	*2. Body center
[B]: Camber (Front view)	*1. Forward	

On-Vehicle Service

Front Wheel Alignment

Among factors for front wheel alignment, only tow setting can be adjusted.

Camber and caster can't be adjusted. Therefore, should camber or caster be out of specification due to the damage caused by hazardous road conditions or collision, whether the damage is in body or in suspension should be determined and damaged body should be repaired or damaged suspension should be replaced.

Preliminary checks prior to adjustment front wheel alignment

Steering and vibration complaints are not always the result of improper alignment. An additional item to be checked is the possibility of tire lead due to worn or improperly manufactured tires. "Lead" is the vehicle deviation from a straight path on a level road without hand pressure on the steering wheel. Refer to Radial Tire Lead/Pull in this section in order to determine if the vehicle has a tire lead problem. Before making any adjustment affecting wheel alignment, the following checks and inspections should be made to ensure correctness of alignment readings and alignment adjustments:

- Check all tires for proper inflation pressures and approximately the same tread wear.
- Check for loose of ball joints. Check tie rod ends; if excessive looseness is noted, it must be corrected before adjusting.
- Check for run-out of wheels and tires.
- Check vehicle trim heights; if out of limits and a correction is to be made, it must be made before adjusting toe.
- Check for loose of suspension arms.
- Check for loose or missing stabilizer bar attachments.
- Consideration must be given to excess loads, such as tool boxes. If this excess load is normally carried in vehicle, it should remain in vehicle during alignment checks.
- Consider condition of equipment being used to check alignment and follow manufacturer's instructions.
- Regardless of equipment used to check alignment, vehicle must be on a level surface both fore and aft and transversely.

NOTE:

To prevent possible incorrect reading of camber of caster, vehicle front (or rear) end must be moved up and down a few times before inspection.

Toe inspection and adjustment

Preparation for toe inspection and adjustment.

- Place vehicle in non-loaded state on level floor.
- Set steering wheel in straight state.
- Check that inflation pressure of each tire is adjusted properly and disc wheel is free from deflection.
- Check that each suspension part is free from bend, dent, wear or damage in any other form.
- Check that ground clearance at the right and left is just about the same.

INSPECTION


Measure toe with toe-in gauge (1).

Toe should be within following specifications.

Toe:

$0 \pm 2 \text{ mm}$ ($0 \pm 0.079 \text{ in.}$)

If toe-in is out of above corresponding specification, adjust tow properly.



ADJUSTMENT

- 1) Loosen right and left tie rod end lock nuts (1) first.
- 2) Rotate right and left tie rods (2) by the same amount to align toe-in to specification. In this adjustment, right and left tie rods (2) should become equal in length "A".

NOTE:

Before rotating tie rods (2), apply grease between tie rods and rack boots so that boots won't be twisted.


- 3) After adjustment, tighten lock nuts (1) to specified torque.


Tightening torque

Tie rod end lock nuts (a) : 45 N·m (4.5 kg-m, 32.5 lb-ft)

NOTE:

Make sure that rack boots are not twisted.





Steering angle check and adjustment

When tie rod or tie rod end was replaced, check toe and then also steering angle with turning radius gauge (1).

If steering angle is not correct, check if right and left tie rods are equal in length "A".

NOTE:

If tie rod lengths were changed to adjust steering angle, reinspect toe-in.

Steering angle

Inside : $37.5^\circ \pm 3^\circ$

Outside : $32.5^\circ \pm 3^\circ$

Reference information

SIDE SLIP

When checked with side slip tester, side slip should satisfy following specification.

Side slip limit

IN : 2 mm/m (0.079 in/3.3 ft)

OUT : 1 mm/m (0.039 in/3.3 ft)

If side slip exceeds above limit, toe or front wheel alignment may not be correct.

Rear Wheel Alignment

Among factors for rear wheel alignment, only toe setting can be adjusted.

Camber and caster can't be adjusted. Therefore, should camber or caster be out of specification due to the damage caused by hazardous road conditions or collision, whether the damage is in body or in suspension should be determined and damaged body should be repaired or damaged suspension should be replaced.

Toe inspection and adjustment

Preparation for toe inspection and adjustment.

- Place vehicle in non-loaded state on level floor.
- Set steering wheel in straight state.
- Check that inflation pressure of each tire is adjusted properly and disc wheel is free from deflection.
- Check that each suspension part is free from bend, dent, wear or damage in any other form.
- Check that ground clearance at the right and left is just about the same.

INSPECTION


Measure toe with toe-in gauge (1).

Toe should be within following specifications.

Toe:

$2.6 \pm 2 \text{ mm}$ ($0.1 \pm 0.079 \text{ in.}$)

If toe-in is out of above corresponding specification, adjust toe properly.




ADJUSTMENT

- 1) Loosen right and left control rod inner nuts (1).
- 2) Adjust toe to satisfy specification by turning right and left control rod inner bolts (cam bolts) (2) by the same amount.
- 3) After adjustment, tighten right and left nuts to specified torque while holding cam bolt with another wrench to prevent it from turning.

Tightening torque

(a) : $90 \text{ N}\cdot\text{m}$ ($9.0 \text{ kg}\cdot\text{m}$, $65.0 \text{ lb}\cdot\text{ft}$)



3. Control rod

Reference information

SIDE SLIP LIMIT

When checked with side slip tester, side slip should satisfy following specification.

Side slip limit

IN : $2.5 \pm 1.5 \text{ mm/m}$ ($0.098 \pm 0.059 \text{ in/3.3 ft}$)

If side slip exceeds above limit, toe-in or front wheel alignment may not be correct.

POWER STEERING (P/S) SYSTEM

WARNING:

For vehicles equipped with Supplemental Restraint (Air Bag) System:

- Service on and around the air bag system components or wiring must be performed only by an authorized SUZUKI dealer. Refer to “Air Bag System Components and Wiring Location View” under “General Description” in air bag system section in order to confirm whether you are performing service on or near the air bag system components or wiring. Please observe all WARNINGS and “Service Precautions” under “On-Vehicle Service” in air bag system section before performing service on or around the air bag system components or wiring. Failure to follow WARNINGS could result in unintentional activation of the system or could render the system inoperative. Either of these two conditions may result in severe injury.
- Technical service work must be started at least 90 seconds after the ignition switch is turned to the “LOCK” position and the negative cable is disconnected from the battery. Otherwise, the system may be activated by reserve energy in the Sensing and Diagnostic Module (SDM).

NOTE:

- Some parts in the Power Steering Gear Box cannot be disassembled or adjusted. For detailed information, refer to the description of POWER STEERING GEAR BOX under ON-VEHICLE SERVICE.
- All steering gear fasteners are important attaching parts in that they could affect the performance of vital parts and systems, and/or could result in major repair expense. They must be replaced with one of the same part number or with an equivalent part if replacement becomes necessary. Do not use a replacement part of lesser quality or substitute design. Torque values must be used as specified during reassembly to assure proper retention of these parts.
- Although the figures in this section show only the left-hand steering vehicle, the same work procedure and data apply to the right-hand steering vehicle.


General Description

P/S System Description


The power steering (P/S) system in this vehicle reduces the driver's effort needed in turning the steering wheel by utilizing the hydraulic pressure generated by the power steering (P/S) pump which is driven by the engine. It is an integral type with the rack and pinion gears and the control valve unit, hydraulic pressure cylinder unit all built in the steering gear box.

The pump is a vane type and is driven by the V-ribbed belt from the crankshaft.

[A]



[B]



[A] : For left-hand steering vehicle

1. Power steering gear box

3. Oil reservoir

[B] : For right-hand steering vehicle

2. Power steering pump

Specifications

Specification and Service Data

Item		Specification	
Hydraulic pressure Control	Relieved pressure	8,400 kPa (84 kg/cm ² or 1,195 psi)	
	Control device	Flow control valve	
		Relief valve	
Power steering pressure switch		Switch turns on (closes) when the pressure is higher than 3,000 – 3,800 kPa (30 – 38 kg/cm ² , 427 – 540 psi). ECM uses this signal for idle speed control.	
Specified fluid		An equivalent of DEXRON-III, DEXRONR-II E or DEXRONR-II	
Fluid capacity of system	LH steering	about 0,86 liters (1.8/1.5 US/Imp pt.)	
	RH steering	about 0,78 liters (1.6/1.3 US/Imp pt.)	
	CAUTION:		
	The value given above is rough amount of fluid in entire system. Fluid level should be in between “LOWER” and “UPPER” level marks on fluid reservoir, which means that appropriate amount of fluid is in it. (For details, refer to “STEERING FLUID LEVEL CHECK” in this section.)		
Steering Wheel Play		0 – 30 mm (0 – 1.2 in.)	
Steering force		Less than 40 N (4.0 kg, 8.8 lb) (Refer to “STEERING FORCE CHECK” of this Section for procedure of force check.)	
P/S belt tension		5.5 – 8.5 mm (0.22 – 0.33 in.) deflection for vehicle with A/C or 4 – 9 mm (0.16 – 0.35 in.) deflection for vehicle without A/C under 100 N (10 kg, 22 lb) pressure	

Diagnosis

Diagnosis Table

Condition	Possible Cause	Correction
Steering wheel feels heavy (at low speed)	Fluid deteriorated, low viscosity, different type of fluid mixed	Replace fluid.
	Pipes or hoses deformed, air entering through joint	Replace defective part.
	Insufficient air purging from P/S circuit	Purge air.
	P/S belt worn, lacking in tension	Adjust belt tension or replace belt as necessary.
	Tire inflation pressure excessively low	Inflate tire.
	Front wheel alignment out of order	Check and adjust front wheel alignment.
	Steering wheel installed improperly (twisted)	Install steering wheel correctly.
	Bind tie rod end ball joint or lower ball joint	Replace defective part.
	P /S pump hydraulic pressure fails to increase	Check pressure and repair or replace defective part.
	P/S pump hydraulic pressure increases but slowly	Check pressure and repair or replace defective part.
	Steering gear box malfunction	Replace gear box.
Steering wheel feels heavy momentarily when turning it to the left or right	Air drawn in due to insufficient amount of fluid	Add fluid and purge air.
	Slipping P/S belt	Adjust belt tension or replace belt as necessary.
	P/S pump hydraulic pressure fails to increase	Check pressure and repair or replace defective part.
	P/S pump hydraulic pressure increases but slowly	Check pressure and repair or replace defective part.
	Steering gear box malfunction	Replace gear box.
Poor recovery from turns (See NOTE.)	Deformed pipes or hoses	Replace defective part.
	Steering column installed improperly	Install steering column correctly.
	Front wheel alignment out of order	Check and adjust front wheel alignment.
	Ball joints binding	Replace defective part.
	P/S pump hydraulic pressure fails to increase	Check pressure and repair or replace defective part.
	P/S pump hydraulic pressure increases but slowly	Check pressure and repair or replace defective part.
	Steering gear box malfunction	Replace gear box.

NOTE:


To check steering wheel for recovery, with vehicle running at 22 mile/h (35 km/h), turn steering wheel 90° and let it free. It should return more than 60°.

Condition	Possible Cause	Correction
Vehicle pulls to one side during straight driving	Mismatched or uneven tire	Replace tire.
	Low or uneven tire inflation pressure	Inflate tires to proper pressure or adjust right & left tires inflation pressure.
	Brake dragging in one wheel	Repair.
	Front wheel alignment out of order	Check and adjust front wheel alignment.
	Rear wheel alignment out of order	Check and adjust rear wheel alignment.
	Malfunction of control valve in gear box	Replace gear box.
Steering wheel play is large and vehicle wanders	Refer to "Diagnosis Table" in "STEERING, SUSPENSION, WHEELS AND TIRES".	Refer to "Diagnosis Table" in "STEERING, SUSPENSION, WHEELS AND TIRES".
Fluid leakage	Loose joints of (hydraulic pressure) pipes and hoses	Retighten.
	Deformed or damaged pipes or hoses	Replace defective part.
Abnormal noise	Air drawn in due to insufficient amount of fluid	Add fluid and purge air.
	Air mixed into fluid from pipes or hoses	Replace pipes or hoses.
	Slipping (loose) P/S belt	Adjust belt tension.
	Worn P/S belt	Replace belt.
	Loose gear box fastening bolt	Retighten bolts.
	Loose linkage or joints	Retighten.
	Pipes or hoses in contact with part of vehicle body	Install pipes and hoses correctly.
	Vanes of P/S pump defective	Replace defective part.
	Malfunction of control valve in gear box	Replace gear box.
	Bearing of P/S pump shaft defective	Replace bearing.

Steering Wheel Play Check

Check steering wheel for looseness or rattle by trying to move it in its shaft direction and lateral direction.

If found defective, repair or replace.



Check steering wheel for play, holding vehicle in straight forward condition on the ground and with engine stopped.

Steering wheel play



"a": 0 – 30 mm (0 – 1.2 in.)

If steering wheel play is not within specification, inspect as follows and replace if found defective.

- Tie-rod end ball stud for wear
- Lower ball joint for wear
- Steering shaft joint for wear
- Steering pinion or rack gear for wear or breakage
- Each part for looseness

Steering Force Check

- 1) Place vehicle on level road and set steering wheel at straight-ahead position.
- 2) Check that tire inflation pressure is as specified. Refer to tire placard.
- 3) Start engine and keep it running till power steering fluid is warmed to 50 – 60°C (122 – 140°F).



- 4) With engine idling, measure steering force by pulling spring balancer hooked on steering wheel in tangential direction.

Steering force


Less than 40 N (4.0 kg, 8.8 lb)

Power Steering Fluid Level Check

With engine stopped, check fluid level indicated on P/S fluid reservoir, which should be between “UPPER” and “LOWER” marks. If it is lower than “LOWER” mark, fill fluid up to “UPPER” mark.


NOTE:

- Be sure to use an specified power steering fluid.
- Fluid level should be checked when fluid is cool.



Power Steering Belt Check

- 1) Remove engine under cover of right side from vehicle body.
 - 2) Check belt for cracks, cuts, deformation, wear and cleanliness.
- If any of above condition are found, replace power steering belt.



- 3) Check belt tension by measuring how much it deflects when pushed at intermediate point of P/S belt with about 10 kg (22 lb) force and adjust it if necessary.

Deflection of P/S belt

“a”: 5.5 – 8.5 mm (0.22 – 0.33 in.)

“b”: 4 – 9 mm (0.16 – 0.35 in.)

[A]:	For vehicle equipped with A/C
[B]:	For vehicle not equipped with A/C
1.	P/S pump pulley
2.	A/C compressor pulley
3.	Crankshaft pulley
4.	Tension pulley

Power Steering Belt Tension Adjustment

- 1) Remove engine under cover of right side and loosen tension pulley bolt (3).
- 2) To adjust P/S belt (5), loosen tension pulley nut (4) and turn tension pulley (1) counterclockwise or clockwise by using special tool (A).

Special tool


(A): 09945-35410

- 3) Adjust belt tension to above specification.
Then tighten tension pulley bolt and nut to specified torque.

Tightening torque

Tension pulley bolt and nut

(a) : 25 N·m (2.5 kg·m, 18.5 lb·ft)



a. Tight	6. P/S pump pulley
b. Loose	7. Crankshaft pulley
2. Tension pulley hole	

Idle Up System Check

- 1) Warm up engine to normal operating temperature.
- 2) Turn A/C switch OFF, if equipped.
- 3) Turn steering wheel fully and check idle speed. Engine idle speed drops a little momentarily when steering wheel is turned fully but returns to its specified level immediately. If power steering pressure switch connector is connected, check the same with that connector disconnected. Momentary drop of engine idle speed should be less when it is connected than when disconnected.


Fluid Leakage Check

Start engine and turn steering wheel fully to the right and left so that maximum hydraulic pressure is provided. Then visually check gear box, P/S pump and P/S fluid reservoir themselves and each joint of their connecting pipes for leakage.


CAUTION:

Never keep steering wheel turned fully for longer than 10 seconds.

[A]




[B]



[A] : Left-Hand Steering Vehicle

[B] : Right-Hand Steering Vehicle

Hydraulic Pressure in P/S Circuit Check




- 1) After cleaning joint of high pressure hose and P/S pump thoroughly, disconnect hose from pump and install special tool (oil pressure gauge, attachment and hose).
Tighten each flare nut to specified torque.

Special tool


- (A): 09915-77410 (Oil pressure gauge)
(B): 09915-77420 (Attachment & hose)

1. P/S fluid reservoir	4. P/S gear box
2. Gauge valve (open)	5. High pressure side
3. P/S pump	6. Low pressure side

- 2) Check each connection for fluid leakage and bleed air. Refer to “AIR BLEEDING PROCEDURE” in this section.



- 3) With engine idling, turn steering wheel and warm up engine till temperature of fluid in tank rises to 50 – 60°C (122 – 140°F).




- 4) Check back pressure by measuring hydraulic pressure with engine idling and hands off steering wheel.

Back pressure: Lower than 1000 kPa (10 kg/cm², 142 psi)

When back pressure is higher than specified values, check control valve and piping for clogging.

1. P/S fluid reservoir	4. P/S gear box
2. Gauge valve (open)	5. High pressure side
3. P/S pump	6. Low pressure side



5) Check relief pressure.

- Increase engine speed to about 1,500 r/min (rpm). Close gauge valve (2) gradually while watching pressure increase indicated by gauge and take reading of relief pressure (maximum hydraulic pressure).

Relief pressure


: 8200 – 8900 kPa (82 – 89 kg/cm², 1166 – 1265 psi)

- When it is higher than specified values, possible cause is malfunction of relief valve.
- When it is lower than specified values, possible cause is either failure of P/S pump (4) or setting of relief valve spring.

CAUTION:

Be sure not to close gauge valve for longer than 10 seconds.

- | |
|------------------------|
| 1. P/S fluid reservoir |
| 3. Oil pressure gauge |
| 5. P/S gear box |



- Next, open gauge valve (2) fully and increase engine speed to about 1,500 r/min. Then turn steering wheel to the left or right fully and take reading of relief pressure.

Relief pressure

: 8200 – 8900 kPa (82 – 89 kg/cm², 1166 – 1265 psi)


- When it is higher than specified values, possible cause is malfunction of relief valve.
- When it is lower than specified values, possible cause is failure in steering gear box (5). Replace gear box.

CAUTION:

Be sure not to hold steering wheel at fully turned position for longer than 10 seconds.


- | |
|------------------------|
| 1. P/S fluid reservoir |
| 3. Oil pressure gauge |
| 4. P/S pump |

Steering Rack Boot Check




Check boot for crack and damage which, if any, means possibility of rusty gear, entry of dust or lack of grease. Also, check if any of such faulty conditions exists.

Tie Rod End Boot Check



Check boot for crack and damage and if any, replace it with a new one.

Steering Shaft Joint Check



Check each shaft joint for wear, breakage and any other damage and if any, replace it with a new one.

Air Bleeding Procedure

- 1) Jack up the front end of vehicle and apply safety stands.
- 2) Fill P/S fluid reservoir with fluid up to specified level.

NOTE:

Before starting engine, place transmission gear shift lever in “Neutral” (shift selector lever to “P” range for A/T model), and set parking brake.

- 3) After running engine at idling speed for 3 to 5 seconds, stop it and add fluid to satisfy specification.
- 4) With engine stopped, turn steering wheel to the right and left as far as it stops, repeat it a few times and fill fluid to specified level.
- 5) With engine running at idling speed, repeat stop-to-stop turn of steering wheel till all foams in P/S fluid reservoir are gone.

NOTE:

Make sure to bleed air completely. If air remains in fluid, P/S pump may make humming noise or steering wheel may feel heavy.


- 6) Finally check to make sure that fluid is filled to specified level.

On-vehicle Service

Power Steering Belt

REMOVAL

- 1) Disconnect negative cable at battery.
- 2) Remove engine under cover of right side and loosen tension pulley bolt (1) and nut (2).
- 3) Remove power steering belt.




INSPECTION

- Check power steering belt for wear and cracks, and replace as required.

INSTALLATION


- 1) Install belt to power steering pump pulley (1), crankshaft pulley (2), A/C pulley (if equipped) (3) and tension pulley (4).
- 2) Adjust belt tension by referring to "POWER STEERING BELT TENSION ADJUSTMENT" in this section.




Tie Rod End

REMOVAL


- 1) Hoist vehicle and remove wheel.
- 2) Remove split pin (1) and tie rod end castle nut (2).





3) Using special tool, remove tie rod end from knuckle.


Special tool
(A): 09913-65210



4) To facilitate adjustment after installation, put a mark (2) on tie rod thread indicating position of tie rod end lock nut (3). Then loosen lock nut and remove tie rod end (4) from tie rod (1).


INSPECTOIN

Tie-rod end ball joint



Inspect for play in tie-rod end ball joint (1). If found defective, replace.

INSTALLATION




- 1) Install tie rod end lock nut (3) and tie rod end (4) to tie rod (1). Tighten lock nut to mark (2) on tie rod thread.
- 2) Install tie rod end to knuckle (5). Tighten castle nut (6) till holes for split pin (7) are aligned but within specified torque range.


Tightening torque

Tie rod end castle nut

(a) : 35 – 55 N·m (3.5 – 5.5 kg-m, 25.5 – 39.5 lb-ft)



- 3) Bend new split pin (7) as shown in figure.




- 4) After installing wheels, lower vehicle and tighten wheel nuts to specified torque.

Tightening torque

Wheel nuts (a) : 85 N·m (8.5 kg-m, 61.5 lb-ft)

- 5) Check that proper amount of toe-in is obtained. Refer to "FRONT WHEEL ALIGNMENT" in this section.




- 6) After confirming proper amount of toe-in, tighten tie rod end lock nut to specified torque.



Tightening torque

Tie rod end lock nut (b) : 45 N·m (4.5 kg-m, 32.5 lb-ft)

Power Steering Gear Box

POWER STEERING GEAR BOX COMPONENTS




1. Blank	8. Mount bracket	14. Boot
2. Steering rack side mount	9. Pinion side boot	15. Clip
3. Gasket	10. Rack side boot	16. Tie rod
4. Cylinder pipe "A"	11. Pinion side boot wire	17. Split pin
5. Cylinder pipe "B"	11-1. Rack side boot wire	 Tightening torque
6. High pressure pipe	12. Boot clip	 Do not reuse.
7. Low pressure return hose	13. Steering tie rod end	

NOTE:

Component enclosed in broken line cannot be disassembled and adjusted.


REMOVAL

- 1) Take out fluid in P/S fluid reservoir with syringe or such.
- 2) After removing joint cover, loosen steering shaft upper joint bolt (1) (but it must not be removed) and remove lower joint bolt (2).

**CAUTION:**

Be sure to set front wheels (tires) in straight direction and remove ignition key from key cylinder before the following steps, otherwise contact coil of airbag system may get damaged.


- 3) With front wheels in straight-ahead position, separate pinion and lower joint.
- 4) Hoist vehicle and remove both right and left front wheels.
- 5) Remove split pin (3) and then remove tie rod castle nut (2) from steering knuckle (1).




- 6) Using special tool, remove tie rod end (2) from knuckle (1).



Special tool

(A): 09913-65210



- 7) [2WD vehicle model]
 - a) Remove exhaust pipe No.2.
 - b) Remove engine rear mounting (1) together with its bracket (2) from engine and member, and remove engine mounting member (3).





- 8) [4WD vehicle model]
 - a) Remove exhaust No.1 and No.2 pipes.
 - b) Disconnect both right and left front suspension control arm ball stud and then using plastic hammer, drive out drive shaft so as to release snap ring fitting to joint spline at transfer right side.
 - c) Remove propeller shaft front joint bolts (1).
 - d) Remove engine rear mounting nuts (2) and then remove suspension frame (4) from body.
 - e) Remove right (5) and left (6) transfer stiffener and then remove transfer mounting bolts and draw out transfer assembly (3) from transaxle.

- 9) Remove cylinder pipes (3) and (4) from steering gear box, using flare nut wrench.

NOTE:

As fluid flows out of disconnected joints, put a receptacle under joints or a plug to pipe.

- 10) Disconnect high pressure pipe (1) and low pressure hose (2) from steering gear box, using flare nut wrench.

NOTE:

As fluid flows out of disconnected joints, have a container under joints or a plug to pipe.


- 11) Remove steering gear box mounting bolts and then remove steering gear box from vehicle.

INSTALLATION

Reverse removal procedure for installation of steering gear box noting the following points.

CAUTION:

Be sure to confirm that steering wheel and front tires (wheels) are in straight position when inserting steering lower joint into steering pinion shaft.



- If a plug was put to disconnected pipe when removing steering gear box, remove that plug before reconnecting pipe.

- Use specified torque as given below.

Tightening torque

Gear box mounting bolts

(a) : 55 N·m (5.5 kg-m, 40.0 lb-ft)

Gear box cylinder pipe flare nuts

(b) : 25 N·m (2.5 kg-m, 18.0 lb-ft)

Gear box high and low pressure pipe flare nuts

(c) : 35 N·m (3.5 kg-m, 25.0 lb-ft)

Castle nuts

(d) : 35 – 55 N·m (3.5 – 5.5 kg-m, 25.5 – 39.5 lb-ft)

Steering shaft upper and lower joint bolts

(e) : 25 N·m (2.5 kg-m, 18.0 lb-ft)

- For installing each part, refer to respective section as indicated below.


Model	Part	Section
2WD	Exhaust pipe No.2	Section 6K
	Mounting member	Section 3
	Engine rear mounting bracket	Section 3
4WD	Drive shaft	Section 4
	Exhaust No.1 and No.2 pipe	Section 6K
	Suspension control arm ball stud	Section 3
	Engine rear mounting nut	Section 3
	Suspension frame	Section 3
	Transfer stiffener	Section 7D
	Transfer assembly	Section 7D


- After installation, be sure to fill specified power steering fluid and bleed air.
- Check toe setting. Adjust as required. Refer to “FRONT WHEEL ALIGNMENT” in this section.

Tie Rod/Rack Boot

REMOVAL

- 1) Remove steering gear box from vehicle referring to “POWER STEERING GEAR BOX” in this section.
- 2) For ease of adjustment after installation, make marking (4) of tie rod end lock nut position of tie rod thread.
- 3) Loosen tie rod end lock nut (2) and remove tie rod end.
- 4) Remove boot wire and clip.
- 5) Remove boot (3) from tie rod (1).





- 6) Unbend bent parts (3 places) (1) of tie rod lock washer and remove tie rod (2) from rack (3).

4. Aluminum plate

5. Vise

INSTALLATION



- 1) Install new tie rod lock washer and tie rod to rack.
- 2) Tighten tie rod ball nut to specified torque.

Tightening torque

Tie rod ball nut

(a) : 70 N·m (7.0 kg·m, 50.5 lb·ft)

- 3) Bend lock washer at 3 places (1) as shown.



- 4) Position boot properly in grooves of gear case (2) and tie rod (4) and clamp it with wire (1) and clip (3).

Wire should be new and should go around twice and be tightened with its both ends twisted together. The twisted ends should be bent in the circumferential direction.

After this, check to ensure that boot is free from twist and dent.

"A": Apply Grease (99000-25050)


"B": Slightly apply Sealant (99000-31120) for resin.

- 5) Install tie rod end lock nut and tie rod end to tie rod. Position lock nut to marking (1) made in removal.

NOTE:


When tie rod was replaced, measure length "A" on removed tie rod and use it on new replacement tie rod so as to position lock nut properly.

- 6) Install steering gear box to vehicle referring to "POWER STEERING GEAR BOX" in this section.



Power Steering Pump

COMPONENTS



1. Power steering pump assembly	6. Low pressure return pipe	11. Belt tension pulley nut
2. Power steering fluid reservoir tank	7. Low pressure return hose & pipe (Gear box side)	12. Power steering belt
3. High pressure hoses & pipe	8. Bracket	Tightening torque
4. Suction hose	9. Belt tension pulley	Do not reuse.
5. Low pressure return hose (Reservoir side)	10. Belt tension pulley bolt	

REMOVAL

NOTE:

Be sure to clean each joint of suction and discharge sides thoroughly before removal.

- 1) Remove engine under cover of right side, loosen belt tension pulley and remove P/S belt.
- 2) Disconnect high pressure pipe and suction hose from pump.
As fluid flows out of disconnected joints, put a container under joints or a plug to hose.

CAUTION:

Take care not to cause damage to A/C condenser during service operation, if equipped.

- 3) Disconnect pressure switch lead harness and A/C wire harness.
- 4) Remove A/C compressor from bracket with A/C hose still attached (if equipped).

NOTE:

Hang removed A/C compressor with a wire hook or the like so as to prevent A/C hose from bending and twisting excessively or being pulled.

- 5) Remove oil pump from bracket.

NOTE:

Plug each port of removed pump to prevent dust or any other foreign matter from entering.

INSTALLATION


Reverse removal procedure.

NOTE:

- Fill specified power steering fluid after installation and bleed air without failure.
- For tightening torques, refer to components figure.
- Adjust power steering belt tension referring to “POWER STEERING BELT TENSION ADJUSTMENT” in this section.
- Bleed air from P/S system by referring to “AIR BLEEDING PROCEDURE” in this section.

DISASSEMBLY


- 1) Clean its exterior thoroughly.
- 2) With aluminum plates placed on vise first, grip pump body with it.



- 3) Remove suction connector bolt (1), suction connector (2) and O-ring (3) from pump body (4).
- 4) Remove power steering pressure switch (terminal set) (5) from pump body.
- 5) Remove plug (6), flow control spring (8) and relief valve (flow control valve) (9) from pump body.
- 6) Remove cover bolts (7), pump cover (10) and O-ring (17) from pump body.
- 7) Remove snap ring (12) from pump shaft.
- 8) Remove vanes (13) from rotor (14).
- 9) Remove cam ring (15), rotor (14), side plate (16) and O-rings (11) from pump body.
- 10) Pull out pulley (18) from pump body.
- 11) Remove oil seal (19) from pump body.


INSPECTION

Pump body, cover, side plate and shaft




Check sliding surfaces of each part for wear and damage. If any defect is found, replace pump assembly.

Cam ring




Check vane sliding surface of cam ring for wear and damage. If any defect is found, replace pump assembly.

Rotor and vane



- Check sliding surfaces of rotor and vane for wear and damage.



- Check clearance between rotor and vane.


Clearance:

Standard 0.01 mm (0.0004 in.)

Limit 0.06 mm (0.0023 in.)


Replace pump assembly if any defect is found in above checks.

1. Thickness gauge



Relief valve (flow control valve) and its spring

- Check fluid passage of relief valve and orifice of connector for obstruction (clogged).
- Check sliding surface of relief valve for wear and damage.



- Check free length of relief valve spring (1).

Free length:

Standard 22.0 mm (0.866 in.)

Limit 19.0 mm (0.748 in.)


Replace if any defective is found.


REASSEMBLY

Reverse disassembly procedure for assembly, noting the following.


- 1) Apply grease to oil seal lip (1). Apply power steering fluid to sliding surface of the shaft (2) and then insert shaft in the pump body.

“A”: Grease 99000-25010






- 2) Apply power steering fluid to O-rings (1) and fit them to pump body.



- 3) Install side plate (1) to pump body.

NOTE:


Carefully align the dowel pins on the side plate (1) at bolt hole (2) as shown in figure.




- 4) Apply power steering fluid to sliding surface of rotor (1).
 5) Install rotor to shaft, directing dot (3) marked side of rotor facing up.
 6) Install new snap ring (2) to shaft, then make sure to fit snap ring into shaft groove securely.

NOTE:


Never reuse the removed snap ring.




- 7) Apply power steering fluid to sliding surface of cam ring (1).
 8) Install cam ring to pump body. The tapered end of cam ring (1) should face the side plate (2).




- 9) Apply power steering fluid to each vane (2).
 10) Install vanes (12 pieces) (2) to rotor (1).



- 11) Apply power steering fluid to O-ring (1).
- 12) Install O-ring (1) to pump body.
- 13) Apply power steering fluid to sliding surface of pump cover and rotor.



- 14) Match the dowel pins (1) to the holes of the cover plate (2) as shown and install pump cover to pump body.




- 15) Gradually tighten pump cover bolts to specified torque.

NOTE:

After installing pump cover (1), check to make sure that shaft can be turned by hand.

Tightening torque

Pump cover bolts (a) : 28 N·m (2.8 kg-m, 20.0 lb-ft)




- 16) Apply power steering fluid to O-ring of terminal switch.
- 17) Install pressure switch (1) to pump body.

Tightening torque

Pressure switch (b) : 28 N·m (2.8 kg-m, 20.0 lb-ft)

- 18) Apply power steering fluid to relief valve (flow control valve).
- 19) Install relief valve (flow control valve) to pump body.
- 20) Install flow control spring.
- 21) Apply power steering fluid to O-rings of plug.
- 22) Install O-rings to plug.




23) Tighten plug (1) to specified torque.


Tightening torque

Plug (c) : 60 N·m (6.0 kg-m, 43.5 lb-ft)

24) Apply power steering fluid to O-ring of suction connector.



25) Install O-ring (2) to suction connector (1).



26) Install suction connector (1) to pump body as shown in figure. Tighten suction connector bolt to specified torque.


Tightening torque

Suction connector bolt

(d) : 12 N·m (1.2 kg-m, 8.5 lb-ft)

Tightening Torque Specification





Fastening part	Tightening torque		
	N•m	kg-m	lb-ft
Gear box mounting bolts (1)	55	5.5	40.0
Gear box cylinder pipe flare nuts (2)	25	2.5	18.0
Gear box high & low pressure pipe flare nuts (3)	35	3.5	25.0
Tie rod end lock nut (4)	45	4.5	32.5
Tie rod ball nut (5)	70	7.0	50.5
Steering shaft upper and lower joint bolts (6)	25	2.5	18.0
Tension pulley bolt and nut (7)	25	2.5	18.0
P/S pump mount bolts (8)	25	2.5	18.0
Pipe clamp bolt (9)	7	0.7	5.5
High pressure pipe mount bolt (Pipe to pump) (10)	55	5.5	40.0
Pump cover bolts (11)	28	2.8	20.0
Plug (12)	60	6.0	43.5
Pressure switch (Terminal) (13)	28	2.8	20.0
Suction connector bolt (14)	12	1.2	8.5
Tie rod end castle nut	35 – 55	3.5 – 5.5	25.5 – 39.5



Required Service Material

Material	Recommended SUZUKI product (Part Number)	Use
Lithium grease	SUPER GREASE (A) (99000-25010)	<ul style="list-style-type: none"> Oil seal lip of P/S pump pulley shaft
Lithium grease (Should be applicable for -40°C – 130°C)	SUPER GREASE (E) (99000-25050)	<ul style="list-style-type: none"> Sliding part of rack against steering housing Steering rack and pinion gear teeth Contacting parts of tie-rod and boot Rack end ball joint
Power steering fluid	Specified A/T fluid	<ul style="list-style-type: none"> To fill fluid reservoir Parts lubrication when installing
Sealant for resin	SILICONE SEALANT (99000-31120)	<ul style="list-style-type: none"> Between steering boot and housing (case)

Special Tool

 <p>09913-65210 Tie-rod end remover</p>	 <p>09915-77410 Oil pressure gauge</p>	 <p>09915-77420 Oil pressure gauge attachment and hose set</p>	 <p>09945-35410 Belt adjuster wrench (10 mm)</p>
--	---	--	---

STEERING WHEEL AND COLUMN

WARNING:

For vehicles equipped with Supplemental Restraint (Air Bag) System:

- Service on and around the air bag system components or wiring must be performed only by an authorized SUZUKI dealer. Please observe all WARNINGS and “Service Precautions” under “On-Vehicle Service” in air bag system section before performing service on or around the air bag system components or wiring. Failure to follow WARNINGS could result in unintentional activation of the system or could render the system inoperative. Either of these two conditions may result in severe injury.
- The procedures in this section must be followed in the order listed to temporarily disable the air bag system and prevent false diagnostic codes from setting. Failure to follow procedures could result in possible air bag system activation, personal injury or otherwise unneeded air bag system repairs.

CAUTION:

When fasteners are removed, always reinstall them at the same location from which they were removed. If a fastener needs to be replaced, use the correct part number fastener for that application. If the correct part number fastener is not available, a fastener of equal size and strength (or stronger) may be used. Fasteners that are not reused, and those requiring thread-locking compound, will be called out. The correct torque value must be used when installing fasteners that require it. If the above procedures are not followed, parts or system damage could result.

General Description

Steering Column

This double tube type steering column has following three important features in addition to the steering function :

- The column is energy absorbing, designed to compress in a front-end collision.
- The ignition switch and lock are mounted conveniently on this column.
- With the column mounted lock, the ignition and steering operations can be locked to inhibit theft of the vehicle.

To insure the energy absorbing action, it is important that only the specified screws, bolts, and nuts be used as designated and that they are tightened to the specified torque.

When the column assembly is removed from the vehicle, special care must be taken in handling it. Use of a steering wheel puller other than the one recommended in this manual or a sharp blow on the end of the steering shaft, leaning on the assembly, or dropping the assembly could shear the plastic shear pins which maintain column length and position.

Steering Wheel and Driver Air Bag (Inflator) Module

The driver air bag (inflator) module is one of the supplemental restraint (air bag) system components and is mounted to the center of the steering wheel. During certain frontal crashes, the air bag system supplements the restraint of the driver's seat belt by deploying the air bags.

The air bag (inflator) module should be handled with care to prevent accidental deployment. When servicing, be sure to observe all WARNINGS and CAUTIONS and "SERVICE PRECAUTIONS" under "ON-VEHICLE SERVICE" in Section 10B.

Diagnosis

For maintenance service of the steering wheel and column, refer to Section 0B.


For diagnosis of the steering wheel and column, refer to Section 3.




For diagnosis of the air bag system, refer to Section 10B.

Inspection and Repair Required after Accident

After an accident, whether the air bag has been deployed or not, be sure to perform checks, inspections and repairs described under "CHECKING STEERING COLUMN ASSEMBLY AND LOWER SHAFT FOR ACCIDENT DAMAGE" as well as "REPAIRS AND INSPECTIONS REQUIRED AFTER ACCIDENT" under "DIAGNOSIS" in Section 10B.

On-Vehicle Service



1. Driver air bag (inflator) module	7. Steering column assembly	 12. Upper and lower joint bolt : After tightening lower joint bolt, tighten upper joint bolt.
2. Steering wheel	8. Steering lock assembly (ignition switch)	 13. Steering column mounting nut : After tightening lower nut, tightening upper nut.
3. Steering wheel nut	9. Steering lower shaft	 Tightening torque
4. Contact coil and combination switch assembly	10. Steering joint cover	
5. Steering column upper cover	11. Immobilizer control module (if equipped)	
6. Steering column lower cover		

Service Precautions

For service precautions, refer to “SERVICE PRECAUTIONS” under “ON-VEHICLE SERVICE” in Section 10B.

Service and diagnosis

For diagnosis and servicing, refer to “SERVICE AND DIAGNOSIS” under “SERVICE PRECAUTIONS” in Section 10B.

Disabling air bag system

For disabling air bag system, refer to “DISABLING AIR BAG SYSTEM” under “SERVICE PRECAUTIONS” in Section 10B.

Enabling air bag system

For enabling air bag system, refer to “ENABLING AIR BAG SYSTEM” under “SERVICE PRECAUTIONS” in Section 10B.

Handling and storage

For handling and storage, refer to “HANDLING AND STORAGE” under “SERVICE PRECAUTIONS” in Section 10B.

Disposal



For disposal, refer to “DISPOSAL” under “SERVICE PRECAUTIONS” in Section 10B.

Driver Air Bag (Inflator) Module

WARNING:


When handling an air bag (inflator) module, be sure to read “SERVICE PRECAUTIONS” in Section 10B and observe each instruction. Failure to follow them could cause a damage to the air bag (inflator) module or result in personal injury.

REMOVAL



- 1) Disconnect negative cable at battery.
- 2) Disable air bag system. Refer to “DISABLING AIR BAG SYSTEM” under “SERVICE PRECAUTIONS” in Section 10B.
- 3) Loosen 2 bolts (1) mounting driver air bag (inflator) module completely.
- 4) Remove driver air bag (inflator) module (3) from steering wheel.
- 5) Disconnect yellow connector (1) in order a) – b) as shown in the figure.
- 6) Disconnect horn connector (2).


INSPECTION

**WARNING:**

Never disassemble driver air bag (inflator) module or measure its resistance. Otherwise, personal injury may result.

CAUTION:


If air bag (inflator) module was dropped from a height of 90 cm (3 ft) or more, it should be replaced.




Check air bag (inflator) module visually and if any of the following is found, replace it with a new one.

- Air bag being deployed
- Trim cover (pad surface) (1) being cracked
- Wire harness or connector (2) being damaged
- Air bag (inflator) module being damaged or having been exposed to strong impact (dropped)

INSTALLATION



- 1) Check that horn wire is connected to horn connector (2) securely.
- 2) Connect yellow connector (1) of driver air bag (inflator) module pushing connector till it is locked.



- 3) Install driver air bag (inflator) module to steering wheel, taking care so that no part of wire harness is caught between them.
- 4) Make sure that clearance between module and steering wheel is uniform all the way.
- 5) Tighten driver air bag (inflator) module mounting bolts (1) to specified torque.

Tightening torque**Driver air bag (inflator) module mounting bolt**

(a) : 9 N·m (0.9 kg-m, 6.5 lb-ft)


- 6) Connect negative cable at battery.
- 7) Enable air bag system. Refer to "ENABLING AIR BAG SYSTEM" under "SERVICE PRECAUTIONS" in Section 10B.

Steering Wheel


CAUTION:

Removal of the steering wheel allows the contact coil to turn freely but do not turn the contact coil (on the combination switch) more than allowable number of turns (about two and a quarter turns from the center position clockwise or counterclockwise respectively), or coil will break.

REMOVAL




- 1) Remove driver air bag (inflator) module from steering wheel. Refer to "DRIVER AIR BAG (INFLATOR) MODULE" in this section.



- 2) Remove steering shaft nut.
- 3) Make alignment marks (1) on steering wheel and shaft for a guide during reinstallation.

CAUTION:

Do not hammer the end of the shaft. Hammering it will loosen the plastic shear pins which maintain the column length and impair the collapsible design of the column.





- 4) Remove steering wheel (1) with special tool.

Special tool

(A) : 09944-36011

INSTALLATION



- 1) Check that vehicle's front tires are at straight-ahead position and contact coil is centered. Refer to "CENTERING CONTACT COIL" in this section.

CAUTION:

These two conditions are prerequisite for installation of steering wheel. If steering wheel has been installed without these conditions, contact coil will break when steering wheel is turned.

- 2) Install steering wheel (1) to steering shaft with 3 lugs (2) on contact coil fitted in three grooves (3) in the back of steering wheel and also aligning marks (4) on steering wheel and steering shaft.

- 3) Tighten steering shaft nut (1) to specified torque.

Tightening torque

Steering shaft nut (a) : 33 N·m (3.3 kg-m, 24.0 lb-ft)

NOTE:

After installing the steering wheel, turn the steering wheel about 1 full rotation so that the cancel cam pin fits into the pin hole in the steering wheel and then check the turn signal lever for proper function.


- 4) Install driver air bag (inflator) module to steering wheel. Refer to "DRIVER AIR BAG (INFLATOR) MODULE" in this section.


Centering Contact Coil

- 1) Check that vehicle's wheels (front tires) are set at straight-ahead position.
- 2) Check that ignition switch is at "LOCK" position.
- 3) Turn contact coil counterclockwise slowly with a light force till contact coil will not turn any further.

NOTE:

Contact coil can turn about 4 and a half turns at maximum, that is, if it is at the center position, can turn about two and a quarter turns both clockwise and counterclockwise.





- 4) From the position where contact coil became unable to turn any further (it stopped), turn it back clockwise about two and a quarter rotations and align center mark (1) with alignment mark.



Contact Coil and Combination Switch Assembly

CAUTION:


Do not turn contact coil (on combination switch) more than allowable number of turns (about two and a quarter turns from the center position clockwise or counterclockwise respectively), or coil will break.

REMOVAL


- 1) Remove steering wheel from steering column referring to "STEERING WHEEL" in this section.
- 2) Remove steering column hole cover (1).



- 3) Remove steering column cover screws (1).
- 4) Separate upper cover (2) and lower cover (3), then remove them.



- 5) Remove contact coil and combination switch assembly screws (1) and disconnect connectors (2) from combination switch (3).




- 6) Disconnect horn connector (1) from instrument panel harness.

- 7) Remove contact coil and combination switch assembly from steering column.


INSPECTION

Check contact coil harness (1) for any signs of scorching, melting or other damage.
If it is damaged, replace.



INSTALLATION


- 1) Check to make sure that vehicle's front tires are set at straight-ahead position and then ignition switch is at "LOCK" position.



- 2) Install contact coil and combination switch assembly (3) and then connect all connectors disconnected in REMOVAL.

NOTE:


New contact coil and combination switch assembly is supplied with contact coil set and held at its center position with a lock pin (1) and seal (2). Remove this lock pin after installing contact coil and combination switch assembly to steering column.



- 3) Install steering column upper cover (2) and lower cover (3), and then tighten steering column cover screws (1).

CAUTION:

When installing lower cover (3) and upper cover (2), be careful so that contact coil and combination switch lead wire is not caught between covers.



- 4) Install steering column hole cover (1).
5) Install steering wheel to steering column. Refer to "STEERING WHEEL" in this section.

Steering Column Assembly

CAUTION:

Once the steering column is removed from the vehicle, the column is extremely susceptible to damage.

- Dropping the column assembly on its end could collapse the steering shaft or loosen the plastic shear pins which maintain column length.
- Leaning on the column assembly could cause it to bend or deform.

Any of the above damage could impair the column's collapsible design.




NOTE:

When servicing steering column or any column-mounted component, remove steering wheel. But when removing steering column simply to gain access to instrument panel components, leave steering wheel installed on steering column.


REMOVAL

WARNING:


Never rest a steering column assembly on the steering wheel with the air bag (inflator) module face down and column vertical. Otherwise, personal injury may result.



- 1) Disconnect negative cable at battery.
- 2) Disable air bag system. Refer to "DISABLING AIR BAG SYSTEM" under "SERVICE PRECAUTIONS" in Section 10B.
- 3) If it is necessary to remove steering wheel and contact coil and combination switch assembly, remove them, referring to "STEERING WHEEL" and "CONTACT COIL AND COMBINATION SWITCH ASSEMBLY" in this section.
If it is not necessary to remove steering wheel and contact coil and combination switch assembly, perform the following procedure.
 - a) Turn steering wheel so that vehicle's front tires are at straight-ahead position.
 - b) Turn ignition switch to "LOCK" position and remove key.
- 4) Remove steering column hole cover (1).
- 5) Remove steering column cover screws (1).
- 6) Separate upper column cover (2) and lower column cover (3), then remove them.
- 7) Disconnect connectors (1) from combination switch assembly (2).




- 8) Disconnect ignition switch connectors (1) from ignition switch (2).




- 9) Using center punch (1), remove three mounting bolts (2) for immobilizer control module cover (if equipped).

NOTE:


Use care not to damage immobilizer control module and other parts with center punch.




- 10) Disconnect immobilizer controller connector (1) (if equipped).



- 11) Disconnect horn connector (1) from instrument panel harness.



- 12) Remove steering joint cover.
- 13) Make alignment marks (1) on joint (2) of steering column and steering lower shaft (3) for a guide during reinstallation.
- 14) Remove joint bolt (steering column side) (4).



- 15) Remove steering column mounting nuts ("A", "B").
- 16) Remove steering column assembly from vehicle.

CAUTION:

Don't separate steering column assembly into steering column and shaft. If column or shaft is defective, replace as an assembly.

- 17) If it is necessary to remove steering lock assembly (ignition switch), remove it referring to "STEERING LOCK ASSEMBLY (IGNITION SWITCH)" in this section.


INSPECTION**NOTE:**

Vehicles involved in accidents resulting in body damage, where steering column has been impacted (or air bag deployed), may have a damaged or misaligned steering column. For checking procedure of steering column assembly, refer to "CHECKING STEERING COLUMN ASSEMBLY AND LOWER SHAFT FOR ACCIDENT DAMAGE" in this section.


INSTALLATION**CAUTION:**

After tightening steering column mounting nuts, shaft joint bolts should be tightened. Wrong tightening order above could cause a damage to shaft joint.


- 1) Be sure that front wheels and steering wheel are in straight forward state.
If steering lock assembly (ignition switch) is removed, install it referring to "STEERING LOCK ASSEMBLY (IGNITION SWITCH)" in this section.




- 2) Align flat part “A” of steering lower shaft (1) with bolt hole “B” of joint (2) of steering column as shown. Then insert steering lower shaft (1) into shaft joint (2) of steering column with matching marks (3) made before removal.




- 3) Install steering column and tighten steering column mounting nuts (“A”, “B”) by hand.



- 4) Connect all connectors disconnected in REMOVAL.
- Ignition switch
 - Combination switch
 - Horn
 - Immobilizer control module (if equipped)
- 5) To install immobilizer control module cover, tighten three new bolts (1) until head of each bolt is broken off to reinstall immobilizer control module cover on immobilizer control module.



- 6) If contact coil and combination switch assembly is removed, install it.
Refer to “CONTACT COIL AND COMBINATION SWITCH ASSEMBLY” in this section.
- 7) Install upper and lower column covers (2 and 3) to steering column assembly by screws (1).



- 8) Tighten mounting nuts to specified torque in the order "A" – "B" indicated in figure.

Tightening torque

Steering column mounting nut

(a) : 14 N·m (1.4 kg-m, 10.5 lb-ft)


- 9) Tighten joint bolt (1) (steering column side) to specified torque.

Tightening torque

Steering shaft joint bolt (steering column side)

(b) : 28 N·m (2.8 kg-m, 20.0 lb-ft)

- 10) Install steering joint cover.




- 11) Install steering column hole cover (1).


- 12) If steering wheel is removed, install steering wheel. Refer to "STEERING WHEEL" in this section.
 13) Enable air bag system. Refer to "ENABLING AIR BAG SYSTEM" under "SERVICE PRECAUTIONS" in Section 10B.
 14) Connect negative cable at battery.

Steering Lock Assembly (Ignition Switch)

REMOVAL

- 1) Remove steering column (1). Refer to "STEERING COLUMN ASSEMBLY" in this section.






- 2) Using center punch (1), loosen and remove steering lock mounting bolts (2).

NOTE:


Use care not to damage aluminum part of steering lock body with center punch.

- 3) Turn ignition key to "ACC" or "ON" position and remove steering lock assembly from steering column.

INSTALLATION



- 1) Position oblong hole (1) of steering shaft (2) in the center of hole (3) in column (4).
- 2) Turn ignition key to "ACC" or "ON" position and install steering lock assembly (5) onto column (4).
- 3) Now turn ignition key to "LOCK" position and pull it out.
- 4) Align hub on lock with oblong hole (1) of steering shaft (2) and rotate shaft to assure that steering shaft (4) is locked.



- 5) Tighten new bolts (1) until head of each bolt is broken off.
- 6) Turn ignition key to "ACC" or "ON" position and check to be sure that steering shaft (2) rotates smoothly. Also check for lock operation.
- 7) Install steering column. Refer to "STEERING COLUMN ASSEMBLY" in this section.


Steering Lower Shaft

CAUTION:

Never turn steering wheel while steering lower shaft is removed.


Should it have been turned and contact coil (on combination switch) have got out of its centered position, it needs to be centered again. Also, turning steering wheel more than about two and a quarter turns will break contact coil.

REMOVAL



- 1) Turn steering wheel so that vehicle's front tires are at straight-ahead position.
- 2) Turn ignition switch to "LOCK" position and remove key.
- 3) Remove steering joint cover (5).
- 4) Make alignment marks (4) on lower shaft (1) and shaft joint of steering column (2) and lower shaft (1) and pinion shaft (3) for a guide during reinstallation.
- 5) Remove lower shaft joint bolts (6).
- 6) Remove steering lower shaft (1).

INSTALLATION



- 1) Be sure that front wheels and steering wheel are in straight forward state.
- 2) Align flat part "A" of steering lower shaft (1) with bolt hole "B" of shaft joint (2) of column as shown. Then insert lower shaft into shaft joint of steering column with matching marks (4).
- 3) Insert lower shaft (1) into pinion shaft (3) with matching marks (4).
- 4) Tighten joint bolt (pinion shaft side) (6) to specified torque first and then joint bolt (steering column side) (5) to specified torque.

Tightening torque

Steering shaft joint bolt (a) : 28 N·m (2.8 kg-m, 20.0 lb-ft)


- 5) Install steering joint cover (7).

Checking Steering Column Assembly and Lower Shaft for Accident Damage

NOTE:

Vehicles involved in accidents resulting in body damage, where steering column has been impacted (or air bag deployed) may have a damaged or misaligned steering column.

CHECKING PROCEDURE



- 1) Take measurement "a", "b" as shown.
If it is shorter than specified length, replace column assembly with new one.


Length

"a" : 504.5 ± 1 mm (19.9 ± 0.04 in.)

"b" : 62.7 mm (2.47 in.)

- 2) Check steering shaft joints and shaft for any damages such as crack, breakage, malfunction or excessive play.
If anything is found faulty, replace as lower shaft assembly or column assembly.
- 3) Check steering shaft for smooth rotation.
If found defective, replace as column assembly.
- 4) Check steering shaft and column for bend, cracks or deformation.
If found defective, replace.

Special Tool



09944-36011
Steering wheel remover


FRONT SUSPENSION



NOTE:

- All front suspension fasteners are an important attaching part in that it could affect the performance of vital parts and systems, and/or could result in major repair expense. They must be replaced with one of the same part number or with an equivalent part if replacement becomes necessary. Do not use a replacement part of lesser quality or substitute design. Torque values must be used as specified during reassembly to assure proper retention of this part.
- Never attempt to heat, quench or straighten any front suspension part. Replace it with a new part or damage to the part may result.

General Description

Construction



1. Strut assembly	4. Wheel	7. Drive shaft	10. Rubber cap
2. Stabilizer bar	5. Suspension control arm	8. Tie rod	 Tightening torque
3. Steering knuckle	6. Vehicle body	9. Brake disc	 Do not reuse.


Diagnosis

Diagnosis Table

Refer to "DIAGNOSIS TABLE" in STEERING, SUSPENSION, WHEELS AND TIRES.


Stabilizer Bar and/or Bushing Check

BAR




Inspect for damage or deformation.
If defective, replace.

BUSHING



Inspect for damage, wear or deterioration.
If defective, replace.

Strut Assembly Check




- Inspect strut for oil leakage, damage or deformation.
 - If strut is found faulty, replace it as an assembly unit, because it can not be disassembled.
 - Inspect strut function refer to the following procedures.
- 1) Check and adjust tire pressures as specified.
 - 2) Bounce vehicle body 3 or 4 times continuously by pushing front end on the side with strut to be checked.
 - 3) Apply the same amount of force at each push and note strut resistance both when pushed and rebounding.
 - 4) Also, note how many times vehicle body rebounds before coming to stop after hands are off. Do the same for strut on the other side.
 - 5) Compare strut resistance and number of rebalance on the right with those on the left. And they must be equal in both. With proper strut, vehicle body should come to stop the moments hands are off or after only one or two small rebalances.

If conditions of struts are in doubt, compare them with known-good vehicle or strut.


- Inspect bearing for wear, abnormal noise or gripping.
If defective, replace.
- Inspect spring seat for cracks or deformation.
If defective, replace.
- Inspect bump stopper for deterioration.
If defective, replace.
- Inspect rebound stopper and strut mount for wear, cracks or deformation.
If defective, replace.

Suspension Control Arm/Steering Knuckle Check




Inspect for cracks, deformation or damage.
If defective, replace.

Suspension Control Arm Bushing Check



Inspect for damage, wear or deterioration.
If defective, replace.

Suspension Control Arm Joint Check




- Check for smooth rotation.
- Inspect ball stud for damage.
- Inspect dust cover for damage.

NOTE:

Suspension control arm and arm joint cannot be separated.

If there is any damage to either, control arm assembly must be replaced as a complete unit.

Front Suspension Frame Check



- Inspect for cracks, deformation or damage.
- Inspect cushion for deterioration or damage (2WD vehicle.)

Front Suspension Fasteners Check



Check each bolt and nut fastening suspension parts for tightness. Tighten loose one, if any, to specified torque, referring to "GENERAL DESCRIPTION" in this section.

Wheel Disc, Nut and Bearing Check

- Inspect each wheel disc for dents, distortion and cracks. A disc in badly damaged condition must be replaced.
- Check wheel nuts for tightness and, as necessary, retighten them to specification.

Tightening torque


Wheel nut (a) : 85 N·m (8.5 kg-m, 61.5 lb-ft)



- Check wheel bearing for wear. When measuring thrust play, apply a dial gauge to wheel hub.

Thrust play limit


0.1 mm (0.004 in.)



- By rotating wheel actually, check wheel bearing for noise and smooth rotation. If defective, replace bearing.

On-vehicle Service


Strut Assembly




1. Strut assembly	6. Strut bearing : Apply grease (99000-25010) to all around bearing.	11. Strut bracket nut
2. Coil spring	7. Strut support	12. Rubber cap
3. Bump stopper	8. Strut nut	Tightening torque
4. Coil spring lower seat	9. Strut support nut	
5. Coil spring upper seat	10. Strut bracket bolt : Insert from vehicle rear side.	

REMOVAL

- 1) Hoist vehicle, allowing front suspension to hang free.
- 2) Remove wheel.



- 3) Remove brake hose mounting bolt (1) and take off brake hose (2) and then ABS wheel speed sensor harness (if equipped) (3) from strut bracket as shown in the figure.
- 4) Remove strut bracket bolts (4).




5) Remove strut support nuts (1).

NOTE:

Hold strut by hand so that it will not fall off.

6) Remove strut assembly.

DISASSEMBLY




1) With special tool (A) placed to spring as shown, turn special tool bolts alternately until spring tension is released. Whether it is released or not can be known by whether strut turns lightly while strut spring is held stationary.

Special tool

(A) : 09940-71431

WARNING:

Use a commercially available spring compressor and follow the operation procedure described in the Instruction Manual supplied with that spring compressor.



2) While keeping spring compressed with special tool as shown above, remove strut nut.

Special tool

(B) : 09900-00411 (Socket)

(C) : 09900-00414 (6 mm)


3) Disassemble strut assembly.

ASSEMBLY

For assembly, reverse disassembly procedure, noting the following instructions.


1) Compress spring with special tool (A) until total length becomes about 250 mm (9.8 in.) as shown.

Length "a": 250 mm (9.8 in.)




U : Upper side (large diam.)

L : Lower side (small diam.)




- 2) Install coil spring lower seat (1) and compressing coil spring, and mate spring end with stepped part of lower seat as shown.
- 3) Install bump stopper and dust cover onto strut rod. For installing direction, refer to above figure in DISASSEMBLY.
- 4) Pull strut rod as far up as possible and use care not to allow it to retract into strut.

2. Small diam. spring end



- 5) Install spring seat on coil spring and then spring upper seat (1) aligning "OUT" mark (3) on spring upper seat and center of strut bracket (2).



- 6) Install bearing (3), strut support (2) and strut nut (1) in this sequence.


Tighten strut nut (1) to specified torque and then apply waterproof coating (paint or lacquer) all around nut and strut rod thread.

Tightening torque

(a): 65 N·m (6.5 kg-m, 47.0 lb-ft)

INSTALLATION

Install strut assembly by reversing removal procedure, noting the following instructions.



- Insert bolts in such direction as shown in figure.
- Tighten all fasteners to specified torque.

Tightening torque

Strut bracket nut (a) : 105 N·m (10.5 kg-m, 76.0 lb-ft)

Strut support nut (b) : 28 N·m (2.8 kg-m, 20.5 lb-ft)

Brake hose mounting bolt (c) : 23 N·m (2.3 kg-m, 16.5 lb-ft)

NOTE:

- Don't twist brake hose and ABS wheel speed sensor harness (if equipped) when installing it.
- Install ABS wheel speed sensor harness (if equipped) to strut bracket as shown in figure.


- Tighten wheel nut to specified torque.

Tightening torque

Wheel nut : 85 N·m (8.5 kg-m, 61.5 lb-ft)


- After installation, confirm front wheel alignment.

Stabilizer Bar and/or Bushings



1. Stabilizer bar	4. Joint	7. Link cushion	Tightening torque
2. Mount bush	5. Joint nut	8. Mount bolt	
3. Mount bracket	6. Link washer	9. Link nut	

REMOVAL



- 1) Remove stabilizer link nuts, washers and cushions.
When loosening link nut, hold stud with wrench.
- 2) Remove stabilizer mount brackets.
- 3) Remove stabilizer.
- 4) Remove stabilizer joints from stabilizer.
When loosening joint nut, hold stud with wrench.

INSTALLATION

- 1) Loosely assemble all components in reverse order of removal.
- 2) With painted mark (1) on stabilizer bar and end face of mount bushing (2) aligned, tighten mount bracket bolts to specified torque.

NOTE:

If painted mark has gone, align the vehicle center and the center of stabilizer bar.

Tightening torque

Stabilizer bar mounting bracket bolts

(a): 23 N·m (2.3 kg-m, 17.0 lb-ft)

- 3) Tighten each nut to specified torque.
When tightening, hold stud with wrench.


Tightening torque

Stabilizer joint nuts

(b): 50 N·m (5.0 kg-m, 36.5 lb-ft)


Stabilizer link nuts

(c): 23 N·m (2.3 kg-m, 17.0 lb-ft)




F. Forward
A. Upper side
B. Lower side

Wheel Hub and Steering Knuckle




1. Front wheel hub	4. Steering knuckle	Tightening torque
2. Circlip	5. Drive shaft nut : Calk, after tightening.	Do not reuse.
3. Wheel bearing : Face grooved rubber seal side to wheel hub.	6. Hub bolt	

REMOVAL



- 1) Hoist vehicle and remove wheel.
- 2) Uncalk drive shaft nut (1).
- 3) Depress foot brake pedal and hold it there. Remove drive shaft nut (1).
- 4) Remove caliper carrier bolts.




- 5) Remove caliper (1) with carrier.

NOTE:

Hang removed caliper with a wire hook or the like (3) so as to prevent brake hose (4) from bending and twisting excessively or being pulled.

Don't operate brake pedal with pads removed.

- 6) Pull brake disc (2) off by using two 8 mm bolts.



7) Pull out wheel hub (1) with special tools.


Special tool

(A) : 09943-17912

(B) : 09942-15511

CAUTION:


When wheel hub is removed, replace wheel bearing with new one.




8) Disconnect tie rod end (1) from steering knuckle (2) with special tool.

Special tool

(A) : 09913-65210



9) Remove wheel speed sensor (1) from knuckle (if equipped with ABS).




10) Loosen strut bracket nuts (1).

F: Forward


R: Rearward

11) Remove ball joint bolt (3) and nut (4).


12) Remove strut bracket bolts from strut bracket and then steering knuckle (2).

DISASSEMBLY


- 1) Uncaulk and remove dust cover (1).
- 2) Remove circlip.



- 3) Using hydraulic press (1) and special tool, remove wheel bearing.

Special tool**(A) : 09913-75520****CAUTION:****When installing wheel bearing, replace it with new one.**


- 4) Remove wheel bearing outside inner race (1).

Special tool**(C) : 09913-65810****(D) : 09913-85230**

- 5) Remove hub bolts (1) with copper hammer or hydraulic press.

CAUTION:**Never remove bolt unless replacement is necessary.
Be sure to use a new bolt for replacement.**

ASSEMBLY




- 1) Face grooved rubber seal side (1) of new wheel bearing (2) upward as shown in figure and press-fit it into knuckle using special tool.

Special tool


(A) : 09913-75510

CAUTION:

When replacing bearing, inner races or outer race, be sure to replace them with new ones as a set.




- 2) Install circlip (1).




- 3) Drive in dust cover so that dimensions "a" and "b" become equal as shown in figure.

CAUTION:

When drive in dust cover, be careful not to deform it.




- 4) Caulk with a punch.



- 5) Insert new stud bolt (1) in hub hole. Rotate stud bolt slowly to assure that serrations are aligned with those made by original bolt.

INSTALLATION


For installation, reverse removal procedure, noting the following instructions.



- Using special tool, drive wheel hub (1) into steering knuckle (2) and then install steering knuckle (2).

Special tool

(A) : 09913-75520



- Install ball joint bolt (1) and nut (2) from the direction as shown.
- Tighten suspension arm ball joint nut (2) to specified torque.

Tightening torque

Suspension arm ball joint nut

(a) : 60 N·m (6.0 kg-m, 43.5 lb-ft)


- Tighten strut bracket nuts (3) to specified torque.

Tightening torque

Strut bracket bolt (b) : 105 N·m (10.5 kg-m, 76.0 lb-ft)

F: Forward

R: Rearward




- Install ABS wheel speed sensor (1) (if equipped with ABS).

Tightening torque

ABS wheel speed sensor mounting bolt

(a) : 23 N·m (2.3 kg-m, 17.0 lb-ft)




- Connect tie rod end (1) to steering knuckle (2) and tighten tie rod end castle nut (3) to specified torque.

Tightening torque

Tie rod end castle nut (a) : 45 N·m (4.5 kg-m, 32.5 lb-ft)

- Install new split pin (4).



- Install brake caliper (3).
- Tighten brake caliper bolt to specified torque.

Tightening torque

Brake caliper bolt : 85 N·m (8.5 kg-m, 61.5 lb-ft)

- Depress foot brake pedal and hold it there.
- Tighten new drive shaft nut (1) to specified torque.

Tightening torque

Drive shaft nut (a) : 175 N·m (17.5 kg-m, 127.0 lb-ft)

CAUTION:

Never reuse drive shaft nut (1).

- Caulk drive shaft nut (1) as shown.

Caulking specification

"a" : 0.5 mm (0.02 in.) or more

CAUTION:

Be careful while caulking nut so that no crack will occur in caulked part of nut. Cracked nut must be replaced with new one.

- Tightening wheel nut to specified torque.


Tightening torque

Wheel nut : 85 N·m (8.5 kg-m, 61.5 lb-ft)


Suspension Control Arm/Bushing

REMOVAL

- 1) Remove stabilizer bar. Refer to "STABILIZER BAR AND/OR BUSHINGS" in this section.
- 2) Remove suspension control arm ball joint bolt (1) and nut (2).



F: Forward



F: Forward


- 3) Remove suspension control arm bolts (1).
- 4) Remove suspension control arm (2).


DISASSEMBLY

- 1) Cut rubber (1) of flange of suspension control arm front bushing.
- 2) Using grinder (3), grind off flange (2) of front bushing.

CAUTION:

Be careful not to damage suspension control arm (4) when grinding flange (2) of front bushing with grinder.






- 3) Remove front bushing (1) using special tool (A) and hydraulic press (2).

Special tool

(A): 09913-75821




- 4) Remove rear bushing using special tools (B), (C) and hydraulic press (1).

Special tool

(B): 09945-55410

(C): 09924-84510-004

ASSEMBLY



- 1) Press-fit front bushing (1) by using special tool (C) and press (2).

Special tool


(C) : 09913-75810

CAUTION:

Be sure to use new bushing.

NOTE:

- Before installing bushing, apply soap water on its circumference to facilitate installation.



- 2) Press-fit rear bushing by using special tools (B), (C) and hydraulic press (1).

Special tool


(B) : 09945-55410

(C) : 09924-84510-004


NOTE:

- Before installing bushing, apply soap water on its circumference to facilitate installation.

INSTALLATION



- 1) Install suspension control arm as shown but tighten suspension control arm bolts (1) only temporarily.



- 2) Install suspension control arm ball joint to steering knuckle. Align ball stud groove with steering knuckle bolt hole. Then install ball joint bolt (1) from the direction as shown in figure. Tighten suspension arm ball joint nut (2) to specified torque.


Tightening torque

Suspension arm ball joint nut

(a) : 60 N·m (6.0 kg-m, 43.5 lb-ft)

- 3) Install stabilizer bar, referring to “STABILIZER BAR AND/OR BUSHINGS” in this section.

F: Forward




- 4) Lower hoist and vehicle in non-loaded condition, tighten control arm bolts (1) to specified torque.

Tightening torque

Control arm bolts (a) : 90 N·m (9.0 kg-m, 65.0 lb-ft)

- 5) Confirm front wheel alignment referring to Section 3.

Front Suspension Frame




1. Stabilizer bar	4. Engine rear mounting	7. Washer (2WD vehicle only)	F. Forward
2. Suspension arm (Left)	5. Mounting member (2WD vehicle only)	8. Cushion (2WD vehicle only)	
3. Suspension arm (Right)	6. Suspension frame	9. Spacer (2WD vehicle only)	

REMOVAL


- 1) Hoist vehicle and remove wheels (right & left).
- 2) Remove stabilizer bar. Refer to “STABILIZER BAR AND/OR BUSHINGS” in this section.
- 3) Remove suspension arms (right & left). Refer to “SUSPENSION CONTROL ARM/BUSHING” in this section.
- 4) Remove engine rear mounting nuts and engine mounting member bolts (2WD vehicle).

NOTE:

- For 2WD vehicle, be careful not to loose cushions (5) and spacers (4) which may stick to suspension frame (1).
- For 4WD vehicle, support transmission to prevent joint parts from being applied excessive force at removal of suspension frame (1).




2. Engine rear mounting
3. Mounting member



- 5) Remove suspension frame from body.

INSTALLATION




- 1) Install suspension frame (1) to body, and tighten bolt to specified torque.

Tightening torque

Suspension frame mounting bolts

(a): 90 N·m (9.0 kg-m, 65.0 lb-ft)



- 2) Install mounting member (2), spacers and cushions to suspension frame (1) if removed and tighten bolts and nuts to specified torque.

Tightening torque


Mounting member bolts

(b): 55 N·m (5.5 kg-m, 40.0 lb-ft)

Engine rear mounting nuts

(g): 45 N·m (4.5 kg-m, 33.0 lb-ft).

3. Rear engine mounting



- 3) Install suspension arms (2) (right & left). Refer to “SUSPENSION CONTROL ARM/BUSHING” in this section.
- 4) Install stabilizer bar (3). Refer to “STABILIZER BAR AND/OR BUSHINGS” in this section.
- 5) Tighten bolts and nuts to each specified torque.

Tightening torque
Suspension control arm mounting bolts
(c): 90 N·m (9.0 kg-m, 65.0 lb-ft)
Suspension arm ball joint nut
(d): 60 N·m (6.0 kg-m, 43.5 lb-ft)
Stabilizer bar mounting bracket bolts
(e): 23 N·m (2.3 kg-m, 17.0 lb-ft)
Stabilizer link nuts
(f): 23 N·m (2.3 kg-m, 17.0 lb-ft)
















- 6) Install wheels (right & left) and lower hoist.
- 7) Confirm front wheel alignment referring to Section 3.

1. Suspension frame
F: Forward
R: Right side
L: Left side

Required Service Material

Material	Recommended SUZUKI product (Part Number)	Use
Lithium grease	SUZUKI SUPER GREASE A (99000-25010)	• Strut bearing

Special Tool

 <p>09900-00411 Hexagon wrench socket</p>	 <p>09900-00414 Hexagon wrench bit 6 mm</p>	 <p>09913-65210 Tie rod end remover</p>	 <p>09913-65810 Bearing puller</p>
 <p>09913-75510 Bearing installer</p>	 <p>09913-75520 Bearing installer</p>	 <p>09913-75810 Bearing installer</p>	 <p>09913-75821 Installer attachment</p>
 <p>09913-85230 Bearing puller attachment</p>	 <p>09924-84510-004 Bearing installer attachment</p>	 <p>09940-71431 Spring compressor</p>	 <p>09942-15511 Sliding hammer</p>
 <p>09943-17912 Front wheel hub remover</p>	 <p>09943-77910 Bushing remover</p>	 <p>09945-55410 Bushing installer</p>	


REAR SUSPENSION (2WD VEHICLE)

NOTE:

- All suspension fasteners are an important attaching part in that it could affect the performance of vital parts and systems, and/or could result in major repair expense. They must be replaced with one of the same part number or with an equivalent part if replacement becomes necessary. Do not use a replacement part of lesser quality or substitute design. Torque values must be used as specified during reassembly to assure proper retention of this part.
- Never attempt to heat, quench or straighten any front suspension part. Replace it with a new part, or damage to the part may result.

General Description


Construction



1. Vehicle body	5. Control rod	Tightening torque
2. Strut assembly	6. Trailing rod	Do not reuse.
3. Rear knuckle	7. Brake drum	
4. Suspension frame	8. Wheel Bearing	

Diagnosis

Strut Assembly Check



1) Inspect strut for oil leakage. If strut is found faulty, replace it as an assembly unit, because it can not be disassembled.

2) Strut function check

Check and adjust tire pressure as specified. Bounce vehicle body three or four times continuously by pushing rear end on the side with strut to be checked. Apply the same amount of force at each push and note strut resistance both when pushed and rebounding.

Also, note how many times vehicle body rebounds before coming to stop after hands are off. Do the same for strut on the other side.

Compare strut resistance and number of rebound on the right with those on the left. And they must be equal in both. With proper strut, vehicle body should come to stop the moment hands are off or after only one or two small rebounds. If struts are suspected, compare them with known good vehicle or strut.

1. Strut assembly

3) Inspect for damage or deformation.

4) Inspect for abnormal noise.

5) Inspect for cracks or deformation in spring seat.


6) Inspect for deterioration of bump stopper.

7) Inspect strut support for wear, cracks or deformation.

Replace any defective part.

Stabilizer Bar, Bushing and/or Joint Check

Stabilizer bar




Inspect for damage or deformation. If defective, replace.

Stabilizer Bushing/Bracket

Inspect for damage, wear deformation or deterioration. If defective, replace.

- | |
|------------------------------|
| 1. Stabilizer bar mount bush |
| 2. Stabilizer bar bracket |




Stabilizer joint

- 1) Check for smooth rotation.
- 2) Inspect ball stud for damage.
- 3) Inspect dust cover for damage.

NOTE:

Stabilizer joint (1) cannot be disassembled.


If there is any damage to either, stabilizer joint assembly must be replaced as a complete unit.



Suspension Knuckle Check

- Inspect for cracks, deformation or damage.
- Inspect bushing for damage, wear or breakage.


If any faulty condition is found, replace.




Control Rod Check

- Inspect for cracks, deformation or damage.
- Inspect bushing for wear and breakage.

If any faulty condition is found, replace.




Trailing Rod Check



- Inspect for cracks, deformation or damage.
- Inspect bushing for wear and breakage.

If any faulty condition is found, replace.

Suspension Frame, Bushing and Pad Check



- Inspect for cracks, deformation or damage.


If any faulty condition is found, replace.

Rear Suspension Fasteners

Check each bolt and nut fastening suspension parts for tightness. Tighten loose one, if any, to specified torque referring to the figure in "GENERAL DESCRIPTION" in this section.


Wheel Disc, Nut and Bearing Check

- Inspect each wheel disc for dents, distortion and cracks.
A disc in badly damaged condition must be replaced.
- Check wheel nuts for tightness and, as necessary, retighten to specification.



Tightening torque


Wheel nuts (a) : 85 N·m (8.5 kg-m, 61.5 lb-ft)



- Check wheel bearings for wear. When measuring thrust play, apply a dial gauge to spindle cap center. If thrust play exceeds limit, replace bearing.

Thrust play limit


“a” : 0.1 mm (0.004 in.)



- By rotating wheel actually, check wheel bearing for noise and smooth rotation. If it is defective, replace bearing.

On-vehicle Service

Rear Strut Assembly





1. Strut upper cap	6. Strut dust cover	11. Strut support nut
2. Strut upper nut	7. Bump stopper	12. Strut bracket nut
3. Strut support	8. Coil spring	13. Strut bracket bolt : Insert from vehicle front side.
4. Spring upper seat	9. Spring lower seat	Tightening torque
5. Spring (rubber) seat	10. Strut	

REMOVAL


NOTE:

When servicing component parts of strut assembly, loosen strut upper nut a little before removing strut assembly. This will make service work easier. Note, however, nut must not be removed at this point.

- 1) Hoist vehicle, allowing rear suspension to hang free.
- 2) Remove wheel.
- 3) Remove E-ring (1) securing brake hose.
- 4) Remove ABS wheel speed sensor harness mounting bolt (if equipped).



- 5) Remove strut bracket bolts and nuts. And then take brake hose off strut bracket using care not to deform brake pipe.




- 6) Remove strut support nuts. (1)
Hold strut by hand so that it will not fall off.
- 7) Remove strut assembly.


DISASSEMBLY

- 1) With special tool (A) placed to spring as shown, turn special tool bolts alternately until spring tension is released. Whether it is released or not can be known by whether strut turns lightly while strut spring is held stationary.

Special tool

(A) : 09940-71431





- 2) While keeping spring compressed with special tool as shown above, remove strut nut.

Special tool


(A): 09945-26010 (17 mm socket)

(B): 09900-00411 (Socket)

(C): 09900-00414 (6 mm)

- 3) Disassemble strut assembly.


ASSEMBLY



- 1) Compress spring with special tool (A) until total length becomes about 290 mm (11.42 in.) as shown.

Length "a": 290 mm (11.42 in.)

A :	Upper side (small diam.)
B :	Lower side (large diam.)




- 2) Install coil spring lower seat (2) and compressing coil spring, mate large-dia. spring end with stepped part of lower seat as shown.


- 3) Install bump stopper onto strut rod.

- 4) Instal dust cover onto bump stopper.


1.	Strut lower seat
----	------------------



- 5) Fit coil spring (rubber) seat (2) in coil spring upper seat (1), making sure that their depth matches all around. No part of rubber seat should stick out higher than upper seat.



- 6) Pull strut rod as far up as possible and use care not to allow it to retract into strut.
- 7) With "OUT" mark (3) on spring upper seat (1) and the center of strut bracket (2) aligned, place upper spring seat together with spring (rubber) seat on coil spring.




- 8) Put strut support (2) on spring upper seat (3).
Tighten strut nut (1) to specified torque.

Tightening torque

Strut upper nut (a) : 65 N·m (6.5 kg-m, 47.0 lb-ft)

- 9) Loosen and remove special tool (A) from compressing coil spring. While loosening special tool, recheck that stepped part of spring seat and spring end are in place to each other as described in foregoing Step 2).
Also, check to make sure that "OUT" mark on upper seat is matched with the center of strut bracket as described in Step 7).

INSTALLATION



- 1) Install strut by reversing REMOVAL Steps 1) – 7). Insert bracket bolts in such a direction as shown in figure.
- 2) Torque all fasteners to specification.

Tightening torque


Strut support nuts (a) : 28 N·m (2.8 kg-m, 20.5 lb-ft)

Strut bracket nuts (b) : 90 N·m (9.0 kg-m, 65.0 lb-ft)

NOTE:

Do not twist brake hose when installing it. Install E-ring (1) as far as it fits to bracket as shown.

Stabilizer Bar and/or Bushings




1. Stabilizer bar	4. Joint	7. Mount bolt
2. Mount bush	5. Joint nut	F : Forward
3. Mount bracket	6. Link nut	Tightening torque

REMOVAL


CAUTION:

To avoid the risk of being burned, start your work after the exhaust system has cooled down.

- 1) Hoist vehicle and remove rear wheels
- 2) Remove stabilizer link nuts. Then remove stabilizer joints from stabilizer bar. When loosening link nut and joint nut, hold stud with wrench.
- 3) Remove stabilizer mount brackets.
- 4) Remove stabilizer bar.



INSTALLATION



- 1) Loosely assemble all components in reverse order of removal.
- 2) With painted mark (2) on stabilizer bar and end face of mount bushing (1) aligned, tighten mount bracket bolts to specified torque.

NOTE:

If painted mark has faded out, align the vehicle center and the center of stabilizer bar.

Tightening torque


Stabilizer bar mounting bracket bolts (a) : 23 N·m (2.3 kg-m, 17.0 lb-ft)


- 3) Tighten each nut to specified torque. When tightening, hold stud with wrench.

Tightening torque

Stabilizer link nuts and joint nuts (b) : 50 N·m (5.0 kg-m, 36.5 lb-ft)


Control Rod




1. Control rod (No.1)	6. No.2 control rod bolt (inner bolt)	11. Joint
2. Control rod (No.2)	7. Control rod washer	12. Stabilizer bar
3. Stabilizer bar link nut	8. Control rod inner nut	F: Forward
4. Control rod outer bolt	9. Suspension frame	 Tightening torque
5. Control rod inner bolt (inner bolt)	10. Suspension frame cap	

REMOVAL


- 1) Hoist vehicle and remove rear wheels.
- 2) Detach spring end from left side control rod (No.2) (if equipped with LSPV).
- 3) Remove stabilizer bar. Refer to "STABILIZER BAR AND/OR BUSHINGS" in this section.
- 4) To facilitate toe adjustment after reinstallation, put match marks (4) on washer (3) and on suspension frame (2).





- 5) Remove suspension frame cap (2).
- 6) Remove control rod (No.2) (4) from suspension frame (1) and knuckle (5).
- 7) Remove control rod (No.1) (3) from suspension frame and knuckle.


INSTALLATION



- 1) Install control rod (No.1) (1).
 - a) Install control rod (No.1) (1), setting it so that its welded nut (8) comes toward the rear.
 - b) Insert inner bolt (4) and outer bolt (3) from the vehicle front and tighten them temporarily by hand.
- 2) Install control rod (No.2) (2).
 - a) Install control rod (No.2) (2), setting it so that its welded nut (8) comes toward the front.
 - b) Insert control rod (No.2) bolt (9) from the vehicle front and outer bolt (3) from the rear.
 - c) Install washer (6) with its graduated part facing down.
 - d) With marks (7) on washer (6) and frame marked before removal aligned to each other, tighten bolts (3) and nut (5) temporarily by hand.

[A] : Correct	U : Upper side
[B] : Wrong	L : Lower side

- 3) Install LSPV spring to control rod (No.2).
Tighten nut temporarily at this step (if equipped with LSPV).




- 4) Install stabilizer bar. Refer to "STABILIZER BAR AND/OR BUSHINGS" in this section.

Tightening torque

Stabilizer bar mounting bracket bolts (a) : 23 N·m (2.3 kg-m, 17.0 lb-ft)

Stabilizer link nuts and joint nuts (b) : 50 N·m (5.0 kg-m, 36.5 lb-ft)

- 5) Install wheels and tighten wheel nuts to specified torque.
- 6) Lower hoist and bounce vehicle up and down to stabilize suspension.



- 7) Tighten control rod bolts and nuts to specified torque with vehicle weight on suspension.

NOTE:

- It is the most desirable to have vehicle off hoist and in non-loaded condition when tightening them.
- Tighten control rod (No.2) inner nut with match marks (1) aligned.

Tightening torque


Control rod (No.1 and No.2) inner nuts and outer bolts (c) : 90 N·m (9.0 kg-m, 65.0 lb-ft)

- 8) If equipped with LSPV, check and adjust LSPV spring referring to "LSPV INSPECTION AND ADJUSTMENT" and perform "FLUID PRESSURE TEST" in Section 5.
- 9) Check rear toe and adjust it as necessary. For check and adjustment procedures, refer to "REAR WHEEL ALIGNMENT" in Section 3.
- 10) Install suspension frame cap.

Trailing Rod

REMOVAL

- 1) Hoist vehicle.
- 2) Detach parking brake cable clamp (2) from trailing rod (1).
- 3) Remove trailing rod bolts (3) and trailing rod (1).




INSTALLATION


- 1) Install trailing rod (1) and tighten bolts by hand.
- 2) Attach parking brake cable clamp (2) to trailing rod.
- 3) Install wheel and tighten wheel nuts to specified torque.
- 4) Lower hoist and bounce vehicle up and down to stabilize suspension.
- 5) Tighten trailing rod bolts to specified torque with vehicle weight on suspension.


Tightening torque

Trailing rod bolts (a) : 90 N·m (9.0 kg-m, 65.0 lb-ft)



Suspension Frame



1. Suspension frame	5. Control rod (No.2)	F : Forward
2. Suspension frame cap	6. Joint	 Tightening torque
3. Suspension frame bolt	7. Stabilizer bar	
4. Control rod (No.1)	8. Pad	


REMOVAL

- 1) Hoist vehicle and remove rear wheels.
- 2) Remove muffler referring to Section 6K.


WARNING:

To avoid the danger of being burned, do not touch the exhaust system when the system is hot. Any service on the exhaust system should be performed when the system has cooled down.


- 3) Remove stabilizer bar. Refer to “STABILIZER BAR AND/OR BUSHINGS” in this section.
- 4) Detach spring end from left side control rod (No.2) (if equipped with LSPV).



- 5) To facilitate toe adjustment after reinstallation, put match marks (4) on washer (3) and on suspension frame (2).
- 6) Remove control rod (No.2) (right and left).
- 7) Remove control rod (No.1) (right and left).




- 8) Remove suspension frame bolts (2) and suspension frame (1).



- 9) Remove suspension frame bushings (1) by using a pipe (2) whose outer diameter (3) is 37 mm (1.46 in.) and inner diameter (4) is 27 mm (1.06 in.) or more, an appropriate support (5) and hydraulic press (6).

7.	54 mm (2.13 in.) or less
8.	47 mm (1.85 in.) or more
9.	38 mm (1.50 in.)
10.	25 mm (0.98 in.)
11.	46 mm (1.81 in.)

INSTALLATION




- 1) Press-fit suspension frame bushings (1) by using special tools (A), (B) and hydraulic press (2).

Special tool

(A) : 09951-16080

(B) : 09940-53111



- 2) Install suspension frame pads (1) to bushings (2) as shown.
- 3) Install suspension frame and tighten suspension frame bolts to specified torque.

Tightening torque


Suspension frame bolts (a) : 90 N·m (9.0 kg-m, 65.0 lb-ft)

- 4) Install control rods referring to "CONTROL ROD" in this section.
- 5) Install stabilizer bar. Refer to "STABILIZER BAR AND/OR BUSHINGS" in this section.
- 6) Install muffler referring to Section 6K.
- 7) Install wheels and tighten wheel nuts to specified torque.
- 8) Check rear toe and adjust it as necessary. For check and adjustment procedures, refer to "REAR WHEEL ALIGNMENT" in this section.


Wheel Hub, Wheel Bearing and Wheel Stud

REMOVAL

- 1) Remove rear brake drum. Refer to "BRAKE DRUM" under "REAR BRAKE" in Section 5.
- 2) Remove spindle cap (1) as shown (by hammering lightly at 3 locations around it so as not to deform or cause damage to seating part of cap).



- 3) Uncaulk spindle nut and remove spindle nut (2).




- 4) Pull wheel hub (1) off by using special tools.

Special tool


(A) : 09943-17912

(B) : 09942-15511

- 5) Remove wheel sensor ring (if equipped with ABS). Refer to "REAR WHEEL SPEED SENSOR RING" in Section 5B.
- 6) Remove hub bolts.
Refer to "WHEEL HUB AND STEERING KNUCKLE" in this section.




INSPECTION



- Wheel bearing (2) and wheel hub (1) form a solid unit.
- When wheel bearing is found defective and its replacement is necessary, replace hub assembly.

INSTALLATION

- 1) Install hub bolts.
Refer to "WHEEL HUB AND STEERING KNUCKLE" in this section.




- 2) Install wheel hub (1) and new spindle nut.
- 3) Tighten spindle nut (2) to specified torque.

NOTE:

Removed spindle nut should be replaced with new one.

Tightening torque

Spindle nut (a) : 175 N·m (17.5 kg-m, 126.5 lb-ft)



- 4) Caulk spindle nut (1) as shown.

2. Caulk

- 5) Install new spindle cap.

NOTE:


When installing spindle cap, hammer lightly several locations on the collar of cap until collar comes closely into contact with wheel hub.

- 6) Install brake drum and wheel. For details, refer to "BRAKE DRUM" under "REAR BRAKE" in Section 5.


Knuckle

REMOVAL


- 1) Hoist vehicle and remove wheel hub referring to "WHEEL HUB, WHEEL BEARING AND WHEEL STUD" in this section.




- 2) Remove E-ring (1) securing brake hose.




- 3) Disconnect brake pipe (1) from wheel cylinder (2) and put wheel cylinder bleeder plug cap (3) onto pipe to prevent fluid from spilling.
- 4) Remove ABS wheel speed sensor from knuckle, if equipped.



- 5) Remove brake back plate (1) from knuckle.



- 6) Loosen control rod outer bolts, trailing rod rear bolt and strut bracket nuts.
- 7) Disconnect control rods (No.1 (2) and No.2 (3)) from knuckle (1).
- 8) Disconnect trailing rod (4) from knuckle (1).




- 9) Remove knuckle (2) from strut.

INSTALLATION

- 1) Install rear knuckle to strut, and connect control rods and trailing rod to knuckle. At this point, temporarily tighten them by hand.
- 2) Tighten strut bracket bolts and nuts to specified torque.


Tightening torque

Strut bracket nuts (a) : 90 N·m (9.0 kg-m, 65.0 lb-ft)



- 3) Apply water tight sealant to mating surfaces of brake back plate and rear knuckle.


“A” : Sealant 99000-31090




- 4) Install brake back plate and tighten back plate bolts to specified torque.

Tightening torque

Back plate bolts (b) : 50 N·m (5.0 kg-m, 36.0 lb-ft)






- 5) For ABS equipped vehicle, check to make sure that ABS wheel speed sensor tooth is free from any metal particles and install it to knuckle.
- 6) Connect brake pipe to wheel cylinder and tighten brake pipe flare nut (1) to specified torque and install bleeder plug cap (2) taken off from pipe back to bleeder plug.

Tightening torque

Brake pipe flare nut (c) : 16 N·m (1.6 kg-m, 12.0 lb-ft)

- 7) Attach brake hose to strut bracket (3) with E-ring (4) securely.
- 8) Install wheel hub referring to "WHEEL HUB, WHEEL BEARING AND WHEEL STUD" in this section.
- 9) Install brake drum referring to "BRAKE DRUM" in Section 5.
- 10) Fill reservoir with brake fluid and bleed brake system. Refer to "AIR BLEEDING OF BRAKE SYSTEM" in Section 5.
- 11) Upon completion of all jobs, depress brake pedal with about 30 kg (66 lbs) load three to five times so as to obtain proper drum-to-shoe clearance.
Adjust parking brake cable. Refer to "PARKING BRAKE INSPECTION AND ADJUSTMENT" in Section 5.
- 12) Install wheel and tighten wheel nuts to specified torque.
- 13) Check to ensure that brake drum is free from dragging and proper braking is obtained.
- 14) Lower hoist and bounce vehicle up and down to stabilize suspension.



- 15) Tighten control rod outer bolts and trailing rod rear bolt to specified torque with vehicle weight on suspension. Then check toe.

Tightening torque

Control rod outer bolts and trailing rod rear bolt (d) : 90 N·m (9.0 kg-m, 65.0 lb-ft)

- 16) Perform brake test (foot brake and parking brake).
- 17) Check each installed part for fluid leakage.








Tightening Torque Specifications

Fastening part	Tightening torque		
	N•m	kg-m	lb-ft
Stabilizer bar mounting bracket	23	2.3	17.0
Stabilizer link nut	50	5.0	36.5
Control rod outer bolt	90	9.0	65.0
Control rod inner bolt & nut			
Trailing rod bolt			
Suspension frame bolt			
Strut support nut	28	2.8	20.5
Strut upper nut	65	6.5	47.0
Strut bracket bolt & nut	90	9.0	65.0
Rear spindle nut	175	17.5	126.5
Back plate bolt	50	5.0	36.0
Wheel nut (hub nut)	85	8.5	61.5

Required Service Material

Material	Recommended SUZUKI product (Part Number)	Use
Lithium grease	SUZUKI SUPER GREASE (A) (99000-25010)	• Wheel bearing
Brake fluid	Indicated on reservoir tank cap or described in owner's manual of vehicle	• Brake reservoir tank
Water tight sealant	SUZUKI SEALING COMPOUND 366E (99000-31090)	• Joint seam of knuckle and brake back plate

Special Tool

 <p>09940-71431 Spring compressor</p>	 <p>1. 09900-00411 Hexagon wrench socket 2. 09900-00414 Hexagon wrench bit 6 mm</p>	 <p>09942-15511 Sliding hammer</p>	 <p>09943-17912 Brake drum remover</p>
 <p>09945-26010 Socket wrench 17 mm</p>	 <p>09940-53111 Bearing installer</p>	 <p>09951-16080 Bearing installer</p>	


REAR SUSPENSION (4WD VEHICLE)

NOTE:

- All suspension fasteners are an important attaching part in that it could affect the performance of vital parts and systems, and/or could result in major repair expense. They must be replaced with one of the same part number or with an equivalent part if replacement becomes necessary. Do not use a replacement part of lesser quality or substitute design. Torque values must be used as specified during reassembly to assure proper retention of this part.
- Never attempt to heat, quench or straighten any suspension part. Replace it with a new part, or damage to the part may result.

General Description


Construction



1. Vehicle body	6. Trailing rod	11. ABS wheel speed sensor ring (if equipped)
2. Strut assembly	7. Brake drum	Tightening torque
3. Rear knuckle	8. Wheel bearing	Do not reuse.
4. Suspension frame	9. Brake back plate	
5. Control rod	10. Drive shaft	

On-vehicle Service


Rear Suspension Frame




1. Suspension frame	4. Differential	F : Forward
2. Control rod (No.1)	5. Differential mounting	Tightening torque
3. Control rod (No.2)	6. Differential mounting bracket	

REMOVAL


- 1) Hoist vehicle and remove wheels (right and left).
- 2) Drain differential oil.
- 3) Remove rear drive shaft nut of left side.
- 4) Detach LSPV spring end from left side control rod (No.2) (if equipped with LSPV).
- 5) Remove stabilizer bar referring to "STABILIZER BAR AND/OR BUSHINGS" in this section.
- 6) To facilitate toe adjustment after reinstallation, put match marks (4) on washer (3) and on suspension frame (2) (right and left).
- 7) Remove control rod (No.2) (1).
- 8) Remove control rod (No.1).






- 9) Remove left drive shaft from differential and knuckle, and disconnect right drive shaft from differential.

1. Used clamp
2. Tire lever



- 10) To facilitate reinstallation, put match marks (1) on No.2 propeller shaft flange and differential flange. Disconnect No.2 propeller shaft from differential.
- 11) Remove differential, differential mounting and mounting bracket from suspension frame.
- 12) Remove suspension frame from vehicle body.


INSTALLATION



- 1) Install suspension frame to vehicle body and tighten suspension frame bolt to specified torque.

Tightening torque

Suspension frame bolts (a) : 90 N·m (9.0 kg-m, 65.0 lb-ft)




- 2) Install differential mounting, mounting bracket and differential to suspension frame.
Tighten each bolt to specified torque referring to Section 7F.
- 3) Connect No.2 propeller shaft to differential aligning match marks on flanges. Tighten bolts and nuts to specified torque referring to Section 4B.
- 4) Install drive shafts (right and left) referring to "DRIVE SHAFT ASSEMBLY" in Section 4C.
- 5) Install control rods referring to "CONTROL ROD" in this section.
- 6) Install stabilizer bar referring to "STABILIZER BAR AND/OR BUSHINGS" in this section.
- 7) If equipped with LSPV, check and adjust LSPV spring referring to "LSPV INSPECTION AND ADJUSTMENT" and perform "FLUID PRESSURE TEST" in Section 5.
- 8) Fill differential oil, referring to Section 7F.
- 9) Install wheels and tighten wheel nuts to specified torque.

Wheel Hub, Wheel Stud/Wheel Bearing Outside Inner Race

REMOVAL

- 1) Hoist vehicle and remove wheel.
- 2) Uncaulk drive shaft nut (1).
- 3) Pull up parking brake lever fully and remove drive shaft nut (1).
- 4) Release parking brake lever and remove brake drum referring to "BRAKE DRUM" in Section 5.




- 5) Pull wheel hub (1) off by using special tools.

Special tool

(A) : 09943-17912


(B) : 09942-15511



- 6) Remove hub bolts (2).

Refer to "WHEEL HUB AND STEERING KNUCKLE" in this section.

1. Wheel hub




- 7) Remove wheel bearing inner race (1).


Special tool

(C) : 09913-61510

(D) : 09925-88210




INSTALLATION



- 1) Install hub bolts.
Refer to "WHEEL HUB AND STEERING KNUCKLE" in this section.
- 2) Install outside inner race (1) to wheel hub (2) using special tool. Installing direction is as shown.


Special tool

(E) : 09940-53111




- 3) Apply grease to outside bearing, outside inner race and oil seal lip.

"A": Grease 99000-25010



- 4) Install wheel hub to knuckle by tightening drive shaft nut. Do not tap wheel hub.



- 5) Install brake drum (1) referring to "BRAKE DRUM" in Section 5.
- 6) Pull up parking brake lever fully and tighten new drive shaft nut (2) to specified torque.

Tightening torque

Drive shaft nut (a) : 175 N·m (17.5 kg-m, 126.5 lb-ft)

- 7) Caulk (3) drive shaft nut (2).

WARNING:

Be careful while caulking nut so that no crack will occur in calked part of nut. Cracked nut must be replaced with new one.


- 8) Install wheel and lower hoist.
- 9) Perform brake test.

Knuckle, Wheel Bearing/Oil Seal

REMOVAL


Once bearing outer race is removed, bearing set (outer race, bearings and inner races) should be replaced with new one.

- 1) Remove wheel hub referring to "WHEEL HUB, WHEEL STUD/WHEEL BEARING OUTSIDE INNER RACE" in this section.
- 2) Remove knuckle from vehicle referring to "KNUCKLE" in this section.



- 3) Remove outside oil seal (1) and snap ring (2) from knuckle.
- 4) Remove inside oil seal (6) from knuckle (5).

3. Outside bearing
4. Bearing outer race (and inner bearing)



- 5) Remove bearing outer race/inner bearing using special tool and hydraulic press.

Special tool

(A) : 09924-84510-004

INSTALLATION


When replacing bearing, inner race or outer race, be sure to replace them with new ones as a set.

- 1) Press-fit new bearing outer race/inner bearing (3) using special tools.

Special tool


(B) : 09913-75520

(C) : 09951-18210



1. Press
2. Knuckle

- 2) Apply grease (lithic grease) to bearing outer race and bearings.




- 3) Press-fit new inside oil seal (2) until special tool contacts with knuckle (1).

Be sure to apply grease (3) to oil seal lip.

Special tool

(D) : 09944-78210



- 4) Install snap ring to knuckle.

- 5) Press-fit new outside oil seal (2) until special tool contacts with knuckle (1).

Be sure to apply grease (3) to oil seal lip.

Special tool

(D) : 09944-78210

(C) : 09951-18210

- 6) Install knuckle referring to “KNUCKLE” in this section.

- 7) Install wheel hub referring to “WHEEL HUB, WHEEL STUD/WHEEL BEARING OUTSIDE INNER RACE” in this section.










Tightening Torque Specifications

Fastening part	Tightening torque		
	N•m	kg-m	lb-ft
Rear suspension frame bolt	90	9.0	65.0
Rear drive shaft nut	175	17.5	126.5
Control rod bolt and nut	90	9.0	65.0
Differential mounting bolt	50	5.0	36.0

Required Service Material

Material	Recommended SUZUKI product (Part Number)	Use
Lithic wheel bearing grease	SUZUKI SUPER GREASE (A) (99000-25010)	Wheel bearing, wheel bearing oil seal lip

Special Tool

 <p>09913-61510 Bearing puller</p>	 <p>09913-75520 Bearing installer</p>	 <p>09924-84510-004 Bearing installer adapter (C)</p>	 <p>09925-88210 Bearing puller attachment</p>
 <p>09940-53111 Bearing installer</p>	 <p>09942-15511 Sliding hammer</p>	 <p>09943-17912 Brake drum remover</p>	 <p>09944-78210 Bearing installer support</p>
 <p>09951-18210 Oil seal remover & installer No.2</p>			

WHEELS AND TIRES

NOTE:

All wheel fasteners are important attaching parts in that they could affect the performance of vital parts and systems, and/or could result in major repair expense. They must be replaced with one of the same part number or with an equivalent part if replacement becomes necessary. Do not use a replacement part of lesser quality or substitute design. Torque values must be used as specified during reassembly to assure proper retention of all parts.

There is to be no welding as it may result in extensive damage and weakening of the metal.

General Description

Tires

The tire is of tubeless type. The tire is designed to operate satisfactorily with loads up to the full rated load capacity when inflated to the recommended inflation pressures.

Correct tire pressures and driving habits have an important influence on tire life. Heavy cornering, excessively rapid acceleration, and unnecessary sharp braking increase tire wear.

Tire placard

The "Tire Placard" is located on the left door (right door for right-hand side steering vehicle) lock pillar and should be referred to tire information.

The placard lists the maximum load, tire size and cold tire pressure where applicable.

NOTE:

Whether rim size and/or maximum load are listed or not depends on regulations of each country.

Inflation of tires

The pressure recommended for any model is carefully calculated to give a satisfactory ride, stability, steering, tread wear, tire life and resistance to bruises.

Tire pressure, with tires cold, (after vehicle has set for 3 hours or more, or driven less than one mile) should be checked monthly or before any extended trip. Set to the specifications on the "Tire Placard" located on the left door (right door for right-hand side steering vehicle) lock pillar.

It is normal for tire pressure to increase when the tires become hot during driving.

Do not bleed or reduce tire pressure after driving. Bleeding reduces the "Cold Inflation Pressure".

Higher than recommended pressure can cause :

- Hard ride
- Tire bruising or carcass damage
- Rapid tread wear at center of tire

Unequal pressure on same axle can cause :


- Uneven braking
- Steering lead
- Reduced handling
- Swoon on acceleration

Lower than recommended pressure can cause :

- Tire squeal on turns
- Hard Steering
- Rapid and uneven wear on the edges of the tread
- Tire rim bruises and rupture

- Tire cord breakage
- High tire temperature
- Reduced handling
- High fuel consumption

Matched tires and wheels (steel type)



Tires and wheels are match mounted at the assembly plant. This means that the radially stiffest part of the tire, or “high spot”, is matched to the smallest radius or “low spot” of the wheel. This is done to provide the smoothest possible ride.

The “high spot” of the tire is originally marked by paint dot (1) on the outboard sidewall. This paint dot will eventually wash off the tire.

The “low spot” of the wheel is originally marked by paint dot (2) on the wheel rim-flange. Properly assembled, the wheel rims’ paint dot should be aligned with the tires’ paint dot as shown in left figure.

Whenever a tire is dismounted from its wheel, it should be remounted so that the tire and wheel are matched. If the tire’s paint dot cannot be located, a line should be scribed on the tire and wheel before dismounting to assure that it is remounted in the same position.

Replacement tires

When replacement is necessary, the original equipment type tire should be used. Refer to the “Tire Placard”. Replacement tires should be of the same size, load range and construction as those originally on the vehicle. Use of any other size or type tire may affect ride, handling, speedometer/odometer calibration, vehicle ground clearance and tire or snow chain clearance to the body and chassis.

It is recommended that new tires be installed in pairs on the same axle. If necessary to replace only one tire, it should be paired with the tire having the most tread, to equalize braking traction.

WARNING:

Do not mix different types of tires on the same vehicle such as radial, bias and bias-belted tires except in emergencies, because handling may be seriously affected and may result in loss of control.

kPa	kgf/cm ²	psi
160	1.6	23
180	1.8	26
200	2.0	29
220	2.2	32
240	2.4	35
260	2.6	38
280	2.8	41
300	3.0	44

The metric term for tire inflation pressure is the kilo pascal (kPa). Tire pressures is usually printed in both kPa and psi on the “Tire Placard”.

Metric tire gauges are available from tool suppliers.

The chart, shown the table, converts commonly used inflation pressures from kPa to psi.

Wheels

Wheel maintenance


Wheel repairs that use welding, heating, or peening are not approved. All damaged wheels should be replaced.

Replacement wheels

Wheels must be replaced if they are bent, dented, have excessive lateral or radial runout, air leak through welds, have elongated bolt holes, if lug nuts won't stay tight, or if they are heavily rusted. Wheels with greater runout than shown in figure below may cause objectional vibrations.

Replacement wheels must be equivalent to the original equipment wheels in load capacity, diameter, rim with offset and mounting configuration. A wheel of improper size or type may affect wheel and bearing life, brake cooling, speedometer/odometer calibration, vehicle ground clearance and tire clearance to body and chassis.

How to measure wheel runout



To measure the wheel runout, it is necessary to use an accurate dial indicator. The tire may be on or off the wheel. The wheel should be installed to the wheel balancer of the like for proper measurement.

Take measurements of both lateral runout (1) and radial runout (2) at both inside and outside of the rim flange. With the dial indicator set in place securely, turn the wheel one full revolution slowly and record every reading of the indicator.

When the measured runout exceeds the specification and correction by the balancer adjustment is impossible, replace the wheel. If the reading is affected by welding, paint or scratch, it should be ignored.

Lateral runout limit

"a" : 1.40 mm (0.055 in.)

Radial runout limit

"b" : 1.14 mm (0.045 in.)


Metric lug nuts and wheel studs

All models use metric lug nuts and wheel studs.

Metric lug nuts and wheel studs size

: M12 x 1.25

If a broken stud is found, see "WHEEL HUB AND STEERING KNUCKLE" under "FRONT SUSPENSION" for Note and Replacement procedure.



Specifications

Tire size (Standard):

185/65R14 or 195/55R15

Wheel size (Standard):

14X5 1/2 JJ (for 185/65R14) or 15X6 JJ (195/55R15)

Tightening torque

Wheel nut: 85 N·m (8.5 kg-m, 61.5 lb-ft)

NOTE:

- Tire inflation pressure should be checked when tires are cool.
- Specified tire inflation pressure should be found on tire placard or in owner's manual which came with the vehicle.

Diagnosis

Diagnosis Table

Refer to DIAGNOSIS TABLE in this section.

Irregular and/or Premature Wear


Irregular and premature wear has many causes. Some of them are: incorrect inflation pressures, lack of tire rotation, driving habits, improper alignment.

If the following conditions are noted, rotation is necessary:

- Front tire wear is different from rear.
- Uneven wear exists across the tread of any tire.
- Front tire wear is unequal between the right and left.
- Rear tire wear is unequal between the right and left.
- There is cupping, flat spotting, etc.

A wheel alignment check is necessary if following conditions are noted:


- Front tire wear is unequal between the right and left.
- Wear is uneven across the tread of any front tire.
- Front tire treads have scuffed appearance with "feather" edges on one side of tread ribs or blocks.



[A] : Hard Cornering, under inflation or lack of tire rotation

[B] : Incorrect wheel alignment, tire construction not uniform or wheel heavy acceleration

Wear Indicators




Original equipment tires have built-in tread wear indicators (1) to show when they need replacement.

These indicators (1) will appear as 12 mm (0.47 in) wide bands when the tire tread depth becomes 1.6 mm (0.063 in).

When the indicators (1) appear in 3 or more grooves at 6 locations, tire replacement is recommended.

Radial Tire Waddle



Waddle is side to side movement at the front and/or rear of the vehicle. It is caused by the steel belt not being straight within the tire. It is most noticeable at a low speed, 8 to 48 kph (5 to 30 mph).

It is possible to locate the faulty tire by road testing the vehicle. If it is on the rear, the rear end of the vehicle shakes from side to side or “waddles”. To the driver in the seat, it feels as though someone is pushing on the side of vehicle.


If the faulty tire is on the front, waddling is more visual. The front sheet metal appears to be moving back and forth and the driver feels as though he is at the pivot point in vehicle.

Waddle can be quickly diagnosed by using Tire Problem Detector (TPD) and following the equipment manufacture’s recommendations.

If TPD is not available, an alternative method of substituting known-good tire/wheel assemblies can be used as follows, although it takes a longer time.

- 1) Ride vehicle to determine whether the front or rear waddles.
- 2) Install tires and wheels that are known to be good (on similar vehicle) in place of those on waddling end of vehicle. If waddling end cannot be identified, substitute rear ones.
- 3) Road test again. If improvement is noted, reinstall originals one at a time till waddle causal tire is found. If no improvement is noted, install known-good tires in place of all four. Then reinstall originals in the same manner as above.

EQUIPMENT MANUFACTURE'S RECOMMENDATIONS

**Radial Tire Lead/Pull**

“Lead/Pull” is the deviation of the vehicle from a straight path on a level road even with no pressure on the steering wheel.


Lead is usually caused by the following conditions.

- Improper tire and wheel alignment.
- Uneven brake assemblies.
- Tire construction.

The way in which a tire is built can produce lead in a vehicle. An example of this is placement of the belt. Off center belts on radial tires can cause the tire to develop a side force while rolling straight down the road. If one side of the tire has a little larger diameter than the other, the tire will tend to roll to one side. This will develop a side force which can produce vehicle lead.


The procedure in above figure (Lead Diagnosis) should be used to make sure that wheel alignment is not mistaken for tire lead.

- Part of the lead diagnosis procedure is different from the proper tire rotation pattern currently in the owner and service manuals. If a medium to high mileage tire is moved to the other side of the vehicle, be sure to check that ride roughness has not developed
- Rear tires will not cause lead.

Balancing Wheels

There are two types of wheel and tire balance : static and dynamic. Static balance, as shown in left figure, is the equal distribution of weight around the wheel. Wheels that are statically unbalanced cause a bouncing action called tramp. This condition will eventually cause uneven tire wear.

1. Heavy spot wheel tramp	[A] : Before correction
2. Balance weights addition point	[B] : Corrective weights
3. C/L of spindle	



Dynamic balance, as shown in left figure, is the equal distribution of weight on each side of the wheel centerline so that when the tire spins there is no tendency for the assembly to move from side to side. Wheels that are dynamically unbalanced may cause shimmy.

1. Heavy spot wheel shimmy	[C] : Before correction
2. Balance weights addition point	[D] : Corrective weights
3. C/L of spindle	

General Balance Procedures

Deposits of mud, etc. must be cleaned from inside of rim.

WARNING:
Stones should be removed from the tread in order to avoid operator injury during spin balancing and to obtain good balance.

Each tire should be inspected for any damage, then balanced according to equipment manufacturer’s recommendation.

OFF-VEHICLE BALANCING

Most electronic off-vehicle balancers are more accurate than the on-vehicle spin balancers. They are easy to use and give a dynamic (two plane) balance. Although they do not correct for drum or disc unbalance as does on-vehicle spin balancing, this is overcome by their accuracy, usually to within 1/8 ounce.

ON-VEHICLE BALANCING

On-vehicle balancing methods vary with equipment and tool manufacturers. Be sure to follow each manufacturer’s instructions during balancing operation.


WARNING:
Wheel spin should be limited to 35 mph (55 km/h) as indicated on speedometer.
This limit is necessary because speedometer only indicates one-half of actual wheel speed when one drive wheel is spinning and the other drive wheel is stopped.
Unless care is taken in limiting drive wheel spin, spinning wheel can reach excessive speeds. This can result in possible tire disintegration or differential failure, which could cause serious personal injury or extensive vehicle damage.

CAUTION:
For vehicle equipped with ABS, using on-vehicle balancing method with ignition switch ON may set malfunction diagnostic trouble code (DTC) of ABS even when system is in good condition.
Never turn ignition switch ON while spinning wheel.

On-Vehicle Service

Wheel

REMOVAL



- 1) Loosen wheel nuts by approximately 180° (half a rotation).
- 2) Hoist vehicle.
- 3) Remove wheel.

CAUTION:

Never use heat to loosen tight wheel because application of heat to wheel can shorten life of wheel and damage wheel bearings.

INSTALLATION

For installation, reverse removal procedure, noting the followings.

- Wheel nuts must be tightened in sequence and to proper torque to avoid bending wheel or brake disc.

NOTE:


Before installing wheels, remove any build-up of corrosion on wheel mounting surface and brake disc mounting surface by scraping and wire brushing. Installing wheels without good metal-to-metal contact at mounting surfaces can cause wheel nuts to loosen, which can later allow a wheel to come off while vehicle is moving.

Tightening order

: "A"-"B"-"C"-"D"

Tightening torque

Wheel nut (a) : 85 N·m (8.5 kg-m, 61.5 lb-ft)



Tire

MOUNTING AND DISMOUNTING

Use a tire changing machine to mount or dismount tires. Follow equipment manufacturer’s instructions. Do not use hand tools or tire irons alone to change tires as they may damage tire beads or wheel rim.

Rim bead seats should be cleaned with a wire brush or coarse steel wool to remove lubricants, old rubber and light rust. Before mounting or dismounting a tire, bead area should be well lubricated with approved tire lubricant.

After mounting, inflate to specified pressure shown on tire placard so that beads are completely seated.

WARNING:
Do not stand over tire when inflating. Bead may break when bead snaps over rim’s safety hump and cause serious personal injury.
Do not exceed specified pressure when inflating. If specified pressure will not seat beads, deflate, re-lubricate and reinflate.
Over inflation may cause bead to break and cause serious personal injury.

Install valve core and inflate to proper pressure.


REPAIR

There are many different materials and techniques on the market to repair tires. As not all of these work on all types of tires, tire manufacturers have published detailed instructions on how and when to repair tires. These instructions can be obtained from each tire manufacturer.

TIRE ROTATION

To equalize wear, rotate tires according to left figure. Radial tires should be rotated periodically. Set tire pressure.

NOTE:
Due to their design, radial tires tend to wear faster in the shoulder area, particularly in front positions. This makes regular rotation especially necessary.



[A] : 5-tire rotation
NOTE: Applicable to vehicles equipped with 5 tires including spare tire all of which are identical in size.
[B] : 4-tire rotation
LH : Left-hand drive
RH : Right-hand drive

SECTION 4A

FRONT DRIVE SHAFT

CONTENTS

General Description	4A-2	On-Vehicle Service	4A-3
Component	4A-2	Drive Shaft Assembly	4A-4
Diagnosis	4A-2	Tightening Torque Specification	4A-17
Diagnosis Table	4A-2	Required Service Material	4A-17
Drive Shaft Boot Check	4A-2	Special Tool	4A-17

General Description

Component


A ball fixed type constant velocity joint is used on the wheel side of front drive shaft. For A/T vehicle, a tripod type constant velocity joint on the differential side and transfer side. For M/T vehicle, a double offset type constant velocity joint is used on the differential or center shaft side. The drive shaft can slide through the tripod joint or the double offset joint in the extension/contraction direction.

Diagnosis

Diagnosis Table


Condition	Possible Cause	Correction
Abnormal Noise	• Worn or breakage drive shaft joint	Replace.
	• Worn or breakage center bearing	Replace.

Drive Shaft Boot Check



Inspect drive shaft boot for tear.
If even a small tear is noted, replace with new one.


On-Vehicle Service



1. Differential side joint (A/T vehicle) :Apply yellow grease included in spare part to joint.	9. Differential side joint (LH of M/T vehicles) :Apply light black grease included in spare part to joint.	17. Center shaft
2. Boot (Differential, transfer or center shaft side)	10. Dynamic damper (2WD vehicle and left side of 4WD model vehicle)	18. Transfer side joint (RH of A/T 4WD vehicle) :Apply yellow grease included in spare part to joint.
3. Circlip	11. Dynamic damper (LH of M/T vehicle)	19. O-ring :Apply grease 99000-25010 to all round of O-ring.
4. Boot band (Small)	12. Center shaft side joint (RH of M/T vehicle) :Apply light black grease included in spare part to joint.	[A] : Tripod type constant velocity joint
5. Snap ring	13. Wheel side joint :Apply black grease included in spare part to joint.	[B] : Double offset type constant velocity joint
6. Wheel side joint :Apply gray grease included in spare part to joint.	14. Center bearing support	[C] : Center shaft for M/T vehicle
7. Boot (Wheel side)	15. Center bearing	Tightening torque
8. Boot band (Large)	16. Circlip	Do not reuse.


Drive Shaft Assembly

REMOVAL



- 1) Undo caulking ("A") and remove drive shaft nut (1) and washer.


- 2) Hoist vehicle.
- 3) Remove wheel.
- 4) Drain transaxle oil or transfer oil.



- 5) Remove tie rod end split pin (1) and castle nut (2).
- 6) Disconnect tie rod end (3) from steering knuckle (4) by using special tool.

Special tool


(A) : 09913-65210



- 7) (For vehicle without center shaft)
Using tire lever (1), pull out drive shaft joint (2) so as to release snap ring fitting of joint spline at differential side.
(For vehicle with center shaft)
Using plastic hammer (3), drive out drive shaft joint (2) so as to release snap ring fitting of joint spline at center shaft.

[A] : Vehicle without center shaft

[B] : Vehicle with center shaft




- 8) Disconnect front suspension control arm ball stud (1) from steering knuckle (2) after removing ball stud bolt (3) and nut.

9) Remove drive shaft assembly.

CAUTION:

To prevent breakage of boots, be careful not to bring them into contact with other parts, when removing drive shaft assembly.




10) (For vehicle with center shaft)


Remove center bearing support bolts (3) and remove center bearing support (2) with center shaft (1) from differential side gear.

DISASSEMBLY

For tripod joint type drive shaft



1) Remove differential side boot band, then take out tripod joint housing (1).




2) Remove grease from shaft and take off snap ring (1) by using special tool, then pull out spider (2) from shaft.

Special tool

(A) : 09900-06107

CAUTION:


To prevent needle bearing of joint from being degreased, do not wash it if it is to be reused.




- 3) Remove boot band, then pull out differential side boot from shaft.
- 4) Pull out damper through shaft. (if equipped)
- 5) Using chisel (1) and hammer, raise claw (4) and remove big band (2) and small band (3).
- 6) Pull out wheel side boot from shaft.

CAUTION:


- **Disassembly of wheel side joint is not allowed. If noise or damage exists in it, replace it as assembly.**
- **Do not disassemble tripod joint spider. If any malcondition is found in it, replace it as differential side joint assembly.**

For DOJ type drive shaft

- 1) Remove boot band (1) of differential side joint.




- 2) Slide boot (1) toward the center of shaft and remove snap ring (2) from outer race, then take shaft out of outer race (3).



- 3) Wipe off grease and remove circlip (1) used to fix cage by using special tool (A).

Special tool

(A) : 09900-06107




- 4) Draw away cage (1) by using bearing puller (2), and remove boot (3) from shaft.

- 5) Remove boot band, then pull out differential side boot from shaft.
- 6) Pull out damper through shaft. (if equipped)
- 7) Undo boot bands of wheel side joint boot, then pull out boot through shaft.


CAUTION:

Do not disassemble wheel side joint. If any malfunction is found in any joint, replace it as assembly.

For center shaft and center bearing support



- 1) Using hydraulic press (1), draw out center shaft (2) from center bearing.




- 2) Remove bearing support circlip (1).

Special tool

(A) : 09900-06108

- 3) Remove center bearing from center bearing support.

ASSEMBLY**For tripod joint type drive shaft**

Judging from abnormality noted before disassembly and what is found through visual check of component parts after disassembly, prepare replacing parts and proceed to reassembly.

Make sure that wheel side joint assembly (1) and tripod joint housing (2) are washed thoroughly and air dried.

Replace boot(s) (3) with new one(s).

CAUTION:

To ensure full performance of joint as designed, be sure to distinguish between two types of grease in repair set and apply specified volume to respective joint. Refer to the followings for identification of the grease.

“A” : Gray grease


“B” : Yellow grease

Grease volume to be applied

“A” : 80 - 90 g (2.8 - 3.2 oz)


“B” : 90 - 100 g (3.2 - 3.5 oz)

[A] : Wheel side
[B] : Differential side




1) Wash disassembled parts. After washing, dry parts completely by blowing air.

2) Install wheel side boot by positioning it so that one groove (1) in shaft shows.




- 3) Place new wheel side small band (1) onto boot putting band outer end (2) against forward rotation (3) as shown in figure.



- 4) Install wheel side small band (1), putting its lower edge against projected end (4) of boot (3) so that clearance "a" is provided as shown in figure.

2 : Shaft



- 5) Fasten small band by using special tool.


NOTE:

- Small band must not come out of its installation section.
- Be sure to caulk small band securely until complete contact "b" is obtained.


Special tool

(A): 09943-57010


- 6) Apply grease to wheel side joint. Use specified grease in tube in wheel side boot set.



- 7) Install wheel side boot so that its projected section (2) fits in dent section (1) in wheel side joint.




- 8) Place new wheel side big band (1) onto boot putting band outer end (1) against forward rotation (2) as shown in figure.




- 9) Install wheel side big band (1), putting its upper edge against projected end (2) of boot (4) so that clearance "a" is provided as shown in figure.

3 : Wheel side joint



- 10) Fasten boot big band (1) by drawing hooks (2) with special tool and engage hooks (3) in slot and window (4).


Special tool
(A): 09943-57020



- 11) Install dynamic damper (1) on drive shaft according to dimension specified below. (if equipped)

Drive shaft dynamic damper installing position

Applicable drive shaft	Position (Distance "a" between reference position and damper)
RH drive shaft for 2WD vehicle	"a" : 369 - 375 mm (14.5 - 14.8 in.)
LH drive shaft for 2WD vehicle and 4WD vehicle	"a" : 189.5 - 195.5 mm (7.5 - 7.7 in.)




- 12) Set new differential side small band and new differential side boot (1) on shaft temporarily.

Apply grease to tripod joint (2). Use specified grease in tube included in spare parts.

- 13) Install tripod joint spider (3) on shaft, facing its chamfered spline inward (wheel side), then fasten it with new snap ring (4).


Special tool

(A) : 09900-06107



- 14) Apply grease to inside of tripod joint housing (1), joint it with tripod joint and fit boot (2) to tripod joint housing.

After fitting boot, insert screwdriver into boot on tripod joint housing side and allow air to enter boot so that air pressure in boot becomes the same as atmospheric pressure.



- 15) When fixing boot (1) to tripod joint housing (2) with differential side big band (3), adjust so that measured dimensions become as indicated below.

Joint set position when fixing boot


Applicable drive shaft	Position (Distance between reference position and small boot band)
2WD vehicle and left side of 4WD vehicle	"a" : 144.0 - 154.0 mm (5.67 - 6.06 in.)
Right side of 4WD vehicle	"b" : 170.0 - 180.0 mm (6.67 - 7.09 in.)

CAUTION:


To prevent any problem caused by washing solution, do not wash tripod joint except its housing. Degreasing of tripod joint with cloth is allowed.

[A] : Wheel side

[B] : Differential side

**CAUTION:**

- Bend each boot band against forward rotation.
- Do not squeeze or distort boot when fastening it with bands.
Distorted boot caused by squeezing air may reduce its durability.

For DOJ type drive shaft

Judging from abnormality noted before disassembly and what is found though visual check of component parts after disassembly, prepare replacing parts and proceed to reassembly.

Make sure that wheel side joint assembly (1) and DOJ housing (2) are washed thoroughly and air dried.

Replace boot(s) (3) with new one(s).

CAUTION:

To ensure full performance of joint as designed, be sure to distinguish between two types of grease in repair set and apply specified volume to respective joint.

“A” : Black grease

“B” : Black grease (rather light than “A”)

Grease volume to be applied

“A” : 45 - 65 g (1.6 - 2.3 oz)


“B” : 70 - 85 g (2.5 - 3.0 oz)


[A] : Wheel side
[B] : Differential side

- 1) Wash disassembled parts. After washing, dry parts completely by blowing air.
- 2) Apply grease to wheel side joint. Use specified grease in tube included in wheel side boot set.
- 3) Install wheel side boot on shaft, fill up boot inside with grease and then fasten boot with bands (1).

CAUTION:

- Bend each boot band against forward rotation (A).
- Do not squeeze or distort boot when fastening it with bands.
Distorted boot caused by squeezing air may reduce its durability.






- 4) Install dynamic damper (1) on LH drive shaft according to dimension specified below.

Drive shaft dynamic damper installing position

Applicable drive shaft	Position (Distance "a" between reference position and damper)
LH drive shaft for 2WD vehicle	"a": 187 - 193 mm (7.4 - 7.6 in.)
LH drive shaft for 4WD vehicle	"a": 191 - 197 mm (7.5 - 7.7 in.)

- 5) Set new differential side small band and new differential side boot on shaft temporarily.



- 6) Drive in the cage (1) by using a pipe (2).


Drive shaft joint cage installing pipe diameter

"a" : 23.0 mm (0.906 in.) or more

"b" : 32.0 mm (1.260 in.) or less

CAUTION:

Install cage directing smaller outside diameter side to wheel side.




- 7) Install circlip (1) by using special tool (A).

Special tool

(A) : 09900-06107


- 8) Apply grease to entire surface of cage.
Use specified grease in tube included in spare parts.

- 9) Insert cage into joint housing (2) and fit snap ring (1) into groove of joint housing (2).




CAUTION:

Position opening of snap ring "c" so that it will not be lined up with a ball.



10) Apply grease to inside of joint housing (1), and fit boot (2) to joint housing. After fitting boot, insert screwdriver into boot on joint housing side and allow air to enter boot so that air pressure in boot becomes the same as atmospheric pressure.



11) When fixing boot (1) to joint housing (2) with differential side big band (3), adjust so that measurements become as indicated below.

Joint set position when fixing boot

Applicable drive shaft	Position (Distance between reference position and small boot band)
LH drive shaft for 2WD vehicle	"d": 166.5 - 176.5 mm (6.56 - 6.95 in.)
LH drive shaft for 4WD vehicle	"d": 158.5 - 168.5 mm (6.24 - 6.63 in.)
RH drive shaft for both 2WD and 4WD vehicles	"e": 188 - 198 mm (7.40 - 7.80 in.)


CAUTION:

- Bend each boot band against forward rotation (A).
- Do not squeeze or distort boot when fastening it with bands.

Distorted boot caused by squeezing air may reduce its durability.

[A] : Differential side

For center shaft and center bearing support



Install center shaft by reversing removal procedure and noting following points


- When installing bearing support circlip (1), make sure that it fits in circlip groove in center bearing support (2) securely as shown.

INSTALLATION

CAUTION:

- To avoid excessive expansion of boot and consequential disconnection of joint in boot, do not pull differential side joint housing.
- Protect boots from any damage, preventing them from unnecessary contact while installing drive shaft.
- Do not hit joint boot with hammer. Inserting joint only by hands is allowed.
- Make sure that differential side joint is inserted fully and its snap ring is seated as it was.

Install drive shaft assembly by reversing removal procedure and noting following points.



- Tighten each bolt and nut to the specified torque.

Tightening torque

Transaxle oil filler/level and drain plugs (for M/T vehicle)

(a) : 21 N·m (2.1 kg-m, 15.5 lb-ft)

Transaxle fluid drain plug (for A/T vehicle)

(b) : 40 N·m (4.0 kg-m, 29.0 lb-st)

Transfer oil filler/level and drain plugs (for A/T vehicle)

(c) : 23 N·m (2.3 kg-m, 17.0 lb-ft)

Ball stud bolt (d) : 60 N·m (6.0 kg-m, 43.5 lb-ft)

Tie rod end castle nut

(e) : 35 - 50 N·m (3.5 - 5.0 kg-m, 25.5 - 36.0 lb-ft)

Drive shaft nut (f) : 175 N·m (17.5 kg-m, 127.0 lb-ft)

Wheel nut (g) : 85 N·m (8.5 kg-m, 61.5 lb-ft)

Center bearing support bolts

(h) : 55 N·m (5.5 kg-m, 40.0 lb-ft)

- Apply sealant to drain plug (1) and filler/level plug (2) for manual transaxle.

"A" : Sealant 99000-31110

- Apply sealant to drain plug (9) and filler/level plug (10) for transfer. (For A/T 4WD vehicle)

"A" : Sealant 99000-31110

- Fill transaxle or transfer with oil as specified. (Refer to Section 7A1, 7B1 or 7D.)

[A] : For M/T 2WD vehicle
[B] : For A/T vehicle
[C] : For M/T 4WD vehicle
[D] : For A/T 4WD vehicle
[E] : For M/T 2WD vehicle
3. Drain plug (for A/T vehicle)
4. Ball stud bolt
5. Castle nut
6. Drive shaft nut
7. Wheel nut
8. Center bearing support bolt






Tightening Torque Specification

Fastening portion	Tightening torque		
	N•m	kg-m	lb-ft
Transfer oil filler/level and drain plugs (for A/T vehicle)	23	2.3	17.0
Transaxle oil filler/level and drain plugs (for M/T vehicle)	21	2.1	15.5
Transaxle fluid drain plug (for A/T vehicle)	40	4.0	29.0
Ball stud bolt	60	6.0	43.5
Tie rod end castle nut	35 - 50	3.5 - 5.0	25.5 - 36.0
Drive shaft nut	175	17.5	127.0
Wheel nut	85	8.5	61.5
Center bearing support bolts	55	5.5	40.0

Required Service Material

Material	Recommended SUZUKI product (Part Number)	Use
Lithium grease	SUZUKI SUPER GREASE A (99000-25010)	• Center shaft O-ring
Sealant	SUZUKI BOND NO. 1215 (99000-31110)	• Oil drain and filler plug for manual transaxle or transfer

Special Tool

 <p>09900-06107 Snap ring pliers (Open type)</p>	 <p>09900-06108 Snap ring pliers (Closing type)</p>	 <p>09913-65210 Tie-rod end remover</p>	 <p>09943-57010 Band compressor</p>
 <p>09943-57020 Band compressor</p>			

SECTION 4B

PROPELLER SHAFTS

CONTENTS

General Description	4B-1	Propeller Shafts	4B-2
On-Vehicle Service.....	4B-2	Tightening Torque Specification	4B-3

4B


General Description

Most universal joints require no maintenance. They are lubricated for life and can not be lubricated on the vehicle.

If a universal joint becomes noisy or worn, it must be replaced.

The propeller shaft is a balanced unit. Handle it carefully so that balance can be maintained.

A viscous coupling is used for the coupling system which distributes an optimum driving force to the front and rear wheels according to the driving conditions. It is located at the center of the propeller shaft.




- | |
|-------------------------|
| 1. Propeller shaft No.1 |
| 2. Propeller shaft No.2 |
| 3. Viscous coupling |

On-Vehicle Service

Propeller Shafts

REMOVAL


- 1) Hoist vehicle.
- 2) Before removing propeller shaft, give match marks (2) on joint flange and propeller shaft as shown.
- 3) Separate No.2 propeller shaft (3) from rear differential flange.
- 4) Remove No.1 propeller shaft (1) from transfer output flange.
- 5) Remove propeller shaft center support brackets (4) from vehicle body. (Bracket and No.1 & No.2 shaft are removed in one without separation.) Use care not to drop it.



INSPECTION

- 1) Check propeller shaft connecting bolts for looseness. If looseness is found, tighten to specified torque.
- 2) Check propeller shaft joints for wear, play and damage. If any defect is found, replace.
- 3) Check propeller shaft center support for biting of foreign matter, crack, abnormal noise and damage. If any defect is found, replace.

INSTALLATION



1) Reverse removal procedure to install propeller shaft, noting following point.

- When installing propeller shaft, align the match marks (2). Otherwise, vibration may occur during driving.
- Use following specification to torque each bolt and nut.

Tightening torque

Propeller shaft No.1 bolts

(a): 23 N·m (2.3 kg-m, 17.0 lb-ft)

Propeller shaft No.2 bolts

(b): 23 N·m (2.3 kg-m, 17.0 lb-ft)

Center coupling bolts

(c): 23 N·m (2.3 kg-m, 17.0 lb-ft)

Center support nuts

(d): 50 N·m (5.0 kg-m, 36.5 lb-ft)

1.	Propeller shaft No.1
3.	Propeller shaft No.2
4.	Propeller shaft center support

Tightening Torque Specification

Fastening portion	Tightening torque		
	N·m	kg-m	lb-ft
Center support nuts	50	5.0	36.5
Propeller shaft No.1 bolts	23	2.3	17.0
Propeller shaft No.2 bolts	23	2.3	17.0
Center coupling bolts	23	2.3	17.0

SECTION 4C

REAR DRIVE SHAFT

CONTENTS


General Description	4C-1	Tightening Torque Specifications	4C-4
On-Vehicle Service.....	4C-1	Required Service Material	4C-4




4C

General Description


A ball fixed type constant velocity joint (BJ) is used on the wheel side of rear drive shaft and a double offset type constant velocity joint (DOJ) on the differential side.

On-Vehicle Service




 1. Wheel side joint (BJ): Apply light black grease included in spare part to joint.	4. Drive shaft	7. Circlip
2. Boot band	 5. Differential side joint (DOJ): Apply light black grease included in spare part to joint.	8. Snap ring
3. Boot	6. Snap ring	 Do not reuse.


REMOVAL



- 1) Remove caulking of drive shaft nut (2) and then remove drive shaft nut and washer (1).



- 2) Remove tire and drain rear differential oil.
- 3) Hoist vehicle.
- 4) Remove parking brake wire mounting bolt (1), rear control rod outer bolts (2) and rear trailing rod rear bolt (3).



- 5) Install used clamp (2) to differential side joint (1) and pull out drive shaft from rear differential gear case by using tire lever (3).
- 6) Remove drive shaft.

INSTALLATION

Install drive shaft assembly by reversing removal procedure and noting following points.

- Be sure to use new drive shaft nut.

Tightening torque

Rear control rod outer bolt (a):

90 N·m (9.0 kg-m, 65.0 lb-ft)

Rear trailing rod rear bolt (b):

90 N·m (9.0 kg-m, 65.0 lb-ft)


Drive shaft nut (c):

175 N·m (17.5 kg-m, 126.5 lb-ft)

- Clean rear wheel bearing oil seal and then apply grease. Replace it if required.

“A”: Grease 99000-25010

- Apply sealant to drain plug for rear differential gear case.
- Fill rear differential gear case with oil as specified, refer to SECTION 7F.



CAUTION:

- **Protect oil seals and boots from any damage, preventing them from unnecessary contact while installing drive shaft.**
- **Do not hit joint boot with hammer. Inserting joint only by hands is allowed.**
- **Make sure that differential side joint is inserted fully and its snap ring is seated as it was.**

DISASSEMBLY

Refer to “Drive Shaft Assembly” in Section 4A.

INSPECTION

Refer to “Drive Shaft Assembly” in Section 4A.

REASSEMBLY

Refer to "Drive Shaft Assembly" in Section 4A.


"A": Light black grease (35 - 55 g/1.2 - 1.9 oz)

"B": Light black grease (50 - 70 g/1.8 - 2.5 oz)

Fixing boot band, adjust so that measurements become as indicated below.

Joint set position when fixing boot

"a": 143.1 - 153.1 mm (5.63 - 6.03 in.) for left side



[A]: Wheel side

[B]: Differential side

Tightening Torque Specifications

Fastening portion	Tightening torque		
	N•m	kg-m	lb-ft
Rear differential oil drain plug	21	2.1	15.0
Rear differential oil level/filler plug	21	2.1	15.0
Rear control rod outer bolt	90	9.0	65.0
Rear trailing rod rear bolt	90	9.0	65.0
Drive shaft nut	175	17.5	126.5

Required Service Material

Material	Recommended SUZUKI product (Part Number)	Use
Lithium grease	SUZUKI SUPER GREASE A (99000-25010)	Rear wheel bearing
Sealant	SUZUKI BOND NO. 1215 (99000-31110)	Differential oil drain plug and level/filler plug

SECTION 5

BRAKES

NOTE:

All front fasteners are important attaching parts in that they could affect the performance of vital parts and systems, and/or could result in major repair expense. They must be replaced with one of same part number or with an equivalent part if replacement becomes necessary. Do not use a replacement part of lesser quality or substitute design. Torque values must be used as specified during reassembly to assure proper retention of all parts. There is to be no welding as it may result in extensive damage and weakening of the metal.

CONTENTS

5

General Description	5-2	Air Bleeding of Brake System	5-15
Diagnosis	5-4	Front Brake	5-17
Road Testing Brakes.....	5-4	Brake pad.....	5-17
Brake Fluid Leaks	5-4	Caliper assembly.....	5-19
Substandard or Contaminated		Brake disc	5-23
Brake Fluid	5-4	Rear Brake	5-25
Diagnosis Table	5-5	Brake drum.....	5-25
Brake Pedal Free Height Inspection	5-8	Brake shoe	5-29
Brake Pedal Play Inspection	5-8	Wheel cylinder.....	5-30
Stop Light Switch Adjustment	5-8	Brake back plate	5-32
Excessive Pedal Travel Inspection	5-9	Master Cylinder.....	5-34
Front Brake Pad Inspection.....	5-9	Master cylinder reservoir.....	5-34
Brake Disc Inspection	5-9	Master cylinder assembly.....	5-35
Parking Brake Inspection and		Brake Booster	5-40
Adjustment	5-10	Brake Hose/Pipe	5-43
Booster Operation Inspection.....	5-11	Front brake hose/pipe	5-43
Fluid Pressure Test (If Equipped		Rear brake hose/pipe.....	5-45
with LSPV)	5-12	Parking brake cable	5-47
Master Cylinder and Brake Fluid		LSPV (Load Sensing Proportioning	
Level Inspection	5-14	Valve) Assembly (If Equipped).....	5-49
Brake Hose and Pipe Inspection.....	5-15	Required Service Material	5-51
On-Vehicle Service.....	5-15	Special Tool.....	5-52

General Description

When the foot brake pedal is depressed, hydraulic pressure is developed in the master cylinder to actuate pistons (two in front and four in rear).

The master cylinder is a tandem master cylinder. Brake pipes are connected to the master cylinder and they make two independent circuits. One connects front right & rear left brakes and the other connects front left & rear right brakes.


The load sensing proportioning valve (LSPV) or the proportioning valve (P valve) is included in these circuits between the master cylinder and the rear brake for the vehicle without ABS.

In this brake system, the disc brake type is used for the front wheel brake and a drum brake type (leading/trailing shoes) for the rear brake.

The parking brake system is mechanical. It applies brake force to only rear wheels by means of the cable and mechanical linkage system. The same brake shoes are used for both parking and foot brakes.

NOTE:

The figures shows left-hand steering vehicle.



[A] : For vehicle without ABS	3. Secondary side	7. LSPV (Load Sensing Proportioning valve)
[B] : For vehicle with ABS	4. Primary side	8. P (Proportioning) valve
1. Brake booster	5. 4-way joint	9. 5-way joint
2. Master cylinder	6. ABS hydraulic unit/control module assembly	A: Forward

Diagnosis

Road Testing Brakes

Brakes should be tested on dry, clean, smooth and reasonably level roadway which is not crowned. Road test brakes by making brake applications with both light and heavy pedal forces at various speeds to determine if the vehicle stops evenly and effectively. Also drive vehicle to see if it leads to one side or the other without brake application. If it does, check the tire pressure, front end alignment and front suspension attachments for looseness. See diagnosis table for other causes.

Brake Fluid Leaks

Check the master cylinder fluid levels. While a slight drop in reservoir level does result from normal lining wear, an abnormally low level indicates a leak in the system. In such a case, check the entire brake system for leakage. If even a slight evidence of leakage is noted, the cause should be corrected or defective parts should be replaced.

Substandard or Contaminated Brake Fluid

Improper brake fluid, mineral oil or water in the fluid may cause the brake fluid to boil or the rubber components in the hydraulic system to deteriorate.

If primary piston cups are swollen, then rubber parts have deteriorated. This deterioration may also be evidenced by swollen wheel cylinder piston cups on the drum brake wheels.

If deterioration of rubber is evident, disassemble all hydraulic parts and wash with alcohol. Dry these parts with compressed air before assembly to keep alcohol out of the system. Replace all rubber parts in the system, including hoses. Also, when working on the brake mechanisms, check for fluid on the linings.

If excessive fluid is found, replace the pads.

If master cylinder piston seals are satisfactory, check for leakage or excessive heat conditions. If leakage is not found, drain fluid, flush with brake fluid, refill and bleed system.

The system must be flushed if there is any doubt as to the grade of fluid in the system or if fluid has been used which contained parts that have been subjected to contaminated fluid.


Diagnosis Table

Condition	Possible Cause	Correction
Not enough braking force	Brake oil leakage from brake lines	Locate leaking point and repair.
	Brake disc or pads stained with oil	Clean or replace.
	Overheated brakes	Determine cause and repair.
	Poor contact of shoes on brake drum	Repair for proper contact.
	Brake shoes linings stained with oil or wet with water	Replace.
	Badly worn brake pad linings	Replace.
	Defective wheel cylinders	Repair or replace.
	Malfunctioning caliper assembly	Repair or replace.
	Air in system	Bleed system.
	Maladjusted sensor spring length of LSPV, if equipped	Check or adjust.
	Broken sensor spring of LSPV, if equipped	Replace.
	Defective LSPV, if equipped	Replace.
	Malfunctioning ABS (Antilock brake system), if equipped	Check system and replace as necessary.
Brake pull (Brakes not working in unison)	Pad linings and/or shoe linings are wet with water or stained with oil in some brakes	Replace.
	Drum-to-shoe clearance out of adjustment in some brakes (Malfunctioning auto adjusting mechanism)	Check for inoperative auto adjusting mechanism.
	Disc and/or drum is out of round in some brakes	Replace.
	Wheel tires are inflated unequally	Inflate equally.
	Malfunction in wheel cylinders	Repair or replace.
	Disturbed front end alignment	Adjust as prescribed.
	Unmatched tires on same axle	Tires with approximately the same amount of tread should be used on the same axle.
	Restricted brake pipes or hoses	Check for soft hoses and damaged lines. Replace with new hoses and new double-walled steel brake tubing.
	Malfunctioning caliper assembly	Check for stuck or sluggish pistons and proper lubrication of caliper slide bush. Caliper should slide.
	Loose suspension parts	Check all suspension mountings.
Noise (high pitched squeak without brake applied)	Loose calipers	Check and torque bolts to specifications.
	Front lining worn out	Replace linings.
Rear brake locked prematurely	Contact wear indicator to brake disc	Replace pads.
	Maladjusted sensor spring length of LSPV, if equipped	Check or adjust.
	Malfunction LSPV assembly, if equipped	Replace assembly.

Condition	Possible Cause	Correction
Excessive pedal travel (Pedal stroke too large)	Partial brake system failure	Check brake systems and repair as necessary.
	Insufficient fluid in master cylinder reservoirs	Fill reservoirs with approved brake fluid. Check for leaks and air in brake system. Check warning light. Bleed system if required.
	Air in system (soft/spongy pedal)	Bleed system.
	Rear brake system not adjusted (malfunctioning auto adjusting mechanism)	Repair auto adjusting mechanism. Adjust rear brakes.
	Bent brake shoes	Replace brake shoes.
	Worn rear brake shoes	Replace brake shoes.
Brake locked (For vehicle equipped with ABS)	Malfunctioning ABS	Check system referring to Section 5B.
Dragging brakes (A very light drag is present in all brakes immediately after pedal is released)	Master cylinder pistons not returning correctly	Replace master cylinder.
	Restricted brake pipes or hoses	Check for soft hoses or damaged pipes and replace with new hoses and/or new double-walled steel brake piping.
	Incorrect parking brake adjustment on rear brakes	Check and adjust to correct specifications.
	Weakened or broken return springs in the brake	Replace.
	Sluggish parking brake cables or linkage	Repair or replace.
	Wheel cylinder or caliper piston sticking	Repair as necessary.
	Badly worn piston seal in caliper	Replace piston seal.
	Improper brake pedal free height	Check brake pedal free height.
Pedal pulsation (Pedal pulsates when depressed for braking)	Damaged or loose wheel bearings	Replace wheel bearings.
	Distorted steering knuckle or rear wheel spindle	Replace knuckle or rear wheel spindle.
	Excessive disc lateral runout	Check per instructions. If not within specifications, replace or machine disc.
	Parallelism between pad and disc not within specifications	Check per instructions. If not within specifications, replace or machine disc.
	Rear drums out of round	Check runout. Repair or replace drum as necessary.
Braking noise	Glazed shoe linings, or foreign matters stuck to linings	Repair or replace shoe linings.
	Worn or distorted shoe linings	Replace shoe lining (or pad).
	Loose front wheel bearings	Replace wheel bearing.
	Distorted backing plates or loose mounting bolts	Replace or retighten securing bolts.
	Contact wear indicator to brake disc	Replace pads.

Condition	Possible Cause	Correction
Brake warning lamp lights after engine start	Parking brake applied	Release parking brake and check that brake warning lamp turns off.
	Insufficient amount of brake fluid	Add brake fluid.
	Brake fluid leaking from brake line	Investigate leaky point, correct it and add brake fluid.
	Brake warning lamp circuit faulty	Repair circuit.
	Malfunctioning EBD system, if equipped with ABS.	Check system referring to Table-E of Section 5B.
Brake warning lamp turns on when brake is applied	Brake fluid leaking from brake line	Investigate leaky point, correct it and add brake fluid.
	Insufficient amount of brake fluid	Add brake fluid.
Brake warning lamp fails to turn on even when parking brake is applied	Brake warning lamp circuit faulty	Replace bulb or repair circuit.
ABS warning lamp turns on after engine start (If equipped)	Malfunctioning ABS	Check system referring to DIAGNOSIS of Section 5B.
ABS warning lamp turns on when brake is applied (If equipped)	Malfunctioning ABS	Check system referring to DIAGNOSIS of Section 5B.
ABS warning lamp does not turn on for 2 sec. after ignition switch has turned ON	Bulb burnt out	Replace bulb.
	Malfunctioning ABS	Check system referring to DIAGNOSIS of Section 5B.
ABS warning lamp flashes	New ABS hydraulic unit/control module assembly installed.	Perform "ABS Hydraulic Unit Operation Check".

Brake Pedal Free Height Inspection




- 1) Check brake pedal free height.
If it is not within specification, check and adjust following item 1) and 2).

Brake pedal free height "a" from dash silencer
222 – 242 mm (8.74 – 9.53 in.)

- 2) Check measurement between booster mounting surface and center of clevis pin hole. When booster push rod clevis has been reinstalled, it is important that the measurement is adjusted (refer to BRAKE BOOSTER INSPECTION AND ADJUSTMENT).
- 3) Check stop light switch position. Adjust it if it is out of specification.
 - pedal for dent
 - brake booster for installation
 - brake booster push rod for length

Brake Pedal Play Inspection




Pedal play should be within specification below. If out of specification, check stop light switch for proper installation position and adjust if necessary.

Also check pedal shaft bolt and master cylinder pin installation for looseness and replace if defective.

Brake pedal play
"a" : 1 - 8 mm (0.04 - 0.31 in.)

Stop Light Switch Adjustment



Adjustment should be made as follows. Pull up brake pedal toward you and while holding it there, adjust switch position so that clearance between end of thread and brake pedal is as specified. Then lock it by turning clockwise.

Clearance between brake pedal and stop light switch
"a" : 0.5 - 1.5 mm (0.02 - 0.06 in.)

Excessive Pedal Travel Inspection


- 1) Start engine.
- 2) Depress brake pedal a few times.
- 3) With brake pedal depressed with approximately 300 N (30 kg, 66 lbs) load, measure brake pedal to wall (dash panel silencer) clearance "a".

If clearance "a" is less than specification, the most possible cause is either rear brake shoes are worn out beyond limit or air is in lines.

Should clearance "a" remain less than specification even after replacement of brake shoes and bleeding of system, other possible but infrequent cause is malfunction of rear brake shoe adjusters or booster push rod length out of adjustment.

- Bleed brake system. Refer to "AIR BLEEDING OF BRAKE SYSTEM".
- Remove brake drums for adjuster inspection. (Refer to "REAR BRAKE".) If defective, correct or replace.

**Clearance "a" between brake pedal and dash panel silencer
over 110 mm (4.33 in.)**




Front Brake Pad Inspection

Inspect pad linings (1) periodically according to maintenance schedule whenever wheels are removed (for tire rotation or other reason). Take a look through each end (or hole) of caliper and check lining thickness of outside and inside pads.

If lining is worn and its thickness ("a" in figure) is less than limit, all pads must be replaced at the same time.

Front brake pad thickness "a" (lining thickness)
Standard : 10 mm (0.40 in.)
Limit : 2 mm (0.08 in.)




Brake Disc Inspection

Refer to "FRONT BRAKE" for inspection point and procedure.

Parking Brake Inspection and Adjustment

INSPECTION



Hold center of parking brake lever grip and pull it up with 200 N (20 kg, 44 lbs) force.

With parking brake lever pulled up as shown, count ratchet notches. There should be 3 to 5 notches.

Also, check if both right and left rear wheels are locked firmly.

To count number of notches easily, listen to click sounds that ratchet makes while pulling parking brake lever without pressing its button.

One click sound corresponds to one notch.

If number of notches is out of specification, adjust cable referring to adjustment procedure so as to obtain specified parking brake stroke.

NOTE:

Check tooth tip of each notch for damage or wear.

If any damage or wear is found, replace parking brake lever.

ADJUSTMENT

NOTE:

Make sure for the following conditions before cable adjustment.

- No air is trapped in brake system.
- Brake pedal travel is proper.
- Brake pedal has been depressed a few times with about 300 N (30 kg, 66 lbs) load.
- Parking brake lever (1) has been pulled up a few times with about 200 N (20 kg, 44 lbs) load.
- Rear brake shoes are not worn beyond limit, and self adjusting mechanism operates properly.

After confirming that above conditions are all satisfied, adjust parking brake lever stroke by loosening or tightening adjust nut (3).


NOTE:

Check brake drum for dragging after adjustment.

2. Brake cable

Parking brake stroke (When lever is pulled up at 200 N (20 kg, 44 lbs)

: 3 to 5 notches



Booster Operation Inspection


There are two ways to perform this inspection, with and without a tester. Ordinarily, it is possible to roughly determine its condition without using a tester.

NOTE:


For this check, make sure that no air is in hydraulic line.

CHECK AIR TIGHTNESS

- 1) Start engine.
- 2) Stop engine after running for 1 to 2 minutes.
- 3) Depress brake pedal several times with the same load as in ordinary braking and observe pedal travel. If pedal goes down deep the first time but its travel decreases as it is depressed the second and more times, air tightness is obtained.



1. 1st
2. 2nd
3. 3rd



- 4) If pedal travel doesn't change, air tightness isn't obtained.


NOTE:


If defective, inspect vacuum lines and sealing parts, and replace any faulty part. When this has been done, repeat the entire test.

1. 1st, 2nd, 3rd

CHECK OPERATION


- 1) With engine stopped, depress brake pedal several times with the same load and make sure that pedal travel doesn't change.






- 2) Start engine while depressing brake pedal. If pedal travel increases a little, operation is satisfactory. But no change in pedal travel indicates malfunction.

CHECK AIR TIGHTNESS UNDER LOAD



- 1) With engine running, depress brake pedal. Then stop engine while holding brake pedal depressed.

H: Hold



- 2) Hold brake pedal depressed for 30 seconds. If pedal height does not change, condition is good. But it isn't if pedal rises.



H: Hold
T: 30 seconds

Fluid Pressure Test (If Equipped with LSPV)

Test procedure for LSPV assembly is as follows.

Before testing, confirm the following.

- Fuel tank is filled with fuel fully.
- Vehicle is equipped with spare tire, tools, jack and jack handle.



- 1) Place vehicle on level floor and set 200 kg (442 lbs) weight slowly on axle housing center.
- 2) Install special tool to front and rear brake.

NOTE:

Pressure gauge should be connected to breather of front (left side brake) and rear (right side brake).

After testing front left side and rear right side, test front right side and rear left side in the same way.

Special tool**Front brake**

(A) : 09956-02310

(B) : 09952-36320

(C) : 09360-10040 (Union bolt as spare part)

(D) : 09161-10009 (Washer as spare part)

(F) : 55473-82030 (Air bleeder plug as a spare part)

Rear brake

(A) : 09956-02310

(E) : 09952-36310

(F) : 55473-82030 (Air bleeder plug as a spare part)

NOTE:

Special tool (B) or (E) is used instead of thread diameter 10 mm attachment of special tool (A).


[A]: Front
[B]: Rear
1. Air bleeder plug
2. Weight

- 3) Depress brake pedal gradually till fluid pressure of front brake becomes as specified below and check corresponding pressure of rear brake then. It should be within specification given below.

Front brake	Rear brake
5,000 kPa	4,300 – 4,700 kPa
50 kg/cm ²	43 – 47 kg/cm ²
711 psi	611 – 668 psi

- 4) As done above, apply 100 kg/cm² pressure to front brake and check that rear brake pressure then is within specification as given below.

Front brake	Rear brake
10,000 kPa	5,800 – 6,200 kPa
100 kg/cm ²	58 – 62 kg/cm ²
1,422 psi	825 – 882 psi



- 5) If rear brake pressure is not within specification, adjust it by changing bolt "A" tightening position as follows.

Tightening torque


LSPV nut (a) : 23 N·m (2.3 kg-m, 17.0 lb-ft)

- If rear brake pressure is higher than specification, move bolt "A" rearward and if it is lower, forward.
- Repeat steps 3) - 5) until rear brake pressure is within specification.
- After adjustment, be sure to torque nut to specification.

1. LSPV lever
2. LSPV spring
3. LSPV stay

- 6) Upon completion of fluid pressure test, bleed brake system and perform brake test.

Master Cylinder and Brake Fluid Level Inspection



- 1) Check master cylinder and reservoir for crack, damage and brake fluid leakage. If any faulty condition exists, correct or replace.
- 2) Check that brake fluid level is between MAX and MIN marks on reservoir.

NOTE:

Be sure to use particular brake fluid either as indicated on reservoir cap of that vehicle or recommended in owner's manual which comes along with that vehicle. Use of any other fluid is strictly prohibited.

Fluid level should be between MIN and MAX lines marked on reservoir.

When brake warning lamp lights sometimes during driving, replenish fluid to MAX level.


When fluid decreases quickly, inspect brake system for leakage. Correct leaky points and then refill to specified level.

CAUTION:

Do not use shock absorber fluid or any other fluid which contains mineral oil. Do not use a container which has been used for mineral oil or a container which is wet from water. Mineral oil will cause swelling and distortion of rubber parts in hydraulic brake system and water mixed into brake fluid will lower fluid boiling point. Keep all fluid containers capped to prevent contamination.

Brake Hose and Pipe Inspection

HOSE



The brake hose assembly should be checked for road hazard damage, for cracks and chafing of outer cover, for leaks and blisters. A light and mirror may be needed for an adequate inspection. If any of above conditions are observed on brake hose, it is necessary to replace it.

PIPE


Inspect the pipe for damage, cracks, dents and corrosion. If any defect is found, replace it.

On-Vehicle Service

Air Bleeding of Brake System

CAUTION:

Brake fluid is extremely damaging to paint. If fluid should accidentally touch painted surface, immediately wipe fluid from paint and clean painted surface.




Bleeding operation is necessary to remove air whenever it entered hydraulic brake system.

Hydraulic lines of brake system are based on the diagonal split system. When a brake pipe or hose was disconnected at the wheel, bleeding operation must be performed at both ends of the line of the removed pipe or hose. When any joint part of the master cylinder of other joint part between the master cylinder and each brake (wheel) was removed, the hydraulic brake system must be bled at all 4 wheel brakes.


NOTE:

Perform bleeding operation starting with wheel cylinder farthest from master cylinder and then at front caliper of the same brake line. Do the same on the other brake line.


1. Right brake caliper	4. Left wheel cylinder
2. Left brake caliper	A : FRONT
3. Right wheel cylinder	B : REAR




- 1) Fill master cylinder reservoir with brake fluid and keep at least one-half full of fluid during bleeding operation.



- 2) Remove bleeder plug cap.
Attach a vinyl tube (1) to bleeder plug, and insert the other end into container (2).



- 3) Depress brake pedal several times, and then while holding it depressed, loosen bleeder plug about one-third to one-half turn.
- 4) When fluid pressure in cylinder is almost depleted, retighten bleeder plug.
- 5) Repeat this operation until there are no more air bubbles in hydraulic line.




- 6) When bubbles stop, depress and hold brake pedal and tighten bleeder plug.

Tightening torque

Front bleeder plug : 10.0 N·m (1.0 kg-m, 7.5 lb-ft)


Rear bleeder plug : 8.0 N·m (0.8 kg-m, 6.0 lb-ft)

- 7) Then attach bleeder plug cap.



- 8) After completing bleeding operation, apply fluid pressure to pipe line and check for leakage.
- 9) Replenish fluid into reservoir up to specified level.
- 10) Check brake pedal for sponginess. If found spongy, repeat entire procedure of bleeding.

Front Brake





[A]. Identification mark of NISSIN made caliper	9. Bleeder plug cap
1. Brake caliper carrier	10. Pad spring
2. Boot	11. Anti noise shim
3. Caliper	12. Caliper pin bolt
4. Disc brake piston	13. Brake disc
5. Piston seal : Apply grease included in spare parts.	14. Slide pin : Apply grease included in spare parts.
6. Cylinder boot : Apply grease included in spare parts.	Tightening torque
7. Brake pad	Do not reuse.
8. Bleeder plug	

Brake pad

REMOVAL

- 1) Loosen wheel nuts and with vehicle lifted up, remove wheels.
- 2) Remove caliper pin bolts (1).





- 3) Remove caliper (1) from caliper carrier (2).

NOTE:


Hang removed caliper (1) with a wire hook (4) or the like so as to prevent brake hose from bending and twisting excessively or being pulled.

Don't operate brake pedal with brake pads removed.

- 4) Remove brake pads (3).

INSPECTION

Check pad lining for wear. When wear exceeds limit, replace with new one.



CAUTION:

Never polish pad lining with sandpaper. If lining is polished with sandpaper, hard particles of sandpaper will be deposited in lining and may damage disc. When pad lining requires correction, replace it with a new one.

Brake pad thickness (lining thickness)

Standard : 10 mm (0.40 in.)


Limit : 2 mm (0.08 in.)

NOTE:

When pads are removed, visually inspect caliper for brake fluid leak. Correct leaky point, if any.


INSTALLATION

- 1) Set brake pad springs (1) and shim (2) and install brake pads (3).



NOTE:

For right side brake, install pad with wear indicator (4) to vehicle center side.



- 2) Install caliper and tighten caliper pin bolts (1) to specified torque.


Tightening torque

Caliper pin bolts (a) :

22 N·m (2.2 kg-m, 16.0 lb-ft) for NISSIN made caliper

35 N·m (3.5 kg-m, 25.5 lb-ft) for other than NISSIN made caliper

- 3) Tighten wheel temporarily and lower lift.



4) Tighten wheel nuts to specified torque.

Tightening torque


Wheel nuts (a) : 85 N·m (8.5 kg-m, 61.5 lb-ft)

5) After completion of installation, check for brake effectiveness.

Caliper assembly


REMOVAL

- 1) Hoist vehicle and remove wheel.
- 2) Loosen flexible hose joint bolt (1) a little at caliper.



CAUTION:

Be careful not to twist flexible hose while loosening the bolt.




- 3) Remove caliper pin bolts (1).
- 4) Remove caliper from caliper carrier.
- 5) Disconnect flexible hose from caliper using care not to twist it. As this will allow brake fluid to flow out of flexible hose, have a container ready beforehand.

DISASSEMBLY

CAUTION:


Clean around caliper with brake fluid before disassembly.



- 1) Remove piston with air blown into flexible hose bolt installation hole.

WARNING:


Do not apply too highly compressed air which will cause piston to jump out of cylinder. Place a cloth (1) to prevent piston from damage. It should be taken out gradually with moderately compressed air. Do not place your fingers in front of piston when using compressed air.



- 2) Remove cylinder boot (1).

CAUTION:

Use care not to cause damage to cylinder boot.



- 3) Remove piston seal using a thin blade like a thickness gauge, etc.

CAUTION:


Be careful not to damage inside (bore side) of cylinder.

- 4) Remove bleeder plug and cap from caliper.


INSPECTION

Pin boot and cylinder boot

Check boots for breakage, crack and damage. If defective, replace.



Piston seal




Excessive or uneven wear of pad lining may indicate unsmooth return of piston.

In such case, replace rubber seal.

ASSEMBLY


Assemble parts in reverse order of disassembly, observing the following instructions.




CAUTION:

- Wash each part cleanly before installation in the same fluid as the one used in master cylinder reservoir.
- Never use other fluid or thinner.
- Before installing piston seal or cylinder boot to cylinder, apply grease to them.
- Install a new piston seal into groove in cylinder securely making sure that it is not twisted.
- Before installing caliper to carrier, install slide pin with grease applied into caliper carrier hole and check for its smooth movement in thrust direction.
- After reassembling brake lines, bleed air from them.

- Install piston seal, boot and piston to caliper referring to the following instructions.




- a) Replace with a new piston seal (1) at every overhaul. After applying grease, fit piston seal (1) into groove in cylinder taking care not to twist it.




- b) Before inserting piston (2) into cylinder, apply grease to boot (1) and install it onto piston as shown.

“A” : 1-grooved side directed cylinder side

“B” : 2-grooved side directed pad side



- c) Fit boot as it is in figure into boot groove in cylinder with fingers.



- d) Insert piston into cylinder by hand and fit boot in boot groove in piston.

NOTE:

Check that boot is fitted in boot groove securely all around piston.

INSTALLATION

- 1) Apply grease to slide pin, then install caliper to caliper carrier.

- 2) Torque caliper pin bolts (1) to specification.

NOTE:


Make sure that boots are fit into groove securely.

Tightening torque


Caliper pin bolts (a) :

22 N·m (2.2 kg-m, 16.0 lb-ft) for NISSIN made caliper

35 N·m (3.5 kg-m, 25.5 lb-ft) for other than NISSIN made caliper



- 3) Connect caliper to flexible hose.



- 4) Torque flexible hose joint bolt to specification.

Tightening torque

Flexible hose joint bolt (b) : 23 N·m (2.3 kg-m, 17.0 lb-ft)

WARNING:

Make sure that flexible hose is not twisted when tightening joint bolt. If it is twisted, reconnect it using care not to twist it.

- 5) Lower hoist.
- 6) Torque wheel nuts to specifications.

Tightening torque


Wheel nuts : 85 N·m (8.5 kg-m, 61.5 lb-ft)

- 7) After completing installation, fill reservoir with brake fluid and bleed air from brake system. Perform brake test and check each installed part for oil leakage.

Brake disc

REMOVAL

- 1) Hoist vehicle and remove wheel.
- 2) Remove caliper assembly by removing caliper carrier bolts (2 pcs)



CAUTION:


During removal, be careful not to damage brake flexible hose and not to depress brake pedal.

NOTE:


Hang removed caliper with a wire hook or the like so as to prevent brake hose from bending and twisting excessively or being pulled.

Don't operate brake pedal with brake pads removed.

- 3) Remove brake disc screw.
- 4) Pull brake disc off by using 8 mm bolts (1) (2 pcs).



INSPECTION



- Using magnetic stand and with dial gauge positioned at about 10 mm (0.39 in.) inward from periphery of disc, measure deflection of disc.

If limit value is exceeded, replace correct or replace.


Disc deflection

Limit : 0.10 mm (0.004 in.) max.

Special tool

(A) : 09900-20606

(B) : 09900-20701



- Using micrometer, measure thickness of brake disc. If it is less than limit, replace brake disc.

Brake disc thickness

Standard : 20.0 mm (0.79 in.)


Limit : 18.0 mm (0.71 in.)

INSTALLATION

- 1) Install disc to wheel hub.
- 2) Install brake disc screw.
- 3) Install caliper assembly to steering knuckle.
- 4) Torque caliper carrier bolts to specification.

Tightening torque


Caliper carrier bolts (a) : 85 N·m (8.5 kg-m, 61.5 lb-ft)



- 5) Torque front wheel nuts to specification.


Tightening torque

Wheel nuts (b) : 85 N·m (8.5 kg-m, 61.5 lb-ft)



- 6) Upon completion of installation, perform brake test.

Rear Brake




<div> </div> 1. Brake back plate : Apply water tight sealant (99000-31090) to joint seam of brake back plate	9. Shoe hold down pin
2. Brake shoe	10. Blank
3. Parking brake shoe lever	11. Parking lever retainer
4. Brake strut	<div> </div> 12. Wheel cylinder : Apply brake fluid to piston cup
5. Quadrant spring	13. Bleeder plug cap
6. Shoe return spring	14. Rubber plug
7. Antirattle spring	15. Rubber plug
8. Shoe hold down spring	<div> </div> Tightening torque


Brake drum

REMOVAL


- 1) Hoist vehicle and remove wheel.
- 2) Remove brake drum screw (1).




2. Brake drum



- 3) Release parking brake lever.
- 4) Remove parking brake lever cover and loosen parking brake cable locking nut (1).




- 5) Remove back plate plug (1) attached to the back side of brake back plate so as to increase clearance between brake shoe and brake drum.
 Insert a screwdriver into plug hole till its tip contacts shoe hold down spring and push screwdriver in the arrow direction.
 With this push, hold down spring is pushed up and releases parking shoe lever from hold down spring, resulting in larger clearance.



- 6) Pull brake drum off by using 8 mm bolts (1) (2 pieces).

INSPECTION

Brake drum



Inspect brake drum for wear.

If limit value of drum inner diameter is exceeded or uneven or stepped wear is excessive, replace drum.

Drum inner diameter "a"

Standard : 200 mm (7.87 in.)

Limit : 202 mm (7.95 in.)

Cracked, scored or grooved drum

A cracked drum is unsafe for further service and must be replaced. Do not attempt to weld a cracked drum.


Smooth up any slight scores. Heavy or extensive scoring will cause excessive brake lining wear and it will probably be necessary to resurface drum braking surface.

If brake linings are slightly worn and drum is grooved, drum should be polished with fine emery cloth but should not be turned.

NOTE:

When drum is removed, visually inspect wheel cylinder for brake fluid leakage. Correct leaky point, if any.

Brake shoe



Measure thickness of brake shoe (1) (not including backing metal). Also, check surface of lining for hardening, excessive wear and oil.

Brake shoe thickness (lining + shoe rim)


Standard : 6.1 mm (0.24 in.)

Limit : 2.6 mm (0.10 in.)


CAUTION:

Never polish lining with sandpaper. If lining is polished with sandpaper, hard particles of sandpaper will be deposited in lining and may damage drum. When it is required to correct lining, replace it with a new one.

INSTALLATION




- 1) Before installing brake drum, to maximize brake shoe-to-drum clearance, put screwdriver between rod (1) and ratchet (2) and push down ratchet as shown in figure.

**NOTE:**

The figure show ratchet position where brake shoe-to-drum clearance is maximum.

1. Rod
2. Ratchet




- 2) Put brake shoe hold down spring back to its original position as shown. (Put shoe hold down spring in place by moving shoe lever so that shoe lever comes to the side of shoe hold down spring.)

1. Brake shoe
2. Shoe hold down spring
3. Parking brake shoe lever

- 3) Install brake drum after making sure that inside of brake drum and brake shoes are free from dirt and oil.
 4) Tighten brake drum screws.
 5) Upon completion of all jobs, depress brake pedal with about 300N (30 kg, 66 lbs) load three to five times so as to obtain proper drum-to-shoe clearance.
 Adjust parking brake cable.
 6) Install parking brake lever cover.
 7) Install wheel and tighten wheel nuts to specified torque.

Tightening torque

(a) : 85 N·m (8.5 kg-m, 61.5 lb-ft)




- 8) Check to ensure that brake drum is free from dragging and proper braking is obtained. Then remove vehicle from hoist and perform brake test (foot brake and parking brake).


Brake shoe

REMOVAL


- 1) Remove brake drum referring to "BRAKE DRUM" in this section.
- 2) Remove shoe hold down springs (1) by turning shoe hold down pins (2).
- 3) Remove return springs, brake shoes and strut.




- 4) Disconnect parking brake shoe lever (1) from parking brake cable (2).



- 5) Remove retainer (1).
- 6) Remove parking brake shoe lever (2) from shoe rim (3).




INSPECTION



- Check ratchet of brake strut (1) assembly for wear or damage.
- Check shoe return spring, strut shoe return spring and shoe hold down spring for damage, corrosion and weakening.
- Check for smooth movement of brake shoe lever (2) along shoe rim.

INSTALLATION

Install parts in reverse order of removal, noting the followings.





- Install shoe hold down springs (2) by pushing them down in place and turning hold down pins (1).
- For procedure hereafter referring to “BRAKE DRUM” in this section.

Wheel cylinder

REMOVAL

- 1) Remove brake drum referring to “BRAKE DRUM” in this section.
- 2) Remove brake shoe referring to “BRAKE SHOE” in this section.
- 3) Loosen brake pipe flare nut (1) but only within the extent that fluid does not leak.






- 4) Remove wheel cylinder mounting bolts. Disconnect brake pipe from wheel cylinder and put bleeder plug cap (1) onto pipe to prevent fluid from spilling.

INSPECTION


Inspect wheel cylinder disassembled parts for wear, cracks, corrosion or damage.

NOTE:


Clean wheel cylinder components with brake fluid.



INSTALLATION



- 1) Take off bleeder plug cap from brake pipe and connect pipe to wheel cylinder (1) just enough to prevent fluid from leaking.



- 2) Tighten wheel cylinder to brake back plate to specified torque.

Tightening torque

Wheel cylinder mounting bolts (a) : 12 N·m (1.2 kg-m, 9.0 lb-ft)

- 3) Tighten flare nut of brake pipe to specified torque.

Tightening torque

Rear brake pipe flare nut (b) : 16 N·m (1.6 kg-m, 11.5 lb-ft)

- 4) Install bleeder plug cap taken off from pipe back to bleeder plug.

1. Brake back plate
2. Brake pipe flare nut
3. Brake pipe
4. Wheel cylinder bolts

- 5) Install brake shoes. Refer to "BRAKE SHOE" in this section.
- 6) Install brake drum. Refer to "BRAKE DRUM" in this section.
- 7) Fill reservoir with brake fluid and bleed brake system. For bleeding operation refer to "AIR BLEEDING OF BRAKE SYSTEM" in this section.
- 8) Upon completion of all jobs, depress brake pedal with about 300N (30 kg, 66 lbs) load 3 to 5 times so as to obtain proper drum-to-shoe clearance.
Adjust parking brake cable.
- 9) Install wheel and tighten wheel nuts to specified torque.

Tightening torque



Wheel nuts : 85 N·m (8.5 kg-m, 61.5 lb-ft)

- 10) Check to ensure that brake drum is free from dragging and proper braking is obtained. Then remove vehicle from hoist and perform brake test (foot brake and parking brake).
- 11) Check each installed part for oil leakage.

Brake back plate


REMOVAL

- 1) Remove brake drum referring to "BRAKE DRUM" in this section.
- 2) Remove brake shoe referring to "BRAKE SHOE" in this section.
- 3) Remove wheel cylinder referring to "WHEEL CYLINDER" in this section.
- 4) Remove cable from brake back plate by squeezing parking brake cable stopper ring (1).
- 5) Remove wheel hub referring to "WHEEL HUB, WHEEL BEARING AND WHEEL STUD" (For 2WD vehicle) or "WHEEL HUB, WHEEL STUD/WHEEL BEARING OUTSIDE INNER RACE" (For 4WD vehicle) in Section 3.




- 6) Remove brake back plate (1) by removing bolts (2).

INSTALLATION



- 1) Apply water tight sealant to mating surfaces of brake back plate and rear axle.


“A” : Sealant 366E 99000-31090



- 2) Install brake back plate and tighten back plate bolts to specified torque.

Tightening torque

Brake back plate bolts (a) : 50 N·m (5.0 kg-m, 36.5 lb-ft)




- 3) Install parking brake cable (3) to brake plate (1).







2. Cable stopper ring

- 4) Install wheel hub referring to “WHEEL HUB, WHEEL BEARING AND WHEEL STUD” (For 2WD vehicle) or “WHEEL HUB, WHEEL STUD/WHEEL BEARING OUTSIDE INNER RACE” (For 4WD vehicle) in Section 3.
- 5) Install wheel cylinder, and tighten wheel cylinder bolts and brake pipe flare nut to specified torque. Refer to “WHEEL CYLINDER” in this section.
- 6) For procedure hereafter refer to “WHEEL CYLINDER” in this section.

Master Cylinder

NOTE:
The figure shows left-hand steering vehicle.




[A]: For vehicle without ABS	 5. Piston cup : Apply brake fluid. Confirm installing direction.	11. Secondary piston stopper bolt
[B]: For vehicle with ABS	 6. Secondary piston pressure cup : Apply brake fluid. Confirm installing direction.	12. Master cylinder body
1. Piston stopper circlip	 7. Piston cup : Apply brake fluid. Confirm installing direction.	13. O-ring
2. Piston stopper	8. Secondary piston	14. Piston stopper pin
 3. Cylinder cup : Apply brake fluid. Confirm installing direction.	9. Return spring secondary seat	 Tightening torque
4. Primary piston	10. Secondary piston return spring	 Do not reuse.

Master cylinder reservoir

REMOVAL

- 1) Disconnect fluid level switch coupler on reservoir.
- 2) Clean outside of reservoir.
- 3) Take out fluid with syringe or such.



4) Remove reservoir pin (1) using special tool (A).

Special tool

(A): 09922-85811

5) Remove reservoir (2).

CAUTION:

Brake fluid is extremely damaging to paint.

Do not allow brake fluid to get on painted surfaces.


INSTALLATION

1) When using new grommets, lubricate them with the same fluid as the one to fill reservoir with. Then press-fit grommets to master cylinder. Grommets must be seated in place.

2) Install reservoir (1) to master cylinder with pin (2).

NOTE:

When inserting pin, drive till both of its ends at the right and left of reservoir become the same length.



3) Connect fluid level switch coupler on reservoir.

4) Fill reservoir with special fluid.


5) Upon completion of installation, check for fluid leakage.

Master cylinder assembly

REMOVAL

1) Clean outside of master cylinder.

2) Drain brake fluid in reservoir.



- 3) Disconnect fluid level switch coupler (1) on reservoir.
- 4) Disconnect brake pipes (2) connected to master cylinder.

CAUTION:

Do not allow brake fluid to get on painted surface. Painted surface will be damaged by brake fluid, flush it with water immediately if any fluid is spilled.

- 5) [For right-hand steering vehicle]
Remove air cleaner outlet hose.
- 6) Remove master cylinder fixing nuts (3).
- 7) Remove master cylinder.

INSPECTION

Inspect all disassembled parts for wear or damage, and replace parts if necessary.

NOTE:

- Wash disassembled parts with brake fluid.
- Do not reuse piston cups.


Inspect master cylinder bore for scoring or corrosion. It is best to replace corroded cylinder. Corrosion can be identified as pits or excessive roughness.

NOTE:


Polishing bore of master cylinder with cast aluminium body with anything abrasive is prohibited, as damage to cylinder bore may occur.

Rinse cylinder in clean brake fluid. Shake excess rinsing fluid from cylinder. Do not use a cloth to dry cylinder, as lint from cloth cannot be kept from cylinder bore surfaces.


DISASSEMBLY



- 1) [For vehicle not equipped with ABS]
Remove piston stopper bolt (1).



- 2) [For vehicle equipped with ABS]
Push in primary piston (1) to remove secondary piston stopper pin (2) from master cylinder as shown.




- 3) Remove circlip (1).
- 4) Remove primary piston. Then remove secondary piston by blowing compressed air (2) into hole. Be cautious during removal as secondary piston jumps out.

ASSEMBLY

CAUTION:

- Never use any mineral oil such as kerosene oil and gasoline when washing and assembling parts.
- Check inside of cylinder wall, pistons and cup seals are free from any foreign objects such as dust and dirt and use care not to cause any damage with a tool during assembly.
- Do not drop parts. Do not use any part which has been dropped.




- 1) Apply brake fluid to inside of cylinder and contact surface of piston assembly.
- 2) Install secondary return spring and secondary piston (1) into cylinder body (4).

NOTE:

For vehicles equipped with ABS, align oblong hole in secondary piston (2) with stopper pin hole (3) in master cylinder body (4) when installing it.

- 3) Install primary piston assembly into cylinder body.



- 4) Install piston stopper bolt (1) or stopper pin (2) with pistons pushed in all the way and tighten or install it.


Tightening torque**Piston stopper bolt (a) :**

10 N·m (1.0 kg-m, 7.5 lb-ft) for LH steering vehicle

2.2 N·m (0.22 kg-m, 1.5 lb-ft) for RH steering vehicle

[A] : For vehicle not equipped with ABS

[B] : For vehicle equipped with ABS



- 5) Install circlip (1).

INSTALLATION

- 1) Install new master cylinder O-ring.
- 2) Install master cylinder to booster and tighten master cylinder fixing nuts (3) to specified torque.

Tightening torque


Master cylinder fixing nuts (a) : 13 N·m (1.3 kg-m, 9.5 lb-ft)

- 3) Connect brake pipe to master cylinder and tighten flare nuts (2) to specified torque.

Tightening torque


Brake pipe flare nuts (b) : 16 N·m (1.6 kg-m, 11.5 lb-ft)

- 4) Connect fluid level switch connector (1) of reservoir.
- 5) [For right-hand steering vehicle]
Install air cleaner outlet hose.
- 6) Fill reservoir with specified brake fluid up to its MAX mark.
- 7) After completing above work, bleed air and check brake pedal for play.



Brake Booster

NOTE:
The figure shows left-hand steering vehicle.




1. Booster assembly	5. Clip	9. Brake master cylinder
2. Gasket	6. Nut	10. Master cylinder fixing nut
3. Brake vacuum hose	7. Clevis pin lock nut	11. Brake vacuum pipe
4. Clevis pin	8. Push rod clevis	Tightening torque

CAUTION:
Never disassemble brake booster. Disassembly will spoil its original function. If faulty condition is found, replace it with new one.

REMOVAL


- 1) Remove master cylinder assembly (9) from booster (1). Refer to “MASTER CYLINDER” in this section.
- 2) Disconnect vacuum hose (3) from booster.
- 3) [For left-hand steering vehicle with ABS]
Remove brake vacuum pipe (11) from dash panel.
- 4) [For right-hand steering vehicle]
 - a) Remove air cleaner case assembly from vehicle body.
 - b) Support engine with support device.



- c) Loosen right side engine mounting bolt (1) and then remove engine mounting nuts (2).
- d) Remove right side engine mounting from timing chain cover and move engine in front direction.

- 5) Remove push rod clevis pin and booster mounting nuts and then remove booster.

INSTALLATION




- 1) Install booster (4) to dash panel. Then connect push rod clevis (5) to pedal arm with clevis pin (2) and clip (6).
- 2) Tighten booster mounting nuts (3) to specified torque.

Tightening torque

Booster mounting nuts (a) : 13 N·m (1.3 kg-m, 9.5 lb-ft)

- 3) [For left-hand steering vehicle with ABS]
Install brake vacuum pipe to dash panel.



- 4) [For right-hand steering vehicle]
 - a) Install right side engine mounting to timing chain cover and tighten right side engine mounting bolt and nuts to specified torque.

Tightening torque


Right side engine mounting bolt

(a) : 55 N·m (5.5 kg-m, 40.0 lb-ft)

Engine mounting nuts

(b) : 75 N·m (7.5 kg-m, 54.5 lb-ft)

- b) Remove support device.
- c) Install air cleaner case assembly to vehicle body.
- 5) Install master cylinder assembly to booster referring to "MASTER CYLINDER" in this section.
- 6) Fill reservoir with specified fluid.
- 7) Bleed air from brake system.
- 8) Perform brake test and check each installed part for fluid leakage.
- 9) [For left-hand steering vehicle]
Check clearance between booster piston rod and master cylinder piston.

INSPECTION AND ADJUSTMENT**Installation position of push rod**

If push rod clevis (1) has been removed, adjust distance between booster installation surface (without including packing) and the center of clevis pin hole to standard value "a" and tighten nut (2) to specified torque.

Distance "a" between center of booster clevis pin hole and booster surface

Standard : 104.5 - 105.5 mm (4.11 - 4.15 in.)

Tightening torque


Clevis pin lock nut (a) : 25 N·m (2.5 kg·m, 18.5 lb·ft)

Clearance Between Booster Piston Rod And Master Cylinder Piston**[For left-hand steering vehicle]**

- a) Set special tool (A) on master cylinder (1) and push pin head (3) until it contacts piston (2).

Special tool

(A) : 09950-96010




- b) Turn special tool upside down and place it on booster (1). Adjust booster piston rod (2) length until rod end contacts pin head.

Clearance "b" (Between special tool and piston rod):

0 mm (0 in.)

Special tool


(A) : 09950-96010



- c) Adjust clearance by turning adjusting screw of piston rod.


Special tool


(B) : 09952-16010

**[For right-hand steering vehicle]****NOTE:**


Adjustment of clearance between booster piston rod and master cylinder piston is not necessary.


For vehicle with ABS



[A] : For left-hand steering vehicle	Y: View Y	5. ABS hydraulic unit
[B] : For right-hand steering vehicle	a-i: Clamp	6. Master cylinder
T : Top side	1. From master cylinder primary to ABS hydraulic unit	7. Front brake hose
F : Front side	2. From master cylinder secondary to ABS hydraulic unit	8. 4-way joint
R : Right side	3. From ABS hydraulic unit to left front brake	 Tightening torque
X : View X	4. From ABS hydraulic unit to right front brake	

For vehicle without ABS



[A] : For left-hand steering vehicle	X : View X	4. Front brake hose
[B] : For right-hand steering vehicle	Y : View Y	5. 5-way joint or P valve
T : Top side	1. From master cylinder primary to left front brake	a-h: Clamp
F : Front side	2. From master cylinder secondary to right front brake	 Tightening torque
R : Right side	3. Master cylinder	

REMOVAL

- 1) Raise and support vehicle properly. Remove tire and wheel.

NOTE:

This operation is not necessary when removing pipes connecting master cylinder.

- 2) Clean dirt and foreign material from both flexible hose end and pipe end fittings.
- 3) Remove brake flexible hose or pipe.

INSTALLATION

Reverse brake flexible hose installation procedure, noting the followings.

- Make sure that steering wheel is in straight-forward position and flexible hose has not twist or kink.
- Check to make sure that flexible hose doesn't contact any part of suspension, both in extreme right and extreme left turn conditions. If it does at any point, remove and correct. Fill and maintain brake fluid level in reservoir.
- Bleed brake system. Refer to "AIR BLEEDING OF BRAKE SYSTEM" in this section.
- Perform brake test and check installed part for fluid leakage.

Rear brake hose/pipe


REMOVAL


- 1) Raise and support vehicle properly. Remove tire and wheel.
- 2) Clean dirt and foreign material from both flexible hose end and pipe end fittings.
- 3) Remove brake flexible hose or pipe.

INSTALLATION

Reverse brake flexible hose installation procedure, nothing the followings.

- Fill and maintain brake fluid level in reservoir.
- Bleed brake system. Refer to "AIR BLEEDING OF BRAKE SYSTEM" in this section.
- Perform brake test and check each installed part for fluid leakage.
- Never reuse protector nut once removed. Be sure to use a new one.
- Install clamps properly referring to figure below and tighten bolts.
- When installing hose, make sure that it has no twist or kink.



[A] : with ABS or P valve	R : Right side	3. Rear brake hose
[B] : with LSPV	L : Left side	a-f: Clamp
T : Top side	1. 4 way joint	 Tightening torque
F : Front side	2. LSPV assembly	

Parking brake cable


REMOVAL


- 1) Raise, suitably support vehicle and remove wheel.
- 2) Remove parking brake cable.

INSTALLATION


Install it by reversing removal procedure, noting the following points.

- Install clamps properly referring to figure below.
- Tighten bolts and nuts to specified torque.
- Adjust parking brake cable. Refer to “PARKING BRAKE INSPECTION AND ADJUSTMENT” in this section.
- Check brake drum for dragging and brake system for proper performance. After removing vehicle from hoist, brake test should be performed.



T : Top side	3. Inner cable end	a : View A	f : View F
F : Front side	4. Spring	b : View B	 Tightening torque
R : Rear side	5. Adjusting nut	c : View C	
1. Backing plate	6. Cable stopper ring	d : View D	
2. Parking brake shoe lever	7. Parking brake lever	e : View E	

LSPV (Load Sensing Proportioning Valve) Assembly (If Equipped)




1. LSPV assembly	3. Adjust nut	5. LSPV mounting bolt
2. Spring	4. Brake pipe	Tightening torque

CAUTION:


Never disassemble LSPV assembly. Disassembly will spoil its original performance. Replace with new one if defective.

REMOVAL


- 1) Clean around reservoir cap and take out fluid with syringe or such.
- 2) Hoist vehicle.
- 3) Disconnect brake pipes from LSPV assembly.
- 4) Remove mounting bolts (3) and adjusting nut (2).
- 5) Remove LSPV assembly (1) with spring (4) from vehicle body.




INSTALLATION



- 1) Install LSPV assembly with spring to vehicle body.



- 2) Apply multi-purpose grease (1) to upper and lower joint of coil spring.



- 3) Torque each bolt and nut to specification as indicated respectively in figure.

Tightening torque

LSPV adjust nut (a) : 23 N·m (2.3 kg-m, 17.0 lb-ft)


Brake pipe flare nuts (b) : 16 N·m (1.6 kg-m, 11.5 lb-ft)

LSPV mounting bolts (c) : 23 N·m (2.3 kg-m, 17.0 lb-ft)

- 4) Fill reservoir with specified fluid and bleed air from brake system.
- 5) After bleeding air, check that LSPV is installed properly referring to following "INSPECTION and ADJUSTMENT".

INSPECTION AND ADJUSTMENT

- 1) Confirm the following before inspection and adjustment.
 - Fuel tank is filled with fuel fully.
 - Vehicle is equipped with spare tire, tools, jack and jack handle.
 - Vehicle is free from any other load.
 - Vehicle is placed on level floor.



- 2) Push up LSPV lever with finger till it stops and measure length of coil spring ("a" in figure).
- 3) Spring length "a" should be as specified.

Spring length "a"

142 mm (5.59 in.)

- 4) If it isn't, adjust it to specification by changing spring position as shown in figure. After adjustment, tighten nut (1) to specified torque.

Tightening torque

LSPV adjust nut (a) : 23 N·m (2.3 kg-m, 17.0 lb-ft)

NOTE:










Check to make sure that LSPV body and brake pipe joints are free from fluid leakage. Replace defective parts, if any.

- 5) Confirm fluid pressure referring to "Fluid Pressure Test".

Required Service Material

Material	Recommended SUZUKI product (Part Number)	Use
Brake fluid	DOT 3 or SAE J1703	<ul style="list-style-type: none"> • To fill master cylinder reservoir. • To clean and apply to inner parts of master cylinder caliper and wheel cylinder when they are disassembled.
Water tight sealant	SEALING COMPOUND 366E (99000-31090)	<ul style="list-style-type: none"> • To apply to mating surfaces of brake back plate and rear axle.

Special Tool

 <p>09900-20606 Dial gauge</p>	 <p>09900-20701 Dial gauge chuck</p>	 <p>09922-85811 Connector pin remover</p>	 <p>09950-78220 Flare nut wrench (10 mm)</p>
 <p>09950-96010 Booster piston rod gauge</p>	 <p>09952-16010 Booster piston rod adjuster</p>	 <p>09952-36310 Fluid pressure gauge attachment (7 mm)</p>	 <p>09952-36320 Fluid pressure gauge attachment</p>
 <p>09956-02310 Fluid pressure gauge</p>			

SECTION 5B

ANTILOCK BRAKE SYSTEM (ABS)

WARNING:

For vehicles equipped with Supplemental Restraint (Air Bag) System :

- Service on and around the air bag system components or wiring must be performed only by an authorized SUZUKI dealer. Refer to “Air Bag System Components and Wiring Location View” under “General Description” in air bag system section in order to confirm whether you are performing service on or near the air bag system components or wiring. Please observe all WARNINGS and “Service Precautions” under “On-Vehicle Service” in air bag system section before performing service on or around the air bag system components or wiring. Failure to follow WARNINGS could result in unintentional activation of the system or could render the system inoperative. Either of these two conditions may result in severe injury.
- Technical service work must be started at least 90 seconds after the ignition switch is turned to the “LOCK” position and the negative cable is disconnected from the battery. Otherwise, the system may be activated by reserve energy in the Sensing and Diagnostic Module (SDM).

5B

NOTE:

All brake fasteners are important attaching parts in that they could affect the performance of vital parts and systems, and/or could result in major repair expense. They must be replaced with one of same part number or with an equivalent part if replacement becomes necessary. Do not use a replacement part of lesser quality or substitute design. Torque values must be used as specified during reassembly to assure proper retention of all parts. There is to be no welding as it may result in extensive damage and weakening of the metal.

CONTENTS

General Description	5B-2	Table-D Code (DTC) Is Not Outputted Even with Diagnosis Switch Terminal Connected to Ground.....	5B-16
Components/Parts Location and Brake Hose/Pipe Routing	5B-2	Table-E EBD Warning Lamp (Brake Warning Lamp) Check – Lamp Comes “On” Steady.....	5B-17
System Schematic	5B-4	Diagnostic Trouble Code (DTC) Check (Using ABS Warning Lamp).....	5B-18
ABS Hydraulic Unit/Control Module Assembly.....	5B-5	Diagnostic Trouble Code (DTC) Check	5B-19
Self-diagnosis function	5B-5	(Using SUZUKI Scan Tool)	5B-19
Fail-safe function	5B-5	Diagnostic Trouble Code (DTC) Clearance.....	5B-19
System Circuit	5B-6	Diagnostic Trouble Code (DTC) Table.....	5B-20
Diagnosis	5B-8	DTC C1013 (DTC 13) – System Specifications Different From ABS Control Module Specifications	5B-22
Precaution in Diagnosing Troubles	5B-8	DTC C1015 (DTC 15) -G Sensor Circuit....	5B-22
ABS Diagnostic Flow Table.....	5B-9	DTC C1021 (DTC 21), DTC C1022 (DTC 22) – Right-front Wheel Speed Sensor Circuit or Sensor Ring	5B-24
ABS Warning Lamp Check	5B-12	DTC C1025 (DTC 25), DTC C1026 (DTC 26) – Left-front Wheel Speed Sensor Circuit or Sensor Ring	5B-24
EBD Warning Lamp (Brake Warning Lamp) Check.....	5B-12		
Table-A ABS Warning Lamp Circuit Check – Lamp Does Not Come “ON” at Ignition Switch ON.....	5B-13		
Table-B ABS Warning Lamp Circuit Check – Lamp Comes “ON” Steady.....	5B-14		
Table-C ABS Warning Lamp Circuit Check – The Lamp Flashes Continuously While Ignition Switch Is ON.....	5B-15		

DTC C1031 (DTC 31), DTC C1032 (DTC 32) – Right-rear Wheel Speed Sensor Circuit or Sensor Ring	5B-24
DTC C1035 (DTC 35), DTC C1036 (DTC 36) – Left-rear Wheel Speed Sensor Circuit or Sensor Ring	5B-24
DTC C1041 (DTC 41) – Right-front Inlet Solenoid Circuit.....	5B-26
DTC C1045 (DTC 45) – Left-front Inlet Solenoid Circuit.....	5B-26
DTC C1051 (DTC 51) – Right-rear Inlet Solenoid Circuit.....	5B-26
DTC C1055 (DTC 55) – Left-rear Inlet Solenoid Circuit.....	5B-26
DTC C1042 (DTC 42) – Right-front Outlet Solenoid Circuit.....	5B-26
DTC C1046 (DTC 46) – Left-front Outlet Solenoid Circuit.....	5B-26
DTC C1052 (DTC 52) – Right-rear Outlet Solenoid Circuit.....	5B-26
DTC C1056 (DTC 56) – Left-rear Outlet Solenoid Circuit.....	5B-26

DTC C1057 (DTC 57) – Power Source Circuit.....	5B-27
DTC C1061 (DTC 61) – ABS Pump Motor Circuit	5B-28
DTC C1063 (DTC 63) – ABS Fail-safe Relay Circuit	5B-29
DTC C1071 (DTC 71) – ABS Control Module	5B-30
ON-Vehicle Service.....	5B-31
Precautions.....	5B-31
ABS Hydraulic Unit Operation Check (Using SUZUKI Scan Tool).....	5B-31
ABS Hydraulic Unit Operation Check (Not Using SUZUKI Scan Tool)	5B-31
ABS Hydraulic Unit/Control Module Assembly	5B-33
Front Wheel Speed Sensor	5B-35
Front Wheel Speed Sensor Ring	5B-37
Rear Wheel Speed Sensor	5B-38
Rear Wheel Speed Sensor Ring.....	5B-41
G Sensor (For 4WD Vehicle Only).....	5B-41
Special Tool	5B-42

General Description

Components/Parts Location and Brake Hose/Pipe Routing

The ABS (Antilock Brake System) controls the fluid pressure applied to the Wheel cylinder of each brake from the master cylinder so that each wheel is not locked even when hard braking is applied.


This ABS has also the following function.

While braking is applied, but before ABS control becomes effective, braking force is distributed between the front and rear so as to prevent the rear wheels from being locked too early for better stability of the vehicle.

The main component parts of this ABS include the following parts in addition to those of the conventional brake system.

- Wheel speed sensor which senses revolution speed of each wheel and outputs its signal.
- ABS warning lamp which lights to inform abnormality when system fails to operate properly.
- ABS hydraulic unit/control module assembly is incorporated ABS control module, ABS hydraulic unit (actuator assembly), fail-safe relay and pump motor relay.
 - ABS control module which sends operation signal to ABS hydraulic unit to control fluid pressure applied to each wheel cylinder based on signal from each wheel speed sensor so as to prevent wheel from locking.
 - ABS hydraulic unit which operates according to signal from ABS control module to control fluid pressure applied to wheel cylinder of each 4 wheels.
 - Fail-safe relay (solenoid valve) which supplies power to solenoid valve in ABS hydraulic unit and pump motor relay.
 - Pump motor relay which supplies power to pump motor in ABS hydraulic unit.
- G sensor which detects vehicle deceleration speed. (For 4WD model only)]

This ABS is equipped with Electronic Brake force Distribution (EBD) system that controls a fluid pressure of rear wheels to best condition, which is the same function as that of proportioning valve, by the signal from wheel sensor independently of change of load due to load capacity and so on. And if the EBD system fails to operate properly, the brake warning lamp lights to inform abnormality.




[A]: RH steering vehicle shown	4. Stop lamp switch
1. ABS hydraulic unit/control module assembly	5. ABS warning lamp
2. G sensor (For 4WD vehicle only)	6. EBD warning lamp (Brake warning lamp)
3. Wheel speed sensors	7. Monitor connector

NOTE:

As for the difference of RH steering vehicle and LH steering vehicle, the location of the combination meter and the brake master cylinder assembly only changes.

System Schematic




1. ABS hydraulic unit/control module assembly	7. "ABS" warning lamp	13. Wheel speed sensor (Right-front)
2. ABS control module	8. "EBD" warning lamp (Brake warning lamp)	14. Wheel speed sensor (Left-front)
3. ABS hydraulic unit	9. Lamp driver module	15. Wheel speed sensor (Right-rear)
4. Fail safe relay	10. ECM	16. Wheel speed sensor (Left-rear)
5. Pump motor relay	11. Data link connector	17. G sensor (For 4WD vehicle only)
6. Stop lamp switch	12. Monitor connector	18. 4 way joint

ABS Hydraulic Unit/Control Module Assembly


ABS control module is a component of ABS hydraulic unit/control module assembly and has the following functions.

Self-diagnosis function

ABS control module diagnoses conditions of the system component parts (whether or not there is any abnormality) all the time and indicates the results (warning of abnormality occurrence and DTC) through the ABS warning lamp as described below.



- 1) When ignition switch is turned ON, ABS warning lamp lights for 2 seconds to check its bulb and circuit.
- 2) When no abnormality has been detected (the system is in good condition), ABS warning lamp turns OFF after 2 seconds.
- 3) When an abnormality in the system is detected, ABS warning lamp lights and the area where that abnormality lies is stored in the memory of EEPROM in ABS control module.



- 4) When Diag. switch terminal (2) of monitor connector (blue) (1) is grounded, the abnormal area is output as DTC. It is indicated by flashing of ABS warning lamp. (Refer to the table below.)

SYSTEM CONDITION		ABS WARNING LAMP	
		Diag. switch terminal is not grounded	Diag. switch terminal is grounded
In good condition at present	No trouble in the past	OFF	DTC 12
	Trouble occurred in the past	OFF	History DTC
Abnormality exists at present	No trouble in the past	ON	Current DTC
	Trouble occurred in the past	ON	Current and history DTCs

- 5) For procedure to clear all DTC's, refer to "DIAGNOSTIC TROUBLE CODE CLEARANCE" in this section.


3. Ground terminal
4. Service wire

Also ABS control module turns ON EBD warning lamp (brake warning lamp) depending on the trouble and EBD warning lamp does not indicate DTC.

Fail-safe function

When an abnormality occurs (an abnormal DTC is detected), ABS control module turns OFF the fail-safe relay which supplies power to ABS hydraulic unit. Thus, with ABS not operating, brakes function just like the brake system of the vehicle without ABS.

System Circuit



1. Battery	9. ABS hydraulic unit/control module assembly	17. Left-rear wheel speed sensor
2. Main fuses	10. Terminal arrangement of connector E35 for ABS hydraulic unit/control module assembly	18. Right-front wheel speed sensor
3. Ignition switch	11. ABS fail-safe relay (Solenoid valve relay)	19. Left-front wheel speed sensor
4. Circuit fuses	12. ABS pump motor relay	20. Data link connector
5. Combination meter	13. Pump motor	21. To ECM
6. ABS warning lamp	14. Solenoid valves	22. Stop lamp
7. Brake warning lamp ("EBD" warning lamp)	15. Monitor connector	23. Stop lamp switch
8. Warning lamp driver module	16. Right-rear wheel speed sensor	24. G sensor (For 4WD vehicle only)

Wire color					
BLK :	Black	LT GRN/BLK :	Light Green/Black	WHT :	White
BLK/ORN :	Black/Orange	LT GRN/RED :	Light Green/Red	WHT/BLK :	White/Black
BLK/RED :	Black/Red	ORN :	Orange	WHT/BLU :	White/Blue
BLU :	Blue	PNK :	Pink	WHT/GRN :	White/Green
BRN :	Brown	PNK/GRN :	Pink/Green	WHT/RED :	White/Red
GRN :	Green	RED :	Red	YEL :	Yellow
GRN/WHT :	Green/White	RED/BLK :	Red/Black		
GRN/ORN :	Green/Orange	RED/WHT :	Red/White		


TERMINAL		CIRCUIT
E35	1	—
	2	Stop lamp switch
	3	Right-front wheel speed sensor (+)
	4	Right-front wheel speed sensor (—)
	5	—
	6	Right-rear wheel speed sensor (—)
	7	Right-rear wheel speed sensor (+)
	8	—
	9	—
	10	Brake warning lamp (EBD warning lamp)
	11	G sensor (For 4WD vehicle only)
	12	Diagnosis switch terminal
	13	Ground (For G sensor) (For 4WD vehicle only)
	14	ABS warning lamp
	15	Left-front wheel speed sensor (+)
	16	Left-front wheel speed sensor (—)
	17	—
	18	Ignition switch
	19	Left-rear wheel speed sensor (+)
	20	Left-rear wheel speed sensor (—)
	21	Data link connector
	22	Ground (for ABS pump motor)
	23	ABS pump motor relay
	24	Ground (for ABS control module)
	25	ABS fail-safe relay

Diagnosis

To ensure that the trouble diagnosis is done accurately and smoothly, observe "PRECAUTIONS IN DIAGNOSING TROUBLES" and follow "ABS DIAGNOSTIC FLOW TABLE".

Precaution in Diagnosing Troubles

- If the vehicles was operated in any of the following ways, ABS warning lamp may light momentarily but this does not indicate anything abnormal in ABS.
 - The vehicle was driven with parking brake pulled.
 - The vehicle was driven with brake dragging.
 - The vehicle was stuck in mud, sand, etc.
 - Wheel spin occurred while driving.
 - Wheel(s) was rotated while the vehicle was jacked up.
- Be sure to read "PRECAUTIONS FOR ELECTRICAL CIRCUIT SERVICE" in Section 0A before inspection and observe what is written there.
- Be sure to use the trouble diagnosis procedure as described in the flow table. Failure to follow the flow table may result in incorrect diagnosis. (Some other diagnosis trouble code may be stored by mistake in the memory of ABS control module during inspection.)
- When disconnecting ABS hydraulic unit/control module connector (1), pull up lock (2) of connector.
When connecting, set the connector on ABS hydraulic unit/control module assembly and push the lock (2) down.



D : Disconnect

C : Connect

ABS Diagnostic Flow Table

Refer to the following pages for the details of each step.

Step	Action	Yes	No
1	1) Perform "Customer Complaint Analysis". 2) Perform "Problem Symptom Confirmation". 3) Perform "Diagnostic Trouble Code Check, Record and Clearance". Is there any malfunction DTC?	Go to Step 2.	Go to Step 5.
2	1) Perform "DRIVING TEST". Is trouble symptom identified?	Go to Step 3.	Go to Step 6.
3	1) Check diagnostic trouble code. Is it malfunction code?	Go to Step 4.	Go to Step 5.
4	1) Inspect and repair referring to applicable diagnostic trouble code table in this section. 2) Perform "FINAL CONFIRMATION TEST" after cleared DTC. Does trouble recur?	Go to Step 7.	End.
5	1) Inspect and repair referring to "DIAGNOSIS" in "BRAKES" section. 2) Perform "FINAL CONFIRMATION TEST".	—	—
6	1) Check intermittent troubles referring to "INTERMITTENT AND POOR CONNECTION" in "GENERAL INFORMATION" section and related circuit of trouble code recorded in Step 2. 2) Perform "FINAL CONFIRMATION TEST" after cleared diagnostic trouble code. Does trouble recur?	Go to Step 7.	End.
7	1) Perform "Diagnostic Trouble Code Check, Record and Clearance". Is there any malfunction code?	Go to Step 2.	Go to Step 5.

1) MALFUNCTION ANALYSIS

a) Customer Complaint Analysis

Record details of the problem (failure, complaint) and how it occurred as described by the customer.

For this purpose, use of such a questionnaire form as shown below will facilitate collecting information to the point required for proper analysis and diagnosis.

CUSTOMER QUESTIONNAIRE (EXAMPLE)

Customer's name:	Model:	VIN:	
Date of issue:	Date of Reg:	Date of problem:	Mileage:

Problem Symptoms	<ul style="list-style-type: none"> ● ABS warning lamp abnormal: fails to turn on/fails to go off/flashes ● Abnormal noise while vehicle is running: from motor, from valve, other_____ ● Wheel is locked at braking: ● Pump motor does not stop (running): ● Braking does not work: ● Other:
Frequency of occurrence	<ul style="list-style-type: none"> ● Continuous/Intermittent (_____ times a day, a month)/ other_____
Conditions for Occurrence of Problem	<ul style="list-style-type: none"> ● Vehicle at stop & ignition switch ON: ● When starting: at initial start only/at every start/Other_____ ● Vehicle speed: while accelerating/while decelerating/at stop/ while turning/while running at constant speed/ other_____ ● Road surface condition: Paved road/rough road/snow-covered road/ other_____ ● Chain equipment:
Environmental Condition	<ul style="list-style-type: none"> ● Weather: fair/cloudy/rain/snow/other_____ ● Temperature: °F (_____ °C)
Diagnostic Trouble Code	<ul style="list-style-type: none"> ● First check: _____ Normal code/malfunction code (_____) ● Second check after test drive: _____ Normal code/malfunction code (_____)

b) Problem Symptom Confirmation

Check if what the customer claimed in "CUSTOMER QUESTIONNAIRE" is actually found in the vehicle and if that symptom is found, whether it is identified as a failure. (This step should be shared with the customer if possible.) Check warning lamps related to brake system referring to "EBD WARNING LAMP (BRAKE WARNING LAMP) CHECK" and "ABS WARNING LAMP CHECK" in this section.

c) Diagnostic Trouble Code (DTC) Check, Record and Clearance

Perform "DIAGNOSTIC TROUBLE CODE CHECK" procedure in this section, record it and then clear it referring to "DIAGNOSTIC TROUBLE CODE CLEARANCE" in this section.

If the malfunction DTC which was once displayed and then cleared cannot be detected (indicated) again when the ignition switch is turned ON, attempt to diagnose the trouble based on the DTC recorded in this step may mislead the diagnosis or make diagnosing difficult. Proceed to Step 2) to check control module for proper self-diagnosis function.

If the malfunction DTC which was once displayed and then cleared can be detected (indicated) again when ignition switch is turned ON, proceed to Step 3).

2) DRIVING TEST

Test drive the vehicle at 40 km/h for more than a minute and check if any trouble symptom (such as abnormal lighting of ABS warning light) exists.

If the malfunction DTC is confirmed again at ignition switch ON, driving test as described in above is not necessary. Proceed to Step 3).

3) DIAGNOSTIC TROUBLE CODE CHECK

Recheck diagnostic trouble code referring to "DTC CHECK" as shown in the following page.

4) DIAGNOSTIC TROUBLE CODE FLOW TABLE

According to Diagnostic flow table for the diagnostic trouble code confirmation in Step 3), locate the cause of the trouble, namely in a sensor, switch, wire harness, connector, actuator assembly or other part and repair or replace faulty parts.

5) "DIAGNOSIS" IN "BRAKES" SECTION

Check the parts or system suspected as a possible cause referring to "DIAGNOSIS" in "BRAKES" section and based on symptoms appearing on the vehicle (symptom obtained through Steps 1)-a, 1)-b and 2) and repair or replace faulty parts, if any).


6) CHECK FOR INTERMITTENT PROBLEM

Check parts where an intermittent trouble is easy to occur (e.g., wire harness, connector, etc.), referring to "INTERMITTENT AND POOR CONNECTION" in "GENERAL INFORMATION" section and related circuit of trouble code recorded in Step 1)-c.

7) FINAL CONFIRMATION TEST

Confirm that the problem symptom has gone and the ABS is free from any abnormal conditions. If what has been repaired is related to the malfunction DTC, clear the DTC once and perform test driving and confirm that no DTC is indicated.

ABS Warning Lamp Check




- 1) Turn ignition switch ON.
 - 2) Check that ABS warning lamp (1) comes ON for about 2 seconds and then goes off.
- If any faulty condition is found, advance to Diagnostic Flow Table-A, B, C or D.

EBD Warning Lamp (Brake Warning Lamp) Check


NOTE:

Perform this check on a level place.



- 1) Turn ignition switch ON with parking brake applied.
 - 2) Check that EBD warning lamp (brake warning lamp) (1) is turned ON.
 - 3) Release parking brake with ignition switch ON and check that EBD warning lamp (brake warning lamp) goes off.
- If it doesn't go off, go to "TABLE-E" in this section.

Table-A ABS Warning Lamp Circuit Check – Lamp Does Not Come “ON” at Ignition Switch ON



1. Main fuse	5. ABS warning lamp	9. Brake fluid level switch
2. Ignition switch	6. Brake warning lamp	10. ABS hydraulic unit/control module assembly
3. Circuit fuse	7. Lamp driver module	11. ABS hydraulic unit/control module connector
4. Combination meter	8. Parking brake switch	

CIRCUIT DESCRIPTION

Operation (ON/OFF) of ABS warning lamp is controlled by ABS control module through lamp driver module in combination meter.

If the Antilock brake system is in good condition, ABS control module turns ABS warning lamp ON at the ignition switch ON, keeps it ON for 2 seconds and then turns it OFF. If an abnormality in the system is detected, ABS warning lamp is turned ON continuously by ABS control module. Also, it is turned ON continuously by lamp driver module when the connector of ABS control module is disconnected.

INSPECTION

Step	Action	Yes	No
1	1) Turn ignition switch ON. Do other warning lamp come ON?	Go to Step 2.	Go to Step 4.
2	1) Disconnect ABS hydraulic unit/control module connector. Does ABS warning lamp light with ignition switch ON?	Substitute a known-good ABS hydraulic unit/control module assembly and recheck.	Go to Step 3.
3	1) Remove combination meter. Is bulb of ABS warning lamp in good condition?	“RED/WHT” circuit shorted to ground. If OK, replace combination meter (lamp driver module).	Replace combination meter.
4	Is IG fuse in good condition?	Open in “BLK/RED” wire to combination meter or poor connection.	Repair and replace.


Table-B ABS Warning Lamp Circuit Check – Lamp Comes “ON” Steady

Refer to TABLE – A for System Circuit Diagram and Circuit Description.

INSPECTION

Step	Action	Yes	No
1	Perform diagnostic trouble code check. Is there any DTC (including code No.12, NO CODES on SUZUKI scan tool) exists?	Go to Step 2.	Go to Step 3.
2	Does malfunction DTC (other than code No.12) exist at Step 1?	Go to Step 7 of “ABS DIAGNOSTIC FLOW TABLE” in this section.	Go to Step 3.
3	1) Disconnect ABS hydraulic unit/control module connector. 2) Check for proper connection to ABS hydraulic unit/control module connector at terminals “E35-14”, “E35-18” and “E35-24”. 3) If OK then ignition switch ON and measure voltage at terminal “E35-18” of connector. Is it 10 – 14 V?	Go to Step 4.	“GRN/ORN” circuit open.
4	1) With ABS hydraulic unit/control module connector disconnected, turn ignition switch ON and light ABS warning lamp. 2) Connect terminal “E35-14” of disconnected connector to ground using service wire. Does ABS warning lamp turn off?	Go to Step 5.	“RED/WHT” circuit open. If wire and connection are OK, replace combination meter (lamp driver module).
5	1) Measure resistance from connector terminal “E35-24” to body ground. Is continuity indicated?	Substitute a known-good ABS hydraulic unit/control module assembly and recheck.	“BLK” circuit open.

Table-C ABS Warning Lamp Circuit Check – The Lamp Flashes Continuously While Ignition Switch Is ON



1. "ABS" warning lamp in combination meter	3. Monitor connector	3-2. Diagnosis ground terminal
2. ABS hydraulic unit/control module assembly	3-1. Diagnosis switch terminal	4. ABS hydraulic unit/control module connector

CIRCUIT DESCRIPTION


When diagnosis switch terminal is shorted or connected to the ground with ignition switch ON, diagnosis trouble code (DTC) is indicated by flashing of ABS warning lamp only in the following cases.

- Normal DTC (12) is indicated if no malfunction DTC is detected in the ABS.
- A history malfunction DTC is indicated by flashing of the lamp if a current malfunction DTC is not detected at that point although a history malfunction DTC is stored in memory.

INSPECTION

Step	Action	Yes	No
1	Is diagnosis switch terminal connected to ground via service wire?	Go to Step 3.	Go to Step 2.
2	1) Ignition switch ON. 2) Measure voltage between diagnosis switch terminal and ground. Is it 10 – 14 V?	Substitute a known-good ABS hydraulic unit/control module assembly and recheck.	"PNK" wire circuit shorted to ground.
3	1) Ignition switch ON. 2) Does flashing of ABS warning lamp indicate DTC?	Go to Step 7 of "ABS DIAGNOSTIC FLOW TABLE" in this section.	Substitute a known-good ABS hydraulic unit/control module assembly and recheck.

Table-D Code (DTC) Is Not Outputted Even with Diagnosis Switch Terminal Connected to Ground



1. ABS warning lamp in combination meter	3. Monitor connector	3-2. Diagnosis ground terminal
2. ABS hydraulic unit/control module assembly	3-1. Diagnosis switch terminal	4. ABS hydraulic unit/control module connector

CIRCUIT DESCRIPTION

When diagnosis switch terminal is connected to ground with ignition switch turned ON, the ABS control module outputs diagnostic trouble code by flashing ABS warning lamp.

INSPECTION

Step	Action	Yes	No
1	Is it shorted diagnosis switch terminal and ground terminal by service wire properly?	Go to Step 2.	Connect service wire securely.
2	1) Disconnect service wire. 2) Disconnect ABS hydraulic unit/control module connector. 3) Measure resistance between diagnosis switch terminal and connector terminal "E35-12". Is it infinite (∞)?	"PNK" circuit open.	Go to Step 3.
3	1) Measure resistance between ground terminal of monitor coupler and body ground. Is continuity indicated?	Go to Step 4.	"BLK" circuit open or poor connection.
4	1) Check for proper connection to ABS hydraulic unit/control module at terminal "E35-12". 2) If OK, then check ABS warning lamp circuit referring to TABLE A, B and C. Is it in good condition?	Substitute a known-good ABS hydraulic with/control module assembly and recheck.	Repair "ABS" warning lamp circuit.

Table-E EBD Warning Lamp (Brake Warning Lamp) Check – Lamp Comes “On” Steady


CIRCUIT DESCRIPTION

EBD warning lamp (brake warning lamp) is controlled by parking brake switch, brake fluid level switch and ABS control module/hydraulic unit assembly through lamp driver module in combination meter. Refer to “TABLE-A” for circuit diagram.

INSPECTION

Step	Action	Yes	No
1	1) Make sure that : <ul style="list-style-type: none"> • Parking brake is completely released. • Brake fluid level is upper than the minimum level. Are the check results OK?	Go to Step 2.	Release parking brake completely and/or replenish brake fluid.
2	Does “ABS” warning lamp come on?	Perform “TABLE-B” previously outlined.	Go to Step 3.
3	1) Disconnect ABS hydraulic unit/control module connector. 2) Check for proper connection to ABS hydraulic unit/control module connector at terminals “E35-10”. 3) If OK, apply chocks to wheels and select gear in neutral position (P range for A/T). 4) Keep brake pedal depressed and start engine. Release parking brake. 5) Connect terminal “E35-10” of disconnected connector to ground using service wire. Does EBD warning lamp (brake warning lamp) turn off?	Substitute a known-good ABS hydraulic unit/control module assembly and recheck.	“PNK/GRN” circuit open. If wire and connection are OK, replace combination meter.


Diagnostic Trouble Code (DTC) Check (Using ABS Warning Lamp)



- 1) Perform ABS WARNING LAMP CHECK described above.
- 2) Using service wire (4), connect diagnosis switch terminal (2) of monitor connector (blue) (1) to ground (3).
- 3) Turn ignition switch ON.
- 4) Read flashing of ABS warning lamp which represents DTC as shown in example below and write it down. When more than 2 DTCs are stored in memory, flashing for each DTC is repeated three times starting with the smallest DTC number in increasing order.


For details of DTC, refer to "DTC TABLE".

Example : When right-front wheel speed sensor circuit opens (DTC 21)



- 5) After completing the check, turn ignition switch off, disconnect service wire from monitor coupler.

Diagnostic Trouble Code (DTC) Check (Using SUZUKI Scan Tool)



- 1) After setting cartridge for ABS to SUZUKI scan tool, connect SUZUKI scan tool to data link connector (1).

Special tool

(A) : SUZUKI scan tool

- 2) Turn ignition switch ON.
- 3) Read DTC according to instructions displayed on SUZUKI scan tool and print it or write it down. Refer to SUZUKI scan tool operator's manual for further details.
- 4) After completing the check, turn ignition switch off and disconnect SUZUKI scan tool from DLC.


Diagnostic Trouble Code (DTC) Clearance


WARNING:

When performing a driving test, select a safe place where there is neither any traffic nor any traffic accident possibility and be very careful during testing to avoid occurrence of an accident.

After repair or replace malfunction part(s), clear all DTCs by performing the following procedure.

- 1) Turn ignition switch OFF.
- 2) Using service wire (4), connect diagnosis switch terminal (2) of monitor connector (blue) (1) to ground terminal (3).
- 3) With connection described in above Step 2) maintained, turn ignition switch ON.





- 4) Repeat disconnecting and reconnecting of service wire between diagnosis and ground terminals 5 times or more at about 1sec. interval within 10 seconds.

O : Open
S : Short
T : About 10 seconds

- 5) Turn ignition switch OFF and disconnect service wire from monitor coupler.
- 6) Perform “DRIVING TEST” (Step 2 of “ABS DIAGNOSTIC FLOW TABLE” in this section) and “DTC CHECK” and confirm that normal DTC (DTC 12) is displayed ; not malfunction DTC.

NOTE:

















It is also possible to clear DTC by using SUZUKI scan tool. Refer to Cartridge Manual for procedure to clear DTC.

Diagnostic Trouble Code (DTC) Table

CAUTION:

Be sure to perform “ABS DIAGNOSTIC FLOW TABLE” before starting diagnosis.

DTC (displayed on SUZUKI scan tool)	DTC (indicated by ABS warning lamp)	ABS warning lamp flashing pattern	DIAGNOSTIC ITEMS	
NO DTC	12		Normal	
C1013	13		ABS control module	
C1015	15		G sensor circuit	
C1021	21		RF	Wheel speed sensor circuit
C1025	25		LF	
C1031	31		RR	
C1035	35		LR	

DTC (displayed on SUZUKI scan tool)	DTC (indicated by ABS warning lamp)	ABS warning lamp flashing pattern	DIAGNOSTIC ITEMS	
C1022	22		RF	Wheel speed sensor circuit or sensor ring
C1026	26		LF	
C1032	32		RR	
C1036	36		LR	
C1041	41		RF	Inlet solenoid valve circuit
C1042	42			Outlet solenoid valve circuit
C1045	45		LF	Inlet solenoid valve circuit
C1046	46			Outlet solenoid valve circuit
C1051	51		RR	Inlet solenoid valve circuit
C1052	52			Outlet solenoid valve circuit
C1055	55		LR	Inlet solenoid valve circuit
C1056	56			Outlet solenoid valve circuit
C1057	57		Power source	
C1061	61		ABS pump motor and/or motor relay circuit	
C1063	63		Fail safe-relay	
C1071	71		ABS control module	

DTC C1013 (DTC 13) – System Specifications Different From ABS Control Module Specifications


DESCRIPTION

When abnormal signal is inputted to a no-used terminal of control module while running or wrong ABS hydraulic unit/control module assembly is installed, this DTC will be set.

INSPECTION

- 1) Ignition switch OFF.
- 2) Check for proper connection from harness to control module.
- 3) If OK, substitute a known-good and correct specifications ABS hydraulic unit/control module assembly.
- 4) Recheck system.

DTC C1015 (DTC 15) -G Sensor Circuit



1. Ignition switch	3. ABS hydraulic unit/control module assembly
2. G sensor	4. ABS hydraulic unit/control module connector

DESCRIPTION

While a vehicle is at stop or running, if the potential difference between the sensor signal terminal “E35-11” and the sensor ground terminal “E35-13” is not within the specified voltage value, or if the signal voltage while at a stop does not vary from that while running, this DTC is set.

Therefore, this DTC may be set when a vehicle is lifted up and its wheel(s) is turned. In such case, clear the DTC and check again.

NOTE:

When ABS hydraulic unit/control module assembly for 4WD vehicle is installed to 2WD vehicle, this DTC is set. Before performing the INSPECTION as shown below, check part number for supply of ABS hydraulic unit/control module assembly referring to parts catalogue.

INSPECTION


Step	Action	Yes	No
1	Is G sensor installed floor securely?	Go to Step 2.	Tighten sensor or bracket screw securely. If not, using new screw.
2	1) Ignition switch OFF. 2) Remove G sensor with bracket. 3) Check for proper connection to G sensor. 4) If OK then check G sensor referring to INSPECTION of "G SENSOR". Is it in good condition?	Go to Step 3.	Replace G sensor.
3	1) Disconnect connectors from ABS hydraulic unit/control module assembly and G sensor. 2) Check for proper connection to ABS control module at terminals "E35-11" and "E35-13". 3) If OK, then turn ignition switch ON and measure voltage between "GRN/ORN" terminal of sensor connector and body ground. Is it 10 – 14 V?	Go to Step 4.	"GRN/ORN" circuit open.
4	Measure voltage between "ORN" terminal of sensor connector and body ground. Is it 0 V?	Go to Step 5.	"ORN" circuit shorted to power circuit.
5	1) Ignition switch OFF. 2) Check that "ORN" circuit is free from open or short to ground and "BLK/ORN" circuit. Is it in good condition?	"BLK/ORN" circuit open. If circuit is OK, substitute a known-good ABS hydraulic unit/control module assembly.	"ORN" circuit open or shorted to ground or "BLK/ORN" circuit.

DTC C1021 (DTC 21), DTC C1022 (DTC 22) – Right-front Wheel Speed Sensor Circuit or Sensor Ring

DTC C1025 (DTC 25), DTC C1026 (DTC 26) – Left-front Wheel Speed Sensor Circuit or Sensor Ring

DTC C1031 (DTC 31), DTC C1032 (DTC 32) – Right-rear Wheel Speed Sensor Circuit or Sensor Ring

DTC C1035 (DTC 35), DTC C1036 (DTC 36) – Left-rear Wheel Speed Sensor Circuit or Sensor Ring



1. Ignition switch	4. Right-front wheel speed sensor	7. ABS hydraulic unit/control module connector
2. ABS control module/hydraulic unit assembly	5. Left-rear wheel speed sensor	
3. Left-front wheel speed sensor	6. Right-rear wheel speed sensor	

DESCRIPTION

The ABS control module monitors the voltage at the terminal of each sensor while the ignition switch is ON. When the voltage is not within the specified range, an applicable DTC will be set. Also, when no sensor signal is inputted at starting or while running, an applicable DTC will be set.

NOTE:

When the vehicle was operated in any of the following ways, one of these DTCs may be set even when the sensor is in good condition. If such possibility is suspected, repair the trouble (dragging of brake, etc.) of the vehicle, clear DTC once and then after performing the driving test as described in Step 2 of “ABS DIAGNOSIS FLOW TABLE”, check whether or not any abnormality exists.

- The vehicle was driven with parking brake pulled.
- The vehicle was driven with brake dragging.
- Wheel spin occurred while driving.
- Wheel(s) was turned while the vehicle was jacked up.
- The vehicle was stuck.

INSPECTION

Step	Action	Yes	No
1	1) Disconnect applicable ABS wheel speed sensor coupler with ignition switch OFF. 2) Measure resistance between terminals of ABS wheel speed sensor. Refer to "FRONT WHEEL SPEED SENSOR" and/or "REAR WHEEL SPEED SENSOR" in this section. Is measured resistance value as specified?	Go to Step 2.	Replace ABS wheel speed sensor assembly.
2	1) Turn ignition switch OFF. 2) Disconnect ABS hydraulic unit/control module connector. 3) Check for proper connection to ABS control module at each sensor terminal. 4) If OK, then turn ignition switch ON and measure voltage between sensor terminal of module connector and body ground. Is it 0V?	Go to Step 3.	ABS wheel speed sensor circuit shorted to power.
3	1) Turn ignition switch OFF. 2) Connect ABS wheel speed sensor coupler. 3) Measure resistance between the following points. <ul style="list-style-type: none"> Both ABS hydraulic unit/control module connector terminals of the corresponding sensor. This check result should be the same as above Step 1. Either terminal of wheel speed sensor coupler and body ground. This check result should be no continuity. Are both check results OK?	Go to Step 4.	Circuit open or shorted to ground.
4	1) Remove applicable ABS wheel speed sensor. 2) Check sensor for damage or foreign material attached. Is it in good condition?	Go to Step 5.	Clean, repair or replace.
5	Check front and/or rear sensor ring for the following (remove rear drum as necessary) : <ul style="list-style-type: none"> Rotor serration (teeth) neither missing nor damaged. No foreign material being attached. Rotor not being eccentric. Wheel bearing free from excessive play. Are they in good condition?	Go to Step 6.	Clean, repair or replace.
6	1) Install ABS wheel speed sensor to knuckle. 2) Tighten sensor bolt to specified torque and check that there is no clearance between sensor and knuckle. Is it OK?	Go to Step 7.	Replace ABS wheel speed sensor.
7	Referring to "Reference" of "FRONT WHEEL SPEED SENSOR" and/or "Reference" of "REAR WHEEL SPEED SENSOR" in this section, check output voltage or waveform. Is specified voltage and/or waveform obtained?	Substitute a known-good ABS hydraulic unit/control module assembly and recheck.	Replace sensor and recheck.

DTC C1041 (DTC 41) – Right-front Inlet Solenoid Circuit

DTC C1045 (DTC 45) – Left-front Inlet Solenoid Circuit

DTC C1051 (DTC 51) – Right-rear Inlet Solenoid Circuit


DTC C1055 (DTC 55) – Left-rear Inlet Solenoid Circuit

DTC C1042 (DTC 42) – Right-front Outlet Solenoid Circuit

DTC C1046 (DTC 46) – Left-front Outlet Solenoid Circuit

DTC C1052 (DTC 52) – Right-rear Outlet Solenoid Circuit

DTC C1056 (DTC 56) – Left-rear Outlet Solenoid Circuit



1. ABS hydraulic unit/control module assembly	3. ABS control module	5. Fail-safe relay
2. ABS hydraulic unit/control module assembly connector	4. Signal	

DESCRIPTION


The ABS control module monitors the output from the valve.

When the output of each valve exceeds the specified value compared with the signal sent from ABS control module, this DTC is set.

INSPECTION

Step	Action	Yes	No
1	1) Check solenoid operation referring to item "ABS HYDRAULIC UNIT OPERATION CHECK" in this section. Is it in good condition?	Check terminal "E35-25" connection. If connection is OK, substitute a known-good ABS hydraulic unit/control module assembly and recheck.	Go to Step 2.
2	1) Ignition switch OFF. 2) Disconnect ABS hydraulic unit/control module connector. 3) Check for proper connection to ABS hydraulic unit/control module connector at terminal "E35-25". 4) If OK, then measure voltage between terminal "E35-25" of module connector and "E35-24". Is it 10 – 14 V?	Substitute a known-good ABS hydraulic unit/control module assembly and recheck.	"WHT/BLU" or "BLK" circuit open.

DTC C1057 (DTC 57) – Power Source Circuit



1. Ignition switch	3. ABS hydraulic unit/control module assembly
2. Main fuse	4. ABS hydraulic unit/control module connector


DESCRIPTION

The ABS control module monitors the power source voltage at terminal “E35-18”. When the power source voltage becomes extremely high or low, this DTC will be set. As soon as the voltage rises or lowers to the specified level, the set DTC will be cleared.

INSPECTION

Step	Action	Yes	No
1	1) Connect a voltmeter between battery positive (+) terminal and body ground. 2) Start the engine and measure the maximum voltage when racing the engine. Is it over 18V?	Check charging system referring to “CHARGING SYSTEM” section.	Go to Step 2.
2	1) Disconnect ABS hydraulic unit/control module connector. 2) Keep the engine idling, measure the voltage between terminal “E35-18” of ABS control module and body ground. Is it always under 9V?	Check charging system referring to “CHARGING SYSTEM” section. Imperfect short between wire “GRN/ORN” and ground.	Poor connection of terminal “E35-18” or “E35-24” of the ABS control module. If the above are in good condition, substitute a known-good ABS hydraulic unit/control module and recheck.

DTC C1061 (DTC 61) – ABS Pump Motor Circuit



1. ABS hydraulic unit/control module assembly	3. ABS pump motor	5. ABS hydraulic unit/control module connector
2. ABS pump motor relay	4. ABS fail safe relay	


DESCRIPTION

The ABS control module monitors the voltage at monitor terminal of pump motor circuit constantly with the ignition switch turned ON. It sets this DTC when the voltage at the monitor terminal does not become high/low according to ON/OFF commands to the motor relay of the module (does not follow these commands).

INSPECTION

Step	Action	Yes	No
1	1) Check pump motor referring to “ABS HYDRAULIC UNIT OPERATION CHECK” in this section. Is it in good condition?	Check terminals “E35-25” and “E35-23” connection. If connections OK, substitute a known-good ABS hydraulic unit/control module assembly and recheck.	Go to Step 2.
2	1) Ignition switch OFF. 2) Disconnect ABS hydraulic unit/control module connector. 3) Check for proper connection to ABS hydraulic unit/control module connector at terminal “E35-23”. 4) If OK, then measure voltage between terminal “E35-23” of module connector and body ground. Is it 10 – 14 V?	Go to Step 3.	“WHT/BLU” circuit open.
3	Measure resistance between terminal “E35-22” of ABS hydraulic unit/control module connector and body ground. Is it infinite (∞)?	“BLK” circuit open.	Substitute a known-good ABS hydraulic unit/control module assembly and recheck.

DTC C1063 (DTC 63) – ABS Fail-safe Relay Circuit



1. Ignition switch	3. ABS hydraulic unit/control module connector	5. To pump motor relay
2. ABS hydraulic unit/control module assembly	4. To solenoid valves	6. Fail-safe relay

DESCRIPTION


ABS control module monitors the voltage at the terminal of solenoid circuit constantly with ignition switch turned ON. Also, immediately after ignition switch is turned ON, perform initial check as follows.

Switch fail-safe relay in the order of OFF → ON and check if voltage changes to Low → High. If anything faulty is found in the initial check and when the voltage is low with ignition switch turned ON, this DTC will be set.

INSPECTION

Step	Action	Yes	No
1	Check battery voltage. Is it about 11 V or higher?	Go to Step 2.	Check charging system referring to "CHARGING SYSTEM" section.
2	Check ABS main fuse and connection. Is it in good condition?	Go to Step 3.	Repair and/or replace fuse.
3	1) Ignition switch OFF. 2) Disconnect ABS hydraulic unit/control module connector. 3) Check proper connection to ABS hydraulic unit/control module at terminal "E35-25". 4) If OK, then measure voltage between connector terminal "E35-25" and body ground. Is it 10 – 14 V?	Substitute a known-good ABS hydraulic unit/control module assembly and recheck.	"WHT/BLU" circuit open or short to ground.

DTC C1071 (DTC 71) – ABS Control Module



1. ABS hydraulic unit/control module assembly	3. ABS pump motor	5. ABS hydraulic unit/control module connector
2. ABS pump motor relay	4. ABS fail safe relay	

DESCRIPTION

This DTC will be set when an internal malfunction is detected in the ABS control module.

INSPECTION


Step	Action	Yes	No
1	Clear all DTCs and check DTC. Is it DTC 71?	Go to Step 2.	Could be a temporary malfunction of the ABS control module.
2	1) Check proper connection of ABS hydraulic unit/control module connector. 2) If OK, disconnect ABS hydraulic unit/control module connector and check the followings. <ul style="list-style-type: none">• Voltage “E35-25” terminal : 10 – 14 V• Resistance between “E35-22” and body ground : Continuity Are the check result as specified above?	Replace ABS hydraulic unit/control module assembly.	Repair and recheck.

ON-Vehicle Service

Precautions

When connector is connected to ABS hydraulic unit/control module assembly, do not disconnect connectors of sensors with ignition switch ON. Then DTC will be set in ABS control module.

ABS Hydraulic Unit Operation Check (Using SUZUKI Scan Tool)




- 1) Connect SUZUKI scan tool to data link connector (DLC) (1) with ignition switch OFF.

Special tool


(A) : SUZUKI scan tool

- 2) Turn ignition switch to ON position and check actuator operation using “HYDRAULIC CONTROL TEST” under “miscellaneous test” (“MISC. TEST”) mode of SUZUKI scan tool.

ABS Hydraulic Unit Operation Check (Not Using SUZUKI Scan Tool)




- 1) Check that basic brake system other than ABS is in good condition.
- 2) Check that battery voltage is 11 V or higher.
- 3) With ABS warning lamp, check that no abnormality is detected in ABS. Refer to “DIAGNOSTIC TROUBLE CODE (DTC) CHECK” in this section.
- 4) Lift up vehicle.
- 5) Set transmission to neutral and release parking brake.
- 6) Turn each wheel gradually by hand to check if brake dragging occurs. If it does, correct.



- 7) With diagnosis switch terminal (1) of monitor connector (blue) (2) connected to ground terminal (3) using service wire (4), turn ignition switch ON and check if ABS warning lamp indicates DTC 12.

If malfunction DTC is indicated, repair it first.

- 8) Turn ignition switch OFF.



- 9) Perform the following checks with help of another person.

Brake pedal (1) should be depressed and then ignition switch (2) turned ON by one person and wheel (3) should be turned by another person's hand. At this time, check that :

- Operation sound of solenoid is heard and wheel turns only about 0.5 sec. (Brake force is depressurized).
- Operation sound of pump motor is heard and pulsation is felt at brake pedal.

- 10) If all 4-wheels cannot be checked during one ignition cycle (OFF → ON), repeat Steps 8) and 9) till all 4 wheels are checked.


If a faulty condition is found in Steps 9) and 10), replace hydraulic unit/control module assembly.

- 11) Turn ignition switch OFF and remove service wire from monitor coupler.

ABS Hydraulic Unit/Control Module Assembly

CAUTION:

Never disassemble ABS hydraulic unit/control module assembly, loosen blind plug or remove motor. Performing any of these prohibited services will affect original performance of ABS hydraulic unit/control module assembly.




1. Brake pipe	3. Bracket
2. ABS hydraulic unit/control module assembly	4. Connector


HYDRAULIC UNIT INSPECTION

Check hydraulic unit for fluid leakage.
If any, repair or replace.

REMOVAL

- 1) Disconnect negative cable from battery.
- 2) Disconnect ABS hydraulic unit/control module assembly connector (1) by pulling up lock (2).






- 3) Using special tool, loosen flare nuts (1) and disconnect brake pipes (2) from ABS hydraulic unit/control module assembly (3).

Special tool

(A) : 09950-78220

NOTE:

Put bleeder plug cap or the like onto pipe to prevent fluid from spilling. Do not allow brake fluid to get on painted surfaces.



- 4) Remove two nuts and disconnect take out ABS hydraulic unit/control module assembly (1) from bracket using flat end rod or the like (2).

CAUTION:

- Do not give an impact to hydraulic unit.
- Use care not to allow dust to enter hydraulic unit.
- Do not place hydraulic unit on its side or upside down. Handling it in inappropriate way will affect its original performance.

INSTALLATION

- 1) Install hydraulic unit/control module assembly by reversing removal procedure.

Tightening torque

Brake pipe flare nut (a) :

16 N·m (1.6 kg-m, 11.5 lb-ft)

ABS hydraulic unit/control module assembly bolt (b) :

9 N·m (0.9 kg-m, 6.5 lb-ft)


ABS hydraulic unit/control module assembly bracket bolt (c) : 23 N·m (2.3 kg-m, 16.5 lb-ft)

- 2) Bleed air from brake system referring to "BRAKES" section.
3) Check each installed part for fluid leakage and perform "ABS HYDRAULIC UNIT OPERATION CHECK" in this section.


NOTE:

For new ABS hydraulic unit/control module assembly, if "ABS HYDRAULIC UNIT OPERATION CHECK" procedure has not been performed, "ABS" warning lamp may flash when ignition switch is turned ON position.

Accordingly preform "ABS HYDRAULIC UNIT OPERATION CHECK" to stop flashing of ABS warning lamp.



Front Wheel Speed Sensor




1. Left front wheel speed sensor	3. Grommet	5. Sensor ring
2. Clamp bolt	4. Connector	

OUTPUT VOLTAGE INSPECTION

- 1) Turn ignition switch OFF.
- 2) Hoist vehicle a little.
- 3) Disconnect wheel speed sensor connector.
- 4) Disconnect wheel speed sensor grommet from vehicle body.
- 5) Connect voltmeter between connector (1) terminals.
- 6) While turning wheel by hand at a speed of approximately 1/2 to 1 rotation per second, check AC voltage of sensor.

**Output AC voltage at 1/2 to 1 rotation per second
: 53 mV or more**


- 7) If measured voltage is not as specified, check sensor, rotor and their installation conditions.



Reference

When using oscilloscope for this check, check if peak-to-peak voltage (1) meets specification and waveform is complete.

**Peak-to-peak voltage at 1/2 to 1 rotation per second
: 150 mV or more at 21 – 42 Hz**




REMOVAL

- 1) Disconnect negative cable at battery.
- 2) Disconnect front wheel speed sensor coupler (1).
- 3) Hoist vehicle and remove wheel.
- 4) Remove harness clamp bolts (2) and grommet (3).
- 5) Remove front wheel speed sensor (4) from knuckle.

CAUTION:

- Do not pull wire harness when removing front wheel speed sensor.
- Do not cause damage to surface of front wheel speed sensor and do not allow dust, etc. to enter its installation hole.




SENSOR INSPECTION

- Check sensor for damage.
- Check sensor for resistance and continuity.


**Between both terminals (1) of sensor
: 1.2 – 1.6 k Ω at 20°C (68°F)**

**Between sensor terminal and sensor body (2)
: No continuity**

- If the check result is not as specified and any malfunction is found, replace.



SENSOR RING INSPECTION



- Check ring for being missing, damaged or deformed.
 - Turn drive shaft and check if ring rotation is free from eccentricity and looseness.
 - Check that no foreign material is attached.
- If any faulty is found, repair or replace. Refer to “DRIVE SHAFT ASSEMBLY” in Section 4A.

INSTALLATION

- 1) Check that no foreign material is attached to sensor (1) and sensor ring (2).
- 2) Install it by reversing removal procedure.


Tightening torque

Front wheel speed sensor bolt (a) :
23 N·m (2.3 kg-m, 17.0 lb-ft)

CAUTION:

Do not pull or twist wire harness more than necessary when installing front wheel speed sensor.

- 3) Check that there is no clearance between sensor and knuckle.




Front Wheel Speed Sensor Ring

NOTE:

The front wheel sensor ring can not be removed or replaced alone. If front wheel sensor ring needs to be replaced, replace it as a wheel side joint assembly of drive shaft.

For removal and installation of wheel side joint assembly of drive shaft, refer to “FRONT DRIVE SHAFT” section.



Rear Wheel Speed Sensor



1. Left rear wheel speed sensor	3. Clip	5. Connector	[A] : 2WD vehicle
2. Clamp bolt	4. Sensor ring	6. Grommet	[B] : 4WD vehicle

OUTPUT VOLTAGE INSPECTION


- 1) Turn ignition switch OFF.
- 2) Remove quarter inner trim (1).
- 3) Turn over floor carpet.
- 4) Hoist vehicle.
- 5) Disconnect connector of wheel speed sensor.



- 6) Connect voltmeter between connector (1) terminals.
- 7) While turning wheel at a speed of approximately 1/2 to 1 rotation per second, check AC voltage of sensor.

**Output AC voltage at 1/2 to 1 rotation per second
: 53 mV or more**

- 8) If measured voltage is not as specified, check sensor, rotor and their installation conditions.





Reference

When using oscilloscope for this check, check if peak-to-peak voltage (1) meets specification and waveform is complete.

**Peak-to-peak voltage at 1/2 to 1 rotation per second
: 150 mV or more at 21 – 42 Hz**

REMOVAL

- 1) Disconnect negative cable at battery.
- 2) Remove quarter inner trim (1).
- 3) Turn over floor carpet.
- 4) Hoist vehicle.



- 5) Disconnect rear wheel speed sensor coupler (1).
- 6) Detach ABS wheel sensor wire harness (2).

NOTE:

Do not detach crimp of rear wheel speed sensor connector from vehicle body unless replacement is necessary.

- 7) Remove rear wheel speed sensor (3) from knuckle.

CAUTION:

- Do not pull wire harness when removing rear wheel speed sensor.
- Do not cause damage to surface of rear wheel speed sensor and do not allow dust, etc. to enter its installation hole.


SENSOR INSPECTION

- Check sensor for damage.
- Check sensor for resistance and continuity.


**Between both terminals of sensor
: 1.2 – 1.6 k Ω at 20°C (68°F)**

**Between sensor terminal and sensor body
: No continuity**

- If the check result is not as specified and any malfunction is found, replace.



SENSOR RING INSPECTION



- Check ring serration (teeth) for being missing, damaged or deformed.

[A]: For 2WD



[B]: For 4WD

- Turn wheel and check if ring rotation is free from eccentricity and looseness.
- Check that no foreign material is attached.
- If any faulty is found, repair or replace.

INSTALLATION

Reverse removal procedure for installation noting the following.

- Check that no foreign material is attached to sensor and ring (1).



- Be sure to install wheel speed sensor (2) and its bolt at the correct (upper) position as shown in figure.
Tighten sensor bolt to specified torque.

Tightening torque

Sensor bolt (a) : 23 N·m (2.3 kg-m, 17.0 lb-ft)

CAUTION:

Do not pull or twist wire harness more than necessary when installing rear wheel speed sensor.

- Check that there is no clearance between sensor and knuckle.

Rear Wheel Speed Sensor Ring

NOTE:


The rear wheel sensor ring can not be removed or replaced alone. If rear wheel sensor ring needs to be replaced, replace it as a wheel side joint assembly of drive shaft (for 4WD vehicle) or wheel hub assembly (for 2WD vehicle).

For removal and installation of wheel side joint assembly of drive shaft or wheel hub assembly, refer to Section 4C or Section 3.

G Sensor (For 4WD Vehicle Only)

REMOVAL

- 1) Turn ignition switch OFF and disconnect battery negative cable.
- 2) Remove ABS fuse from fuse box.
- 3) Disconnect ABS hydraulic unit/control module assembly connector by pulling up lock.
- 4) Remove left front seat assembly.
- 5) Remove console box.
- 6) Remove G sensor (1) from floor.
- 7) Disconnect connector from sensor.



CAUTION:

Sensor must not be dropped or shocked. It will affect its original performance.

2. Label

INSPECTION

Connect positive cable of 12 volt battery to "A" terminal of sensor and ground cable to "C" terminal. Then using voltmeter, check voltage between "B" terminal and "C" terminal.


G sensor specification

When placed horizontally : 2 – 3 V

When placed upright with arrow upward : 3 – 4 V

When placed upright with arrow downward : 1 – 2 V

If measured voltage is not as specified, replace sensor.




[A] : Horizontal

[B] : Upright with arrow upward

[C] : Upright with arrow downward

INSTALLATION

- 1) Connect connector to sensor securely.
- 2) Install sensor onto floor so that arrow mark (1) directs vehicle forward.




Tightening torque

G sensor bolt (a) : 3.0 N·m (0.3 kg-m, 2.2 lb-ft)


- 3) Connect ABS hydraulic unit/control module assembly connector.
- 4) Install ABS fuse to fuse box.
- 5) Install console box.
- 6) Install left front seat assembly.
- 7) Connect negative cable at battery.

Special Tool




09931-76011

Tech 1A kit (SUZUKI scan tool) See NOTE "A" below.




Mass storage cartridge for Tech 1A




09931-76030

16/14 pin DLC cable for Tech 1A



09950-78220

Flare nut wrench (10 mm)



Tech 2 kit (SUZUKI scan tool) See NOTE "B" below.

NOTE:

- "A" : This kit includes the following items and substitutes for the Tech 2 kit.
 1. Storage case, 2. Operator's manual, 3. Tech 1A, 4. DLC cable, 5. Test lead/probe, 6. Power source cable, 7. DLC cable adaptor, 8. Self-test adaptor
- "B" : This kit includes the following items and substitutes for the Tech 1A kit.
 1. Tech 2, 2. PCMCIA card, 3. DLC cable, 4. SAE 16/19 adapter, 5. Cigarette cable, 6. DLC loopback adapter, 7. Battery power cable, 8. RS232 cable, 9. RS232 adapter, 10. RS232 loopback connector, 11. Storage case, 12. Power supply

SECTION 6

ENGINE GENERAL INFORMATION AND DIAGNOSIS (M13/M16 ENGINES)

WARNING:

For vehicles equipped with Supplemental Restraint (Air Bag) System :

- Service on and around the air bag system components or wiring must be performed only by an authorized SUZUKI dealer. Refer to “Air Bag System Components and Wiring Location View” under “General Description” in air bag system section in order to confirm whether you are performing service on or near the air bag system components or wiring. Please observe all WARNINGS and “Service Precautions” under “On-Vehicle Service” in air bag system section before performing service on or around the air bag system components or wiring. Failure to follow WARNINGS could result in unintentional activation of the system or could render the system inoperative. Either of these two conditions may result in severe injury.
- Technical service work must be started at least 90 seconds after the ignition switch is turned to the “LOCK” position and the negative cable is disconnected from the battery. Otherwise, the system may be activated by reserve energy in the Sensing and Diagnostic Module (SDM).

NOTE:

Whether the following systems (parts) are used in the particular vehicle or not depends on vehicle specifications. Be sure to bear this in mind when performing service work.

- EGR valve
- Heated oxygen sensor(s) or CO adjusting resistor
- Three way catalytic converter
- Immobilizer indicator lamp
- Knock sensor

CONTENTS

General Information	6-3	Diagnostic Trouble Code (DTC)	
Statement on Cleanliness and Care	6-3	Clearance.....	6-15
General Information on Engine Service	6-3	Diagnostic trouble code (DTC) table	6-16
Precaution on fuel system service.....	6-4	Fail-safe table.....	6-19
Fuel pressure relief procedure	6-5	Visual inspection	6-21
Fuel leakage check procedure	6-5	Engine basic inspection	6-22
Engine Diagnosis	6-5	Engine diagnosis table	6-24
General Description	6-5	Scan Tool Data	6-29
On-Board Diagnostic System (Vehicle with		Inspection of ECM and Its Circuits.....	6-34
Immobilizer Indicator Lamp).....	6-6	Component Location.....	6-39
On-Board Diagnostic System (Vehicle without		Table A-1 Malfunction Indicator Lamp Circuit	
Immobilizer Indicator Lamp).....	6-9	Check - Lamp Does Not Come “ON” at	
Precaution in Diagnosing Trouble	6-10	Ignition Switch ON (But Engine at Stop)	6-40
Engine Diagnostic Flow Table.....	6-11	Table A-2 Malfunction Indicator Lamp Circuit	
Customer problem inspection form		Check - Lamp Remains “ON” after Engine	
(example)	6-13	Starts.....	6-41
Malfunction indicator lamp (MIL) check.....	6-14	Table A-3 MIL Check - MIL Flashes at	
Diagnostic trouble code (DTC) check.....	6-14	Ignition Switch ON (Vehicle without	
		Immobilizer Indicator Lamp).....	6-41

Table A-4 MIL Check - MIL Does Not Flash or Just Remains ON Even with Grounding Diagnosis Switch Terminal (Vehicle without Immobilizer Indicator Lamp).....	6-42
Table A-5 ECM Power and Ground Circuit Check - MIL Does Not Light at Ignition Switch ON and Engine Doesn't Start Though It Is Cranked Up.....	6-42
DTC P0105 (DTC No.11) Manifold Absolute Pressure (MAP) Circuit Malfunction.....	6-45
DTC P0110 (DTC No.18) Intake Air Temp. (IAT) Circuit Malfunction.....	6-48
DTC P0115 (DTC No.19) Engine Coolant Temperature (ECT) Circuit Malfunction.....	6-50
DTC P0120 (DTC No.13) Throttle Position Circuit Malfunction.....	6-52
DTC P0121 Throttle Position Circuit Range/Performance Problem.....	6-54
DTC P0130 (DTC No.14) Heated Oxygen Sensor (HO2S) Circuit Malfunction (Sensor-1).....	6-56
DTC P0133 Heated Oxygen Sensor (HO2S) Circuit Slow Response (Sensor-1).....	6-58
DTC P0134 Heated Oxygen Sensor (HO2S) Circuit No Activity Detected (Sensor-1).....	6-59
DTC P0135 (DTC No.14) Heated Oxygen Sensor (HO2S) Heater Circuit Malfunction (Sensor-1).....	6-60
DTC P0136 Heated Oxygen Sensor (HO2S) Circuit Malfunction (Sensor-2).....	6-62
DTC P0141 Heated Oxygen Sensor (HO2S) Heater Circuit Malfunction (Sensor-2).....	6-64
DTC P0171 Fuel System Too Lean.....	6-66
DTC P0172 Fuel System Too Rich.....	6-66
DTC P0300 Random Misfire Detected (Misfire Detected at 2 or More Cylinders).....	6-70
DTC P0301 Cylinder 1 Misfire Detected.....	6-70
DTC P0302 Cylinder 2 Misfire Detected.....	6-70
DTC P0303 Cylinder 3 Misfire Detected.....	6-70
DTC P0304 Cylinder 4 Misfire Detected.....	6-70
DTC P0325 (DTC No.17) Knock Sensor Circuit Malfunction.....	6-74
DTC P0335 (DTC No.23) Crankshaft Position (CKP) Sensor Circuit Malfunction ...	6-76

DTC P0340 (DTC No.15) Camshaft Position (CMP) Sensor Circuit Malfunction.....	6-79
DTC P0400 Exhaust Gas Recirculation Flow Malfunction.....	6-82
DTC P0420 Catalyst System Efficiency below Threshold.....	6-85
DTC P0443 Purge Control Valve Circuit Malfunction.....	6-88
DTC P0480 Radiator Cooling Fan Control System Malfunction.....	6-89
DTC P0500 (DTC No.16) Vehicle Speed Sensor (VSS) Malfunction.....	6-91
DTC P0505 (DTC No.26) Idle Control System Malfunction.....	6-93
DTC P1450 Barometric Pressure Sensor Low/High Input.....	6-95
DTC P1451 Barometric Pressure Sensor Performance Problem.....	6-95
DTC P1500 Engine Starter Signal Circuit Malfunction.....	6-97
DTC P1510 ECM Back-Up Power Supply Malfunction.....	6-98
DTC P1600 Serial Communication Problem Between ECM and TCM.....	6-99
DTC P1717 A/T Drive Range (Park/Neutral Position) Signal Circuit Malfunction.....	6-101
Table B-1 Fuel Injector Circuit Check.....	6-103
Table B-2 Fuel Pump and Its Circuit Check.....	6-104
Table B-3 Fuel Pressure Check.....	6-106
Table B-4 Idle Air Control System Check	6-108
Table B-5 A/C Signal Circuits Check (Vehicle with A/C).....	6-111
Table B-6 Electric Load Signal Circuit Check.....	6-115
Table B-7 Radiator Fan Control System Check.....	6-117
Table B-8 Power Steering Pressure (PSP) Switch Signal Circuit Check (If equipped)....	6-119
Table B-9 Generator Control Signal Circuit Check.....	6-120
Special Tool	6-121

General Information

Statement on Cleanliness and Care

An automobile engine is a combination of many machined, honed, polished and lapped surfaces with tolerances that are measured in the thousands of an millimeter (ten thousands of an inch).


Accordingly, when any internal engine parts are serviced, care and cleanliness are important.

Throughout this section, it should be understood that proper cleaning and protection of machined surfaces and friction areas is part of the repair procedure. This is considered standard shop practice even if not specifically stated.

- A liberal coating of engine oil should be applied to friction areas during assembly to protect and lubricate the surfaces on initial operation.
- Whenever valve train components, pistons, piston rings, connecting rods, rod bearings, and crankshaft journal bearings are removed for service, they should be retained in order.

At the time of installation, they should be installed in the same locations and with the same mating surfaces as when removed.

- Battery cables should be disconnected before any major work is performed on the engine. Failure to disconnect cables may result in damage to wire harness or other electrical parts.



- Throughout this manual, the four cylinders of the engine are identified by numbers; No.1 (1), No.2 (2), No.3 (3) and No.4 (4) counted from crankshaft pulley side to flywheel side.

General Information on Engine Service


THE FOLLOWING INFORMATION ON ENGINE SERVICE SHOULD BE NOTED CAREFULLY, AS IT IS IMPORTANT IN PREVENTING DAMAGE, AND IN CONTRIBUTING TO RELIABLE ENGINE PERFORMANCE.

- When raising or supporting engine for any reason, do not use a jack under oil pan. Due to small clearance between oil pan and oil pump strainer, jacking against oil pan may cause it to be bent against strainer resulting in damaged oil pick-up unit.
- It should be kept in mind, while working on engine, that 12-volt electrical system is capable of violent and damaging short circuits.

When performing any work where electrical terminals can be grounded, ground cable of the battery should be disconnected at battery.

- Any time the air cleaner, throttle body or intake manifold is removed, the intake opening should be covered. This will protect against accidental entrance of foreign material which could follow intake passage into cylinder and cause extensive damage when engine is started.

Precaution on fuel system service



- Work must be done with no smoking, in a well-ventilated area and away from any open flames.
- As fuel feed line (between fuel pump and fuel delivery pipe) is still under high fuel pressure even after engine was stopped, loosening or disconnecting fuel feed line directly may cause dangerous spout of fuel to occur where loosened or disconnected.

Before loosening or disconnecting fuel feed line, make sure to release fuel pressure according to “FUEL PRESSURE RELIEF PROCEDURE”. A small amount of fuel may be released after the fuel line is disconnected. In order to reduce the chance of personal injury, cover the fitting to be disconnected with a shop cloth. Put that cloth in an approved container when disconnection is completed.


- Never run engine with fuel pump relay disconnected when engine and exhaust system are hot.
- Fuel or fuel vapor hose connection varies with each type of pipe. When reconnecting fuel or fuel vapor hose, be sure to connect and clamp each hose correctly referring to figure Hose Connection.

After connecting, make sure that it has no twist or kink.

- When installing injector or fuel delivery pipe, lubricate its O-ring with spindle oil or gasoline.
- When connecting fuel pipe flare nut, first tighten flare nut by hand and then tighten it to specified torque.

[A] :	With short pipe, fit hose as far as it reaches pipe joint as shown.
[B] :	With following type pipe, fit hose as far as its peripheral projection as shown.
[C] :	With bent pipe, fit hose as its bent part as shown or till pipe is about 20 to 30 mm (0.79 – 1.18 in.) into the hose.
[D] :	With straight pipe, fit hose till pipe is, about 20 to 30 mm (0.79 – 1.18 in.) into the hose.
1.	Hose
2.	Pipe
3.	Clamp
4.	Clamp securely at a position 3 to 7 mm (0.12 – 0.27 in.) from hose end.
5.	20 to 30 mm (0.79 – 1.18 in.)

Fuel pressure relief procedure



CAUTION:

This work must not be done when engine is hot. If done so, it may cause adverse effect to catalyst.

After making sure that engine is cold, release fuel pressure as follows.

- 1) Place transmission gear shift lever in "Neutral" (Shift selector lever to "P" range for A/T model), set parking brake, and block drive wheels.
- 2) Remove relay box cover.
- 3) Disconnect fuel pump relay (1) from relay box.
- 4) Remove fuel filler cap to release fuel vapor pressure in fuel tank and then reinstall it.
- 5) Start engine and run it till it stops for lack of fuel. Repeat cranking engine 2 – 3 times for about 3 seconds each time to dissipate fuel pressure in lines. Fuel connections are now safe for servicing.
- 6) Upon completion of servicing, connect fuel pump relay (1) to relay box and install relay box cover.

Fuel leakage check procedure

After performing any service on fuel system, check to make sure that there are no fuel leakages as follows.

- 1) Turn ON ignition switch for 3 seconds (to operate fuel pump) and then turn it OFF.
Repeat this (ON and OFF) 3 or 4 times and apply fuel pressure to fuel line. (till fuel pressure is felt by hand placed on fuel feed hose.)
- 2) In this state, check to see that there are no fuel leakages from any part of fuel system.

Engine Diagnosis


General Description

This vehicle is equipped with an engine and emission control system which are under control of ECM.

The engine and emission control system in this vehicle are controlled by ECM. ECM has an On-Board Diagnostic system which detects a malfunction in this system and abnormality of those parts that influence the engine exhaust emission. When diagnosing engine troubles, be sure to have full understanding of the outline of "On-Board Diagnostic System" and each item in "Precaution in Diagnosing Trouble" and execute diagnosis according to "ENGINE DIAGNOSTIC FLOW TABLE".

There is a close relationship between the engine mechanical, engine cooling system, ignition system, exhaust system, etc. and the engine and emission control system in their structure and operation. In case of an engine trouble, even when the malfunction indicator lamp (MIL) doesn't turn ON, it should be diagnosed according to this flow table.

On-Board Diagnostic System (Vehicle with Immobilizer Indicator Lamp)



ECM in this vehicle has following functions.

- When the ignition switch is turned ON with the engine at a stop, malfunction indicator lamp (MIL) (1) turns ON to check the bulb of the malfunction indicator lamp (1).
- When ECM detects a malfunction which gives an adverse effect to vehicle emission while the engine is running, it makes the malfunction indicator lamp (1) in the meter cluster of the instrument panel turn ON or flash (flashing only when detecting a misfire which can cause damage to the catalyst) and stores the malfunction area in its memory.
(If it detects that continuously 3 driving cycles are normal after detecting a malfunction, however, it makes MIL (1) turn OFF although DTC stored in its memory will remain.)
- As a condition for detecting a malfunction in some areas in the system being monitored by ECM and turning ON the malfunction indicator lamp (1) due to that malfunction, 2 driving cycle detection logic is adopted to prevent erroneous detection.
- When a malfunction is detected, engine and driving conditions then are stored in ECM memory as freeze frame data. (For the details, refer to description on Freeze frame data.)
- It is possible to communicate by using not only SUZUKI scan tool (2) but also generic scan tool. (Diagnostic information can be accessed by using a scan tool.)

3. Immobilizer indicator lamp

WARM-UP CYCLE

A warm-up cycle means sufficient vehicle operation such that the coolant temperature has risen by at least 22°C (40°F) from engine starting and reaches a minimum temperature of 70°C (160°F).

DRIVING CYCLE

A "Driving Cycle" consists of engine startup, driving mode where a malfunction would be detected if present, and engine shutoff.

2 DRIVING CYCLES DETECTION LOGIC

The malfunction detected in the first driving cycle is stored in ECM memory (in the form of pending DTC and freeze frame data) but the malfunction indicator lamp does not light at this time. It lights up at the second detection of same malfunction also in the next driving cycle.

PENDING DTC

Pending DTC means a DTC detected and stored temporarily at 1 driving cycle of the DTC which is detected in the 2 driving cycle detection logic.

FREEZE FRAME DATA

[A]		
1. Trouble Code	P0102	(1st)
2. Engine Speed	782 RPM	↑
3. Eng Cool Tmp	80°C	
4. Vehicle Spd.	0 km/h	
5. MAP Sensor	39kPa	
6. St. Term FT1	-0.8% Lean	
7. Lg. Term FT1	-1.6% Lean	
8. Fuel 1 Stat.	Closed Loop	
9. Fuel 2 Stat.	Not used	
10. Load value	25.5%	[B]

ECM stores the engine and driving conditions (in the form of data as shown in the figure) at the moment of the detection of a malfunction in its memory. This data is called “Freeze frame data”. Therefore, it is possible to know engine and driving conditions (e.g., whether the engine was warm or not, where the vehicle was running or stopped, where air/fuel mixture was lean or rich) when a malfunction was detected by checking the freeze frame data. Also, ECM has a function to store each freeze frame data for three different malfunctions in the order as the malfunction is detected. Utilizing this function, it is possible to know the order of malfunctions that have been detected. Its use is helpful when rechecking or diagnosing a trouble.

Priority of freeze frame data :

ECM has 4 frames where the freeze frame data can be stored. The first frame stores the freeze frame data of the malfunction which was detected first. However, the freeze frame data stored in this frame is updated according to the priority described below. (If malfunction as described in the upper square “1” below is detected while the freeze frame data in the lower square “2” has been stored, the freeze frame data “2” will be updated by the freeze frame data “1”.)

[A] : An Example of Freeze Frame Data

[B] : 1st, 2nd or 3rd in parentheses here represents which position in the order the malfunction is detected.

PRIORITY	FREEZE FRAME DATA IN FRAME 1
1	Freeze frame data at initial detection of malfunction among misfire detected (P0300-P0304), fuel system too lean (P0171) and fuel system too rich (P0172)
2	Freeze frame data when a malfunction other than those in “1” above is detected

In the 2nd through the 4th frames, the freeze frame data of each malfunction is stored in the order as the malfunction is detected. These data are not updated.

Shown in the table below are examples of how freeze frame data are stored when two or more malfunctions are detected.

			FRAME			
			FRAME 1	FRAME 2	FRAME 3	FRAME4
			FREEZE FRAME DATA to be updated	1st FREEZE FRAME DATA	2nd FREEZE FRAME DATA	3rd FREEZE FRAME DATA
MALFUNCTION DETECTED ORDER		No malfunction	No freeze frame data			
	1	P0400 (EGR) detected	Data at P0400 detection	Data at P0400 detection	—	—
	2	P0171 (Fuel sys- tem) detected	Data at P0171 detection	Data at P0400 detection	Data at P0171 detection	—
	3	P0300 (Misfire) detected	Data at P0171 detection	Data at P0400 detection	Data at P0171 detection	Data at P0300 detection
	4	P0301 (Misfire) detected	Data at P0171 detection	Data at P0400 detection	Data at P0171 detection	Data at P0300 detection

Freeze frame data clearance :


The freeze frame data is cleared at the same time as clearance of diagnostic trouble code (DTC).

DATA LINK CONNECTOR (DLC)

DLC (1) is in compliance with SAEJ1962 in its installation position, the shape of connector and pin assignment.


Serial data line (K line of ISO 9141) is used for SUZUKI scan tool or generic scan tool to communicate with ECM, TCM, ABS control module and Air bag SDM.

SUZUKI serial data line is used for SUZUKI scan tool to communicate with immobilizer control module.



2.	B+
3.	Serial data line (K line of ISO 9141)
4.	ECM ground
5.	Body ground
6.	SUZUKI serial data line

On-Board Diagnostic System (Vehicle without Immobilizer Indicator Lamp)



ECM diagnosis troubles which may occur in the area including the following parts when the ignition switch is ON and the engine is running, and indicates the result by turning on or flashing malfunction indicator lamp (1).

- Heated oxygen sensor (if equipped)
- ECT sensor
- TP sensor
- IAT sensor
- MAP sensor
- CMP sensor
- CKP sensor
- Knock sensor (if equipped)
- VSS
- CPU (Central Processing Unit) of ECM


ECM and malfunction indicator lamp (1) operate as follows.

- Malfunction indicator lamp (1) lights when the ignition switch is turned ON (but the engine at stop) with the diagnosis switch terminal ungrounded regardless of the condition of Engine and Emission control system. This is only to check the malfunction indicator lamp (1) bulb and its circuit.
- If the above areas of Engine and Emission control system is free from any trouble after the engine start (while engine is running), malfunction indicator lamp (1) turns OFF.
- When ECM detects a trouble which has occurred in the above areas, it makes malfunction indicator lamp (1) turn ON while the engine is running to warn the driver of such occurrence of trouble and at the same time it stores the trouble area in ECM back-up memory. (The memory is kept as it is even if the trouble was only temporary and disappeared immediately. And it is not erased unless the power to ECM is shut off for specified time or it is cleared by SUZUKI scan tool.)

ECM also indicates trouble area in memory by means of flashing of malfunction indicator lamp (1) at the time of inspection. (i.e. when diagnosis switch terminal (2) is connected to ground terminal (3) with a service wire and ignition switch is turned ON.)

NOTE:

- When a trouble occurs in the above areas and disappears soon while the diagnosis switch terminal is ungrounded and the engine is running, malfunction indicator lamp (1) lights and remains ON as long as the trouble exists but it turns OFF when the normal condition is restored.

DATA LINK CONNECTOR (DLC)

ELC (1) is in compliance with SAEJ1962 in its installation position, the shape of connector and pin assignment.

Serial data line (K line of ISO 9141) is used for SUZUKI scan tool to communicate with ECM, TCM, ABS control module and Air bag SDM.

SUZUKI serial data line is used for SUZUKI scan tool to communicate with immobilizer control module.

2.	B+
3.	Serial data line (K line of ISO 9141)
4.	ECM ground
5.	Body ground
6.	SUZUKI serial data line

Precaution in Diagnosing Trouble

- Don't disconnect couplers from ECM, battery cable from battery, ECM ground wire harness from engine or main fuse before confirming diagnostic information (DTC, freeze frame data, etc.) stored in ECM memory. Such disconnection will erase memorized information in ECM memory.
- Diagnostic information stored in ECM memory can be cleared as well as checked by using SUZUKI scan tool or generic scan tool (Vehicle with immobilizer indicator lamp). Before using scan tool, read its Operator's (Instruction) Manual carefully to have good understanding as to what functions are available and how to use it.
- Priorities for diagnosing troubles (Vehicle with immobilizer indicator lamp).
If two or more DTCs are stored, proceed to the flow table of the DTC which has detected earliest in the order (it can be identified by referring freeze frame data) and follow the instruction in that table.
If no instructions are given, troubleshoot diagnostic trouble codes according to the following priorities.
 - Diagnostic trouble codes (DTCs) other than DTC P0171/P0172 (Fuel system too lean/too rich), DTC P0300/P0301/P0302/P0303/P0304 (Misfire detected) and DTC P0400 (EGR flow malfunction)
 - DTC P0171/P0172 (Fuel system too lean/too rich) and DTC P0400 (EGR flow malfunction)
 - DTC P0300/P0301/P0302/P0303/P0304 (Misfire detected)
- Be sure to read "Precautions for Electrical Circuit Service" in Section 0A before inspection and observe what is written there.
- ECM Replacement
When substituting a known-good ECM, check for following conditions. Neglecting this check may cause damage to a known-good ECM.
 - Resistance value of all relays, actuators is as specified respectively.
 - MAP sensor and TP sensor are in good condition and none of power circuits of these sensors is shorted to ground.

Engine Diagnostic Flow Table

Refer to the following pages for the details of each step.

Step	Action	Yes	No
1	Customer Complaint Analysis 1) Perform customer complaint analysis referring to the followings. Was customer complaint analysis performed?	Go to Step 2.	Perform customer complaint analysis.
2	DTC and Freeze Frame Data Check, Record and Clearance 1) Check for DTC (including pending DTC) referring to the followings. Is there any DTC(s)?	Print DTC and freeze frame data or write them down and clear them by referring to "DTC Clearance" section. Go to Step 3.	Go to Step 4.
3	Visual Inspection 1) Perform visual inspection referring to the followings. Is there any faulty condition?	Repair or replace malfunction part. Go to Step 11.	Go to Step 5.
4	Visual Inspection 1) Perform visual inspection referring to the followings. Is there any faulty condition?		Go to Step 8.
5	Trouble Symptom Confirmation 1) Confirm trouble symptom referring to the followings. Is trouble symptom identified?	Go to Step 6.	Go to Step 7.
6	Rechecking and Record of DTC/Freeze Frame Data 1) Recheck for DTC and freeze frame data referring to "DTC Check" section. Is there any DTC(s)?	Go to Step 9.	Go to Step 8.
7	Rechecking and Record of DTC/Freeze Frame Data 1) Recheck for DTC and freeze frame data referring to "DTC Check" section. Is there any DTC(s)?		Go to Step 10.
8	Engine Basic Inspection and Engine Diagnosis Table 1) Check and repair according to "Engine Basic Inspection" and "Engine Diagnosis Table" section. Are check and repair complete?	Go to Step 11.	Check and repair malfunction part(s). Go to Step 11.
9	Trouble shooting for DTC 1) Check and repair according to applicable DTC diag. flow table. Are check and repair complete?		
10	Check for Intermittent Problems 1) Check for intermittent problems by referring to the followings. Is there any faulty condition?	Repair or replace malfunction part(s). Go to Step 11.	Go to Step 11.
11	Final Confirmation Test 1) Clear DTC if any. 2) Perform final confirmation test by referring to the followings. Is there any problem symptom, DTC or abnormal condition?	Go to Step 6.	End.

1. CUSTOMER COMPLAINT ANALYSIS

Record details of the problem (failure, complaint) and how it occurred as described by the customer. For this purpose, use of such an inspection form will facilitate collecting information to the point required for proper analysis and diagnosis.

2. DTC/FREEZE FRAME DATA CHECK, RECORD AND CLEARANCE

First, check DTC (including pending DTC), referring to “DTC check” section. If DTC is indicated, print it and freeze frame data or write them down and then clear them by referring to “DTC clearance” section. DTC indicates malfunction that occurred in the system but does not indicate whether it exists now or it occurred in the past and the normal condition has been restored now. To check which case applies, check the symptom in question according to Step 4 and recheck DTC according to Step 5.

Attempt to diagnose a trouble based on DTC in this step only or failure to clear the DTC in this step will lead to incorrect diagnosis, trouble diagnosis of a normal circuit or difficulty in troubleshooting.

NOTE:

If only Automatic transmission DTCs (P0702-P1895) or Immobilizer DTCs (P1620-P1623) are indicated in this step, perform trouble diagnosis according to “Diagnosis” in Section 7B or Section 8G.

3. and 4. VISUAL INSPECTION

As a preliminary step, be sure to perform visual check of the items that support proper function of the engine referring to “Visual Inspection” section.

5. TROUBLE SYMPTOM CONFIRMATION

Based on information obtained in Step 1 Customer complaint analysis and Step 2 DTC/freeze frame data check, confirm trouble symptoms. Also, reconfirm DTC according to “DTC Confirmation Procedure” described in each DTC Diagnosis section.

6. and 7. RECHECKING AND RECORD OF DTC/FREEZE FRAME DATA

Refer to “DTC check” section for checking procedure.

8. ENGINE BASIC INSPECTION AND ENGINE DIAGNOSIS TABLE

Perform basic engine check according to the “Engine Basic Inspection Flow Table” first. When the end of the flow table has been reached, check the parts of the system suspected as a possible cause referring to ENGINE DIAGNOSIS TABLE and based on symptoms appearing on the vehicle (symptoms obtained through steps of customer complaint analysis, trouble symptom confirmation and/or basic engine check) and repair or replace faulty parts, if any.

9. TROUBLESHOOTING FOR DTC (See each DTC Diag. Flow Table)

Based on the DTC indicated in Step 5 and referring to the applicable DTC diag. flow table in this section, locate the cause of the trouble, namely in a sensor, switch, wire harness, connector, actuator, ECM or other part and repair or replace faulty parts.

10. CHECK FOR INTERMITTENT PROBLEM

Check parts where an intermittent trouble is easy to occur (e.g., wire harness, connector, etc.), referring to “INTERMITTENT AND POOR CONNECTION” in Section 0A and related circuit of DTC recorded in Step 2.

11. FINAL CONFIRMATION TEST

Confirm that the problem symptom has gone and the engine is free from any abnormal conditions. If what has been repaired is related to the DTC, clear the DTC once, perform DTC confirmation procedure and confirm that no DTC is indicated.

Customer problem inspection form (example)

User name:	Model:	VIN:	
Date of issue:	Date Reg.	Date of problem:	Mileage:

PROBLEM SYMPTOMS

- ☐ **Difficult Starting**
- ☐ No cranking
- ☐ No initial combustion
- ☐ No combustion
- ☐ Poor starting at
(☐cold ☐warm ☐always)
- ☐ Other _____

- ☐ **Poor Driveability**
- ☐ Hesitation on acceleration
- ☐ Back fire/☐After fire
- ☐ Lack of power
- ☐ Surging
- ☐ Abnormal knocking
- ☐ Other _____

- ☐ **Poor Idling**
- ☐ Poor fast idle
- ☐ Abnormal idling speed
(☐High ☐Low) (r/min.)
- ☐ Unstable
- ☐ Hunting (r/min. to r/min.)
- ☐ Other _____

- ☐ **Engine Stall when**
- ☐ Immediately after start
- ☐ Accel. pedal is depressed
- ☐ Accel. pedal is released
- ☐ Load is applied
- ☐ A/C ☐Electric load ☐P/S
- ☐ Other _____
- ☐ Other _____

☐ OTHERS:

VEHICLE/ENVIRONMENTAL CONDITION WHEN PROBLEM OCCURS**Environmental Condition**

- | | |
|-------------|---|
| Weather | <input type="checkbox"/> Fair <input type="checkbox"/> Cloudy <input type="checkbox"/> Rain <input type="checkbox"/> Snow <input type="checkbox"/> Always <input type="checkbox"/> Other _____ |
| Temperature | <input type="checkbox"/> Hot <input type="checkbox"/> Warm <input type="checkbox"/> Cool <input type="checkbox"/> Cold (°F/ °C) <input type="checkbox"/> Always |
| Frequency | <input type="checkbox"/> Always <input type="checkbox"/> Sometimes (times/ day, month) <input type="checkbox"/> Only once <input type="checkbox"/> Under certain condition |
| Road | <input type="checkbox"/> Urban <input type="checkbox"/> Suburb <input type="checkbox"/> Highway <input type="checkbox"/> Mountainous (<input type="checkbox"/> Uphill <input type="checkbox"/> Downhill) <input type="checkbox"/> Tarmacadam <input type="checkbox"/> Gravel |
| | <input type="checkbox"/> Other _____ |

Vehicle Condition

- | | |
|-------------------|---|
| Engine condition | <input type="checkbox"/> Cold <input type="checkbox"/> Warming up phase <input type="checkbox"/> Warmed up <input type="checkbox"/> Always <input type="checkbox"/> Other at starting
<input type="checkbox"/> Immediately after start <input type="checkbox"/> Racing without load <input type="checkbox"/> Engine speed (r/min) |
| Vehicle condition | During driving: <input type="checkbox"/> Constant speed <input type="checkbox"/> Accelerating <input type="checkbox"/> Decelerating
<input type="checkbox"/> Right hand corner <input type="checkbox"/> Left hand corner <input type="checkbox"/> When shifting (Lever position) <input type="checkbox"/> At stop
<input type="checkbox"/> Vehicle speed when problem occurs (km/h, mile/h) <input type="checkbox"/> Other _____ |


- | | |
|--------------------------------------|--|
| Malfunction indicator lamp condition | <input type="checkbox"/> Always ON <input type="checkbox"/> Sometimes ON <input type="checkbox"/> Always OFF <input type="checkbox"/> Good condition |
|--------------------------------------|--|

- | | |
|-------------------------|---|
| Diagnostic trouble code | First check: <input type="checkbox"/> No code <input type="checkbox"/> Malfunction code () |
| | Second check: <input type="checkbox"/> No code <input type="checkbox"/> Malfunction code () |

NOTE:

The above form is a standard sample. It should be modified according to conditions characteristic of each market.


Malfunction indicator lamp (MIL) check



- 1) Turn ignition switch ON (but the engine at stop) and check that MIL (1) lights.
If MIL does not light up (or MIL dims), go to "Diagnostic Flow Table A-1" for troubleshooting.
If MIL flushes, go to "Diagnostic Flow Table A-3" (vehicle without immobilizer indicator lamp).
- 2) Start engine and check that MIL turns OFF.
If MIL remains ON and no DTC is stored in ECM, go to "Diagnostic Flow Table A-2" for troubleshooting.

Diagnostic trouble code (DTC) check

[Using SUZUKI scan tool]




- 1) Prepare SUZUKI scan tool.
- 2) With ignition switch OFF, connect it to data link connector (DLC) (1) located on underside of instrument panel at driver's seat side.

Special tool

(A) : SUZUKI scan tool

- 3) Turn ignition switch ON and confirm that MIL lights.
- 4) Read DTC, pending DTC and freeze frame data according to instructions displayed on scan tool and print it or write it down.
Refer to scan tool operator's manual for further details.
If communication between scan tool and ECM is not possible, check if scan tool is communicable by connecting it to ECM in another vehicle. If communication is possible in this case, scan tool is in good condition. Then check data link connector and serial data line (circuit) in the vehicle with which communication was not possible.
- 5) After completing the check, turn ignition switch off and disconnect scan tool from data link connector.

[Without using SUZUKI scan tool] (vehicle without immobilizer indicator lamp)



- 1) Check malfunction indicator lamp referring to “Malfunction Indicator Lamp Check” in this section.
- 2) With the ignition switch OFF position, disconnect SUZUKI scan tool if connected and using service wire (4), connect diagnosis switch terminal (1) to ground terminal (2) in monitor coupler (3).
- 3) With the ignition switch ON position and leaving engine OFF, read DTC from flashing pattern of malfunction indicator lamp. Refer to “Diagnostic Trouble Code Table”.
If lamp remains ON, go to “Diagnostic Flow Table A-4”.

NOTE:

- If abnormality or malfunction lies in two or more areas, malfunction indicator lamp indicates applicable codes three times each.
And flashing of these codes is repeated as long as diagnosis terminal is grounded and ignition switch is held at ON position.
- Take a note of diagnostic trouble code indicated first.

- 4) After completing the check, turn the ignition switch OFF position and disconnect service wire from monitor coupler.

Diagnostic Trouble Code (DTC) Clearance

Using scan tool

- 1) Connect SUZUKI scan tool or generic scan tool (Vehicle with immobilizer indicator lamp) to data link connector in the same manner as when making this connection for DTC check.
- 2) Turn ignition switch ON.
- 3) Erase DTC and pending DTC according to instructions displayed on scan tool. Refer to scan tool operator’s manual for further details.
- 4) After completing the clearance, turn ignition switch off and disconnect scan tool from data link connector.

NOTE:

DTC and freeze frame data stored in ECM memory are also cleared in following cases. Be careful not to clear them before keeping their record.

- When power to ECM is cut off (by disconnecting battery cable, removing fuse or disconnecting ECM connectors)
- When the same malfunction (DTC) is not detected again during 40 engine warm-up cycles. (Vehicle with immobilizer indicator lamp)

Without using scan tool

- 1) Turn the ignition switch OFF position.
- 2) Disconnect battery negative cable for specified time below to erase diagnostic trouble code stored in ECM memory and reconnect it.

Time required to erase DTC :

Ambient temperature	Time to cut power to ECM
Over 0°C (32°F)	30 sec. or longer
Under 0°C (32°F)	Not specifiable. Select a place with higher than 0°C (32°F) temperature.

Diagnostic trouble code (DTC) table

DTC NO.	DETECTING ITEM	DETECTING CONDITION (DTC will set when detecting :)	MIL (vehicle with immobilizer indicator lamp)	MIL (vehicle without immobilizer indicator lamp)
P0105 (No.11)	Manifold absolute pressure circuit malfunction	Low pressure-high vacuum-low voltage (or MAP sensor circuit shorted to ground) High pressure-low vacuum-high voltage (or MAP sensor circuit open)	1 driving cycle	1 driving cycle
P0110 (No.18)	Intake air temp. circuit malfunction	Intake air temp. circuit low input Intake air temp. circuit high input	1 driving cycle	1 driving cycle
P0115 (No.19)	Engine coolant temp. circuit malfunction	Engine coolant temp. circuit low input Engine coolant temp. circuit high input	1 driving cycle	1 driving cycle
P0120 (No.13)	Throttle position circuit malfunction	Throttle position circuit low input Throttle position circuit high input	1 driving cycle	1 driving cycle
P0121	Throttle position circuit performance problem	Poor performance of TP sensor	2 driving cycles	Not applicable
P0130 (No.14)	HO2S circuit malfunction (Sensor-1)	Min. output voltage of HO2S-higher than specification Max. output voltage of HO2S-lower than specification	2 driving cycle	1 driving cycle
P0133	HO2S circuit slow response (Sensor-1)	Response time of HO2S-1 output voltage between rich and lean is longer than specification.	2 driving cycles	Not applicable
P0134	HO2S circuit no activity detected (Sensor-1)	Output voltage of HO2S-1 fails to go above specification. (or HO2S-1 circuit open or short)	2 driving cycles	1 driving cycle
P0135 (No.14)	HO2S heater circuit malfunction (Sensor-1)	Terminal voltage is lower than specification at heater OFF or it is higher at heater ON.	2 driving cycles	1 driving cycle

DTC NO.	DETECTING ITEM	DETECTING CONDITION (DTC will set when detecting :)	MIL (vehicle with immobilizer indicator lamp)	MIL (vehicle without immobilizer indicator lamp)
P0136	HO2S circuit malfunction (Sensor-2)	Max. voltage of HO2S-2 is lower than specification or its min. voltage is higher than specification	2 driving cycles	Not applicable
P0141	HO2S heater circuit malfunction (Sensor-2)	Terminal voltage is lower than specification at heater OFF or it is higher at heater ON. (or heater circuit or short)	2 driving cycles	Not applicable
P0171	Fuel system too lean	Short term fuel trim or total fuel trim (short and long terms added) is larger than specification for specified time or longer. (fuel trim toward rich side is large.)	2 driving cycles	Not applicable
P0172	Fuel system too rich	Short term fuel trim or total fuel trim (short and long term added) is smaller than specification for specified time or longer. (fuel trim toward lean side is large.)	2 driving cycles	Not applicable
P0300 P0301 P0302 P0303 P0304	Random misfire detected Cylinder 1 misfire detected Cylinder 2 misfire detected Cylinder 3 misfire detected Cylinder 4 misfire detected	Misfire of such level as to cause damage to three way catalyst	MIL flashing during misfire detection	Not applicable
		Misfire of such level as to deteriorate emission but not to cause damage to three way catalyst	2 driving cycles	Not applicable
P0325 (No.17)	Knock sensor circuit malfunction	Knock sensor circuit low input Knock sensor circuit high input	1 driving cycle	1 driving cycle
P0335 (No.23)	Crankshaft position sensor circuit malfunction	No signal for 2 sec. During engine cranking	1 driving cycle	1 driving cycle
P0340 (No.15)	Camshaft position sensor circuit malfunction	No signal during engine running	1 driving cycle	1 driving cycle
P0400	Exhaust gas recirculation flow malfunction detected	Excessive or insufficient EGR flow	2 driving cycles	Not applicable
P0420	Catalyst system efficiency below threshold	Output waveforms of HO2S-1 and HO2S-2 are similar. (Time from output voltage change of HO2S-1 to that of HO2S-2 is shorter than specification.)	2 driving cycles	Not applicable
P0443	Purge control valve circuit malfunction	Purge control valve circuit is open or shorted to ground	2 driving cycles	Not applicable
P0480	Radiator fan control circuit malfunction	Radiator cooling fan relay terminal voltage is low when cooling temp. is lower than specification	2 driving cycles	Not applicable
P0500 (No.16)	Vehicle speed sensor malfunction	No signal while running in "D" range or during fuel cut at decelerating	2 driving cycles	1 driving cycle
P0505	Idle control system malfunction	No closed signal to IAC valve is detected	2 driving cycles	Not applicable

DTC NO.	DETECTING ITEM	DETECTING CONDITION (DTC will set when detecting :)	MIL (vehicle with immo- bilizer indi- cator lamp)	MIL (vehicle without immobi- lizer indica- tor lamp)
P0601 (No.71)	Internal control module memory check sum error	Data write error (or check sum error) when written into ECM	2 driving cycles	1 driving cycle
P1450 (No.29)	Barometric pressure sensor circuit malfunction	Barometric pressure is lower or higher than specification. (or sensor malfunction)	1 driving cycle	1 driving cycle
P1451	Barometric pressure sensor performance problem	Difference between manifold absolute pressure (MAP sensor value) and barometric pressure (barometric pressure sensor value) is larger than specification during cranking.	2 driving cycles	Not applicable
P1500	Starter signal circuit malfunction	Starter signal is not inputted from engine cranking till its start and after or it is always inputted	2 driving cycles	Not applicable
P1510	ECM backup power source malfunction	No backup power after starting engine	1 driving cycle	Not applicable
P1600	Serial communication problem between ECM and TCM	No signal or check sum error while engine running	1 driving cycle	Not applicable
P1717	AT D-range signal circuit malfunction	No "D" range (park/neutral position signal) is inputted while vehicle running	2 driving cycles	Not applicable

DTC NO.	DETECTING ITEM	DETECTING CONDITION (DTC will set when detecting :)	MIL
*P0705	Transmission Range Sensor Circuit Malfunction	Refer to Section 7B.	
☆*P0710	Transmission Fluid Temperature Sensor Circuit Malfunction		
*P0715	Input/turbine Speed Sensor Circuit Malfunction		
*P0720	Output Shaft Speed Sensor Circuit Malfunction		
*P0725	Engine Speed Input Circuit Malfunction		
*P0741	Torque Converter Clutch System Performance or Stuck Off		
*P0743	Torque Converter Clutch System Electrical		
*P0748	Pressure Control Solenoid A Electrical		
*P0751	Shift solenoid A (No.1) performance or stuck off		
*P0753	Shift Solenoid A (No.1) Electrical		
*P0756	Shift solenoid B (No.2) performance or stuck off		
*P0758	Shift Solenoid B (No.2) Electrical		
*P1700	Throttle Position Signal Input Malfunction		
*P1702	Internal Control Module Memory Check Some Error		

DTC NO.	DETECTING ITEM	DETECTING CONDITION (DTC will set when detecting :)	MIL
*P1705	Engine coolant temp. signal input malfunction	Refer to Section 7B.	
☆*P1895	TCM to ECM torque reduction circuit malfunction		
P1620 (No.84)	ECU code not registered	Refer to Section 8G.	
P1621 (No.83)	No ECU code transmitted from Immobilizer Control Module		
P1622 (No.82)	Fault in ECM		
P1623 (No.81)	ECU code not matched		

NOTE:

- For parenthetic No. in DTC column, it is used for vehicle without immobilizer indication lamp.
- For star (☆) marked items in MIL column, MIL does not light even when DTC is detected. DTC is erased after turning ignition switch OFF. Bear these in mind when diagnosing troubles.
- DTC No.12 appears when none of the other codes is identified.
- For vehicle with immobilizer indication lamp, star (*) marked DTCs can be read with SUZUKI scan tool ECM application.

Fail-safe table

When any of the following DTCs is detected, ECM enters fail-safe mode as long as malfunction continues to exist but that mode is canceled when ECM detects normal condition after that.

DTC NO.	TROUBLE AREA	FAIL-SAFE OPERATION	SYMPTOM
P0105 (No.11)	MAP SENSOR	ECM uses value determined by throttle opening and engine speed. ECM stops EGR, EVAP purge and idle air control.	Hard starting/ rough or incorrect idle/ excessive fuel consumption/ hesitation/ poor acceleration/ surge/ detonation or spark knock
P0110 (No.18)	IAT SENSOR	ECM controls actuators assuming that intake air temperature is 20°C.	Hard starting/ rough or incorrect idle/ excessive fuel consumption/ hesitation poor acceleration/ detonation or spark knock
P0115 (No.19)	ECT SENSOR	ECM controls actuators assuming that engine coolant temperature is 80°C. Radiator fan motor ON.	Hard starting/ rough or incorrect idle/ excessive fuel consumption/ hesitation poor acceleration/ detonation or spark knock
P0120 (No.13)	TP SENSOR	ECM controls actuators assuming that throttle opening is 20°.	Rough or incorrect idle/ excessive fuel consumption/ hesitation/ poor acceleration
P0130, P0134 (No.14)	HEATED OXYGEN SENSOR-1	—	Hard starting/rough or incorrect idle/ excessive fuel consumption/ hesitation/ poor acceleration
P0325 (No.17)	KNOCK SENSOR	—	Detonation/ spark knock

DTC NO.	TROUBLE AREA	FAIL-SAFE OPERATION	SYMPTOM
P0335 (No.23)	CKP SENSOR	<ul style="list-style-type: none"> Fix ignition timing. ECM changes injection control system from sequential injection to simultaneous one. 	Hard starting/ engine stall
P0340 (No.15)	CMP SENSOR	ECM changes injection control system from sequential injection to simultaneous one.	Hard starting
P0400	EGR VALVE	—	Hard starting/rough or incorrect idle/ excessive fuel consumption/ hesitation/ poor acceleration/ surge/ detonation or spark knock/ engine stall
P0420	CATALYST	—	—
P0443	PURGE CONTROL VALVE	—	Rough or incorrect idle/ surge/ hard starting/ engine stall
P0480	RADIATOR FAN CONTROL SYSTEM	—	Engine overheating
P0500 (No.16)	VEHICLE SPEED SENSOR	ECM stops idle air control.	Rough or incorrect idle
P0505	IDLE CONTROL SYSTEM	—	Engine stall/ rough or incorrect idle
P0601 (No.71)	ECM INTERNAL	—	Hard starting/ rough or incorrect idle/ excessive fuel consumption/ detonation or spark knock/ hesitation poor acceleration/
P1450 (No.29)	BAROMETRIC PRESSURE SENSOR	ECM controls actuators assuming that barometric pressure is 100 kPa (760 mmHg).	Hard starting/ rough or incorrect idle

Visual inspection

Visually check following parts and systems.

INSPECTION ITEM	REFERRING SECTION
• Engine oil – level, leakage	Section 0B
• Engine coolant – level, leakage	Section 0B
• Fuel – level, leakage	Section 0B
• A/T fluid – level, leakage	Section 0B
• Air cleaner element – dirt, clogging	Section 0B
• Battery – fluid level, corrosion of terminal	
• Water pump belt – tension, damage	Section 0B
• Throttle cable – play, installation	
• Vacuum hoses of air intake system – disconnection, looseness, deterioration, bend	Section 6E1
• Connectors of electric wire harness – disconnection, friction	
• Fuses – burning	Section 8
• Parts – installation, bolt – looseness	
• Parts – deformation	
• Other parts that can be checked visually	
• Check following items at engine start, if possible	
– Malfunction indicator lamp – Operation	Section 6
– Charge warning lamp – Operation	Section 6H
– Engine oil pressure warning lamp – Operation	Section 8 (Section 6 for pressure check)
– Engine coolant temp. meter – Operation	Section 8
– Fuel level meter – Operation	Section 8
– Tachometer, if equipped – Operation	
– Abnormal air being inhaled from air intake system	
– Exhaust system – leakage of exhaust gas, noise	

Engine basic inspection


This check is very important for troubleshooting when ECM has detected no DTC and no abnormality has been found in visual inspection.

Follow the flow table carefully.

Step	Action	Yes	No
1	Was "ENGINE DIAG. FLOW TABLE" performed?	Go to Step 2.	Go to "ENGINE DIAG. FLOW TABLE".
2	Check battery voltage. Is it 11 V or more?	Go to Step 3.	Charge or replace battery.
3	Is engine cranked?	Go to Step 4.	Go to "DIAGNOSIS" in Section 6G.
4	Does engine start?	Go to Step 5.	Go to Step 7.
5	Check idle speed as follows : 1) Warm up engine to normal operating temp. 2) Shift transmission to neutral position for M/T ("P" position for A/T). 3) All of electrical loads are switched off. 4) Check engine idle speed with scan tool. See Fig. 1. Is it 650 – 750 r/min (700 – 800 r/min. for A/T vehicle)?	Go to Step 6.	Go to "ENGINE DIAGNOSIS TABLE".
6	Check ignition timing as follows : 1) When SUZUKI scan tool is not available, connect test switch terminal of monitor connector to ground. See Fig. 2. When using SUZUKI scan tool, select "MISC" mode on SUZUKI scan tool and fix ignition timing to initial one. See Fig. 3. 2) Using timing light (1), check initial ignition timing. See Fig. 4. Is it $5^{\circ} \pm 3^{\circ}$ BTDC at specified idle speed?	Go to "ENGINE DIAGNOSIS TABLE".	Check ignition control related parts referring to Section 6F1.
7	Is immobilizer control system equipped?	Go to Step 8.	Go to Step 9.
8	Check immobilizer system malfunction as follows. 1) Check immobilizer indicator lamp or MIL (malfunction indicator lamp) for flashing. Is it flashing when ignition switch is turned to ON position?	Go to "DIAGNOSIS" in Section 8G.	Go to Step 9.
9	Check fuel supply as follows : 1) Check to make sure that enough fuel is filled in fuel tank. 2) Turn ignition switch ON for 2 seconds and then OFF. Is fuel pressure felt from fuel feed hose (1) when ignition switch is turned ON? See Fig. 5.	Go to Step 11.	Go to Step 10.
10	Check fuel pump for operating. Was fuel pump operating sound heard from fuel filler for about 10 seconds after ignition switch ON and stop?	Go to "DIAG. FLOW TABLE B-3".	Go to "DIAG. FLOW TABLE B-2".

Step	Action	Yes	No
11	Check ignition spark as follows : 1) Disconnect injector couplers. 2) Remove spark plugs and connect them to high tension cords. 3) Ground spark plugs. 4) Crank engine and check if each spark plug sparks. Is it in good condition?	Go to Step 12.	Go to "DIAGNOSIS" in Section 6F1.
12	Check fuel injector for operation as follows : 1) Install spark plugs and connect injector connectors. 2) Using sound scope (1), check operating sound of each injector (2) when cranking engine. See Fig. 6. Was injector operating sound heard from all injectors?	Go to "ENGINE DIAGNOSIS TABLE".	Go to "DIAG. FLOW TABLE B-1".


[A] Fig. 1 for Step 5 / [B] Fig. 2 for Step 6 / [C] Fig. 3 for Step 6



[B] : When not using SUZUKI scan tool:

[C] : When using SUZUKI scan tool

[A] Fig. 4 for Step 6 / [B] Fig. 5 for Step 9 / [C] Fig. 6 for Step 12



Engine diagnosis table

Perform troubleshooting referring to following table when ECM has detected no DTC and no abnormality has been found in visual inspection and engine basic inspection previously.

Condition	Possible Cause	Reference Item
Hard Starting (Engine cranks OK)	Faulty spark plug	Spark plugs in Section 6F1.
	Leaky high-tension cord	High-tension cords in Section 6F1.
	Loose connection or disconnection of high-tension cords or lead wires	High-tension cords in Section 6F1.
	Faulty ignition coil	Ignition coil in Section 6F1.
	Dirty or clogged fuel hose or pipe	Diagnostic Flow Table B-3.
	Malfunctioning fuel pump	Diagnostic Flow Table B-3.
	Air inhaling from intake manifold gasket or throttle body gasket	
	Faulty idle air control system	Diagnostic Flow Table B-4.
	Faulty ECT sensor or MAP sensor	ECT sensor or MAP sensor in Section 6E1.
	Faulty ECM	
	Low compression	Compression check in Section 6A1.
	Poor spark plug tightening or faulty gasket	Spark plugs in Section 6F1.
	Compression leak from valve seat	Valves inspection in Section 6A1.
	Sticky valve stem	Valves inspection in Section 6A1.
	Weak or damaged valve springs	Valve springs inspection in Section 6A1.
	Compression leak at cylinder head gasket	Cylinder head inspection in Section 6A1.
	Sticking or damaged piston ring	Cylinders, pistons and piston rings inspection in Section 6A1.
	Worn piston, ring or cylinder	Cylinders, pistons and piston rings inspection in Section 6A1.
	Malfunctioning PCV valve	PCV system in Section 6E1.
Low oil pressure	Improper oil viscosity	Engine oil and oil filter change in Section 0B.
	Malfunctioning oil pressure switch	Oil pressure switch inspection in Section 8.
	Clogged oil strainer	Oil pan and oil pump strainer cleaning in Section 6A1.
	Functional deterioration of oil pump	Oil pump in Section 6A1.
	Worn oil pump relief valve	Oil pump in Section 6A1.
	Excessive clearance in various sliding parts	

Condition	Possible Cause	Reference Item
Engine noise Note : Before checking mechanical noise, make sure that : Specified spark plug is used. Specified fuel is used.	Improper valve lash	Valve lash in Section 6A1.
	Worn valve stem and guide	Valves inspection in Section 6A1.
	Weak or broken valve spring	Valve springs inspection in Section 6A1.
	Warped or bent valve	Valves inspection in Section 6A1.
	Worn piston, ring and cylinder bore	Pistons and cylinders inspection in Section 6A1.
	Worn rod bearing	Crank pin and connecting rod bearing inspection in Section 6A1.
	Worn crank pin	Crank pin and connecting rod bearing inspection in Section 6A1.
	Loose connecting rod nuts	Connecting rod installation in Section 6A1.
	Low oil pressure	Previously outlined.
	Low oil pressure	Previously outlined.
	Worn bearing	Crankshaft and bearing inspection in Section 6A1.
	Worn crankshaft journal	Crankshaft and bearing inspection in Section 6A1.
	Loose bearing cap bolts	Crankshaft inspection in Section 6A1.
	Excessive crankshaft thrust play	Crankshaft thrust play inspection in Section 6A1.
Overheating	Inoperative thermostat	Thermostat in Section 6B.
	Poor water pump performance	Water pump in Section 6B.
	Clogged or leaky radiator	Radiator in Section 6B.
	Improper engine oil grade	Engine oil and oil filter change in Section 0B.
	Clogged oil filter or oil strainer	Oil pressure check in Section 6A1.
	Poor oil pump performance	Oil pressure check in Section 6A1.
	Faulty radiator fan control system	Radiator fan control system in Section 6E1.
	Dragging brakes	Trouble diagnosis in Section 5.
	Slipping clutch	Trouble diagnosis in Section 7C1.
	Blown cylinder head gasket	Cylinder head in Section 6A1.

Condition	Possible Cause	Reference Item
Poor gasoline mileage	Leaks or loose connection of high-tension cord	High-tension cords in Section 6F1.
	Faulty spark plug (improper gap, heavy deposits and burned electrodes, etc.)	Spark plugs in Section 6F1.
	Malfunctioning EGR valve (if equipped)	EGR system in Section 6E1.
	High idle speed	Refer to item "Improper engine idling" latterly outlined.
	Poor performance of TP sensor, ECT sensor or MAP sensor	TP sensor, ECT sensor or MAP sensor in Section 6E1.
	Faulty fuel injector(s)	Diagnostic Flow Table B-1.
	Faulty ECM	
	Low Compression	Previously outlined
	Poor valve seating	Valves inspection in Section 6A1.
	Dragging brakes	Trouble diagnosis in Section 5.
	Slipping clutch	Trouble diagnosis in Section 7C1.
	Thermostat out of order	Thermostat in Section 6B.
	Improper tire pressure	Refer to Section 3.
Excessive engine oil consumption	Blown cylinder head gasket	Cylinder head in Section 6A1.
	Leaky camshaft oil seals	Camshaft in Section 6A1.
	Sticky piston ring	Piston cleaning in Section 6A1.
	Worn piston and cylinder	Pistons and cylinders inspection in Section 6A1.
	Worn piston ring groove and ring	Pistons inspection in Section 6A1.
	Improper location of piston ring gap	Pistons assembly in Section 6A1.
	Worn or damaged valve stem seal	Valves removal and installation in Section 6A1.
	Worn valve stem	Valves inspection in Section 6A1.
Engine hesitates (Momentary lack of response as accelerator is depressed. Can occur at all vehicle speeds. Usually most severe when first trying to make vehicle move, as from a stop sign.)	Spark plug faulty or plug gap out of adjustment	Spark plugs in Section 6F1.
	Leaky high-tension cord	High-tension cords in Section 6F1.
	Fuel pressure out of specification	Diagnostic Flow Table B-3.
	Malfunctioning EGR valve (if equipped)	EGR system in section 6E1.
	Poor performance of TP sensor, ECT sensor or MAP sensor	TP sensor, ECT sensor or MAP sensor in Section 6E1.
	Faulty fuel injector	Diagnostic Flow Table B-1.
	Faulty ECM	
	Engine overheating	Refer to "Unit Repair Overhaul" in Section 6A1.
	Low compression	Previously outlined.
Surge (Engine power variation under steady throttle or cruise. Feels like vehicle speeds up and down with no change in accelerator pedal.)	Leaky or loosely connected high-tension cord	High-tension cords in Section 6F1.
	Faulty spark plug (excess carbon deposits, improper gap, and burned electrodes, etc.)	Spark plugs in Section 6F1.
	Variable fuel pressure	Diagnostic Flow Table B-3.
	Kinky or damaged fuel hose and lines	
	Faulty fuel pump (clogged fuel filter)	
	Malfunctioning EGR valve	EGR system in Section 6E1.
	Poor performance of MAP sensor	MAP sensor in Section 6E1.
	Faulty fuel injector	Diagnostic Flow Table B-1.
	Faulty ECM	

Condition	Possible Cause	Reference Item
Excessive detonation (Engine makes continuously sharp metallic knocks that change with throttle opening. Sounds like pop corn popping.)	Faulty spark plug	Spark plugs in Section 6F1.
	Loose connection of high-tension cord	High-tension cords in Section 6F1.
	Engine overheating	Refer to "Unit Repair Overhaul" in Section 6A1.
	Clogged fuel filter (faulty fuel pump) or fuel lines	Diagnostic Flow Table B-1 or B-2.
	Air inhaling from intake manifold or throttle body gasket	
	Malfunctioning EGR valve (if equipped)	EGR system in Section 6E1.
	Poor performance of knock sensor, ECT sensor or MAP sensor	Knock sensor malfunction in this section, ECT sensor or MAP sensor in Section 6E1.
	Faulty fuel injector(s)	Diagnostic Flow Table B-1.
	Faulty ECM	
	Excessive combustion chamber deposits	Piston and cylinder head cleaning in Section 6A1.
Engine has no power	Faulty spark plug	Spark plugs in Section 6F1.
	Faulty ignition coil with ignitor	Ignition coil in Section 6F1.
	Leaks, loose connection or disconnection of high-tension cord	High-tension cords in Section 6F1.
	Faulty knock sensor	Knock sensor malfunction in this section.
	Clogged fuel hose or pipe	Diagnostic Flow Table B-3.
	Malfunctioning fuel pump	Diagnostic Flow Table B-2.
	Air inhaling from intake manifold gasket or throttle body gasket	
	Engine overheating	Refer to "Unit Repair Overhaul" in Section 6A1.
	Malfunctioning EGR valve (if equipped)	EGR system inspection in Section 6E1.
	Maladjusted accelerator cable play	Accelerator cable play in Section 6E1.
	Poor performance of TP sensor, ECT sensor or MAP sensor	TP sensor, ECT sensor or MAP sensor in Section 6E1.
	Faulty fuel injector(s)	Diagnostic Flow Table B-1.
	Faulty ECM	
	Dragging brakes	Trouble diagnosis in Section 5.
	Slipping clutch	Trouble diagnosis in Section 7C1.
	Low compression	Compression check in Section 6A1.

Condition	Possible Cause	Reference Item
Improper engine idling or engine fails to idle	Faulty spark plug	Spark plugs in Section 6F1.
	Leaky or disconnected high-tension cord	High-tension cords in Section 6F1.
	Faulty ignition coil with ignitor	Ignition coil in Section 6F1.
	Fuel pressure out of specification	Diagnostic Flow Table B-3.
	Leaky manifold, throttle body, or cylinder head gasket	
	Malfunctioning EGR valve (if equipped)	EGR system in Section 6E1.
	Faulty idle air control system	Diagnostic Flow Table B-4.
	Faulty evaporative emission control system	EVAP emission control system in Section 6E1.
	Faulty EGR system (if equipped)	EGR system in Section 6E1.
	Faulty fuel injector(s)	Diagnostic Flow Table B-1.
	Poor performance of ECT sensor, TP sensor or MAP sensor	ECT sensor, TP sensor or MAP sensor in Section 6E1.
	Faulty ECM	
	Loose connection or disconnection of vacuum hoses	
	Malfunctioning PCV valve	PCV system in Section 6E1.
	Engine overheating	Refer to "Overheating" section.
	Low compression	Compression check in Section 6A1.
Excessive hydrocarbon (HC) emission or carbon monoxide (CO)	Faulty spark plug	Spark plugs in Section 6F1.
	Leaky or disconnected high-tension cord	High-tension cords in Section 6F1.
	Faulty ignition coil with ignitor	Ignition coil assembly in Section 6F1.
	Low compression	Compression check in Section 6A1.
	Lead contamination of three way catalytic converter	Check for absence of filler neck restrictor.
	Faulty evaporative emission control system	EVAP emission control system in Section 6E1.
	Fuel pressure out of specification	Diagnostic Flow Table B-3.
	Closed loop system (A/F feed back compensation) fails	
	<ul style="list-style-type: none"> Faulty TP sensor Poor performance of ECT sensor or MAP sensor 	TP sensor in Section 6E1. ECT sensor or MAP sensor in Section 6E1.
	Faulty injector(s)	Diagnostic Flow Table B-1
	Faulty ECM	
	Engine not at normal operating temperature	
	Clogged air cleaner	
	Vacuum leaks	
Excessive nitrogen oxides (NOx) emission	Improper ignition timing	See Section 6F1.
	Lead contamination of catalytic converter	Check for absence of filler neck restrictor.
	Faulty EGR system (if equipped)	EGR system in Section 6E1.
	Fuel pressure out of specification	Diagnostic Flow Table B-3.
	Closed loop system (A/F feed back compensation) fails	
	<ul style="list-style-type: none"> Faulty TP sensor Poor performance of ECT sensor or MAP sensor 	TP sensor in Section 6E1. ECT sensor or MAP sensor in Section 6E1.
	Faulty injector(s)	Diagnostic Flow Table B-1.
	Faulty ECM	

Scan Tool Data

As the data values given below are standard values estimated on the basis of values obtained from the normally operating vehicles by using a scan tool, use them as reference values. Even when the vehicle is in good condition, there may be cases where the checked value does not fall within each specified data range. Therefore, judgment as abnormal should not be made by checking with these data alone.

Also, conditions in the table below that can be checked by the scan tool are those detected by ECM and output from ECM as commands and there may be cases where the engine or actuator is not operating (in the condition) as indicated by the scan tool. Be sure to use the timing light to check the ignition timing.

NOTE:

- With the generic scan tool, only star (*) marked data in the table below can be read.
- The triangle (Δ) marked data in the table below can not be read for vehicle without immobilizer indicator lamp.
- When checking the data with the engine running at idle or racing, be sure to shift M/T gear to the neutral gear position and A/T gear to the "Park" position and pull the parking brake fully. Also, if nothing or "no load" is indicated, turn OFF A/C, all electric loads, P/S and all the other necessary switches.

	SCAN TOOL DATA	VEHICLE CONDITION	NORMAL CONDITION/ REFERENCE VALUES
*	FUEL SYSTEM B1 (FUEL SYSTEM STATUS)	At specified idle speed after warming up	CLOSED (closed loop)
*	CALC LOAD (CALCULATED LOAD VALUE)	At specified idle speed with no load after warming up	3 – 9%
		At 2500 r/min with no load after warming up	12 – 17%
*	COOLANT TEMP. (ENGINE COOLANT TEMP.)	At specified idle speed after warming up	80 – 100°C, 176 – 212°F
*	SHORT FT B1 (SHORT TERM FUEL TRIM)	At specified idle speed after warming up	– 20 – +20%
*	LONG FT B1 (LONG TERM FUEL TRIM)	At specified idle speed after warming up	– 15 – +15%
*	MAP (INTAKE MANIFOLD ABSOLUTE PRESSURE)	At specified idle speed with no load after warming up	24 – 37 kPa, 180 – 280 mmHg
*	ENGINE SPEED	At idling with no load after warming up	Desired idle speed ±50 r/min
*	VEHICLE SPEED	At stop	0 km/h, 0 MPH
*	IGNITION ADVANCE (IGNITION TIMING ADVANCE FOR NO.1 CYL- INDER)	At specified idle speed with no load after warming up	1.3L : 5 - 11° BTDC 1.6L : 5 - 15° BTDC
*	INTAKE AIR TEMP.	At specified idle speed after warming up	Ambient temp. : +30°C –5°C
*	MAF (MASS AIR FLOW RATE)	At specified idle speed with no load after warming up	1 – 4 gm/sec
		At 2500 r/min with no load after warming up	4 – 9 gm/sec

		SCAN TOOL DATA	VEHICLE CONDITION		NORMAL CONDITION/ REFERENCE VALUES	
	*	THROTTLE POS (ABSOLUTE THROTTLE POSITION)	Ignition switch ON/engine stopped	Throttle valve fully closed	7 – 18%	
				Throttle valve fully open	70 – 90%	
	*	O2S B1 S1 (HEATED OXYGEN SENSOR-1)	At specified idle speed after warming up		0 – 0.95 V	
Δ	*	O2S B1 S2 (HEATED OXYGEN SENSOR-2)	When engine is running at 2000 r/min. for 3 min or longer after warming up.		0 – 0.95 V	
Δ	*	O2S FT B1 S1	At specified idle speed after warming up		– 20 – +20%	
Δ	*	DIS. WITH MIL ON	–		–	
		DESIRED IDLE (DESIRED IDLE SPEED)	At idling with no load after warming up, M/T at neutral, A/T at “P” range		M/T	700 r/min
					A/T	750 r/min
		TP SENSOR VOLT (THROTTLE POSITION SENSOR OUTPUT VOLTAGE)	Ignition switch ON/engine stopped	Throttle valve fully closed	More than 0.2 V	
				Throttle valve fully open	Less than 4.8 V	
		INJ PULSE WIDTH (FUEL INJECTION PULSE WIDTH)	At specified idle speed with no load after warming up		2.0 – 4.0 msec.	
			At 2500 r/min with no load after warming up		2.0 – 3.6 msec.	
		IAC FLOW DUTY (IDLE AIR CONTROL FLOW DUTY)	At idling with no load after warming up		5 – 25%	
		TOTAL FUEL TRIM	At specified idle speed after warming up		– 35 – +35%	
		BATTERY VOLTAGE	Ignition switch ON/engine stop		10 – 14 V	
		CANIST PRG DUTY (EVAP CANISTER PURGE FLOW DUTY)	–		0 – 100%	
		CLOSED THROT POS (CLOSED THROTTLE POSITION)	Throttle valve at idle position		ON	
			Throttle valve opens larger than idle position		OFF	
		FUEL CUT	When engine is at fuel cut condition		ON	
			Other than fuel cut condition		OFF	
		RADIATOR FAN (RADIATOR FAN CONTROL RELAY)	Ignition switch ON	Engine coolant temp. : Lower than 95°C (203°F)	OFF	
				Engine coolant temp. : 97.5°C (208°F) or higher	ON	
		ELECTRIC LOAD	Ignition switch ON/Headlight, small light and rear window defogger all turned OFF		OFF	
			Ignition switch ON/Headlight, small light or rear window defogger turned ON		ON	
		A/C SWITCH	Engine running after warming up, A/C not operating		OFF	
			Engine running after warming up, A/C operating		ON	

	SCAN TOOL DATA	VEHICLE CONDITION		NORMAL CONDITION/ REFERENCE VALUES
	PNP SIGNAL (PARK/NEUTRAL POSITION SIGNAL) A/T only	Ignition switch ON	Selector lever in "P" or "N" position	P/N Range
			Selector lever in "R", "D", "2" or "L" position	D Range
	EGR VALVE	At specified idle speed after warming up		0%
Δ	FUEL TANK LEVEL	—		0 – 100%
	BAROMETRIC PRESS	—		Display the barometric pressure
	FUEL PUMP	Within 3 seconds after ignition switch ON or engine running		ON
		Engine stop at ignition switch ON.		OFF
	BRAKE SW	Ignition switch ON	Brake pedal is depressing	ON
			Brake pedal is releasing	OFF
	BLOWER FAN	Ignition switch ON	Blower fan switch ON	ON
			Blower fan switch OFF	OFF
	A/C MAG CLUTCH	Ignition switch ON	A/C switch ON	ON
			A/C switch OFF	OFF

SCAN TOOL DATA DEFINITIONS :**FUEL SYSTEM (FUEL SYSTEM STATUS)**

Air/fuel ratio feedback loop status displayed as either open or closed loop. Open indicates that ECM ignores feedback from the exhaust oxygen sensor.

Closed indicates final injection duration is corrected for oxygen sensor feedback.

CALC LOAD (CALCULATED LOAD VALUE, %)

Engine load displayed as a percentage of maximum possible load. Value is calculated mathematically using the formula : actual (current) intake air volume ÷ maximum possible intake air volume x 100%.

COOLANT TEMP. (ENGINE COOLANT TEMPERATURE, °C, °F)

It is detected by engine coolant temp. sensor

SHORT FT B1 (SHORT TERM FUEL TRIM, %)

Short term fuel trim value represents short term corrections to the air/fuel mixture computation. A value of 0 indicates no correction, a value greater than 0 means an enrichment correction, and a value less than 0 implies an enleanment correction.

LONG FT B1 (LONG TERM FUEL TRIM, %)

Long term fuel trim Value represents long term corrections to the air/fuel mixture computation. A value of 0 indicates no correction, a value greater than 0 means an enrichment correction, and a value less than 0 implies an enleanment correction.

MAP (INTAKE MANIFOLD ABSOLUTE PRESSURE, kPa, inHg)

It is detected by manifold absolute pressure sensor and used (among other things) to compute engine load.

ENGINE SPEED (rpm)

It is computed by reference pulses from crankshaft position sensor.

VEHICLE SPEED (km/h, MPH)

It is computed based on pulse signals from vehicle speed sensor.

IGNITION ADVANCE (IGNITION TIMING ADVANCE FOR NO.1 CYLINDER, °)

Ignition timing of NO.1 cylinder is commanded by ECM. The actual ignition timing should be checked by using the timing light.

INTAKE AIR TEMP. (°C, °F)

It is detected by intake air temp. sensor and used to determine the amount of air passing into the intake manifold as air density varies with temperature.

MAF (MASS AIR FLOW RATE, gm/s, lb/min)

It represents total mass of air entering intake manifold which is computed based on signals from MAP sensor, IAT sensor, TP sensor, etc.

THROTTLE POS (ABSOLUTE THROTTLE POSITION, %)

When throttle position sensor is fully closed position, throttle opening is indicated as 0% and 100% full open position.

OXYGEN SENSOR B1 S1 (HEATED OXYGEN SENSOR-1, V)

It indicates output voltage of HO2S-1 installed on exhaust manifold (pre-catalyst).

OXYGEN SENSOR B1 S2 (HEATED OXYGEN SENSOR-2, V)

It indicates output voltage of HO2S-2 installed on exhaust pipe (post-catalyst). It is used to detect catalyst deterioration.

DESIRED IDLE (DESIRED IDLE SPEED, rpm)

The Desired Idle Speed is an ECM internal parameter which indicates the ECM requested idle. If the engine is not running, this number is not valid.

TP SENSOR VOLT (THROTTLE POSITION SENSOR OUTPUT VOLTAGE, V)

The Throttle Position Sensor reading provides throttle valve opening information in the form of voltage.

INJ PULSE WIDTH (FUEL INJECTION PULSE WIDTH, msec.)

This parameter indicates time of the injector drive (valve opening) pulse which is output from ECM (but injector drive time of NO.1 cylinder for multiport fuel injection).

IAC FLOW DUTY (IDLE AIR (SPEED) CONTROL DUTY, %)

This parameter indicates current flow time rate within a certain set cycle of IAC valve (valve opening rate) which controls the amount of bypass air (idle speed).

TOTAL FUEL TRIM (%)

The value of Total Fuel Trim is obtained by putting values of short Term Fuel Trim and Long Term Fuel Trim together. This value indicates how much correction is necessary to keep the air/fuel mixture stoichiometrical.

BATTERY VOLTAGE (V)

This parameter indicates battery positive voltage inputted from main relay to ECM.

CANIST PURGE DUTY (EVAP CANISTER PURGE FLOW DUTY, %)

This parameter indicates valve ON (valve open) time rate within a certain set cycle of EVAP purge solenoid valve which controls the amount of EVAP purge.

0% means that the purge valve is completely closed while 100% is a fully open valve.

CLOSED THROTTLE POSITION (ON/OFF)

This parameter will read ON when throttle valve is fully closed, or OFF when the throttle is not fully closed.

FUEL CUT (ON/OFF)

ON : Fuel being cut (output signal to injector is stopped)

OFF : Fuel not being cut

RADIATOR FAN (RADIATOR FAN CONTROL RELAY, ON/OFF)

ON : Command for radiator fan control relay operation being output.

OFF : Command for relay operation not being output.

ELECTRIC LOAD (ON/OFF)

ON : Headlight, small light or rear window defogger ON signal inputted.

OFF : Above electric loads all turned OFF.

A/C SWITCH (ON/OFF)

ON : Command for A/C operation being output from ECM to A/C compressor magnet clutch.

OFF : Command for A/C operation not being output.

FUEL TANK LEVEL (%)

This parameter indicates approximate fuel level in the fuel tank. As the detectable range of the fuel level sensor is set as 0 to 100%, however, with some models whose fuel tank capacity is smaller, the indicated fuel level may be only 70% even when the fuel tank is full.

PNP SIGNAL (PARK/NEUTRAL POSITION SIGNAL, P/N RANGE or D RANGE)

It is detected by signal from TCM.

D range : A/T is in "R", "D", "2" or "L" range.

P/N range : A/T is in "P" or "N" range or the above signal is not inputted from TCM.

EGR VALVE (%)

This parameter indicates opening rate of EGR valve which controls the amount of EGR flow.

Inspection of ECM and Its Circuits



ECM and its circuits can be checked at ECM wiring couplers by measuring voltage and resistance.

CAUTION:
ECM cannot be checked by itself. It is strictly prohibited to connect voltmeter or ohmmeter to ECM with coupler disconnected from it.

VOLTAGE CHECK

- 1) Remove ECM (1) from vehicle body referring to Section 6E.
- 2) Check voltage at each terminal of couplers (2) connected.

NOTE:
As each terminal voltage is affected by the battery voltage, confirm that it is 11 V or more when ignition switch is ON.




- 1. ECM
- 2. ECM couplers (Viewed from harness side)

TERMINAL NO.	CIRCUIT	NORMAL VOLTAGE	CONDITION
C20	1	Ground	—
	2	Ground	—
	3	Ground	—
	4	EVAP canister purge valve	10 – 14 V Ignition switch ON
	5	Power steering pressure switch (if equipped)	10 – 14 V Ignition switch ON
			0 – 1.5 V With engine running at idle, turning steering wheel to the right or left as far as it stops, repeating it a few times
	6	Idle air control valve	0 – 13 V At specified idle speed after engine warmed up
	7	Heater of HO2S-1 (Vehicle with EGR)	10 – 14 V Ignition switch ON
	8	Fuel injector No.4	10 – 14 V Ignition switch ON
	9	Fuel injector No.1	10 – 14 V Ignition switch ON
	10	Sensor ground	—
	11	Camshaft position sensor	0 – 0.8 V and 4 – 6 V Ignition switch ON
	12	Generator control signal	Min. 4.8 V Ignition switch ON
	13	Heated oxygen sensor-1 (Vehicle with EGR system)	Refer to DTC P0130 diag. flow table
		CO adjusting resistor (if equipped)	—
	14	Engine coolant temperature sensor	0.55 - 0.95 V Ignition switch ON Engine coolant temp. : 80°C (176°F)
	15	Intake air temperature sensor	2.0 – 2.7 V Ignition switch ON Intake air temp. : 20°C (68°F)
	16	Throttle position sensor	0.2 – 1.0 V Ignition switch ON Throttle valve at idle position
			2.8 – 4.8 V Ignition switch ON Throttle valve at full open position
	17	EGR valve (stepper motor coil 3)	10 – 14 V Ignition switch ON
	18	EGR valve (stepper motor coil 1)	10 – 14 V Ignition switch ON
	19	Ignition coil No.2	—
	20	Ignition coil No.1	—
	21	Fuel injector No.2	10 – 14 V Ignition switch ON
	22	Power source for sensors	4.75 – 5.25 V Ignition switch ON
	23	Crankshaft position sensor	—
	24	Fuel pump relay	0 – 1 V For 2 seconds after ignition switch ON
			10 – 14 V After the time shown above
	25	Knock sensor (vehicle with EGR)	2.1 – 2.9 V Ignition switch ON
	26	Manifold absolute pressure sensor	3.3 – 4.0 V Ignition switch ON and Barometric pressure : 100 kPa (760 mmHg)
	27	Diag. switch terminal (vehicle without immobilizer)	4 – 6 V Ignition switch ON
	28	EGR valve (stepper motor coil 4)	10 – 14 V Ignition switch ON
	29	EGR valve (stepper motor coil 2)	10 – 14 V Ignition switch ON
	30	Engine start switch (Engine start signal)	6 – 12 V While engine cranking
			0 V Other than above
	31	Fuel injector No.3	10 – 14 V Ignition switch ON

TERMINAL NO.	CIRCUIT	NORMAL VOLTAGE	CONDITION
C21	1 A/C compressor relay (if equipped)	0 – 1 V	A/C operated
		10 – 14 V	A/C not operated
	2 Stop lamp switch	0 V	Ignition ON and stop lamp switch OFF
		10 – 14 V	Ignition ON and stop lamp switch ON
	3 Radiator fan relay No.2	10 – 14 V	Ignition switch ON and Engine coolant temp. : 100°C (212°F) or lower
		0 – 1 V	Ignition switch ON and Engine coolant temp. : 102.5°C (216.5°F) or higher
	4 Heater of HO2S-2 (if equipped)	10 – 14 V	Ignition switch ON
	5 Power source	10 – 14 V	Ignition switch ON
	6 Power source	10 – 14 V	Ignition switch ON
	7 A/C triple pressure switch	10 – 14 V	A/C not operated
	8 Monitor output (without immobilizer)	–	–
	9 A/C condenser fan relay (if equipped)	0 – 1 V	Ignition switch ON Condenser fan motor operated
		10 – 14 V	Ignition switch ON Condenser fan motor not operated
	10 Main relay	10 – 14 V	Ignition switch OFF
		0.4 – 1.5 V	Ignition switch ON
	11 A/C evaporator inlet air temp. sensor	–	–
	12 Blank	–	–
	13 Heated oxygen sensor-2 (if equipped)	Refer to DTC 0130 diag. flow table	
	14 A/C evaporator outlet air temp. sensor	–	–
	15 Test switch terminal (vehicle without immobilizer)	–	–
	16 A/C input signal (if equipped)	10 – 14 V	Ignition ON and A/C switch OFF
		0 – 2 V	Ignition ON and A/C switch ON
	17 Electric load signal (+)	0 V	Ignition switch ON Small light and rear defogger OFF
		10 – 14 V	Ignition switch ON Small light or rear defogger ON
	18 Radiator fan relay No.1	10 – 14 V	Ignition switch ON and Engine coolant temp. : 95°C or lower (203°F)
		0 – 1 V	Ignition switch ON and Engine coolant temp. : 97.5°C or higher (208°F)
	19 Immobilizer indicator lamp (vehicle with immobilizer)	0 – 1 V	Ignition switch ON
		10 – 14 V	When engine running
	20 Sensor ground (vehicle body)	–	–
	21 Blank	–	–
	22 Blank	–	–
	23 Ignition switch	10 – 14 V	Ignition switch ON
	24 Vehicle speed sensor	0 V and 4 – 6 V	Ignition switch ON Front left tire turned slowly with front right tire locked

TERMINAL NO.	CIRCUIT	NORMAL VOLTAGE	CONDITION
G07	1 Tachometer	0 – 1 V	Ignition switch ON
	2 Blank	–	–
	3 Blank	–	–
	4 Blank	–	–
	5 Engine coolant temp. signal for TCM (A/T)	0 V and 10 – 14 V	Ignition switch ON
	6 D-range ID-up signal (A/T)	10 – 14 V	Ignition switch ON
	7 Malfunction indicator lamp	0 – 1 V	Ignition switch ON
		10 – 14 V	When engine running
	8 Data link connector (SUZUKI serial data line) (Vehicle with immobilizer)	4 – 6 V	Ignition switch ON
	9 Engine coolant temp. signal for meter	0 – 1 V and 10 – 14 V	Ignition switch ON
	10 Electric load signal (–)	0 – 2 V	Ignition ON and blower fan turned OFF
		10 – 14 V	Ignition ON and blower fan turned ON
	11 Power source for back-up	10 – 14 V	Anytime
	12 Torque control input signal (A/T)	0 V and 10 – 14 V	Ignition switch ON
	13 Data link connector (K line of ISO 9141)	10 – 14 V	Ignition switch ON
	14 Throttle opening signal for TCM (A/T)	0 V and 10 – 14 V	Ignition switch ON
	15 Fuel level sensor (gauge) (vehicle with heated oxygen sensor 2)	0 – 2 V	Ignition ON and fuel tank fully filled
		4.5 – 7.5 V	Ignition ON and fuel tank emptied
	16 Blank	–	–
	17 Serial data for TCM (A/T)	10 – 14 V and 0 – 1 V	Ignition switch ON

Resistance Check



- 1) Disconnect ECM couplers from ECM with ignition switch OFF.

CAUTION:

Never touch terminals of ECM itself or connect voltmeter or ohmmeter.

- 2) Check resistance between each terminal of connectors disconnected.

CAUTION:


- Be sure to connect ohmmeter probe from wire harness side of coupler.
- Be sure to turn OFF ignition switch for this check.
- Resistance in table below represents that when parts temperature is 20°C (68°F).

1. ECM coupler disconnected

2. Ohmmeter

TERMINALS	CIRCUIT	STANDARD RESISTANCE
C20-7 to C21-23	HO2S-1 heater (if equipped)	5.0 – 6.4 Ω
C21-4 to C21-23	HO2S-2 heater (if equipped)	12.0 – 14.3 Ω
C20-9 to C21-5/6	No.1 injector	11.3 – 13.8 Ω
C20-21 to C21-5/6	No.2 injector	11.3 – 13.8 Ω
C20-31 to C21-5/6	No.3 injector	11.3 – 13.8 Ω
C20-8 to C21-5/6	No.4 injector	11.3 – 13.8 Ω
C20-18 to C21-5/6	EGR valve (stepper motor coil 1) (if equipped)	20 – 24 Ω
C20-29 to C21-5/6	EGR valve (stepper motor coil 2) (if equipped)	20 – 24 Ω
C20-17 to C21-5/6	EGR valve (stepper motor coil 3) (if equipped)	20 – 24 Ω
C20-28 to C21-5/6	EGR valve (stepper motor coil 4) (if equipped)	20 – 24 Ω
C20-4 to C21-5/6	EVAP canister purge valve	30 – 34 Ω
C20-24 to C21-23	Fuel pump relay	56 – 146 Ω
C21-1 to C21-23	A/C compressor relay	56 – 146 Ω
C21-9 to C21-23	A/C condenser fan relay	56 – 146 Ω
C21-18 to C21-23	Radiator fan relay 1	56 – 146 Ω
C21-10 to G07-11	Main relay	56 – 146 Ω
C20-1 to Body ground	Ground	Continuity
C20-2 to Body ground	Ground	Continuity
C20-3 to Body ground	Ground	Continuity


Component Location



1. TP sensor	10. Radiator fan control relay No.2	19. ECM
2. MAP sensor	11. Radiator fan control relay No.3	20. Monitor connector
3. IAC valve	12. EVAP canister purge valve	21. VSS
4. IAT sensor	13. ECT sensor	22. Knock sensor (if equipped)
5. A/C compressor relay	14. Ignition coil with igniter	23. CMP sensor
6. A/C condenser fan relay	15. HO2S-1 (if equipped)	24. EGR valve (if equipped)
7. Fuel pump relay	16. HO2S-2 (if equipped)	25. Power steering pressure switch
8. Main relay	17. CKP sensor	* : This figure shows left-hand steering vehicle, these parts are installed at the other side for right-hand steering vehicle.
9. Radiator fan control relay No.1	18. TCM	

Table A-1 Malfunction Indicator Lamp Circuit Check - Lamp Does Not Come “ON” at Ignition Switch ON (But Engine at Stop)

WIRING DIAGRAM



1. BATT fuse	3. IG fuse	5. Monitor connector (vehicle without immobilizer indicator lamp)	7. To ignition switch
2. Main fuse box	4. To battery	6. MIL	8. Main relay

CIRCUIT DESCRIPTION

When the ignition switch is turned ON, ECM causes the main relay to turn ON (close the contact point). Then, ECM being supplied with the main power, turns ON the malfunction indicator lamp (MIL). When the engine starts to run and no malfunction is detected in the system, MIL goes OFF but if a malfunction was or is detected, MIL remains ON even when the engine is running.

INSPECTION

Step	Action	Yes	No
1	MIL Power Supply Check 1) Turn ignition switch ON. Do other indicator/warning lights in combination meter comes ON?	Go to Step 2.	“IG METER” fuse blown, main fuse blown, ignition switch malfunction, “BLK/WHT” circuit between “IG” fuse and combination meter or poor coupler connection at combination meter.
2	ECM Power and Ground Circuit Check Does engine start?	Go to Step 3.	Go to TABLE A-5 ECM POWER AND GROUND CIRCUIT CHECK. If engine is not cranked, go to DIAGNOSIS in Section 6G.

Step	Action	Yes	No
3	MIL Circuit Check 1) Turn ignition switch OFF and disconnect connectors from ECM. 2) Check for proper connection to ECM at terminal G07-7. 3) If OK, then using service wire, ground terminal G07-7 in connector disconnected. Does MIL turn on at ignition switch ON?	Substitute a known-good ECM and recheck.	Bulb burned out or "PPL/YEL" wire circuit open. Test switch terminal circuit grounded (vehicle without immobilizer indicator lamp).

Table A-2 Malfunction Indicator Lamp Circuit Check - Lamp Remains "ON" after Engine Starts

WIRING DIAGRAM / CIRCUIT DESCRIPTION

Refer to table A-1.

INSPECTION

Step	Action	Yes	No
1	Diagnostic Trouble Code (DTC) Check 1) Check DTC referring to DTC CHECK section. Is there any DTC(s)?	Go to Step 2 of ENGINE DIAG. FLOW TABLE.	Go to Step 2.
2	DTC Check 1) Start engine and recheck DTC while engine running. Is there any DTC(s)?		Go to Step 3.
3	MIL Circuit Check 1) Turn OFF ignition switch. 2) Disconnect connectors from ECM. Does MIL turn ON at ignition switch ON?	"PPL/YEL" wire circuit shorted to ground.	Substitute a known-good ECM and recheck.

Table A-3 MIL Check - MIL Flashes at Ignition Switch ON (Vehicle without Immobilizer Indicator Lamp)

WIRING DIAGRAM / CIRCUIT DESCRIPTION

Refer to TABLE A-1.

INSPECTION

Step	Action	Yes	No
1	MIL Flashing Pattern Check 1) Turn ignition switch ON. Does lamp flashing pattern indicate diagnostic trouble code?	Go to Step 2.	Substitute a known-good ECM and recheck.
2	Diag. Switch Circuit Check Is diag. switch terminal connected to ground via service wire?	System is in good condition.	"PPL/WHT" circuit shorted to ground. If circuit is OK substitute a known-good ECM and recheck.

Table A-4 MIL Check - MIL Does Not Flash or Just Remains ON Even with Grounding Diagnosis Switch Terminal (Vehicle without Immobilizer Indicator Lamp)

WIRING DIAGRAM / CIRCUIT DESCRIPTION


Refer to TABLE A-1.

INSPECTION

Step	Action	Yes	No
1	MIL Circuit Check 1) Turn ignition switch OFF and disconnect connectors from ECM. Does MIL turn ON at ignition switch ON?	"PPL/YEL" circuit shorted to ground.	Go to Step 2.
2	ECM/PCM Connection Check 1) Turn ignition switch OFF. Is connector (C20-27 connection) connected to ECM/PCM properly?	Go to Step 3.	Poor connector connection.
3	Diag. Switch Terminal Circuit Check 1) Connect connectors to ECM. 2) Using service wire, ground C20-27 terminal with connectors connected to ECM. 3) Turn ignition switch ON. Does MIL flash?	"PPL/WHT" or "BLK" circuit open.	Substitute a known-good ECM and recheck.

Table A-5 ECM Power and Ground Circuit Check - MIL Does Not Light at Ignition Switch ON and Engine Doesn't Start Though It Is Cranked Up

WIRING DIAGRAM



1. BATT fuse	3. IG fuse	5. Monitor connector (vehicle without immobilizer indicator lamp)	7. To ignition switch
2. Main fuse box	4. To battery	6. MIL	8. Main relay


CIRCUIT DESCRIPTION

When the ignition switch turned ON, the main relay turns ON (the contact point closes) and the main power is supplied to ECM.

INSPECTION


Step	Action	Yes	No
1	Main Relay Operating Sound Check Is operating sound of main relay heard at ignition switch ON?	Go to Step 5.	Go to Step 2.
2	Main Relay Check 1) Turn OFF ignition switch and remove main relay (1). 2) Check for proper connection to main relay (1). 3) Check resistance between each two terminals. See Fig. 1 and 2. Between terminals C and D : Infinity Between terminals A and B : 56 – 146 Ω 4) Check that there is continuity between terminals C and D when battery is connected to terminals A and B. See Fig. 3. Is main relay in good condition?	Go to Step 3.	Replace main relay.
3	Fuse Check Is main fuse in good condition? See Fig. 4.	Go to Step 4.	Check for short in circuits connected to this fuse.
4	ECM Power Circuit Check 1) Turn OFF ignition switch, disconnect connectors from ECM and install main relay. 2) Check for proper connection to ECM at terminals C21-23, C21-10, C21-5 and C21-6. 3) If OK, then measure voltage between terminal C21-23 and ground, C21-10 and ground with ignition switch ON. Is each voltage 10 – 14 V?	Go to Step 5.	“BLK/WHT”, “BLK/YEL” or “BRN/WHT” circuit open.
5	ECM Power Circuit Check 1) Using service wire, ground terminal C21-10 and measure voltage between terminal C21-5 and ground at ignition switch ON. Is it 10 – 14 V?	Check ground circuits “BRN/WHT” and “BLK/YEL” for open. If OK, then substitute a known-good ECM and recheck.	Go to Step 6.
6	Is operating sound of main relay heard in Step 1?	Go to Step 7.	“BLK/YEL” or “BLK/RED” wire open.
7	Main relay check 1) Check main relay according to procedure in Step 2. Is main relay in good condition?	“BLK/YEL” or “BLK/RED” wire open.	Replace main relay.

[A] Fig. 1 for Step 2 / [B] Fig. 2 for Step 2



1. Main relay


[C] Fig. 3 for Step 2 / [D] Fig. 4 for Step 3



1. Fuse

DTC P0105 (DTC No.11) Manifold Absolute Pressure (MAP) Circuit Malfunction

WIRING DIAGRAM / CIRCUIT DESCRIPTION



DTC DETECTING CONDITION	POSSIBLE CAUSE
<ul style="list-style-type: none"> MAP sensor signal is 0.19 V or lower (Low pressure – High vacuums – Low voltage) or MAP sensor signal is 4.5 V or higher (High pressure – Low vacuums – High voltage) 	<ul style="list-style-type: none"> “ORN” circuit open “GRY/RED” circuit open or shorted to ground “LT GRN/RED” circuit open or shorted to ground MAP sensor malfunction ECM malfunction

NOTE:

- When this DTC and DTC P0120 (No.13) are indicated together, it is possible that “GRY/RED” circuit is open.
- When DTC P0105 (No.11), P0110 (No.18), P0115 (No.19) and P0120 (No.13) are indicated together, it is possible that “ORN” circuit is open.

DTC CONFIRMATION PROCEDURE

- 1) Clear DTC, start engine and keep it at idle for 1 min.
- 2) Select “DTC” mode on scan tool and check DTC.


INSPECTION


Step	Action	Yes	No
1	Was "ENGINE DIAG. FLOW TABLE" performed?	Go to Step 2.	Go to "ENGINE DIAG. FLOW TABLE".
2	Check MAP Sensor and Its Circuit. 1) Connect scan tool to DLC with ignition switch OFF. 2) Turn ignition switch ON. 3) Check intake manifold pressure. Is it 114 kPa or more or 43 kPa or less?	Go to Step 3.	Intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection" in Section 0A.
3	Check Wire Harness. 1) Disconnect MAP sensor connector with ignition switch OFF. 2) Check for proper connection of MAP sensor at "LT GRN/RED" and "GRY/RED" wire terminals. 3) If OK, then with ignition switch ON, check voltage between each of "GRY/RED" or "LT GRN/RED" wire terminals and body ground. See Fig. 1. Is voltage about 4 – 6 V at each terminal?	Go to Step 4.	"GRY/RED" wire open or shorted to ground circuit or shorted to power circuit (See NOTE), "LT GRN/RED" wire open or shorted to ground, poor C20-26 connection or C20-22 connection. If wire and connection are OK, confirm that MAP sensor is normal and then substitute a known-good ECM and recheck.
4	Check MAP sensor. Check MAP sensor according to "MAP Sensor Individual Check" below. Is it in good condition?	"GRY/RED" wire shorted to "ORN" wire, "LT GRN/RED" wire open, poor C20-10 connection. If wire and connection are OK, substitute a known-good ECM and recheck.	Replace MAP sensor.

NOTE:

When battery voltage is applied to "GRY/RED" wire, it is possible that MAP sensor is also faulty.

Fig. 1 for Step 3



Map sensor individual check

- 1) Disconnect connector from MAP sensor (1).
- 2) Remove MAP sensor (1).
- 3) Arrange 3 new 1.5 V batteries (2) in series (check that total voltage is 4.5 – 5.0 V) and connect its positive terminal to “Vin” terminal of sensor and negative terminal to “Ground” terminal. Then check voltage between “Vout” and “Ground”. Also, check if voltage reduces when vacuum is applied up to 400 mmHg by using vacuum pump (3).

Output voltage (When input voltage is 4.5 – 5.5 V, ambient temp. 20 – 30°C, 68 – 86°F)


ALTITUDE (Reference)		BAROMETRIC PRESSURE		OUTPUT VOLTAGE
(ft)	(m)	(mmHg)	(kPa)	(V)
0	0	760	100	3.3 – 4.3
2 000	610	707	94	3.0 – 4.1
2 001	611	Under 707 over 634	94	2.7 – 3.7
5 000	1 524	85	85	2.5 – 3.3
5 001	1 525	Under 634 over 567	85	2.5 – 3.3
8 000	2 438	76	76	2.5 – 3.3
8 001	2 439	Under 567 over 526	76	2.5 – 3.3
10 000	3 048	70	70	

If check result is not satisfactory, replace MAP sensor (1).

- 4) Install MAP sensor (1) securely.
- 5) Connect MAP sensor (1) connector securely.

DTC P0110 (DTC No.18) Intake Air Temp. (IAT) Circuit Malfunction

WIRING DIAGRAM / CIRCUIT DESCRIPTION



DTC DETECTING CONDITION	POSSIBLE CAUSE
<ul style="list-style-type: none"> Low intake air temperature (High voltage-High resistance) or High intake air temperature (Low voltage-Low resistance) 	<ul style="list-style-type: none"> "LT GRN/BLK" circuit open or shorted to power. "ORN" circuit open IAT sensor malfunction ECM malfunction

NOTE:

- When DTC P0105 (No.11), P0110 (No.18), P0115 (No.19) and P0120 (No.13) are indicated together, it is possible that "ORN" circuit is open.
- Before inspecting, be sure to check that ambient temperature is higher than -40°C (-40°F).

DTC CONFIRMATION PROCEDURE


- 1) Clear DTC, start engine and keep it at idle for 1 min.
- 2) Select "DTC" mode no scan tool and check DTC.

INSPECTION

Step	Action	Yes	No
1	Was "ENGINE DIAG. FLOW TABLE" performed?	Go to Step 2.	Go to "ENGINE DIAG. FLOW TABLE".
2	Check IAT Sensor and Its Circuit. 1) Connect scan tool to DLC with ignition switch OFF. 2) Turn ignition switch ON. 3) Check intake air temp. displayed on scan tool. Is -40°C (-40°F) or 119°C (246°F) indicated?	Go to Step 3.	Intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection" in Section 0A.


Step	Action	Yes	No
3	Check Wire Harness. 1) Disconnect IAT sensor connector with ignition switch OFF. 2) Check for proper connection to IAT sensor at "LT GRN/BLK" and "ORN" wire terminals. 3) If OK, then with ignition switch ON, is voltage applied to "LT GRN/BLK" wire terminal about 4 – 6 V? See Fig. 1.	Go to Step 5.	"LT GRN/BLK" wire open or shorted to power, or poor C20-15 connection. If wire and connection are OK, substitute a known-good ECM and recheck.
4	Does scan tool indicate – 40°C (– 40°F) at Step 2.	Go to Step 6.	Go to Step 5.
5	Check Wire Harness 1) Check intake air temp. displayed on scan tool with ignition switch ON. Is – 40°C (– 40°F) indicated?	Replace IAT sensor.	"LT GRN/BLK" wire shorted to ground. If wire is OK, substitute a known-good ECM and recheck.
6	Check Wire Harness. 1) Using service wire, connect IAT sensor connector terminals. 2) Check intake air temp. displayed on scan tool with ignition switch ON. Is 119°C (246°F) indicated?	Replace IAT sensor.	"LT GRN/BLK" wire open or poor C20-10 connection. If wire and connection are OK, substitute a known-good ECM and recheck.

[A] Fig. 1 for Step 3 / [B] Fig. 2 for Step 4



DTC P0115 (DTC No.19) Engine Coolant Temperature (ECT) Circuit Malfunction

WIRING DIAGRAM / CIRCUIT DESCRIPTION



DTC DETECTING CONDITION	POSSIBLE CAUSE
<ul style="list-style-type: none">Low engine coolant temperature (High voltage-High resistance) orHigh engine coolant temperature (Low voltage-Low resistance)	<ul style="list-style-type: none">“LT GRN” circuit open or shorted to power“ORN” circuit openECT sensor malfunctionECM malfunction

NOTE:

- Before inspecting, be sure to check that coolant temp. meter in combination meter indicates normal operating temperature (Engine is not overheating).
- When this DTC and P1709 are stored together, also clear DTC stored in TCM after completion of repair.
- When DTC P0105 (No.11), P0110 (No.18), P0115 (No.19) and P0120 (No.13) are indicated together, it is possible that “ORN” circuit be open.

DTC CONFIRMATION PROCEDURE


- Clear DTC, start engine and keep it at idle for 1 min.
- Select “DTC” mode no scan tool and check DTC.

INSPECTION

Step	Action	Yes	No
1	Was “ENGINE DIAG. FLOW TABLE” performed?	Go to Step 2.	Go to “ENGINE DIAG. FLOW TABLE”.


Step	Action	Yes	No
2	Check ECT Sensor and its Circuit. 1) Connect scan tool with ignition switch OFF. 2) Turn ignition switch ON. 3) Check engine coolant temp. displayed on scan tool. Is – 40°C (– 40°F) or 119°C (246°F) indicated?	Go to Step 3.	Intermittent trouble. Check for intermittent referring to “Intermittent and Poor Connection” in Section 0 A.
3	Check Wire Harness. 1) Disconnect ECT sensor connector. 2) Check engine coolant temp. displayed on scan tool. Is – 40°C (– 40°F) indicated?	Replace ECT sensor.	“LT GRN” wire shorted to ground. If wire is OK, substitute a known-good ECM and recheck.
4	Does scan tool indicate – 40°C (– 40°F) at Step 2.	Go to Step 6.	Go to Step 5.
5	Check Wire Harness. 1) Disconnect ECT sensor connector with ignition switch OFF. 2) Check for proper connection to ECT sensor at “ORN” and “LT GRN” wire terminals. If OK, then with ignition switch ON, is voltage applied to “LT GRN” wire terminal about 4 – 6 V? See Fig. 1.	Go to Step 4.	“LT GRN” wire open or shorted to power, or poor C20-14 connection. If wire and connection are OK, substitute a known-good ECM and recheck.
6	Check Wire Harness. 1) Using service wire, connect ECT sensor connector terminals. See Fig. 2. 2) Turn ignition switch ON and check engine coolant temp. displayed on scan tool. Is 119°C (246°F) indicated?	Replace ECT sensor.	“ORN” wire open or poor C20-10 connection. If wire and connection are OK, substitute a known-good ECM and recheck.

[A] Fig. 1 for Step 5 / [B] Fig. 2 for Step 6



DTC P0120 (DTC No.13) Throttle Position Circuit Malfunction

WIRING DIAGRAM / CIRCUIT DESCRIPTION



DTC DETECTING CONDITION	POSSIBLE CAUSE
<ul style="list-style-type: none">Signal voltage high orSignal voltage low	<ul style="list-style-type: none">“ORN” circuit open“GRY/BLU” circuit open or shorted to ground“GRY/RED” circuit open or shorted to power or groundTP sensor malfunctionECM malfunction

NOTE:

- When DTC P0105 (No.11), P0110 (No.18), P0115 (No.19) and P0120 (No.13) are indicated together, it is possible that “ORN” or “GRY/RED” circuit be open.
- When this DTC and P1700 are stored together, also clear DTC stored in TCM after completion of repair.
- When this DTC and DTC P0105 (No.11) are indicated together, it is possible that “GRY/RED” circuit be open.

DTC CONFIRMATION PROCEDURE


- 1) Clear DTC, start engine and keep it at idle for 1 min.
- 2) Select “DTC” mode no scan tool and check DTC.

INSPECTION

Step	Action	Yes	No
1	Was “ENGINE DIAG. FLOW TABLE” performed?	Go to Step 2.	Go to “ENGINE DIAG. FLOW TABLE”.


Step	Action	Yes	No
2	<p>Check TP Sensor and Its Circuit.</p> <ol style="list-style-type: none"> 1) Connect scan tool to DLC with ignition switch OFF and then turn ignition switch ON. 2) Check throttle valve opening percentage displayed on scan tool. <p>Is it displayed 2% or less?</p> <ol style="list-style-type: none"> 3) Check throttle valve opening percentage displayed on scan tool while opening throttle valve from idle position to full open position. <p>Is it displayed 96% or higher?</p>	Go to Step 3.	Intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection" in Section 0A.
3	<p>Check Wire Harness.</p> <ol style="list-style-type: none"> 1) Disconnect connector from TP sensor with ignition switch OFF. 2) Check for proper connection to TP sensor at "GRY/RED", "GRY/BLU" and "ORN" wire terminals. 3) If OK, then with ignition switch ON, check voltage between each of "GRY/RED" or "GRY/BLU" wire terminals and body ground. See Fig. 1. <p>Is voltage about 4 – 6 V at each terminal?</p>	Go to Step 4.	<p>"GRY/RED" wire open, "GRY/RED" wire shorted to ground or power circuit or "GRY/BLU" wire, "ORN" wire open or shorted to ground circuit or poor C20-22 or C20-16 connection.</p> <p>If wire and connection are OK, substitute a known-good ECM and recheck.</p>
4	<p>Check TP Sensor.</p> <ol style="list-style-type: none"> 1) Check resistance between terminals of TP sensor. See Fig. 2. <p>Between 1 and 2 : 2.5 – 6.0 kΩ Between 1 and 3 : 100 Ω – 20 kΩ varying according to throttle valve opening</p> <p>Are measured values within specifications?</p>	<p>"ORN" wire open or poor C20-10 connection.</p> <p>If wire and connection are OK, substitute a known-good ECM and recheck.</p>	Replace TP sensor.

[A] Fig. 1 for Step 3 / [B] Fig. 2 for Step 4



DTC P0121 Throttle Position Circuit Range/Performance Problem

WIRING DIAGRAM / CIRCUIT DESCRIPTION



DTC DETECTING CONDITION	POSSIBLE CAUSE
<p>DTC will set when the following conditions are detected.</p> <ul style="list-style-type: none"> • After engine warmed up. • While vehicle running at specified engine speed. • No change in intake manifold pressure (constant throttle opening) • Difference between actual throttle opening (detected from TP sensor) and opening calculated by ECM (obtained on the basis of engine speed and intake manifold pressure) is larger than specified value. <p>*2 driving cycle detection logic, continuous monitoring</p>	<ul style="list-style-type: none"> • TP sensor malfunction • High resistance in the circuit • ECM malfunction

DTC CONFIRMATION PROCEDURE

WARNING:


- When performing a road test, select a place where there is no traffic or possibility of a traffic accident and be very careful during testing to avoid occurrence of an accident.
- Road test should be carried out with 2 persons, a driver and a tester, on a level road.

- 1) Turn ignition switch OFF. Clear DTC with ignition switch ON, check vehicle and environmental condition for :
 - Altitude (barometric pressure) : 2400 m, 8000 ft or less (560 mmHg, 75 kPa or more)
 - Ambient temp. : -10°C, 14°F or higher
 - Intake air temp. : 70°C, 158°F or lower
 - Engine coolant temp. : 70 – 110°C, 158 – 230°F
- 2) Warm up engine to normal operating temperature.
- 3) Increase vehicle speed to 50 – 60 km/h, 30 – 40 mph in 3rd gear or “D” range and hold throttle valve at that opening position for 1 min.
- 4) Stop vehicle.
- 5) Check DTC in “DTC” mode and pending DTC in “ON BOARD TEST” or “PENDING DTC” mode.

INSPECTION


Step	Action	Yes	No
1	Was "ENGINE DIAG. FLOW TABLE" performed?	Go to Step 2.	Go to "ENGINE DIAG. FLOW TABLE".
2	Is SUZUKI scan tool available?	Go to Step 3.	Go to Step 4.
3	Check TP Sensor and its Circuit. 1) Turn ignition switch OFF and connect SUZUKI scan tool to DLC. 2) Turn ignition switch ON and check TP sensor output voltage when throttle valve is at idle position and fully opened. See Fig. 2. Dose voltage vary within specified value linearly as shown in figure?	If voltmeter was used, check terminal C20-16 for poor connection. If OK, substitute a known-good ECM and recheck.	Go to Step 5.
4	Check TP Sensor and its Circuit. 1) Turn ignition switch ON. 2) Check voltage at terminal C20-16 of ECM connector connected, when throttle valve is at idle position and fully opened. See Fig. 1. Dose voltage vary within specified value linearly as shown in figure?	If voltmeter was used, check terminal C20-16 for poor connection. If OK, substitute a known-good ECM and recheck.	Go to Step 5.
5	Check TP Sensor. 1) Turn ignition switch OFF. 2) Disconnect TP sensor connector. 3) Check for proper connection to TP sensor at each terminal. 4) If OK, then measure resistance between terminals and check if each measured value is as specified below. See Fig. 3. Between 1 and 2 : 4.0 – 6.0 k Ω Between 1 and 3 : 0.02 – 6.0 k Ω , varying according to throttle valve opening. Are measured values as specified?	High resistance in "GRY/RED", "GRY/BLU" or "ORN" circuit. If wire and connection are OK, substitute a known-good ECM and recheck.	Replace TP sensor.

[A] Fig. 1 for Step 4 / [B] Fig. 2 for Step 3 and 4 / [C] Fig. 3 for Step 5



DTC P0130 (DTC No.14) Heated Oxygen Sensor (HO2S) Circuit Malfunction (Sensor-1)

WIRING DIAGRAM / CIRCUIT DESCRIPTION



DTC DETECTING CONDITION	POSSIBLE CAUSE
<ul style="list-style-type: none"> When running at idle speed after engine warmed up and running at specified vehicle speed, HO2S-1 output voltage does not go below 0.3 V or over 0.6 V. *2 driving cycle detection logic, Monitoring once/1 driving. 	<ul style="list-style-type: none"> Heated oxygen sensor-1 malfunction "WHT" or "ORN" circuit open (poor connection) or short

DTC CONFIRMATION PROCEDURE

WARNING:


- When performing a road test, select a place where there is no traffic or possibility of a traffic accident and be very careful during testing to avoid occurrence of an accident.
- Road test should be carried out with 2 persons, a driver and a tester.

- Turn ignition switch OFF. Clear DTC with ignition switch ON, check vehicle and environmental condition for :
 - Altitude (barometric pressure) : 2400 m, 8000 ft or less (560 mmHg, 75 kPa or more)
 - Ambient temp. : -10°C , 14°F or higher
 - Intake air temp. : 70°C , 158°F or lower
- Warm up engine to normal operating temperature.
- Drive vehicle at 50 – 60 km/h, 30 – 40 mph for 2 min.
- Stop vehicle and run engine at idle for 2 min.
- Check DTC in "DTC" mode and pending DTC in "ON BOARD TEST" or "PENDING DTC" mode.

INSPECTION

Step	Action	Yes	No
1	Was "ENGINE DIAG. FLOW TABLE" performed?	Go to Step 2.	Go to "ENGINE DIAG. FLOW TABLE".
2	Is there DTC(s) other than HO2S-1 (DTC P0130)?	Go to applicable DTC Diag. Flow Table.	Go to Step 3.
3	<p>Check HO2S-1 signal.</p> <p>1) Connect scan tool to DLC with ignition switch OFF.</p> <p>2) Warm up engine to normal operating temperature and keep it at 2000 r/min. for 60 sec.</p> <p>3) Repeat racing engine (Repeat depressing accelerator pedal 5 to 6 times continuously and take foot off from pedal to enrich and enlean A/F mixture). See Fig. 1.</p> <p>Does HO2S-1 output voltage deflect between 0.3 V and over 0.6 V repeatedly?</p>	Intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection" in Section 0A.	<p>Check "WHT" and "ORN" wires for open and short, and connections for poor connection.</p> <p>If wires and connections are OK, replace HO2S-1.</p>

Fig. 1 for Step 3




DTC P0133 Heated Oxygen Sensor (HO2S) Circuit Slow Response (Sensor-1)**WIRING DIAGRAM / CIRCUIT DESCRIPTION**

Refer to DTC P0130 section.

DTC DETECTING CONDITION	POSSIBLE CAUSE
<ul style="list-style-type: none"> When running at specified idle speed after engine warmed up and running at specified vehicle speed, response time (time to change from lean to rich or from rich to lean) of HO2S-1 output voltage is about 1 sec. at minimum or average time of 1 cycle is 5 sec. at minimum. See. Fig. 1 <p>*2 driving cycle detection logic, Monitoring once/1 driving.</p>	<ul style="list-style-type: none"> Heated oxygen sensor-1 malfunction

Fig. 1

**DTC CONFIRMATION PROCEDURE**

Refer to DTC P0130 section.

INSPECTION

Step	Action	Yes	No
1	Was "ENGINE DIAG. FLOW TABLE" performed?	Go to Step 2.	Go to "ENGINE DIAG. FLOW TABLE".
2	Is there DTC(s) other than HO2S-1 (DTC P0133)?	Go to applicable DTC Diag. Flow Table.	Replace HO2S-1.

DTC P0134 Heated Oxygen Sensor (HO2S) Circuit No Activity Detected (Sensor-1)

WIRING DIAGRAM / CIRCUIT DESCRIPTION

Refer to DTC P0130 section.

DTC DETECTING CONDITION	POSSIBLE CAUSE
<ul style="list-style-type: none"> Engine warmed up. While running under other than high load and high engine speed conditions or at specified idle speed (engine is in closed loop condition), HO2S-1 output voltage is high or low continuously. <p>*2 driving cycle detection logic, Continuous monitoring.</p>	<ul style="list-style-type: none"> “WHT” or “ORN” circuit open or short Heated oxygen sensor malfunction Fuel system malfunction Exhaust gas leakage

DTC CONFIRMATION PROCEDURE


Refer to DTC P0130 section.

INSPECTION

Step	Action	Yes	No
1	Was “ENGINE DIAG. FLOW TABLE” performed?	Go to Step 2.	Go to “ENGINE DIAG. FLOW TABLE”.
2	Is there DTC(s) other than Fuel system (DTC P0171/P0172) and HO2S-1 (DTC P0134)?	Go to applicable DTC Diag. Flow Table.	Go to Step 3.
3	Check HO2S-1 and Its Circuit. 1) Connect scan tool to DLC with ignition switch OFF. 2) Warm up engine to normal operating temperature and keep it at 2000 r/min. for 60 sec. 3) Repeat racing engine (Repeat depressing accelerator pedal 5 to 6 times continuously and take foot off from pedal to enrich and enlean A/F mixture). Does HO2S-1 output voltage deflect between 0.3V and over 0.6V repeatedly?	Go to DTC P0171 and P0172 Diag. Flow Table (Fuel System Check).	Check “WHT” and “ORN” wires for open and short, and connections for poor connection. If wires and connections are OK, replace HO2S-1.

DTC P0135 (DTC No.14) Heated Oxygen Sensor (HO2S) Heater Circuit Malfunction (Sensor-1)

WIRING DIAGRAM / CIRCUIT DESCRIPTION



DTC DETECTING CONDITION	POSSIBLE CAUSE
DTC will set when one of the following conditions is met. <ul style="list-style-type: none">• Low voltage at terminal C20-7 when engine is running at high load.• High voltage at terminal C20-7 when engine is running under condition other than above. *2 driving cycle detection logic, Continuous monitoring.	<ul style="list-style-type: none">• HO2S-1 heater circuit open or shorted to ground• ECM malfunction

DTC CONFIRMATION PROCEDURE

WARNING:


- When performing a road test, select a place where there is no traffic or possibility of a traffic accident and be very careful during testing to avoid occurrence of an accident.
- Road test should be carried out with 2 persons, a driver and a tester.

- 1) Turn ignition switch OFF.
- 2) Clear DTC with ignition switch ON, start engine and keep it at idle for 1 min.
- 3) Start vehicle and depress accelerator pedal fully for 5 sec. or longer.
- 4) Stop vehicle.
- 5) Check DTC in “DTC” mode and pending DTC in “ON BOARD TEST” or “PENDING DTC” mode.

INSPECTION


Step	Action	Yes	No
1	Was "ENGINE DIAG. FLOW TABLE" performed?	Go to Step 2.	Go to "ENGINE DIAG. FLOW TABLE".
2	<p>Check Heater for operation.</p> <ol style="list-style-type: none"> 1) Check voltage at terminal C20-7. See Fig. 1. 2) Warm up engine to normal operating temperature. 3) Stop engine. 4) Turn ignition switch ON and Check voltage at terminal C20-7. See Fig. 1. Voltage should be over 10 V. 5) Start engine, run it at idle and check voltage at the same terminal. Voltage should be below 1.9 V. <p>Are check results specified ones?</p>	Intermittent trouble Check for intermittent referring to "Intermittent and Poor Connection" in Section 0A.	Go to Step 3.
3	<p>Check Heater of Sensor-1.</p> <ol style="list-style-type: none"> 1) Disconnect HO2S-1 coupler with ignition switch OFF. 2) Check for proper connection to HO2S-1 at "BLK/WHT" and "PNK/BLK" wire terminals. 3) If OK, then check heater resistance. See Fig. 2. <p>Is it 5.0 – 6.4 Ω at 20°C, 68°F?</p>	"PNK/BLK" wire open or shorted to ground or poor connection at C20-7. If wire and connection are OK, substitute a known-good ECM and recheck.	Replace HO2S-1.

[A] Fig. 1 for Step 2 / [B] Fig. 2 for Step 3



- 1) Turn ignition switch OFF.
Clear DTC with ignition switch ON, check vehicle and environmental condition for :
 - Altitude (barometric pressure) : 2400 m, 8000 ft or less (560 mmHg, 75 kPa or more)
 - Ambient temp. : -10°C, 14°F or higher
 - Intake air temp. : 70°C, 158°F or lower
 - No exhaust gas leakage and loose connection
- 2) Warm up engine to normal operating temperature.
- 3) Drive vehicle under usual driving condition for 5 min. and check HO2S-2 output voltage and “short term fuel trim” with “Data List” mode on scan tool, and write it down.
- 4) Stop vehicle (don’t turn ignition switch OFF).
- 5) Increase vehicle speed to higher than 20 mph, 32 km/h and then stop vehicle.
- 6) Repeat above steps 5) 4 times.
- 7) Increase vehicle speed to about 80 km/h (50 mph) in 3rd gear or 2 range.
- 8) Release accelerator pedal and with engine brake applied, keep vehicle coasting (fuel cut condition) for 10sec. or more.
- 9) Stop vehicle (do not turn ignition switch OFF) and run engine at idle for 2 min.
After this step 9), if “Oxygen Sensor Monitoring TEST COMPLETED” is displayed in “READINESS TESTS” mode and DTC is not displayed in “DTC” mode, confirmation test is completed.
If “TEST NOT COMPLTD” is still being displayed, proceed to next step 10).

- 10) Drive vehicle under usual driving condition for 10 min. (or vehicle is at a stop and run engine at idle for 10 min. or longer)
- 11) Stop vehicle (do not turn ignition switch OFF). Confirm test results according to "Test Result Confirmation Flow Table" in "DTC CONFIRMATION PROCEDURE" of DTC P0420.




★Usual driving : Driving at 50 – 60 km/h, 30 – 40 mph including short stop according to traffic signal. (under driving condition other than high-load, high-engine speed, rapid accelerating and decelerating)

INSPECTION

Step	Action	Yes	No
1	Was "ENGINE DIAG. FLOW TABLE" performed?	Go to Step 2.	Go to "ENGINE DIAG. FLOW TABLE".
2	Check Exhaust System for leakage, loose connection and damage. Is it good condition?	Go to Step 3.	Repair or replace.
3	Check HO2S-2 and Its Circuit. Was HO2S-2 output voltage indicated on scan tool in step 3) of DTC confirmation test less than 1.275 V?	Go to Step 4.	"WHT" or "ORN" circuit short to power supply circuit or HO2S-2 malfunction.
4	Check Short Term Fuel Trim. Did short term fuel trim vary within – 20 – + 20% range in step 3) of DTC confirmation test?	Check "WHT" or "ORN" wire for open and short, and connection for poor connection. If wire and connection are OK, replace HO2S-2.	Check fuel system. Go to DTC P0171/P0172 Diag. Flow Table.

DTC P0141 Heated Oxygen Sensor (HO2S) Heater Circuit Malfunction (Sensor-2)

WIRING DIAGRAM / CIRCUIT DESCRIPTION



DTC DETECTING CONDITION	POSSIBLE CAUSE
DTC will set when one of the following conditions is met. <ul style="list-style-type: none">• Low voltage at terminal C21-4 for specified time after engine start or while engine running at high load.• High voltage at terminal C21-4 while engine running under other than above condition. *2 driving cycle detection logic, continuous monitoring.	<ul style="list-style-type: none">• HO2S-2 heater circuit open or shorted to ground• ECM malfunction

DTC CONFIRMATION PROCEDURE


- 1) Turn ignition switch OFF once and then ON.
- 2) Clear DTC, start engine and warm up engine to normal operating temperature.
- 3) Keep it at 2000 r/min for 2 min.
- 4) Check pending DTC in “ON BOARD TEST” or “PENDING DTC” mode and DTC in “DTC” mode.

INSPECTION

Step	Action	Yes	No
1	Was “ENGINE DIAG. FLOW TABLE” performed?	Go to Step 2.	Go to “ENGINE DIAG. FLOW TABLE”.
2	Check HO2S-2 Heater and Its Circuit. <ol style="list-style-type: none">1) Warm up engine to normal operating temperature.2) Stop engine.3) Turn ignition switch ON and check voltage at terminal C21-4 See Fig. 1. Voltage should be over 10 V.4) Start engine, run it at idle and check voltage at the same terminal after 1 min. from engine start. Voltage should be below 1.9 V. Are check result as specified?	Intermittent trouble. Check for intermittent referring to “Intermittent and Poor Connection” in Section 0A.	Go to Step 3.

Step	Action	Yes	No
3	Check Heater of Sensor-2. 1) Disconnect HO2S-2 coupler with ignition switch OFF. 2) Check for proper connection to HO2S-2 at "BLK/WHT" and "PNK/BLU" wire terminals. 3) If OK, then check heater resistance. Is it 12.0 – 14.3 Ω at 20°C, 68°F?	"PNK/BLU" wire open or shorted to ground or poor connection at C21-4. If wire and connection are OK, substitute a known-good ECM and recheck.	Replace HO2S-2.

Fig. 1 for Step 2



DTC DETECTING CONDITION	POSSIBLE CAUSE
<p>When one of the following conditions is met while engine running under closed loop condition.</p> <ul style="list-style-type: none"> Air/fuel ratio too lean (Total fuel trim (short and long terms added) is more than 30%) Air/fuel ratio too rich (Total fuel trim is less than – 30%) <p>※2 driving cycle detection logic, continuous monitoring.</p>	<ul style="list-style-type: none"> Vacuum leaks (air drawn in). Exhaust gas leakage. Heated oxygen sensor-1 circuit malfunction. Fuel pressure out of specification. Fuel injector malfunction (clogged or leakage). MAP sensor poor performance. ECT sensor poor performance. IAT sensor poor performance. TP sensor poor performance. EVAP control system malfunction. PCV valve malfunction.

DTC CONFIRMATION PROCEDURE**WARNING:**

- When performing a road test, select a place where there is no traffic or possibility of a traffic accident and be very careful during testing to avoid occurrence of an accident.
- Road test should be carried out with 2 persons, a driver and a tester, on a level road.


- 1) Turn ignition switch OFF.
- 2) Clear DTC with ignition switch ON.
- 3) Check vehicle and environmental condition for :
 - Altitude (barometric pressure) : 2400 m, 8000 ft or less (560 mmHg, 75 kPa or more)
 - Ambient temp. : -10°C, 14°F or higher
 - Intake air temp. : 70°C, 158°F or lower
- 4) Start engine and drive vehicle under usual driving condition (described in DTC confirmation procedure of DTC P0136) for 5 min. or longer and until engine is warmed up to normal operating temperature.
- 5) Keep vehicle speed at 50 – 60 km/h, 30 – 40 mph in 5th gear or “D” range for 5 min. or more.
- 6) Stop vehicle (do not turn ignition switch OFF).
- 7) Check pending DTC in “ON BOARD TEST” or “PENDING DTC” mode and DTC in “DTC” mode.

INSPECTION


Step	Action	Yes	No
1	Was “ENGINE DIAG. FLOW TABLE” performed?	Go to Step 2.	Go to “ENGINE DIAG. FLOW TABLE”.
2	Is there DTC(s) other than fuel system (DTC P0171/P0172)?	Go to applicable DTC Diag. Flow Table.	Go to Step 3.
3	Check HO2S-1 Output Voltage. 1) Connect scan tool to DLC with ignition switch OFF. 2) Warm up engine to normal operating temperature and keep it at 2000 r/min. for 60 sec. 3) Repeat racing engine (Repeat depressing accelerator pedal 5 to 6 times continuously and take foot off from pedal to enrich and enlean A/F mixture). Does HO2S-1 output voltage deflect between below 0.3 V and over 0.6 V repeatedly?	Go to Step 4.	Go to DTC P0130 Diag. Flow Table (HO2S-1 circuit check).
4	Check Fuel Pressure (Refer to section 6E1 for details). 1) Release fuel pressure from fuel feed line. 2) Install fuel pressure gauge. 3) Check fuel pressure. See Fig. 1. With fuel pump operating and engine at stop : 270 – 310 kPa, 2.7 – 3.1 kg/cm ² , 38.4 – 44.0 psi. At specified idle speed : 270 – 310 kPa, 2.7 – 3.1 kg/cm ² , 38.4 – 44.0 psi. Is measured value as specified?	Go to Step 5.	Go to Diag. Flow Table B-3 Fuel Pressure Check.


Step	Action	Yes	No
5	<p>Check Fuel Injectors and Circuit.</p> <ol style="list-style-type: none"> 1) Using sound scope (1) or such, check operating sound of each injector (2) when engine is running. Cycle of operating sound should vary according to engine speed. See Fig. 2. If no sound or an unusual sound is heard, check injector circuit (wire or coupler) or injector. 2) Turn ignition switch OFF and disconnect a fuel injector connector. 3) Check for proper connection to fuel injector at each terminal. See Fig. 3. 4) If OK, then check injector resistance. Injector Resistance : 11.3 – 13.8 Ω at 20°C (68°F) 5) Carry out steps 1) and 3) on each injector. 6) Check each injector for injected fuel volume (1) referring to Section 6E1. See Fig. 4. Injected Fuel Volume : 43 – 47 cc/15 sec 1.45/1.51 – 1.58/1.65 US/Imp.oz/15 sec) 7) Check each injector for fuel leakage after injector closed. Fuel Leakage : Less than 1 drop/min (3). <p>Is check result in step 1) and 3) to 7) satisfactory?</p>	Go to Step 6.	Check injector circuit or replace fuel injector(s).
6	<p>Check EVAP Canister Purge Valve.</p> <ol style="list-style-type: none"> 1) Disconnect purge hose from EVAP canister purge valve. 2) Place finger against the end of EVAP canister purge valve. 3) Check that vacuum is not felt there when engine is cool and running at idle. See Fig. 5. <p>Is vacuum felt?</p>	Check evaporative emission control system (See Section 6E1).	Go to Step 7.
7	<p>Check Intake Manifold Absolute Pressure Sensor for performance (See DTC P0105 (No.11) Diag. Flow Table).</p> <p>Is it in good condition?</p>	Go to Step 8.	Repair or replace.
8	<p>Check Engine Coolant Temp. Sensor for performance (See Section 6E1).</p> <p>Is it in good condition?</p>	Go to Step 9.	Replace engine coolant temp. sensor.
9	<p>Check Intake Air Temp. Sensor for performance (See Section 6E1).</p> <p>Is it in good condition?</p>	Go to Step 10.	Replace intake air temp. sensor.
10	<p>Check Throttle Position Sensor for performance (See Step 4 of DTC P0121 Diag. Flow Table).</p> <p>Is it in good condition?</p>	Go to Step 11.	Replace throttle position sensor.
11	<p>Check PCV Valve for valve clogging (See Section 6E1).</p> <p>Is it in good condition?</p>	Substitute a known-good ECM and recheck.	Replace PCV valve.

[A] Fig. 1 for Step 4 / [B] Fig. 2 for Step 5 / [C] Fig. 3 for Step 5



[D] Fig. 4 for Step 5 / [E] Fig. 5 for Step 6



DTC P0300 Random Misfire Detected (Misfire Detected at 2 or More Cylinders)**DTC P0301 Cylinder 1 Misfire Detected****DTC P0302 Cylinder 2 Misfire Detected****DTC P0303 Cylinder 3 Misfire Detected****DTC P0304 Cylinder 4 Misfire Detected****WIRING DIAGRAM**

1. Ignition coil No. 1
2. Ignition coil No. 2
3. CKP sensor
4. CMP sensor
5. Fuel injector

CIRCUIT DESCRIPTION

ECM monitors crankshaft revolution speed and engine speed via the crankshaft position sensor and cylinder No. via the camshaft position sensor. Then it calculates the change in the crankshaft revolution speed and from how many times such change occurred in every 200 or 1000 engine revolutions, it detects occurrence of misfire. When ECM detects a misfire (misfire rate per 200 revolutions) which can cause overheat and damage to the three way catalytic converter, it makes the malfunction indicator lamp (MIL) flash as long as misfire occurs at that rate.

After that, however, when the misfire rate drops, MIL remains ON until it is judged as normal 3 times under the same driving conditions.

Also, when ECM detects a misfire (misfire rate per 1000 revolutions) which will not cause damage to three way catalytic converter but can cause exhaust emission to be deteriorated, it makes MIL light according to the 2 driving cycle detection logic.

DTC DETECTING CONDITION	POSSIBLE CAUSE
<ul style="list-style-type: none"> • Engine under other than high revolution condition • Not on rough road • Engine speed changing rate (below specified value) • Manifold absolute pressure changing rate (below specified value) • Throttle opening changing rate (below specified value) • Misfire rate per 200 or 1000 engine revolutions (how much and how often crankshaft revolution speed changes) is higher than specified value 	<ul style="list-style-type: none"> • Engine overheating • Vacuum leaks (air inhaling) from air intake system • Ignition system malfunction (spark plug(s), high-tension cord(s), ignition coil assembly) • Fuel pressure out of specification • Fuel injector malfunction (clogged or leakage) • Engine compression out of specification • Valve lash (clearance) out of specification • Manifold absolute pressure sensor malfunction • Engine coolant temp. sensor malfunction • PCV valve malfunction • EVAP control system malfunction • EGR system malfunction

DTC CONFIRMATION PROCEDURE

NOTE:

Among different types of random misfire, if misfire occurs at cylinders 1 and 4 or cylinders 3 and 2 simultaneously, it may not possible to reconfirm DTC by using the following DTC confirmation procedure. When diagnosing the trouble of DTC P0300 (Random misfire detected) of the engine which is apparently misfiring, even if DTC P0300 cannot be reconfirmed by using the following DTC confirmation procedure, proceed to the following Diag. Flow Table.

WARNING:

- When performing a road test, select a place where there is no traffic or possibility of a traffic accident and be very careful during testing to avoid occurrence of an accident.
- Road test should be carried out with 2 persons, a driver and a tester.

- 1) Turn ignition switch OFF.
- 2) Clear DTC with ignition switch ON.
- 3) Check vehicle and environmental condition for :
 - Altitude (barometric pressure) : 2400 m, 8000 ft or less (560 mmHg, 75 kPa or more)
 - Ambient temp. : -10°C, 14°F or higher
 - Intake air temp. : 70°C, 158°F or lower
 - Engine coolant temp. : -10 – 110°C, 14 – 230°F
- 4) Start engine and keep it at idle for 2 min. or more.
- 5) Check DTC in “DTC” mode and pending DTC in “ON BOARD TEST” or “PENDING DTC” mode.
- 6) If DTC is not detected at idle, consult usual driving based on information obtained in “Customer complaint analysis” and “Freeze frame data check”.

INSPECTION

CAUTION:


For iridium spark plugs, do not adjust air gap or clean.

Step	Action	Yes	No
1	Was “ENGINE DIAG. FLOW TABLE” performed?	Go to Step 2.	Go to “ENGINE DIAG. FLOW TABLE”.

Step	Action	Yes	No
2	Is there DTC other than Fuel system (DTC P0171/P0172) and misfire (DTC P0300-P0304)?	Go to applicable DTC Diag. Flow Table.	Go to Step 3.
3	<p>Check Ignition System.</p> <ol style="list-style-type: none"> 1) Remove spark plugs and check them for; <ul style="list-style-type: none"> • Air gap : 1.0 – 1.1 mm (0.040 – 0.043 in.) See Fig. 1. • Carbon deposits/Insulator damage/Plug type If abnormality is found, adjust, clean or replace. 2) Disconnect all injector connectors. 3) Connect spark plugs to high tension cords and then ground spark plugs. 4) Crank engine and check that each spark plug sparks. <p>Are above check results satisfactory?</p>	Go to Step 4.	Check ignition system parts (Refer to Section 6F1).
4	<p>Check Fuel Pressure (Refer to Section 6E1 for details).</p> <ol style="list-style-type: none"> 1) Release fuel pressure from fuel feed line. 2) Install fuel pressure gauge. See Fig. 2. 3) Check fuel pressure. <p>With fuel pump operating and engine at stop : 270 – 310 kPa, 2.7 – 3.1 kg/cm², 38.4 – 44.0 psi.</p> <p>At specified idle speed : 270 – 310 kPa, 2.7 – 3.1 kg/cm², 38.4 – 44.0 psi.</p> <p>Is measured value as specified?</p>	Go to Step 5.	Go to Diag. Flow Table B-3 fuel pressure check.
5	<p>Check Fuel Injectors and Circuit.</p> <ol style="list-style-type: none"> 1) Using sound scope (3) or such, check operating sound of each injector (4) when engine is running. Cycle of operating sound should vary according to engine speed. See Fig 3. If no sound or an unusual sound is heard, check injector circuit (wire or connector) or injector. 2) Turn ignition switch OFF and disconnect a fuel injector connector. 3) Check for proper connection to fuel injector at each terminal. See Fig. 4. 4) If OK, then check injector resistance. <p>Injector Resistance : 11.3 – 13.8 Ω at 20°C (68°F)</p> <ol style="list-style-type: none"> 5) Carry out steps 1) and 3) on each injector. 6) Check each injector for injected fuel volume referring to Section 6E1. See Fig. 5. <p>Injected Fuel Volume : 43 – 47 cc/15 sec (1.45/1.51 – 1.58/1.65 US/Imp. oz/15 sec)</p> <ol style="list-style-type: none"> 7) Check each injector for fuel leakage after injector closed. <p>Fuel Leakage : Less than 1 drop/min.</p> <p>Is check result in step 1) and 3) to 7) satisfactory?</p>	Go to Step 6.	Check injector circuit or replace fuel injector(s).
6	<p>Check PCV Valve for clogging (See Section 6E1).</p> <p>Is it in good condition?</p>	Go to Step 7.	Replace PCV valve.


Step	Action	Yes	No
7	Check EVAP Canister Purge Valve for Closing. 1) Disconnect purge hose from EVAP canister purge valve. 2) Place finger against the end of EVAP canister purge valve. 3) Check that vacuum is not felt there, when engine is cool and running at idle. See Fig. 6. Is vacuum felt?	Check evaporative emission control system (See Section 6E1).	Go to Step 8.
8	Check MAP Sensor for performance (See DTC P0105 Diag. Flow Table). Is it in good condition?	Go to Step 9.	Repair or replace.
9	Check ECT Sensor for performance (See Section 6E1). Is it in good condition?	Go to Step 10.	Replace engine coolant temp. sensor.
10	Check Parts or System which can cause engine rough idle or poor performance. • Engine compression (See Section 6A1). • Valve lash (See Section 6A1). • Valve timing (Timing belt installation. See Section 6A1). Are they in good condition?	Check wire harness and connection of ECM ground, ignition system and fuel injector for intermittent open and short.	Repair or replace.

[A] Fig. 1 for Step 3 / [B] Fig. 2 for Step 4 / [C] Fig. 3 for Step 5




- | |
|--------------------------------------|
| 1. Fuel pressure gauge & 3 way joint |
| 2. Fuel feed hose |

[D] Fig. 4 for Step 5 / [E] Fig. 5 for Step 5 / [F] Fig. 6 for Step 7



DTC P0325 (DTC No.17) Knock Sensor Circuit Malfunction

WIRING DIAGRAM / CIRCUIT DESCRIPTION



DTC DETECTING CONDITION	POSSIBLE CAUSE
<ul style="list-style-type: none"> Knock sensor voltage is 3.91 V or more or Knock sensor voltage is 1.23 V or less 	<ul style="list-style-type: none"> “WHT” circuit open or shorted to ground Knock sensor malfunction ECM malfunction


DTC CONFIRMATION PROCEDURE

- 1) Clear DTC, start engine and keep it at idle for 1 min.
- 2) Select “DTC” mode on scan tool and check DTC.

INSPECTION


Step	Action	Yes	No
1	Was “ENGINE DIAG. FLOW TABLE” performed?	Go to Step 2.	Go to “ENGINE DIAG. FLOW TABLE”.
2	Check Knock Sensor Signal. 1) With engine running, check voltage from C20-25 terminal of ECM connector to body ground. See Fig. 1. Is voltage about 1.23 – 3.91 V?	Knock sensor and its circuit are in good condition. Intermittent trouble or faulty ECM. Recheck, referring to “Intermittent and Poor Connection” in Section 0A.	Go to Step 3.
3	Check Knock Sensor Output. 1) Stop engine. 2) With ignition switch at OFF position, disconnect knock sensor connector. 3) With ignition switch at ON position, check voltage from “WHT” terminal of knock sensor connector to body ground. See Fig. 2. Is it 4 – 5 V?	Faulty knock sensor. Substitute a known-good knock sensor and recheck.	“WHT” wire open, shorted to ground circuit or poor C20-25 connection. If wire and connection are OK, substitute a known-good ECM and recheck.

[A] Fig. 1 for Step 2 / [B] Fig. 2 for Step 3



DTC P0335 (DTC No.23) Crankshaft Position (CKP) Sensor Circuit Malfunction


WIRING DIAGRAM / CIRCUIT DESCRIPTION



DTC DETECTING CONDITION	POSSIBLE CAUSE
<ul style="list-style-type: none">No CKP sensor signal for 2 seconds at engine cranking.	<ul style="list-style-type: none">CKP sensor circuit open or short.Crankshaft timing belt pulley teeth damaged.CKP sensor malfunction, foreign material being attached or improper installation.ECM malfunction.

REFERENCE

Connect oscilloscope between terminals C20-23 of ECM connector connected to ECM and ground and check CKP sensor signal.



1. BTDC 5° (Crank angle)	[B] : Waveforms at specified idle speed
[A] : Oscilloscope Waveforms	[C] : Waveforms at 2000 r/min


DTC CONFIRMATION PROCEDURE

- 1) Clear DTC and crank engine for 2 sec.
- 2) Select “DTC” mode on scan tool and check DTC.


INSPECTION


Step	Action	Yes	No
1	Was "ENGINE DIAG. FLOW TABLE" performed?	Go to Step 2.	Go to "ENGINE DIAG. FLOW TABLE".
2	Check CKP Sensor and Connector for proper installation. Is CKP sensor installed properly and connector connected securely?	Go to Step 3.	Correct.
3	Check Wire Harness and Connection. 1) Disconnect connector from CKP sensor. 2) Check for proper connection to CKP sensor at each terminal. 3) If OK, turn ignition switch ON and check for voltage at each terminal of sensor connector disconnected. See Fig. 1. Terminal "B+" : 10 – 14 V Terminal "Vout" : 4 – 5 V Terminal "GND" : 0 – 1 V Is check result satisfactory?	Go to Step 5.	Go to Step 4.
4	Was terminal "Vout" voltage out of specification in Step 3 check?	"YEL/BLK" wire open, short or poor connection. If wire and connection are OK, substitute a known-good ECM and recheck.	"BLK/RED" or "BLK/ORN" wire open, short or poor connection.
5	Check Ground Circuit for open. 1) Turn ignition switch OFF. 2) Check for continuity between "GND" terminal of CKP sensor connector and engine ground. Is continuity indicated?	Go to Step 6.	"BLK/ORN" wire open or poor ground connection.
6	Check CKP Sensor for operation. 1) Remove CKP sensor from sensor case. 2) Remove metal particles on end face of CKP sensor, if any. 3) Connect each connector to ECM and CKP sensor. 4) Turn ignition switch ON. 5) Check for voltage at terminal C20-23 of connector connected to ECM by passing magnetic substance (iron) while keeping approximately 1 mm (0.03 in.) gap with respect to end face of CKP sensor. See Fig. 2 and 3. Does voltage vary from low (0 – 1 V) to high (4 – 5 V) or from high to low?	Go to Step 7.	Replace CKP sensor.
7	Check Signal Rotor for the following. See Fig. 4. • Damage • No foreign material attached Is it in good condition?	Intermittent trouble or faulty ECM. Check for intermittent referring to "Intermittent and Poor Connection" in Section 0A.	Clean rotor teeth or replace CMP sensor.

[A] Fig. 1 for Step 3 / [B] Fig. 2 for Step 6



[C] Fig. 3 for Step 6 / [D] Fig. 4 for Step 7




DTC P0340 (DTC No.15) Camshaft Position (CMP) Sensor Circuit Malfunction**WIRING DIAGRAM / CIRCUIT DESCRIPTION**

DTC DETECTING CONDITION	POSSIBLE CAUSE
<ul style="list-style-type: none"> No CMP sensor signal during engine running (CKP sensor signal is inputted). 	<ul style="list-style-type: none"> CMP sensor circuit open or short. Signal rotor teeth damaged. CMP sensor malfunction, foreign material being attached or improper installation. ECM malfunction.

REFERENCE

Connect oscilloscope between terminals C20-11 of ECM connector connected to ECM and body ground and check CMP sensor signal. When CKP circuit is failed (open or short), ECM identify the cylinder only by CMP sensor signal.



1. No.1 cylinder	3. No.3 cylinder	[A] : Oscilloscope Waveforms	[C] : CKP sensor signal
2. No.2 cylinder	4. No.4 cylinder	[B] : Waveforms at specified idle speed	[D] : CMP sensor signal


DTC CONFIRMATION PROCEDURE

- 1) Clear DTC.
- 2) Start engine and keep it at idle for 1 min.
- 3) Select "DTC" mode on scan tool and check DTC.


INSPECTION

Step	Action	Yes	No
1	Was "ENGINE DIAG. FLOW TABLE" performed?	Go to Step 2.	Go to "ENGINE DIAG. FLOW TABLE".
2	Check CMP Sensor and connector for proper installation. Is CMP sensor installed properly and connector connected securely?	Go to Step 3.	Correct.
3	Check Wire Harness and Connection. 1) Disconnect connector from CMP sensor. 2) Check for proper connection to CMP sensor at each terminal. 3) If OK, turn ignition switch ON and check for voltage at each terminal of sensor connector disconnected. See Fig. 1. Terminal "B+" : 10 – 14 V Terminal "Vout" : 4 – 5 V Terminal "GND" : 0 – 1 V Is check result satisfactory?	Go to Step 5.	Go to Step 4.
4	Was terminal "Vout" voltage out of specification in Step 3 check?	"BLU" wire open, short or poor connection. If wire and connection are OK, substitute a known-good ECM and recheck.	"BLK/RED" or "BLK/ORN" wire open, short or poor connection.
5	Check Ground Circuit for open. 1) Turn ignition switch OFF. 2) Check for continuity between "GND" terminal of CMP sensor connector and engine ground. Is continuity indicated?	Go to Step 6.	"BLK/ORN" wire open or poor ground connection.
6	Check CMP Sensor for operation. 1) Remove CMP sensor from sensor case. 2) Remove metal particles on end face of CMP sensor, if any. 3) Connect each connector to ECM and CMP sensor. 4) Turn ignition switch ON. 5) Check for voltage at terminal C20-11 of connector connected to ECM by passing magnetic substance (iron) while keeping approximately 1 mm (0.03 in.) gap with respect to end face of CMP sensor. See Fig. 2 and 3. Does voltage vary from low (0 – 1 V) to high (4 – 5 V) or from high to low?	Go to Step 7.	Replace CMP sensor.
7	Check Signal Rotor for the following. See Fig. 4. • Damage • No foreign material attached Is it in good condition?	Intermittent trouble or faulty ECM. Check for intermittent referring to "Intermittent and Poor Connection" in Section 0A.	Clean rotor teeth or replace CMP sensor.

[A] Fig. 1 for Step 3 / [B] Fig. 2 for Step 6




[C] Fig. 3 for Step 6 / [D] Fig. 4 for Step 7



- 1) Turn ignition switch OFF.
Clear DTC with ignition switch ON, check vehicle and environmental condition for :
 - Altitude (barometric pressure) : 2400 m, 8000 ft or less (560 mmHg, 75 kPa or more)
 - Ambient temp. : -10°C, 14°F or higher
 - Intake air temp. : 70°C, 122°F or lower
- 2) Start engine and warm it up to normal operating temperature (70 – 110°C, 158 – 230°F) and run it at idle for 5 min.
- 3) Increase vehicle speed to 80 – 88 km/h, 50 – 55 mph in 5th gear or in “D” range.
- 4) Hold throttle valve at that opening position for 2 min. or longer.
- 5) Increase engine speed to 4000 r/min. in 3rd gear or in “2” range.
- 6) Release accelerator pedal and with engine brake applied, keep vehicle coasting (fuel cut condition) till engine speed reaches 1500 r/min.

- 7) Stop vehicle (don't turn ignition switch OFF) and confirm test results according to following "Test Result Confirmation Flow Table".



TEST RESULT CONFIRMATION FLOW TABLE


Step	Action	Yes	No
1	Check DTC in "DTC" mode and pending DTC in "ON BOARD TEST". Is DTC or pending DTC displayed?	Proceed to applicable DTC flow table.	Go to Step 2.
2	Set scan tool to "READINESS TESTS" mode and check if testing has been completed. Is test completed?	No DTC is detected. (Confirmation test is completed)	Repeat DTC confirmation procedure.

INSPECTION

Step	Action	Yes	No
1	Was "ENGINE DIAG. FLOW TABLE" performed?	Go to Step 2.	Go to "ENGINE DIAG. FLOW TABLE".
2	Do you have SUZUKI scan tool?	Go to Step 4.	Go to Step 5.
3	EGR Valve Operation Check : 1) With ignition switch OFF, install SUZUKI scan tool. 2) Check EGR system referring to Section 6E1. Is it in good condition?	Go to Step 4.	Go to Step 5.
4	MAP Sensor Check : 1) Check MAP sensor for performance referring to Section 6E1. Is check result satisfactory?	Intermittent trouble or faulty ECM. Check for intermittent referring to "Intermittent and Poor Connection" in Section 0A.	Repair or replace.

Step	Action	Yes	No
5	EGR Valve Power Supply Circuit Check : 1) With ignition switch OFF, disconnect EGR valve coupler. 2) With ignition switch ON, check voltage between terminal 2 and terminal 5 of EGR valve connector and ground. See Fig.1. Is each voltage 10 – 14 V?	Go to Step 7.	Faulty "BLK/RED" wire.
6	EGR Valve Stepper Motor Coil Circuit Check : 1) With ignition switch OFF, connect EGR valve coupler and disconnect ECM couplers. 2) Check resistance between C21-5 and C20-18, 29, 17, 28. Is each resistance 20 – 24 Ω at 20°C, 68°F?	Go to Step 8.	Faulty "GRY", "GRY/WHT", "GRY/YEL", "BRN/WHT" wire or EGR valve.
7	MAP sensor Check : 1) Check MAP sensor for performance referring to Section 6E1. Is check result satisfactory?	EGR passage clogged or EGR valve malfunction. If all above are OK, intermittent trouble or faulty ECM. Check for intermittent referring to "Intermittent and Poor Connection" in Section 0A.	Repair or replace.


Fig. 1 for Step 5



1. EGR valve connector

DTC P0420 Catalyst System Efficiency below Threshold


WIRING DIAGRAM / CIRCUIT DESCRIPTION



ECM monitors oxygen concentration in the exhaust gas which has passed the three way catalytic converter by HO2S-2 (2).

When the catalyst is functioning properly, the variation cycle of HO2S-2 (2) output voltage (oxygen concentration) is slower than that of HO2S-1 (1) output voltage because of the amount of oxygen in the exhaust gas which has been stored in warm up three way catalytic converter (3) and three way catalytic converter (4).

REFERENCE



[A] : Oscilloscope Waveforms

DTC DETECTING CONDITION	POSSIBLE CAUSE
<ul style="list-style-type: none"> While vehicle running at constant speed under other than high load. Time from rich or lean switching command is output till HO2S-2 output voltage crosses 0.45 V is less than specified value. <p>*2 driving cycle detection logic, monitoring once/1 driving</p>	<ul style="list-style-type: none"> Exhaust gas leak Three way catalytic converter malfunction Fuel system malfunction HO2S-2 malfunction HO2S-1 malfunction

DTC CONFIRMATION PROCEDURE

WARNING:

- When performing a road test, select a place where there is no traffic or possibility of a traffic accident and be very careful during testing to avoid occurrence of an accident.
- Road test should be carried out with 2 persons, a driver and tester, on a level road.

1) Turn ignition switch OFF.

Clear DTC with ignition switch ON, check vehicle and environmental condition for :

- Altitude (barometric pressure) : 2400 m, 8000 ft or less (560 mmHg, 75 kPa or more)
- Ambient temp. : -10°C , 14°F or higher
- Intake air temp. : 70°C , 158°F or lower
- Engine coolant temp. : $70 - 110^{\circ}\text{C}$, $158 - 230^{\circ}\text{F}$


2) Start engine and drive vehicle at 55 – 65 km/h, 35 – 45 mph for 8 min. or longer.

While this driving, if “Catalyst Monitoring TEST COMPLETED” is displayed in “READINESS TESTS” mode and DTC is not displayed in “DTC” mode, confirmation test is completed.

If “TEST NOT COMPLETE” is still being displayed, continue test driving.

3) Decrease vehicle speed at 50 – 60 km/h, 30 – 40 mph, and hold throttle valve at that opening position for 2 min. and confirm that short term fuel trim vary within -20% – $+20\%$ range.

4) Stop vehicle (do not turn ignition switch OFF) and confirm test results according to following “Test Result Confirmation Flow Table”.



TEST RESULT CONFIRMATION FLOW TABLE


Step	Action	Yes	No
1	Check DTC in “DTC” mode and pending DTC in “ON BOARD TEST” or “PENDING DTC” mode. Is DTC or pending DTC displayed?	Proceed to applicable DTC Diag. Flow Table.	Go to Step 2.
2	Set scan tool to “READINESS TESTS” mode and check if testing has been completed. Is test completed?	No DTC is detected (confirmation test is completed).	Repeat DTC confirmation procedure.

INSPECTION

Step	Action	Yes	No
1	Was "ENGINE DIAG. FLOW TABLE" performed?	Go to Step 2.	Go to "ENGINE DIAG. FLOW TABLE".
2	Check Short Term Fuel Trim. Did short term fuel trim vary within – 20% – +20% range in step 3) of DTC confirmation test?	Go to Step 3.	Check fuel system. Go to DTC P0171/P0172 Diag. Flow Table.
3	Check HO2S-2 for Output Voltage. Perform steps 1) through 9) of DTC confirmation procedure for DTC P0136 (HO2S-2 malfunction) and check output voltage of HO2S-2 then. Is over 0.6 V and below 0.3 V indicated?	Replace three way catalytic converter.	Check "WHT" and "ORN" wires for open and short, and connections for poor connection. If wires and connections are OK, replace HO2S-2.

DTC P0443 Purge Control Valve Circuit Malfunction

WIRING DIAGRAM / CIRCUIT DESCRIPTION



1. EVAP canister purge valve

DTC DETECTING CONDITION	POSSIBLE CAUSE
Canister purge control valve circuit is opened or shorted.	<ul style="list-style-type: none">• “BLK” circuit open or short• “BLK/RED” circuit open or short• Canister purge valve malfunction


DTC CONFIRMATION PROCEDURE

- 1) Clear DTC with ignition switch ON.
- 2) Select “DTC” mode on scan tool and check DTC.

INSPECTION


Step	Action	Yes	No
1	Was “ENGINE DIAG. FLOW TABLE” performed?	Go to Step 2	Go to “ENGINE DIAG. FLOW TABLE”.
2	Check EVAP Canister Purge Valve operation. 1) With ignition switch OFF, disconnect coupler from canister purge valve. 2) Check resistance of EVAP canister purge valve. Resistance between two terminals : 30 – 34 Ω at 20°C (68°F) Resistance between terminal and body : 1 MΩ or higher See Fig.1. Is it as specified?	“BLK” circuit open or short. “BLK/RED” circuit open or short.	Replace EVAP canister purge valve.

Fig. 1 for Step 2



DTC P0480 Radiator Cooling Fan Control System Malfunction

WIRING DIAGRAM / CIRCUIT DESCRIPTION



1. Radiator fan relay No.1	3. Radiator fan relay No.3	5. Main fuse	7. Ignition switch
2. Radiator fan relay No.2	4. Radiator fan motor	6. J/B	

DTC DETECTING CONDITION	POSSIBLE CAUSE
Low voltage at terminal C21-18 when engine coolant temp. is below 97.5°C, 207.5°F. *2 driving cycle detection logic, continuous monitoring.	<ul style="list-style-type: none"> • “BLK/WHT” or “BRN” circuit open or short • Radiator cooling fan relay malfunction • ECM malfunction

DTC CONFIRMATION PROCEDURE


- 1) Turn ignition switch OFF.
- 2) Clear DTC with ignition switch ON.
- 3) Warm up engine until radiator cooling fan starts to operate.
- 4) Check pending DTC in “ON BOARD TEST” or “PENDING DTC” mode and DTC in “DTC” mode.

INSPECTION

Step	Action	Yes	No
1	Was “ENGINE DIAG. FLOW TABLE” performed?	Go to Step 2.	Go to “ENGINE DIAG. FLOW TABLE”.
2	Check Radiator Cooling Fan Relay and Its Circuit. 1) Turn ignition switch ON. 2) Check for voltage at terminal C21-18 of ECM connector connected, under following condition. See Fig. 1. When engine coolant temp. is lower than 97.5°C, 207.5°F and A/C switch turns OFF : 10 – 14 V Is voltage as specified?	Intermittent trouble or faulty ECM. Check for intermittent referring to “Intermittent and Poor Connection” in Section 0A.	Go to Step 3.


Step	Action	Yes	No
3	Check Radiator Cooling Fan Control Relay. 1) Turn ignition switch OFF and remove radiator cooling fan relay. 2) Check for proper connection to the relay at “BLK/WHT”, “BRN”, “BLU/RED” and “BLU/GRN” wire terminals. 3) If OK, then measure resistance between terminals a and b. See Fig. 2 and 3. Is it 56 – 146 Ω?	“BLK/WHT” or “BRN” circuit open or short. If wires and connections are OK, substitute a known-good ECM and recheck.	Replace radiator cooling fan relay.

[A] Fig. 1 for Step 2 / [B] Fig. 2 for Step 3




- | |
|----------------------------|
| 1. Radiator fan relay No.1 |
| 2. Radiator fan relay No.2 |
| 3. Radiator fan relay No.3 |

Fig. 3 for Step 3



DTC P0500 (DTC No.16) Vehicle Speed Sensor (VSS) Malfunction

WIRING DIAGRAM / CIRCUIT DESCRIPTION



1. VSS (vehicle speed sensor)	3. Power supply from ignition switch
2. VSS connector	4. Speedometer, P/S control module and multi information display

DTC DETECTING CONDITION	POSSIBLE CAUSE
<ul style="list-style-type: none"> VSS signal not inputted while vehicle running in "D" range or during fuel cut at deceleration. *2 driving cycle detection logic, continuous monitoring 	<ul style="list-style-type: none"> "BLK/ORN" circuit open "PPL" or "BLK/RED" circuit open or short VSS malfunction ECM malfunction Speedometer malfunction

DTC CONFIRMATION PROCEDURE

WARNING:

- When performing a road test, select a place where there is no traffic or possibility of a traffic accident and be very careful during testing to avoid occurrence of an accident.
- Road test should be carried out with 2 persons, a driver and a tester.


- Clear DTC and warm up engine to normal operating temperature.
- Increase vehicle speed to 80 km/h, 50 mph in 3rd gear or "2" range while observing vehicle speed displayed on scan tool.
- Release accelerator pedal and with engine brake applied, keep vehicle coasting (fuel cut condition) for 4 sec. or more.
- Check pending DTC and DTC.

INSPECTION

Step	Action	Yes	No
1	Was "ENGINE DIAG. FLOW TABLE" performed?	Go to Step 2.	Go to "ENGINE DIAG. FLOW TABLE".
2	Does speedometer indicate vehicle speed?	Go to Step 3.	Go to Step 5.
3	Check Vehicle Speed Signal. Is vehicle speed displayed on scan tool in step 2) and 3) of DTC confirmation procedure?	Intermittent trouble or faulty ECM. Check for intermittent referring to "Intermittent and Poor Connection" in Section 0A.	Go to Step 4.


Step	Action	Yes	No
4	Check VSS Signal Circuit. 1) Turn ignition switch to OFF position. 2) Disconnect combination meter connectors. Refer to Section 8. 3) Disconnect P/S control module connector (if equipped). 4) Turn ignition switch to ON position, without running engine. 5) Measure voltage from terminal "a" of VSS connector to ground. See Fig. 2. Is voltage within 4 – 5 V?	Faulty speedometer. Faulty P/S control module. Faulty multi information display.	"PPL" wire open or short. Poor connection of ECM connector terminal. If OK, substitute a known-good ECM and recheck.
5	Check VSS Power Supply. 1) With ignition switch at OFF position, disconnect VSS connector. 2) Turn ignition switch to ON position, without running engine. 3) Measure voltage from terminal "b" to "c" of VSS connector. See Fig. 1. Is voltage within 10 – 14 V?	Go to Step 6.	"BLK/RED" or "BLK/ORN" wire open or short.
6	Check VSS Signal Circuit. 1) Measure voltage from terminal "a" of VSS connector to ground. See Fig. 2. Is voltage more than 4 V?	Go to Step 7.	"PPL" wire open or short. Poor connection of ECM connector terminal. If OK, substitute a known-good ECM and recheck.
7	Check Signal Rotor. 1) Remove VSS. 2) Visually inspect VSS sensor signal rotor for damage. Was any damage found?	Faulty VSS signal rotor.	Poor connection of VSS connector terminal. If OK, substitute a known-good VSS and recheck.

[A] Fig. 1 for Step 5 / [B] Fig. 2 for Step 4 and Step 6



DTC P0505 (DTC No.26) Idle Control System Malfunction

CIRCUIT DESCRIPTION



1. Ignition switch	3. Main relay
2. Battery	4. IAC valve

DTC DETECTING CONDITION	POSSIBLE CAUSE
<ul style="list-style-type: none"> No closed signal to IAC valve is detected after engine start. <p>※2 driving cycle detection logic, continuous monitoring.</p>	<ul style="list-style-type: none"> “BLK/RED”, “GRN/RED” or “BLK” circuit open or short IAC valve malfunction ECM malfunction

DTC CONFIRMATION PROCEDURE


- 1) Turn ignition switch OFF.
- 2) Clear DTC with ignition switch ON.
- 3) Start engine and run it at idle for 1 min.
- 4) Check DTC and pending DTC.

INSPECTION

Step	Action	Yes	No
1	Was “ENGINE DIAG. FLOW TABLE” performed?	Go to Step 2.	Go to “ENGINE DIAG. FLOW TABLE”.
2	Is SUZUKI scan tool available?	Go to Step 3.	Go to Step 4.
3	Check Idle Air Control System. <ol style="list-style-type: none"> 1) Connect SUZUKI scan tool to DLC with ignition switch OFF, set parking brake and block drive wheels. 2) Warm up engine to normal operating temperature. 3) Clear DTC and select “MISC TEST” mode on SUZUKI scan tool. Is it possible to control (increase and reduce) engine idle speed by using SUZUKI scan tool?	Intermittent trouble or faulty ECM. Check for intermittent referring to “Intermittent and Poor Connection” in Section 0A.	Go to Step 5.

Step	Action	Yes	No
4	<p>Check Idle Air Control System.</p> <ol style="list-style-type: none"> 1) Remove IAC valve from throttle body referring to "IAC Valve Removal" in Section 6E1. 2) Check IAC valve for operation referring to "IAC Valve Inspection" in Section 6E1. See Fig. 1. <p>Is check result satisfactory?</p>	<p>Intermittent trouble or faulty ECM.</p> <p>Check for intermittent referring to "Intermittent and Poor Connection" in Section 0A.</p>	Go to Step 5.
5	<p>Check Wire Harness for open and short.</p> <ol style="list-style-type: none"> 1) Turn ignition switch OFF. 2) Disconnect IAC valve connector. 3) Check for proper connection to IAC valve at each terminals. 4) If OK, disconnect ECM connector. 5) Check for proper connection to ECM at C20-6 terminal. 6) If OK, check "BLK/RED", "GRN/RED" and "BLK" circuit for open and short. <p>Are they in good condition?</p>	Replace IAC valve and recheck.	Repair or replace.

Fig. 1 for Step 4



DTC P1450 Barometric Pressure Sensor Low/High Input**DTC P1451 Barometric Pressure Sensor Performance Problem****WIRING DIAGRAM / CIRCUIT DESCRIPTION**

Barometric pressure sensor is installed in ECM.

DTC DETECTING CONDITION	POSSIBLE CAUSE
DTC P1450 : Barometric pressure : Sensor voltage is 4.7 V or higher, or 1.6 V or lower	<ul style="list-style-type: none"> ECM (barometric pressure sensor) malfunction
DTC P1451 : <ul style="list-style-type: none"> Vehicle stopped Engine cranking Difference between barometric pressure and intake manifold absolute pressure is 26 kPa, 200 mmHg or more Difference between intake manifold absolute pressure at engine start and the pressure after engine start is 1.3 kPa, 10 mmHg or less. *2 driving cycle detection logic, monitoring once/1 driving.	<ul style="list-style-type: none"> Manifold absolute pressure sensor and its circuit malfunction ECM (barometric pressure sensor) malfunction

DTC CONFIRMATION PROCEDURE

- 1) Turn ignition switch OFF.
- 2) Clear DTC with ignition switch ON.
- 3) Turn ignition switch ON for 2 sec., crank engine for 2 sec. and run it at idle for 1 min.
- 4) Check pending DTC in "ON BOARD TEST" or "PENDING DTC" mode and DTC in "DTC" mode.

INSPECTION**DTC P1450 :**

Step	Action	Yes	No
1	Was "ENGINE DIAG. FLOW TABLE" performed?	Substitute a known-good ECM and recheck.	Go to "ENGINE DIAG. FLOW TABLE" in this section.

DTC P1451 :**NOTE:**

Note that atmospheric pressure varies depending on weather conditions as well as altitude. Take that into consideration when performing these check.


Step	Action	Yes	No
1	Was "ENGINE DIAG. FLOW TABLE" performed?	Go to Step 2.	Go to "ENGINE DIAG. FLOW TABLE" in this section.

Step	Action	Yes	No
2	Check Barometric Pressure Sensor. 1) Connect scan tool to DLC with ignition switch OFF. 2) Turn ignition switch ON and select "DATA LIST" mode on scan tool. 3) Check manifold absolute pressure. Is it barometric pressure (approx. 100 kPa, 760 mmHg) at sea level?	Go to Step 3.	Substitute a known-good ECM and recheck.
3	Check MAP Sensor. 1) Remove MAP sensor from intake manifold and connect vacuum pump gauge to MAP sensor. See Fig. 1. 2) Connect scan tool to DLC and turn ignition switch ON. 3) Check intake manifold absolute pressure displayed on scan tool for specified valve. See Table 1. Is check result satisfactory?	Check air intake system for air being drawn in and engine compression. If OK, then substitute a known-good ECM and recheck.	Replace MAP sensor.

Table 1


Applying Vacuum	Displayed Value on Scan Tool
0	Barometric pressure (Approx. 100 kPa, 760 mmHg)
27 kPa 200 mmHg	Barometric pressure – 27 kPa (Approx. 73 kPa, 560 mmHg)
67 kPa 500 mmHg	Barometric pressure – 67 kPa (Approx. 33 kPa, 260 mmHg)

Fig. 1 for Step 3



DTC P1500 Engine Starter Signal Circuit Malfunction

CIRCUIT DESCRIPTION



1. Ignition switch

2. Transmission range switch (A/T)

3. Starter motor

DTC DETECTING CONDITION	POSSIBLE CAUSE
<ul style="list-style-type: none"> Low voltage at terminal C20-30 when cranking engine or High voltage at terminal C20-30 after starting engine. <p>*2 driving cycle detection logic, continuous monitoring.</p>	<ul style="list-style-type: none"> "BLK/YEL" circuit open ECM malfunction

DTC CONFIRMATION PROCEDURE


- 1) Turn ignition switch OFF.
- 2) Clear DTC with ignition switch ON, crank engine and run it at idle for 3 min.
- 3) Check pending DTC in "ON BOARD TEST" or "PENDING DTC" mode and DTC in "DTC" mode.

INSPECTION

Step	Action	Yes	No
1	Was "ENGINE DIAG. FLOW TABLE" performed?	Go to Step 2.	Go to "ENGINE DIAG. FLOW TABLE".
2	Check Terminal Voltage. 1) Check for voltage at terminal C20-30 of ECM connector connected, under following condition. While engine cranking : 6 – 10 V After starting engine : 0 V Is voltage as specified?	Poor C20-30 connection or intermittent trouble. Check for intermittent referring to "Intermittent and Poor Connection" in Section 0A. If wire and connections are OK, substitute a known-good ECM and recheck.	"BLK/YEL" circuit open.

DTC P1510 ECM Back-Up Power Supply Malfunction

WIRING DIAGRAM / CIRCUIT DESCRIPTION



Battery voltage is supplied so that diagnostic trouble code memory, values for engine control learned by ECM, etc. are kept in ECM even when the ignition switch is turned OFF.

DTC DETECTING CONDITION	POSSIBLE CAUSE
<ul style="list-style-type: none">Low voltage at terminal G07-11 after starting engine.	<ul style="list-style-type: none">“WHT/RED” circuit openECM malfunction

DTC CONFIRMATION PROCEDURE


- 1) Clear DTC, start engine and run it at idle for 1 min.
- 2) Select “DTC” mode on scan tool and check DTC.

INSPECTION

Step	Action	Yes	No
1	Was “ENGINE DIAG. FLOW TABLE” performed?	Go to Step 2.	Go to “ENGINE DIAG. FLOW TABLE” in this section.
2	Check Terminal Voltage. 1) Check for voltage at terminal G07-11 of ECM connector connected, under each condition, ignition switch OFF and engine running. Is it 10 – 14 V at each condition?	Poor G07-11 connection or intermittent trouble. Check for intermittent referring to “Intermittent and Poor Connection” in Section 0A. If wire and connections are OK, substitute a known- good ECM and recheck.	“WHT/RED” circuit open.

DTC P1600 Serial Communication Problem Between ECM and TCM

WIRING DIAGRAM



CIRCUIT DESCRIPTION

TCM constantly sends information while ignition switch is ON as to whether judgement was made or not with respect to all detectable DTCs as well as whether or not abnormality exists after judgement.

DTC DETECTING CONDITION	POSSIBLE CAUSE
No signal inputted from TCM to ECM or check sum error while engine running	<ul style="list-style-type: none"> • “GRN/YEL” circuit open or short • TCM power or ground circuit open • TCM malfunction • ECM malfunction

DTC CONFIRMATION PROCEDURE


- 1) Turn ignition switch OFF.
- 2) Clear DTC with ignition switch ON.
- 3) Start engine and run it at idle for 1 min.
- 4) Select “DTC” mode on scan tool and check DTC.

INSPECTION

Step	Action	Yes	No
1	Was “ENGINE DIAG. FLOW TABLE” performed?	Go to Step 2.	Go to “ENGINE DIAG. FLOW TABLE”.
2	Check Signal Voltage. Check voltage between terminal G07-17 and body ground with ignition switch ON. Does it change between 0 – 12 V? See Fig. 1.	Intermittent trouble or faulty ECM or TCM. Check for intermittent trouble referring to “Intermittent and poor connection” in Section 0A.	Go to Step 3.
3	Is it about 12 V at Step 2?	“GRN/YEL” wire open, poor G43-27 connection or TCM power or ground circuit open. If wires and connections are OK, substitute a known-good TCM and recheck.	Go to Step 4.


Step	Action	Yes	No
4	<p>Check Signal Circuit.</p> <p>1) Disconnect TCM coupler with ignition switch OFF.</p> <p>2) Check voltage between G43-27 terminal and body ground with ignition switch ON. See Fig. 2.</p> <p>Is it about 12 V?</p>	<p>Check TCM power and ground circuit for open. If OK, substitute a known-good TCM and recheck.</p>	<p>“GRN/YEL” wire shorted to ground or poor G07-17 terminal connection. If wire and connection are OK, substitute a known-good ECM and recheck.</p>

[A] Fig. 1 for Step 2 / [B] Fig. 2 for Step 4



DTC P1717 A/T Drive Range (Park/Neutral Position) Signal Circuit Malfunction

WIRING DIAGRAM / CIRCUIT DESCRIPTION



1. From ignition switch

2. Transmission range switch

DTC DETECTING CONDITION	POSSIBLE CAUSE
<ul style="list-style-type: none"> “D” range signal not inputted (Park/Neutral position signal inputted) to ECM while vehicle running *2 driving cycle detection logic, continuous monitoring. 	<ul style="list-style-type: none"> “GRY/RED” circuit open Transmission range switch malfunction “R”, “D”, “2” or “L” range signal circuit open TCM power or ground circuit open TCM or ECM malfunction

DTC CONFIRMATION PROCEDURE

WARNING:

- When performing a road test, select a place where there is no traffic or possibility of a traffic accident and be very careful during testing to avoid occurrence of an accident.
- Road test should be carried out with 2 persons, a driver and a tester.

- Turn ignition switch OFF.
- Clear DTC with ignition switch ON.
- Start engine and shift selector lever to “D” range.
- Increase vehicle speed to higher than 32 km/h, 20 mph and then stop vehicle.
- Repeat above step 4) 9 times.
- Shift selector lever to “2” range and repeat above step 4) and 5).
- Shift selector lever to “L” range and repeat above step 4) and 5).
- Check DTC in “DTC” mode and pending DTC in “ON BOARD TEST” or “PENDING DTC” mode.

INSPECTION

Step	Action	Yes	No
1	Was “ENGINE DIAG. FLOW TABLE” performed?	Go to Step 2.	Go to “ENGINE DIAG. FLOW TABLE”.
2	Is SUZUKI scan tool available?	Go to Step 3.	Go to Step 4.

Step	Action	Yes	No
3	Check PNP Signal (“D” range signal). 1) Connect SUZUKI scan tool to DLC with ignition switch OFF. 2) Turn ignition switch ON and check PNP signal (“P/N” or “D” range) on display when shifting selector lever to each range. Is “D” range on display (Is 0 – 1 V indicated) no matter which of “R”, “D”, “2” and “L” range positions selector lever may be at? See Table 1.	Intermittent trouble or faulty ECM. Check for intermittent referring to “Intermittent and poor connection” in Section 0A.	Go to Step 5.
4	Check PNP Signal (“D” range signal). 1) Turn ignition switch ON. 2) Check voltage at terminal G07-6 of ECM connector connected. See Fig. 1. Is “D” range on display (Is 0 – 1 V indicated) no matter which of “R”, “D”, “2” and “L” range positions selector lever may be at? See Table 1.	Intermittent trouble or faulty ECM. Check for intermittent referring to “Intermittent and poor connection” in Section 0A.	Go to Step 5.
5	Is “P/N range on display (Is 10 – 14 V indicated) when selector lever is at one of “R”, “D”, “2” and “L” range positions only?	Check transmission range sensor and circuits referring to section 7B1.	Go to Step 6.
6	Check PNP Signal Circuit. 1) Turn ignition switch OFF. 2) Disconnect TCM connectors. 3) Check for proper connection to TCM at terminal. 4) If OK, then check voltage at terminal in TCM connector disconnected, with ignition switch ON. Is it 10 – 14 V? See Fig. 2.	“BLK/RED” circuit open, poor transmission range switch connector connection, select cable maladjusted, transmission range sensor maladjusted or transmission range sensor malfunction. If all above are OK, substitute a known-good TCM and recheck.	“GRY/RED” circuit open or poor G07-6 connection. If wire and connection are OK, substitute a known-good ECM and recheck.

[A] Fig. 1 for Step 4 / [B] Fig. 2 for Step 6





Table 1 for Step 3 and 4

		Scan tool or voltmeter	
		SUZUKI SCAN TOOL	VOLTAGE AT G07-6
Selector lever position	“P” and “N” range	P/N range	10 – 14V
	“R”, “D”, “2” and “L” range	D range	0 – 1V

Table B-1 Fuel Injector Circuit Check

WIRING DIAGRAM




1. No.1 injector	3. No.3 injector
2. No.2 injector	4. No.4 injector

INSPECTION

Step	Action	Yes	No
1	Was "ENGINE DIAG. FLOW TABLE" performed?	Go to Step 2.	Go to "ENGINE DIAG. FLOW TABLE".
2	Check Injector for operating sound. Using sound scope, check each injector for operating sound at engine cranking. Do all 4 injectors make operating sound?	Fuel injector circuit is in good condition.	Go to Step 3.
3	Dose none of 4 injectors make operating sound at Step 2?	Go to Step 4.	Check coupler connection and wire harness of injector not making operating sound and injector itself (Refer to Section 6E1).
4	Check power circuit of injectors for open and short. Is it normal?	Check all 4 injectors for resistance respectively. If resistance is OK, substitute a known-good ECM and recheck.	Power circuit open or short.

Table B-2 Fuel Pump and Its Circuit Check

WIRING DIAGRAM



1. Fuel pump relay	2. Fuel pump
--------------------	--------------


INSPECTION

CAUTION:
Check to make sure that connection is made between correct terminals. Wrong connection can cause damage to ECM, wire harness, etc.

Step	Action	Yes	No
1	Was "ENGINE DIAG. FLOW TABLE" performed?	Go to Step 2.	Go to "ENGINE DIAG. FLOW TABLE".
2	Check Fuel Pump Control System for operation. See Fig. 1. Is fuel pump heard to operate for 2 sec. after ignition switch ON?	Fuel pump circuit is in good condition.	Go to Step 3.
3	Check Fuel Pump for operation. 1) Remove fuel pump relay from relay box with ignition switch OFF. 2) Check for proper connection to relay at each terminals. 3) If OK, using service wire, connect terminals C61-3 and C61-4 of relay connector. See Fig. 2. Is fuel pump heard to operate at ignition switch ON?	Go to Step 4.	"PNK", "BLK" or "BLK/RED" circuit open or fuel pump malfunction.

Step	Action	Yes	No
4	<p>Check Fuel Pump Relay for operation.</p> <p>1) Check resistance between each two terminals of fuel pump relay. See Fig.3. Between terminals “c” and “d” : Infinity Between terminals “a” and “b” : 56 – 146 Ω</p> <p>2) Check that there is continuity between terminals “c” and “d” when battery is connected to terminals “a” and “b”. See Fig. 3.</p> <p>Is fuel pump relay in good condition?</p>	<p>“BRN” circuit open or poor C20-24 connection.</p> <p>If wire and connection are OK, substitute a known-good ECM and recheck.</p>	Replace fuel pump relay.


[A] Fig. 1 for Step 2 / [B] Fig. 2 for Step 3 / [C] Fig. 3 for Step 4



1. Fuel pump relay

Table B-3 Fuel Pressure Check

WIRING DIAGRAM



1. Injector	3. Fuel pressure regulator	(A) : Fuel pressure gauge	(C) : Attachment
2. Delivery pipe	4. Fuel pump	(B) : Hose	

INSPECTION

Step	Action	Yes	No
1	Check Fuel Pressure (Refer to Section 6E1 for details). 1) Release fuel pressure from fuel feed line. 2) Install fuel pressure gauge. 3) Check fuel pressure by repeating ignition switch ON and OFF. See Fig. 1. Is fuel pressure then 270 – 310 kPa (2.7 – 3.1 kg/cm ² , 38.4 – 44.0 psi)?	Go to Step 2.	Go to Step 5.
2	Is 200 kPa (2.0 kg/cm ² , 28.4 psi) or higher fuel pressure retained for 1 minute after fuel pump is stopped at Step 1?	Go to Step 3.	Go to Step 4.
3	Check Fuel Pressure Regulator for Operation. 1) Start engine and warm it up to normal operating temperature. 2) Keep it running at specified idle speed. Is fuel pressure then within 200 – 240 kPa (2.0 – 2.4 kg/cm ² , 28.4 – 34.1 psi)?	Normal fuel pressure.	Clogged vacuum passage for fuel pressure regulator or faulty fuel pressure regulator.
4	Is there fuel leakage from fuel feed line hose, pipe or their joint?	Fuel leakage from hose, pipe or joint.	Go to Step 10.
5	Was fuel pressure higher than spec. in Step 1?	Go to Step 6.	Go to Step 7.
6	1) Disconnect fuel return hose from fuel pressure regulator and connect new return hose to it. 2) Put the other end of new return hose into approved gasoline container. 3) Operate fuel pump. Is specified fuel pressure obtained then?	Restricted fuel return hose or pipe.	Faulty fuel pressure regulator.
7	Was no fuel pressure applied in Step 1?	Go to Step 8.	Go to Step 9.

Step	Action	Yes	No
8	With fuel pump operated and fuel return hose blocked by pinching it, is fuel pressure applied?	Faulty fuel pressure regulator.	Shortage of fuel or fuel pump or its circuit malfunction (refer to TABLE B-2 FUEL PUMP AND ITS CIRCUIT CHECK).
9	1) Operate fuel pump. 2) With fuel return hose blocked by pinching it, check fuel pressure. Is it 450 kPa (4.5 kg/cm ² , 63.9 psi) or more?	Faulty fuel pressure regulator.	Clogged fuel filter, Restricted fuel feed hose or pipe, Faulty fuel pump or Fuel leakage from hose connection in fuel tank.
10	1) Disconnect fuel return hose from pressure regulator and connect new return hose to it. 2) Insert the other end of new return hose into approved gasoline container. 3) Check again if specified pressure is obtained. While doing so, does fuel come out of return hose?	Faulty fuel pressure regulator.	Fuel leakage from injector, Fuel leakage from between injector and delivery pipe, Faulty fuel pump (faulty check valve in fuel pump) or Fuel leakage from fuel pressure regulator diaphragm.

Fig. 1 for Step 1



**Special tool****(A) : 09912-58441****(B) : 09912-58431****(C) : 09912-58490**

Table B-4 Idle Air Control System Check

1. IAC valve	2. Main relay	3. To TCM
--------------	---------------	-----------

INSPECTION

Step	Action	Yes	No
1	Check engine idle speed and IAC duty referring to "Idle Speed/IAC Duty Inspection" in Section 6E1. Is idle speed within specification?	Go to Step 2.	Go to Step 4.
2	Is IAC duty within specification in Step 1?	Go to Step 3.	Check for followings : Vacuum leak EVAP canister purge control system Clog of IAC air passage Accessory engine load Closed throttle position (TP sensor) Stuck of PCV valve
3	Is engine idle speed kept specified speed even with headlight ON?	Vehicle with power steering system: Go to Step 4. Vehicle without power steering system: System is in good condition.	Check electric load signal circuit referring to TABLE B-6. If check result is OK, check IAC system for operation referring to Step 3 or Step 4 of DTC P0505 Diag. Flow Table.

Step	Action	Yes	No
4	Is engine idle speed kept specified speed even with steering wheel turned to the right or left as far as it stops (vehicle with power steering system)?	System is in good condition.	Check power steering pressure switch signal circuit referring to TABLE B-8. If check result is OK, check IAC system for operation referring to Step 3 or Step 4 of DTC P0505 Diag. Flow Table.
5	Was idle speed higher than specification in Step 1?	Go to Step 6.	Go to Step 9.
6	Check A/C (input) signal circuit referring to Step 1 of Table B-5 A/C Signal Circuits Check, if equipped. (A/C signal can be also checked by using SUZUKI scan tool.) Is it in good condition?	Go to Step 7.	Repair or replace A/C signal circuit or A/C system.
7	Check IAC system referring to Step 3 or Step 4 of DTC P0505 Diag. Flow Table. Is check result satisfactory?	Go to Step 8.	Go to Step 5 of DTC P0505 Diag. Flow Table.
8	Was IAC duty less than about 3% (or more than about 97% for OFF duty meter) in Step 1 of this table?	Check abnormal air inhaling from air intake system, PCV valve and EVAP canister purge control system.	Check TP sensor (closed throttle position) and ECT sensor for performance. If sensors are OK, substitute a known-good ECM.
9	Is SUZUKI scan tool available?	Go to Step 10.	Go to Step 11.
10	Check PNP signal ("D" range signal). 1) Connect SUZUKI scan tool to DLC with ignition switch OFF. 2) Turn ignition switch ON and check PNP signal ("P/N" and "D" range) on display when shifting selector lever to each range. See Table 1. Is check result satisfactory?	Go to Step 12.	Repair or replace.
11	Check PNP signal ("D" range signal). 1) Turn ignition switch ON. 2) Check voltage at terminal G07-6 of ECM connector connected. See Fig. 1 and Table 1. Is check result satisfactory?	Go to Step 12.	Repair or replace.
12	Check IAC system referring to Step 3 or Step 4 of DTC P0505 Diag. Flow Table. Is check result satisfactory?	Go to Step 11.	Go to Step 5 of DTC P0505 Diag. Flow Table.
13	Was IAC duty more than about 30% (or less than 70% for OFF duty meter) in Step 1 of this table?	Check parts or system which can cause engine low idle. Accessory engine load Clog of air passage Etc.	Substitute a known-good ECM and recheck.

Fig. 1 for Step 11





Table 1 for Step 10 and 11

		Scan tool or voltmeter	
		SUZUKI SCAN TOOL DISPLAY	VOLTAGE AT G07-6
Selector lever position	“P” and “N” range	P/N range	10 – 14V
	“R”, “D”, “2” and “L” range	D range	0 – 1V

Table B-5 A/C Signal Circuits Check (Vehicle with A/C)

1. Blower fan motor	4. A/C pressure switch	7. A/C condenser fan relay	10. A/C compressor
2. Blower fan switch	5. A/C evaporator outlet air temp. sensor	8. A/C condenser fan motor	
3. A/C switch	6. A/C evaporator inlet air temp. sensor	9. A/C compressor relay	

INSPECTION


Step	Action	Yes	No
1	Check evaporator temp. sensor resistance. 1) Disconnect ECM connectors with ignition switch at OFF position. 2) Check resistance between terminals C21-14 and C21-20 and terminals C21-11 and C21-20. See Fig. 1. Is it within specification? At 0°C 6.3 – 6.9 kΩ At 25°C 1.8 – 2.2 kΩ	Go to Step 2.	Faulty A/C evaporator temp. sensor or its circuit.
2	Check A/C switch signal. 1) Check voltage at terminal C21-16 under each condition given below. Ignition switch ON A/C switch OFF : 10 – 14V Ignition switch ON A/C switch ON : 0 – 1V Is check result satisfactory?	Go to Step 3.	“GRN/BLK” wire open or short Poor C21-16 terminal connection If wire and connection are OK, substitute a known-good ECM and recheck. Go to Step 3.
3	Check A/C Condenser Fan Control System. Is A/C cooling fan started when A/C switch and heater blower switch turned ON?	Go to Step 7.	Go to Step 4.
4	Check A/C Condenser Fan Control Relay and its Circuit. 1) Check voltage at terminal C21-9 under each condition given below. Ignition switch ON A/C switch OFF : 10 – 14V Ignition switch ON A/C switch ON : 0 – 1V Is check result satisfactory?	Go to Step 5.	“BLU/YEL” wire open or short Poor C21-9 terminal connection If wire and connection are OK, substitute a known-good ECM and recheck. Go to Step 5.
5	Check A/C Condenser Fan Control Relay. 1) Turn ignition switch OFF and remove A/C condenser fan control relay. 2) Check for proper connection to relay at terminals “c” and “d”. 3) If OK, check that there is continuity between “c” and “d” when battery is connected to terminals “a” and “b”. See Fig.2. Is check result satisfactory?	Go to Step 6.	Replace A/C condenser fan control relay.

Step	Action	Yes	No
6	Check A/C Condenser Fan. 1) Turn ignition switch OFF. 2) Disconnect A/C condenser fan motor connector. 3) Check for proper connection to motor at "RED/BLU" and "BLK" terminals. 4) If OK, connect battery to motor and check for operation. See Fig. 3. Is it in good condition?	"RED/BLU" or "BLK" circuit open.	Replace A/C condenser fan motor.
7	Check A/C Compressor Control System. Is A/C compressor started when A/C switch and heater blower switch turned ON while engine running?	A/C control system is in good condition.	Go to Step 8.
8	1) Check voltage at C21-1 terminal under each condition given below. While engine running, A/C switch OFF : 0 V While engine running, A/C switch ON : 10 – 14V Is check result satisfactory?		"BRN/YEL" wire open or short Poor C21-1 terminal connection If wire and connection are OK, substitute a known-good ECM and recheck. Go to Step 9.
9	Check A/C Compressor Control Relay. 1) Turn ignition switch OFF and remove A/C compressor control relay. 2) Check for proper connection to relay at terminals "c" and "d". 3) If OK, check that there is continuity between "c" and "d" when battery is connected to terminals "a" and "b". See Fig. 2. Is check result satisfactory?	Check A/C compressor referring to Section 1B.	Replace A/C compressor control relay.

NOTE:

When A/C evaporator thermistor temp. is below 2.5°C (36.5°F), A/C remains OFF (C21-1 terminal voltage becomes 0 – 1 V). This condition is not abnormal.

[A] Fig. 1 for Step 1 / [B] Fig. 2 for Step 5 and 9



- | |
|----------------------------|
| 1. A/C condenser fan relay |
| 2. A/C compressor relay |

Fig. 3 for Step 6





Table B-6 Electric Load Signal Circuit Check

1. Blower fan motor	3. Rear defogger	5. To A/C switch
2. Blower fan switch	4. Position lamp	

INSPECTION

Step	Action	Yes	No
1	Is SUZUKI scan tool available?	Go to Step 2.	Go to Step 3.
2	Check Electric Load Signal Circuit. 1) Connect SUZUKI scan tool to DLC with ignition switch OFF. 2) Start engine and select "DATA LIST" mode on scan tool. 3) Check electric load signal under following each condition. See Table 1. Is check result satisfactory?	Electric load signal circuit is in good condition.	"YEL/BLK" and/or "BLU/BLK" circuit open or short, Electric load diodes malfunction or Each electric load circuit malfunction.
3	Check Electric Load Signal Circuit. 1) Turn ignition switch ON. 2) Check voltage at each terminals C21-17 and G07-10 of ECM connector connected, under above each condition. See Fig. 1 and Table 1. Is each voltage as specified?	Electric load signal circuit is in good condition.	"YEL/BLK" and/or "BLU/BLK" circuit open or short, Electric load diodes malfunction or Each electric load circuit malfunction.



Fig. 1 for Step 3

Table 1 for Step 2 and 3

		Scan tool or voltmeter		
		SUZUKI SCAN TOOL	VOLTAGE AT C21-17	VOLTAGE AT G07-10
Ignition switch ON, Small light, heater blower fan and rear defogger all turned	OFF	OFF	0V	10 – 14V
	ON	ON	10 – 14V	0V

Table B-7 Radiator Fan Control System Check




1. Radiator fan relay No.1	3. Radiator fan relay No.3	5. Main fuse box	7. Ignition switch
2. Radiator fan relay No.2	4. Radiator fan	6. Circuit fuse box	

INSPECTION


Step	Action	Yes	No
1	<p>Check Fan Control System.</p> <p>1) Connect scan tool to DLC with ignition switch OFF.</p> <p>2) Start engine and select "DATA LIST" mode on scan tool.</p> <p>3) Warm up engine until coolant temp. is 97.5°C, 208°F or higher and A/C switch turn OFF. (If engine coolant temp. does not rise, check engine cooling system or ECT sensor.)</p> <p>Is radiator cooling fan started when engine coolant temp. reached above temp.?</p>	Radiator cooling fan control system is in good condition.	Go to Step 2.
2	<p>Check Radiator Fan Relay and Its Circuit.</p> <p>1) Check DTC and pending DTC with scan tool.</p> <p>Is DTC P0480 displayed?</p>	Go to DTC P0480 Diag. Flow Table.	Go to Step 3.
3	<p>Check Radiator Fan Relays.</p> <p>1) Turn ignition switch OFF and remove radiator cooling fan relays. (No.1 – No.3)</p> <p>2) Check for proper connection to relay at terminals "c" and "d".</p> <p>3) If OK, check that there is continuity between "c" and "d" when battery is connected to terminals "a" and "b". See Fig. 1.</p> <p>Is check result satisfactory?</p>	Go to Step 4.	Replace radiator fan relay(s).

Step	Action	Yes	No
4	<div>Check Radiator Fan.</div> <div>1) Turn ignition switch OFF.</div> <div>2) Disconnect cooling fan motor connector.</div> <div>3) Check for proper connection to motor at “BLU/RED” and “BLK” terminals.</div> <div>4) If OK, connect battery to motor and check for operation.</div> <div>See Fig. 2.</div> <div>Is it in good condition?</div>	“BLU/WHT”, “BLU/RED” or “BLK” circuit open.	Replace radiator fan motor.

[A] Fig. 1 for Step 3 / [B] Fig. 2 for Step 4



1. Radiator fan relay No.1
2. Radiator fan relay No.2
3. Radiator fan relay No.3


Table B-8 Power Steering Pressure (PSP) Switch Signal Circuit Check (If equipped)

1. Power steering pressure switch

INSPECTION


Step	Action	Yes	No
1	<p>Check PSP Switch Signal Circuit.</p> <p>1) Connect SUZUKI scan tool to DLC with ignition switch OFF.</p> <p>2) Start engine and select "DATA LIST" mode on scan tool.</p> <p>3) Check power steering pressure switch.</p> <p>Engine running and steering wheel at straight-ahead position : OFF</p> <p>Engine running and steering wheel turned to the right or left as far as it stops : ON</p> <p>Is it in good condition?</p> <p>Is each voltage as specified?</p>	Signal circuit is in good condition.	Go to Step 2.
2	<p>Check Wire Harness.</p> <p>1) Turn ignition switch OFF and disconnect PSP switch connector.</p> <p>2) Check for proper connection to PSP switch.</p> <p>3) If OK, then check voltage at "YEL" PSP switch wire terminal with ignition switch ON. See Fig. 1.</p> <p>Is it 10 – 14V?</p>	Power steering switch malfunction or power steering system malfunction.	<p>"YEL" wire open or shorted to ground or Poor C20-5 connection.</p> <p>If wire and connection are OK, Substitute a known-good ECM (PCM) and recheck.</p>

Fig. 1 for Step 2



1. Power steering pump

Table B-9 Generator Control Signal Circuit Check



1. Generator












CIRCUIT DESCRIPTION

ECM sends signal (0 – 1V) to generator terminal C to suspend charging during vehicle take off or fast acceleration.

INSPECTION

Step	Action	Yes	No
1	<p>Check Generator Control Signal Circuit.</p> <p>1) Check voltage at terminal C20-12 under each condition given below (vehicle at stop).</p> <p>While engine idling : 10 – 14 V</p> <p>While engine running at 2000 rpm or less and throttle valve is not totally closed : 0 – 1 V</p> <p>Is check result satisfactory?</p>	<p>Generator Control signal circuit is in good condition.</p>	<p>“RED/BLU” wire open or short. Poor C20-12 terminal connection.</p> <p>If wire and connection are OK, substitute a known-good ECM and recheck.</p>

Special Tool

 <p>09912-58441 Pressure gauge</p>	 <p>09912-58431 Pressure hose</p>	 <p>09912-58490 3-way joint & hose</p>	 <p>09912-58421 Checking tool set (See NOTE "A".)</p>
 <p>09912-57610 Checking tool plate</p>	 <p>09917-47010 Vacuum pump gauge</p>	 <p>09930-88530 Injector test lead</p>	 <p>09931-76011 Tech 1A kit (SUZUKI scan tool) (See NOTE "B".)</p>
 <p>Mass storage cartridge for Tech 1A</p>	 <p>09931-76030 16/14 pin DLC adapter for Tech 1A</p>	 <p>Tech 2 kit (SUZUKI scan tool) (See NOTE "C".)</p>	

NOTE:

- "A" : This kit includes the following items.

1. Tool body & washer, 2. Body plug, 3. Body attachment, 4. Holder, 5. Return hose & clamp, 6. Body attachment-2 & washer, 7. Hose attachment-1, 8. Hose attachment-2

- "B" : This kit includes the following items and substitutes for the Tech 2 kit.

1. Storage case, 2. Operator's manual, 3. Tech 1A, 4. DLC cable, 5. Test lead/probe, 6. Power source cable, 7. DLC cable adaptor, 8. Self-test adaptor

- "C" : This kit includes the following items and substitutes for the Tech 1A kit.

1. Tech 2, 2. PCMCIA card, 3. DLC cable, 4. SAE 16/19 adapter, 5. Cigarette cable, 6. DLC loopback adapter, 7. Battery power cable, 8. RS232 cable, 9. RS232 adapter, 10. RS232 loopback connector, 11. Storage case, 12. Power supply

SECTION 6A1

ENGINE MECHANICAL (M13 AND M16 ENGINES)

WARNING:

For vehicles equipped with Supplemental Restraint (Air Bag) System :

- Service on and around the air bag system components or wiring must be performed only by an authorized SUZUKI dealer. Refer to “Air Bag System Components and Wiring Location View” under “General Description” in air bag system section in order to confirm whether you are performing service on or near the air bag system components or wiring. Please observe all WARNINGS and “Service Precautions” under “On-Vehicle Service” in air bag system section before performing service on or around the air bag system components or wiring. Failure to follow WARNINGS could result in unintentional activation of the system or could render the system inoperative. Either of these two conditions may result in severe injury.
- Technical service work must be started at least 90 seconds after the ignition switch is turned to the “LOCK” position and the negative cable is disconnected from the battery. Otherwise, the system may be activated by reserve energy in the Sensing and Diagnostic Module (SDM).

6A1


CONTENTS

General Description	6A1-2	Engine Mountings	6A1-23
Engine	6A1-2	Unit Repair Overhaul	6A1-24
Engine Lubrication	6A1-3	Engine Assembly	6A1-24
Diagnosis	6A1-4	Timing Chain Cover	6A1-28
Diagnosis Table	6A1-4	Oil Pump	6A1-31
Compression Check	6A1-4	Timing Chain and Chain Tensioner	6A1-35
Engine Vacuum Check	6A1-6	Camshaft, Tappet and Shim	6A1-39
Oil Pressure Check	6A1-7	Valves and Cylinder Head	6A1-45
Valve Lash (Clearance)	6A1-9	Pistons, Piston Rings, Connecting Rods and Cylinders	6A1-56
On-Vehicle Service	6A1-12	Main Bearings, Crankshaft and Cylinder Block	6A1-66
Air Cleaner Element	6A1-12	Required Service Material	6A1-80
Knock Sensor	6A1-13	Tightening Torque Specification	6A1-81
Cylinder Head Cover	6A1-13	Special Tool	6A1-82
Throttle Body and Intake Manifold	6A1-15		
Exhaust Manifold	6A1-18		
Oil Pan and Oil Pump Strainer	6A1-20		

General Description

Engine

The engine is water-cooled, in line 4 cylinders, 4 stroke cycle gasoline unit with its DOHC (Double overhead camshaft) valve mechanism arranged for "V" type valve configuration and 16 valves (4 valves/one cylinder). The double overhead camshaft is mounted over the cylinder head; it is driven from crankshaft through timing chain, and no push rods are provided in the valve train system.



Engine Lubrication


The oil pump is of a trochoid type, and mounted on the crankshaft. Oil is drawn up through the oil pump strainer and passed through the pump to the oil filter.

The filtered oil flows into 2 paths in cylinder block.

In one path, oil reaches the crankshaft journal bearings. Oil from the crankshaft journal bearings is supplied to the connecting rod bearings by means of intersecting passages drilled in the crankshaft, and then injected from the big end of connecting rod to lubricate piston, rings, and cylinder wall.

In other path oil goes up to the cylinder head and lubricates valves and camshafts, etc., after passing through the internal oilway of camshafts.

An oil relief valve is provided on the oil pump. This valve starts relieving oil pressure when the pressure exceeds about 400 kPa (4.0 kg/cm², 56.9 psi).



Diagnosis

Diagnosis Table

Refer to “ENGINE DIAGNOSIS FLOW TABLE” in Section 6.


Compression Check

Check compression pressure on all 4 cylinders as follows:


- 1) Warm up engine to normal operating temperature.
- 2) Stop engine after warming up.

NOTE:


After warming up engine, place transaxle gear shift lever in “Neutral” (shift selector lever to “P” range for A/T model), and set parking brake and block drive wheels.



- 3) Remove cylinder head upper cover (1).




- 4) Disconnect ignition coil couplers (1).
- 5) Remove ignition coil assemblies (2) with high-tension cord (3).
- 6) Remove all spark plugs.
- 7) Disconnect fuel injector wires (4) at the coupler.



- 8) Install special tools (compression gauge) into spark plug hole.

Special tool

- (A) : 09915-64510-001
 (B) : 09915-64510-002
 (C) : 09915-64530
 (D) : 09915-67010



- 9) Disengage clutch (1) (to lighten starting load on engine) for M/T vehicle, and depress accelerator pedal (2) all the way to make throttle fully open.

- 10) Crank engine with fully charged battery, and read the highest pressure on compression gauge.


NOTE:

- For measuring compression pressure, crank engine at least 250 rpm by using fully charged battery.
- If measured compression pressure is lower than limit value, check installation condition of special tool. If it is properly installed, possibility is compression pressure leakage from where piston ring and valve contact.


Compression pressure

Standard	1400 kPa (14.0 kg/cm², 199.0 psi)
Limit	1100 kPa (11.0 kg/cm², 156.0 psi)
Max. difference between any two cylinders	100 kPa (1.0 kg/cm², 14.2 psi)

- 11) Carry out Steps 8) through 10) on each cylinder to obtain 4 readings.



- 12) After checking, install spark plugs and ignition coil assemblies (1) with high-tension cord (2).
- 13) Connect ignition coil couplers (3).
- 14) Connect fuel injector wires (4) at the coupler.



- 15) Check cylinder head upper cover gasket for deterioration and then install it into groove of cylinder head upper cover (1) securely.

- 16) Install cylinder head upper cover with gasket on to cylinder head cover.

Engine Vacuum Check



The engine vacuum that develops in the intake line is a good indicator of the condition of the engine. The vacuum checking procedure is as follows :

- 1) Warm up engine to normal operating temperature.

NOTE:

After warming up engine, be sure to place transaxle gear shift lever in “Neutral” (shift selector lever to “P” range for A/T model), and set parking brake and block drive wheels.

- 2) Stop engine and turn off the all electric switches.
- 3) Remove cap (1) from intake manifold.



- 4) Connect special tool (Vacuum gauge) to intake manifold.

Special tool

(A) : 09915-67310

- 5) Run engine at specified idle speed and read vacuum gauge.
Vacuum should be within specification.

Vacuum specification (at sea level)

59 – 73 kPa (45 – 55 cmHg, 17.7 – 21.6 inHg)

at specified idle speed


- 6) After checking, disconnect special tool (Vacuum gauge) from intake manifold.
- 7) Install cap to intake manifold.

Oil Pressure Check

NOTE:


Prior to checking oil pressure, check the following items.

- Oil level in oil pan
If oil level is low, add oil up to Full level mark (hole) on oil level gauge.




1. Full level mark (hole)
2. Low level mark (hole)

- Oil quality
If oil is discolored, or deteriorated, change it.
For particular oil to be used referring to the table in Section 0B.
- Oil leaks
If leak is found, repair it.



- 1) Disconnect oil pressure switch coupler (1).
- 2) Remove exhaust manifold cover, if necessary.
- 3) Remove oil pressure switch (2) from cylinder block.



- 4) Install special tools (Oil pressure gauge) to vacated threaded hole.

Special tool

(A) : 09915-77310

(B) : 09915-78211

- 5) Start engine and warm it up to normal operating temperature.

NOTE:


Be sure to place transaxle gear shift lever in "Neutral" (shift selector lever to "P" range for A/T model), and set parking brake and block drive wheels.

- 6) After warming up, raise engine speed to 4,000 rpm and measure oil pressure.

Oil pressure specification

**More than 270 kPa (2.7 kg/cm², 39.8 psi)
at 4,000 rpm**

- 7) Stop engine and remove oil pressure gauge and attachment.




- 8) Before reinstalling oil pressure switch (2), be sure to wrap its screw threads with sealing tape (1) and tighten switch to specified torque.

NOTE:

If sealing tape edge is bulged out from screw threads of switch, cut it off.

Tightening torque


Oil pressure switch (a) : 14 N·m (1.4 kg-m, 10.5 lb-ft)



- 9) Start engine and check oil pressure switch for oil leakage.
If oil leakage is found, repair it.
- 10) Connect oil pressure switch coupler (1).

Valve Lash (Clearance)

INSPECTION




- 1) Remove negative cable at battery.
- 2) Remove cylinder head cover referring to "CYLINDER HEAD COVER".
- 3) Remove right side engine under cover, if necessary.
- 4) Using 17 mm wrench, turn crankshaft pulley (1) clockwise until cam lobes (2) become perpendicular to shim faces (3) at valves "1" and "7" as shown in figure.
- 5) Check valve lashes with thickness gauge (4) according to the following procedure.
 - a) Check valve lashes at valves "1" and "7".
 - b) Turn camshafts by 90° (by turning crankshaft with wrench).
 - c) Make sure that cam lobes are perpendicular to shim faces at valves to be checked (in this case, "3" and "8"), if not, adjust it by turning crankshaft. Check valve lashes.
 - d) In the same manner as b) – c), check valve lashes at valves "4" and "6".
 - e) In the same manner as b) – c) again, check valve lashes at valves "2" and "5".

If valve lash is out of specification, record valve lash and adjust it to specification by replacing shim.


Valve clearance specification

	When cold (Coolant temperature is 15 – 25°C (59 – 77°F))	When hot (Coolant temperature is 60 – 68°C (140 – 154°F))
Intake	0.18 – 0.22 mm (0.007 – 0.009 in.)	0.21 – 0.27 mm (0.008 – 0.011 in.)
Exhaust	0.28 – 0.32 mm (0.011 – 0.013 in.)	0.30 – 0.36 mm (0.012 – 0.014 in.)

REPLACEMENT OF SHIM



- 1) Close the valve whose shim (2) is to be replaced by turning crankshaft, then turn tappet (3) till its cut section (1) faces inside as shown in figure.
- 2) Lift down the valve by turning crankshaft to 360°.
- 3) Hold tappet at that position using special tool as follows.
 - a) Remove its housing bolts.




- b) Check housing No. and select special tool corresponding to housing No., referring to “special tool selection table”.

Special tool selection table

No. on camshaft housing	Embossed mark on special tool
I2	IN2
I3, I4, I5	IN345
E2	EX2
E3, E4, E5	EX345

A: I : Intake side or E : Exhaust side
B: Position from timing chain side
C: Pointing to timing chain side



- c) Hold down the tappet so as not to contact the shim by installing special tool on camshaft housing with housing bolt (1) tighten housing bolts to specified torque.


Special tool

(A) : 09916-67020

Tightening torque

Camshaft housing bolts (for tightening of special tool)

(a) : 8 N·m (0.8 kg·m, 6.0 lb·ft)




- 4) Turn camshaft by approximately 90° clockwise and remove shim (3).

WARNING:

Never put in the hand between cam shaft and tappet.

1. Special tool
2. Magnet



- 5) Using a micrometer (2), measure the thickness of the removed shim (1), and determine replacement shim by calculating the thickness of new shim with the following formula and table.

Intake side:

A = B + C – 0.20 mm (0.008 in.)

Exhaust side:

A = B + C – 0.30 mm (0.012 in.)

A : Thickness of new shim

B : Thickness of removed shim


C : Measured valve clearance

For example of intake side :

When thickness of removed shim is 2.40 mm (0.094 in.), and measured valve clearance is 0.45 mm (0.018 in.).

$$A = 2.40 \text{ mm (0.094 in.)} + 0.45 \text{ mm (0.018 in.)} - 0.20 \text{ mm (0.008 in.)} = 2.65 \text{ mm (0.104 in.)}$$

Calculated thickness of new shim = 2.65 mm (0.104 in.)




- 6) Select new shim No. (1) with a thickness as close as possible to calculated value.

Available new shims No.

Thickness mm (in.)	Shim No.	Thickness mm (in.)	Shim No.
2.175 (0.0856)	218	2.675 (0.1053)	268
2.200 (0.0866)	220	2.700 (0.1063)	270
2.225 (0.0876)	223	2.725 (0.1073)	273
2.250 (0.0886)	225	2.750 (0.1083)	275
2.275 (0.0896)	228	2.775 (0.1093)	278
2.300 (0.0906)	230	2.800 (0.1102)	280
2.325 (0.0915)	233	2.825 (0.1112)	283
2.350 (0.0925)	235	2.850 (0.1122)	285
2.375 (0.0935)	238	2.875 (0.1132)	288
2.400 (0.0945)	240	2.900 (0.1142)	290
2.425 (0.0955)	243	2.925 (0.1152)	293
2.450 (0.0965)	245	2.950 (0.1161)	295
2.475 (0.0974)	248	2.975 (0.1171)	298
2.500 (0.0984)	250	3.000 (0.1181)	300
2.525 (0.0994)	253		
2.550 (0.1004)	255		
2.575 (0.1014)	258		
2.600 (0.1024)	260		
2.625 (0.1033)	263		
2.650 (0.1043)	265		

- 7) Install new shim facing shim No. side with tappet.




- 8) Lift valve by turning crankshaft counterclockwise (in opposite direction against above Step 4) and remove special tool.

Special tool

(A) : 09916-67020

1. Tappet
2. Camshaft



- 9) Install camshaft housing (1) and tighten bolts to specified torque.

Tightening torque


Camshaft housing bolts (a) : 11 N·m (1.1 kg-m, 8.0 lb-ft)

- 10) Check valve clearance again after adjusting it.
- 11) After checking and adjusting all valves.
- 12) Install cylinder head cover referring to "CYLINDER HEAD COVER".

On-Vehicle Service

Air Cleaner Element

REMOVAL




- 1) Disconnect air cleaner outlet No.1 hose (1) from air cleaner case (2).
- 2) Open air cleaner case by unhooking its clamps.
- 3) Remove air cleaner element from case.

INSTALLATION

Reverse removal procedure for installation.

INSPECTION AND CLEANING

- Check air cleaner element for dirt. Replace excessively dirty element.
- Blow off dust by compressed air from air outlet side of element.




Knock Sensor

Refer to "KNOCK SENSOR" in Section 6E1.


Cylinder Head Cover

REMOVAL


- 1) Disconnect negative cable at battery.
- 2) Remove cylinder head upper cover (1).




- 3) Disconnect ignition coil couplers (1).
- 4) Remove ignition coil assemblies (2) with high-tension cord (3).




- 5) Remove oil level gauge (1).
- 6) Disconnect PCV hose (2) from PCV valve (3) and disconnect breather hose (4) from cylinder head cover.
- 7) Remove power steering hose bracket from cylinder head cover, if equipped.
- 8) Remove cylinder head cover mounting bolts in such order as indicated in figure.




- 9) Remove cylinder head cover (1) with cylinder head cover gasket (2) and spark plug hole gasket (3).



INSTALLATION




- 1) Install new spark plug hole gaskets (1) and new cylinder head cover gasket (2) to cylinder head cover (3) as shown in figure.
- 2) Remove oil, old sealant, and dust from sealing surface on cylinder head and cover. After cleaning, apply sealant "A" to the following point.



- Cylinder head cover gasket (1) sealing surface area (2) as shown.

"A" : Sealant 99000-31150




- Timing chain cover (1) and cylinder head (2) matching surface as shown.

"A" : Sealant 99000-31150

- 3) Install cylinder head cover to cylinder head.

NOTE:

When installing cylinder head cover, use care so that cylinder head cover gasket or spark plug hole gaskets will not get out of place or fall off.



- 4) Tighten bolts in such order as indicated in figure a little at a time till they are tightened to specified torque.


Tightening torque

Cylinder head cover bolts (a) : 8 N·m (0.8 kg·m, 6.0 lb·ft)

- 5) Connect PCV hose (2) to PCV valve (1).
- 6) Connect breather hose (4).
- 7) Install oil level gauge (3).

- 8) Install power steering hose bracket to cylinder head cover, if removed.
- 9) Install ignition coil assemblies with high-tension cord.
- 10) Connect ignition coil couplers and clamp harness securely.
- 11) Install cylinder head upper cover.
- 12) Connect negative cable at battery.


Throttle Body and Intake Manifold




1. Intake manifold	7. EVAP canister purge valve	13. Intake manifold mounting bolt (short)	19. Cushion
2. Intake manifold gasket	8. TP sensor	14. Intake manifold mounting bolt (long)	20. Fuel delivery pipe mounting bolt
3. Throttle body	9. IAC valve	15. EGR pipe gasket	Tightening torque
4. Gasket	10. Fuel delivery pipe	16. O-Ring	Do not reuse.
5. EGR pipe	11. Intake manifold stiffener	17. Grommet	
6. MAP sensor	12. Intake manifold mounting nut	18. Injector assembly	

REMOVAL


- 1) Relieve fuel pressure according to fuel pressure relief procedure described in Section 6.
- 2) Disconnect negative cable at battery.
- 3) Drain coolant by loosening drain plug (1).

**WARNING:**


To help avoid danger of being burned, do not remove drain plug (1) and radiator cap while engine and radiator are still hot. Scalding fluid and steam can be blown out under pressure if plug and cap are taken off too soon.




- 4) Remove air cleaner outlet No.1 and No.2 hoses.




- 5) Disconnect the following electric lead wires :
 - IAC valve (1)
 - TP sensor (2)
 - EVAP canister purge valve (3)
 - MAP sensor (4)
 - Fuel injector wire harness at couplers (5)
 - Ground terminal from intake manifold
 - Each wire harness clamps
- 6) Disconnect accelerator cable from throttle body and remove its bracket from intake manifold.



- 7) Disconnect the following hoses :
 - Brake booster hose (1) from intake manifold
 - PCV hose (2) from PCV valve
 - Canister purge hose (3) from EVAP canister purge valve
 - Water hoses (4) from throttle body and thermostat case
 - Fuel pressure regulator vacuum hose from intake manifold
 - Fuel feed hose and return hose from each pipe
- 8) Remove fuel delivery pipe with fuel injectors from cylinder head.
- 9) Disconnect EGR pipe (5) from EGR valve.



10) Remove intake manifold stiffener (1).



11) Remove intake manifold (1) with throttle body (2) and EGR pipe (3) from cylinder head, and then its gasket.

INSTALLATION


Reverse removal procedure for installation noting the followings.

- Use new intake manifold gasket and EGR pipe gasket.
- Tighten bolts (1) and nuts (2) to specified torque.

Tightening torque


Intake manifold bolts and nuts



(a) : 25 N·m (2.5 kg-m, 18.0 lb-ft)



- Check to ensure that all removed parts are back in place. Reinstall any necessary parts which have not been reinstalled.
- Adjust accelerator cable play referring to Section 6E1.
- Refill cooling system referring to Section 6B.
- Upon completion of installation, turn ignition switch ON but engine OFF and check for fuel leaks.
- Finally, start engine and check for engine coolant leaks.


Exhaust Manifold




1. Exhaust manifold	6. Exhaust manifold stiffener	11. Exhaust manifold mounting bolt
2. Exhaust manifold gasket	7. Gasket	 Tightening torque
3. Heated oxygen sensor (if equipped)	8. Exhaust manifold mounting nut	 Do not reuse.
4. Exhaust manifold cover	9. Exhaust manifold stiffener bolt	
5. Engine hook	10. Exhaust pipe bolt	

WARNING:
To avoid danger of being burned, do not service exhaust system while it is still hot. Service should be performed after system cools down.


REMOVAL



- 1) Disconnect negative cable at battery.
- 2) connect heated oxygen sensor coupler (1) (if equipped) and detach it from its stay.
- 3) Remove exhaust manifold cover (2).




- 4) Remove exhaust manifold stiffener (1).
- 5) Disconnect exhaust No.1 pipe (2) from exhaust manifold.



- 6) Remove exhaust manifold (1) and its gasket from cylinder head.

INSTALLATION




- 1) Install new gasket to cylinder head.
Then install exhaust manifold.
Tighten manifold bolts and nuts to specified torque.

Tightening torque

Exhaust manifold bolts and nuts

(a) : 50 N·m (5.0 kg-m, 36.5 lb-ft)



- 2) Install seal ring and connect exhaust No.1 pipe (1) to exhaust manifold.
Before installing seal ring, check it for deterioration or damage, and replace as necessary.
Tighten pipe fasteners to specified torque.

Tightening torque


Exhaust No.1 pipe bolts (a) : 50 N·m (5.0 kg-m, 36.5 lb-ft)

- 3) Install exhaust manifold stiffener (2).
Tighten exhaust manifold stiffener bolts to specified torque.

Tightening torque

Exhaust manifold stiffener bolts


(b) : 50 N·m (5.0 kg-m, 36.5 lb-ft)



- 4) Install exhaust manifold cover (1) .
- 5) Connect heated oxygen sensor coupler (2) and fit coupler to bracket securely (if equipped).

- 6) Connect negative cable to battery.
- 7) Check exhaust system for exhaust gas leakage.


Oil Pan and Oil Pump Strainer




[A] : Sealant application amount	3. O-ring	8. Oil pan nut
"a" : 3 mm (0.12 in.)	4. Gasket	9. Oil pan bolt
"b" : 2 mm (0.08 in.)	5. Drain plug	Tightening torque
1. Oil pan : Apply sealant 99000-31150 to mating surface.	6. Strainer bolt	Do not reuse.
2. Strainer	7. Bracket bolt	


REMOVAL

- 1) Remove oil level gauge.
- 2) Remove exhaust No.1 pipe (1), exhaust manifold stiffener (2) and transaxle stiffener (3).




- 3) Drain engine oil by removing drain plug.
- 4) For 4WD vehicle remove clutch housing (torque converter housing for A/T vehicle) lower plate (1).
- 5) For 2WD vehicle, remove transaxle stiffener.
- 6) For 4WD vehicle, remove transfer referring to Section 7D.






- 7) Remove oil pan and then oil pump strainer (1) from cylinder block.

CLEAN




- Clean oil pump strainer screen (1).



- Clean sealing surface on oil pan and cylinder block. Remove oil, old sealant and dust from sealing surface.

INSTALLATION




- 1) Apply sealant continuously to oil pan mating surface as shown in figure.

"A" : sealant 99000-31150

Sealant amount for oil pan

Width "a" : 3 mm (0.12 in.)

Height "b" : 2 mm (0.08 in.)



- 2) Install new O-rings (2) in the position as shown in figure and install oil pump strainer (1).


Tighten strainer bolt (3) first and then bracket bolt (4) to specified torque.

Tightening torque

Oil pump strainer bolt (a) : 11 N·m (1.1 kg-m, 8.0 lb-ft)

Oil pump strainer bracket bolt

(b) : 11 N·m (1.1 kg-m, 8.0 lb-ft)



- 3) After fitting oil pan to cylinder block, run in securing bolts and start tightening at the center :
move wrench outward, tightening one bolt at a time. Tighten bolts and nuts to specified torque.


Tightening torque

Oil pan bolts and nuts (a) : 11 N·m (1.1 kg-m, 8.0 lb-ft)


- 4) Install new gasket and drain plug to oil pan.
Tighten drain plug to specified torque.

Tightening torque

Oil pan drain plug bolt (b) : 50 N·m (5.0 kg-m, 36.5 lb-ft)



- 5) For 4WD vehicle, install clutch housing (torque converter housing for A/T vehicle) lower plate (1).
6) For 2WD vehicle, install transaxle stiffener.
7) For 4WD vehicle, install transfer referring to Section 7D.



- 8) Install transaxle stiffener (3), exhaust manifold stiffener (2) and exhaust No.1 pipe (1).
Tighten bolts to specified torque.

Tightening torque

Exhaust No.1 pipe bolts (a) : 50 N·m (5.0 kg-m, 36.5 lb-ft)

Exhaust manifold stiffener bolts (b) :


50 N·m (5.0 kg-m, 36.5 lb-ft)


Transaxle stiffener bolts (c) :

50 N·m (5.0 kg-m, 36.5 lb-ft)

- 9) Install oil level gauge.
10) Refill engine with engine oil referring to "ENGINE OIL AND OIL FILTER" in Section 0B.
11) Verify that there is no engine oil leakage and exhaust gas leakage at each connection.

Engine Mountings




[A] : 4WD MODEL	3. Engine left mounting	8. Mounting member
[B] : AT MODEL	4. Engine left mounting bracket No.1	9. Suspension frame
[C] : MT MODEL	5. Engine left mounting bracket No.2	 Tightening torque
1. Engine right mounting	6. Engine rear mounting	
2. Engine right mounting bracket	7. Engine front torque bush	

Unit Repair Overhaul


Engine Assembly

REMOVAL

- 1) Relieve fuel pressure according to procedure described in Section 6.
- 2) Disconnect negative and positive cables at battery.
- 3) Remove engine hood after disconnecting windshield washer hose.
- 4) Remove right and left side engine under covers.
- 5) Remove A/C compressor and/or P/S belt (if equipped).
- 6) Remove water pump belt.
- 7) Drain engine oil, transaxle oil or A/T fluid (for A/T vehicle) and transfer oil (for 4WD vehicle).
- 8) Drain coolant.

**WARNING:**

To help avoid danger of being burned, do not remove drain plug (1) and radiator cap while engine and radiator are still hot. Scalding fluid and steam can be blown out under pressure if plug and cap are taken off too soon.




- 9) Remove air cleaner case and hoses.

- 10) With hose connected, detach A/C compressor and/or P/S pump from its bracket (if equipped).

NOTE:

Suspend removed A/C compressor and/or P/S pump at a place where no damage will be caused during removal and installation of engine assembly.




11) Disconnect the following electric lead wires:

- TP sensor (1)
- MAP sensor (2)
- ECT sensor
- CMP sensor
- CKP sensor
- Knock sensor
- Heated oxygen sensor
- EGR valve (3)
- IAC valve (4)
- EVAP canister purge valve (5)
- Injectors (6)
- Ignition coil assembly (7)
- Engine oil pressure switch
- Generator (8)
- Starting motor
- Magnet clutch switch of A/C compressor (if equipped)
- Ground terminal (9) from intake manifold and cylinder block
- VSS
- Back up light switch (For M/T vehicle)
- Shift switch (10) (For A/T vehicle)
- A/T VSS (11) (For A/T vehicle)
- NC1 sensor (12)
- A/T shift solenoid (13) (For A/T vehicle)
- Speedometer sensor
- Battery ground cable (14) from transaxle
- Each wire harness clamps

12) Remove fuse box from its bracket.


13) Disconnect the following cables :

- Accelerator cable
- Gear select control cable (For M/T vehicle)
- Gear shift control cable (For M/T vehicle)
- Gear select cable (15) (For A/T vehicle)




14) Disconnect the following hoses :


- Brake booster hose (1) from intake manifold
- Canister purge hose (2) from EVAP canister purge valve
- Fuel feed and return hoses from each pipe
- Heater inlet and outlet hoses from each pipe
- Radiator inlet and outlet hoses from each pipe
- A/T fluid hoses from each pipe




- 15) Remove suspension frame (1) with stabilizer bar and suspension control arms.
Refer to Section 3.



- 16) Remove exhaust No.1 and No.2 pipes.
- 17) Disconnect right and left drive shaft joints from differential gear referring to Section 4A.
For engine and transaxle removal, it is not necessary to remove drive shafts from steering knuckle.
- 18) For 4WD vehicle, remove propeller shaft referring to Section 4B.
- 19) Remove generator referring to Section 6H.
- 20) Remove clutch operation cylinder from transaxle. (For M/T vehicle)



- 21) Install lifting device.
- 22) Remove engine left mounting bolts (1) and engine right mounting bracket nuts (2).



- 23) Before removing engine with transaxle from body, recheck to make sure all hoses, electric wires and cables are disconnected from engine and transaxle.
- 24) Lower engine with transaxle from body.


NOTE:

Before lowering engine, to avoid damage to P/S pump and/or A/C compressor, raise it through clearance made on engine crankshaft pulley side. At this time, use care so that no excessive force is applied to hoses.

- 25) Disconnect transaxle from engine, referring to Section 7A1 or 7B1.
- 26) Remove clutch cover and clutch disk, referring to Section 7C1 (M/T).

INSTALLATION

- 1) Install clutch cover and clutch disk referring to Section 7C1.
- 2) Connect transaxle to engine referring to Section 7A1 or 7B1.
- 3) Lift engine with transaxle into engine compartment, but do not remove lifting device.



- 4) Install engine left mounting bolts (1) and engine right mounting bracket nuts (2).

Tighten these bolts and nuts to specified torque.

Tightening torque

Engine left mounting bolts


(a) : 55 N·m (5.5 kg-m, 40.0 lb-ft)

Engine right mounting bracket nuts

(b) : 75 N·m (7.5 kg-m, 54.5 lb-ft)

- 5) Remove lifting device.


- 6) Install clutch operating cylinder to transaxle.
- 7) Install generator referring to Section 6H.
- 8) For 4WD vehicle, install propeller shaft referring to Section 4B.
- 9) Connect drive shaft joints referring to Section 4A.



- 10) Install exhaust No.1 and No.2 pipes and tighten pipe fasteners to specified torque.

Tightening torque


Exhaust pipe bolts (a) : 50 N·m (5.0 kg-m, 36.5 lb-ft)



- 11) Install suspension frame (1) with stabilizer bar and suspension control arms.
Refer to Section 3.
- 12) Reverse disconnected hoses, cables and electric wires for connection.
- 13) Install air cleaner case and hoses referring to "AIR CLEANER OUTLET HOSE".
- 14) Install A/C compressor and/or P/S pump to its bracket (if equipped).
- 15) Adjust water pump belt tension referring to Section 0B.
- 16) Adjust A/C compressor and/or P/S belt tension (if equipped) referring to Section 0B.
- 17) Adjust accelerator cable play referring to Section 6E1.

- 18) Check to ensure that all removed parts are back in place. Reinstall any necessary parts which have not been reinstalled.
- 19) Refill cooling system with coolant, engine with engine oil and A/T with specified A/T fluid (vehicle with A/T).
- 20) Connect negative cable at battery.
- 21) Verify that there is no fuel leakage, coolant leakage, oil leakage, A/T fluid leakage (vehicle with A/T) and exhaust gas leakage at each connection.


Timing Chain Cover



[A] : Sealant application amount	3. Oil seal : Apply engine oil to oil seal lip.	8. Oil pan mounting bolt
"a" : 3 mm (0.12 in.)	4. Timing chain cover : Apply sealant 99000-31140 to the mating surface of cylinder and cylinder head. : Apply sealant 99000-31150 to the mating surface of timing chain cover referring to the figure of Step 1) in INSTALLATION.	9. Oil pan mounting nut
"b" : 2 mm (0.08 in.)	5. Pin	10. Cylinder head cover : Apply sealant 99000-31150 to the sealing point for timing chain cover mating surface and cylinder head gasket sealing point. Refer to "CYLINDER HEAD COVER INSTALLATION".
1. Crankshaft pulley bolt	6. Cylinder head cover gasket	Tightening torque
2. Crankshaft pulley	7. Timing chain cover mounting bolts	Do not reuse.

REMOVAL

1) Remove engine assembly from vehicle referring to "REMOVAL" of "ENGINE ASSEMBLY" in this section.




2) Remove crankshaft pulley bolt (2).

To lock crankshaft pulley (1), use special tool with it as shown in figure.

Special tool

(A) : 09917-68221



3) Remove crankshaft pulley (1).

If it is hard to remove, use special tools as shown in figure.

Special tool


(A) : 09944-36011

(B) : 09926-58010

4) Remove cylinder head cover and oil pan.

5) Remove P/S pump bracket (if equipped).

6) Remove water pump pulley.



7) Remove timing chain cover (1).

CLEAN

- Clean sealing surface on timing chain cover, cylinder block and cylinder head.


Remove oil, old sealant and dust from sealing surface.

INSPECTION

- Check oil seal (1) lip for fault or other damage.
Replace as necessary.

NOTE:

When installing new oil seal, press fit to timing chain cover (2) by using special tool (Bearing installer) as shown in the figure.




Special tool


(A) : 09913-75810

Drive in dimension**“a” : 1.5 mm (0.06 in.)****INSTALLATION**

Reverse removal procedure to install timing chain cover, noting the following points.



- 1) Apply sealant “A” to mating surface of cylinder and cylinder head and “B” to mating surface of timing chain cover as shown in figure.

“A” : Sealant 99000-31140**“B” : Sealant 99000-31150****Sealant amount for timing chain cover****Width “a” : 3 mm (0.12 in.)****Height “b” : 2 mm (0.08 in.)**

- 2) Apply engine oil to oil seal lip, then install timing chain cover (1).


Tighten bolts and nut to specified torque.

NOTE:

Before installing timing chain cover, check that pin is securely fitted.


Tightening torque**Timing chain cover bolts (a) : 23 N·m (2.3 kg-m, 17.0 lb-ft)**

- 3) Install water pump pulley.
- 4) Install P/S pump bracket (if equipped).
- 5) Install cylinder gear cover.
- 6) Install oil pan.
- 7) Install crankshaft pulley (1). Tighten bolt (2) to specified torque. To lock crankshaft pulley, use special tool with it as shown in the figure.

Special tool**(A) : 09917-68221****Tightening torque****Crankshaft pulley bolt (a) : 150 N·m (15.0 kg-m, 108.5 lb-ft)**

- 8) Install engine assembly to vehicle referring to “INSTALLATION” of “ENGINE ASSEMBLY” in this section.

Oil Pump




[A]: Sealant application amount	1207B 1207C	4. Timing chain cover : Apply sealant 99000-31140 to the mating surface of cylinder and cylinder head. : Apply sealant 99000-31150 to mating surface of timing chain cover referring to the figure of Step 1) in "TIMING CHAIN COVER INSTALLATION".	10. Circlip
"a": 3 mm (0.12 in.)		5. Pin	11. Oil pump mounting bolt
"b": 2 mm (0.08 in.)		6. Oil seal	12. Timing chain cover mounting bolts
1. Rotor plate		7. Relief valve	Tightening torque
2. Outer rotor		8. Spring	Do not reuse.
3. Inner rotor		9. Retainer	Apply thin coat of engine oil to sliding surface of each parts.


REMOVAL

Remove timing chain cover referring to "TIMING CHAIN COVER".


DISASSEMBLY

- 1) Remove rotor plate (1) by removing its mounting bolts.







2) Remove outer rotor (1) and inner rotor (2).



3) Remove relief valve (1), spring (2) and retainer (3) by removing circlip (4).

INSPECTION

- Check oil seal lip for fault or other damage. Replace as necessary.



NOTE:


When installing new oil seal (1), press-fit it to oil pump case (2) by using special tool as shown in the figure.

Special tool


(A) : 09913-75810

Drive in dimension

“a” : 1.5 mm (0.06 in.)




- Check outer (1) and inner rotors (2), rotor plate, and oil pump case for excessive wear or damage.



- Check relief valve (1) for excessive wear or damage and operates smoothly.

MEASUREMENT

Radial clearance




Check radial clearance between outer rotor (1) and case (2), using thickness gauge (3).

If clearance exceeds its limit, replace outer rotor or case.

Limit on radial clearance between outer rotor and case for oil pump
: 0.310 mm (0.0122 in.)

Side clearance





Using straight edge (1) and thickness gauge (2), measure side clearance.


Limit on side clearance for oil pump inner rotor
: 0.15 mm (0.0059 in.)

ASSEMBLY

- 1) Wash, clean and then dry all disassembled parts.
- 2) Apply thin coat of engine oil to inner and outer rotors, oil seal lip portion, and inside surfaces of oil pump case and plate.
- 3) Install outer (1) and inner rotors (2) to oil pump case.



- 4) Install relief valve component (1) to rotor plate (2).



- 5) Install rotor plate and tighten all bolts to specified torque.
After installing plate, check to be sure that rotors turn smoothly by hand (0.3 N·m (0.03 kg-m, 0.25 lb-ft) torque or below).


Tightening torque

Oil pump rotor plate bolts (a) : 11 N·m (1.1 kg-m, 8.0 lb-ft)

INSTALLATION

For installation referring to "TIMING CHAIN COVER".


Timing Chain and Chain Tensioner



1. Crankshaft timing sprocket	4. Timing chain tensioner : Apply engine oil to sliding surface.	7. Chain tensioner mounting bolt
2. Timing chain : Apply engine oil.	5. Timing chain tensioner adjuster assembly	8. Chain guide mounting bolt
3. Timing chain No.1 guide : Apply engine oil to sliding surface.	6. Chain tensioner adjuster mounting bolt	Tightening torque

REMOVAL


- 1) Remove timing chain cover referring to "TIMING CHAIN COVER".
- 2) Align both intake and exhaust camshaft timing sprocket marks (1) with notches (2) of cylinder head respectively by turning crankshaft.
- 3) Remove timing chain tensioner adjuster assembly (3).
- 4) Remove timing chain tensioner (4).
- 5) Remove timing chain No.1 guide (5).
- 6) Remove timing chain (6) with crankshaft timing sprocket (7).



CAUTION:


After timing chain is removed, never turn crankshaft and camshafts independently more than its allowable turning range described in "INSTALLATION" section.
If turned, interference may occur between piston and valves and valves themselves, and parts related to piston and valves may be damaged.

INSPECTION




Timing chain tensioner

- Check shoe (1) for wear or damage.




Crankshaft timing sprocket

- Check teeth of sprocket for wear or damage.




Timing chain

- Check timing chain for wear or damage.



Timing chain tensioner adjuster


- Check that tooth surface (1) are free from damage.



Timing chain No.1 guide

- Check shoe (1) for wear or damage.

INSTALLATION


**CAUTION:**

After timing chain is removed, never turn crankshaft and camshafts independently more than such an extent ("a", "b") as shown in figure.


If turned, interference may occur between piston and valves and valves themselves, and parts related to piston and valves may be damaged.

- 1) Check that match marks (1) on intake and exhaust camshaft timing sprockets are in match with notches (2) on cylinder head as shown in figure.
- 2) Set key (3) and turn crankshaft to position key on upside of crankshaft.

"a" : 90°	4. Camshaft (IN and EX) allowable turning range. By marks on camshaft timing sprocket within 15° from notches on cylinder head on both right and left.
"b" : 15°	5. Crankshaft allowable turning range. By key on crankshaft, within 90° from top on both right and left.




- 3) Install timing chain by aligning dark blue plate (1) of timing chain and triangle mark (2) on camshaft timing sprocket as shown in figure.
- 4) Fit crankshaft timing sprocket to timing chain by aligning gold plate (3) of timing chain and mark (4) on crankshaft timing sprocket. Then install crankshaft timing sprocket fitted with chain to crankshaft.



- 5) Apply engine oil to sliding surface of timing chain No.1 guide (1) and install it as shown in figure.
Tighten guide bolts to specified torque.

Tightening torque**Timing chain No.1 guide bolts**

(a) : 9 N·m (0.9 kg-m, 6.5 lb-ft)




- 6) Apply engine oil to sliding surface of chain tensioner (1) and install chain tensioner and spacer.
Tighten tensioner bolt to specified torque


Tightening torque

Timing chain tensioner bolt


(a) : 22 N·m (2.2 kg-m, 16.0 lb-ft)



- 7) Check that match marks (1) on intake and exhaust camshaft timing sprockets are in match with making timing chain (2) and match mark on crankshaft timing sprocket (3) are in with marking timing chain(4).



- 8) Screw in plunger (1) by turning body (2) in arrow direction and install a retainer (3) (wire) to hold plunger in place.




- 9) Install timing chain tensioner adjuster assembly (1) with a retainer (2).

Tighten adjuster bolts to specified torque and then remove a retainer from chain tensioner adjuster assembly.

Tightening torque

Timing chain tensioner adjuster bolts


(a) : 11 N·m (1.1 kg-m, 8.0 lb-ft)



- 10) Apply engine oil to timing chain and then turn crankshaft clockwise by 2 revolutions and check that match marks (1) on intake and exhaust camshaft timing sprockets are in match with notches (2) on cylinder head and key (3) is on upside of crankshaft as shown in figure.
If each marking chain and each match mark are no matches, adjust each sprockets and timing chain.

- 11) Install timing chain cover referring to "TIMING CHAIN COVER".
12) Perform Steps 3) to 8) of "INSTALLATION" of "TIMING CHAIN COVER" in this section.



Camshaft, Tappet and Shim



1. Intake camshaft	4. Tappet	Tightening torque
2. Exhaust camshaft	5. Camshaft housing	Apply engine oil to sliding surface of each part.
3. Shim : Shim No. on it faces tappet side.	6. Camshaft housing bolt	

REMOVAL

- 1) Remove timing chain cover referring to “TIMING CHAIN COVER”.
- 2) Remove timing chain referring to “TIMING CHAIN AND CHAIN TENSIONER”.
- 3) Loosen camshaft housing bolts in such order as indicated in figure and remove them.
- 4) Remove camshaft housings.
- 5) Remove intake and exhaust camshafts.



- 6) Remove tappets (2) with shims (1).


INSPECTION

Cam wear

Using a micrometer, measure cam height “a”. If measured height is below its limit, replace camshaft.

Cam height “a” of camshaft

	Standard	Limit
Intake cam	44.919 – 45.079 mm (1.768 – 1.775 in.)	44.80 mm (1.764 in.)
Exhaust cam	44.399 – 44.559 mm (1.748 – 1.754 in.)	44.28 mm (1.743 in.)





Camshaft runout

Set camshaft between two “V” blocks, and measure its runout by using a dial gauge.

If measured runout exceeds below limit, replace camshaft.

Camshaft runout limit
 : 0.10 mm (0.0039 in.)






Camshaft journal wear

Check camshaft journals and camshaft housings for pitting, scratches, wear or damage.

If any malfunction is found, replace camshaft or cylinder head with housing. Never replace cylinder head without replacing housings.

Check clearance by using gaging plastic. Checking procedure is as follows.

- 1) Clean housings and camshaft journals.
- 2) Remove all tappets with shims.
- 3) Install camshafts to cylinder head.
- 4) Place a piece of gaging plastic to full width of journal of camshaft (parallel to camshaft).
- 5) Install camshaft housing.




- 6) Tighten camshaft housing bolts in such order as indicated in figure a little at a time till they are tightened to specified torque.

NOTE:

Do not rotate camshaft while gaging plastic is installed.

Tightening torque


Camshaft housing bolts (a) : 11 N·m (1.1 kg-m, 8.0 lb-ft)



- 7) Remove housing, and using scale (2) on gaging plastic (1) envelop, measure gaging plastic width at its widest point.

Camshaft journal clearance

Standard	Limit
0.045 – 0.087 mm (0.0018 – 0.0034 in.)	0.12 mm




If measured camshaft journal clearance exceeds limit, measure journal (housing) bore and outside diameter of camshaft journal. Replace camshaft or cylinder head assembly whichever the difference from specification is greater.

Camshaft journal diameter [A]

Item	Standard
No.1	26.934 – 26.955 mm (1.0604 – 1.0612 in.)
Other	22.934 – 22.955 mm (0.9029 – 0.9037 in.)


Camshaft journal bearing bore [B]

Item	Standard
No.1	27.000 – 27.021 mm (1.0630 – 1.0638 in.)
Other	23.000 – 23.021 mm (0.9055 – 0.9063 in.)



Wear of tappet and shim

Check tappet and shim for pitting, scratches or damage. If any malcondition is found, replace.



Measure cylinder head bore and tappet outside diameter to determine cylinder head-to-tappet clearance. If clearance exceeds limit, replace tappet or cylinder head.

Cylinder head to tappet clearance

Standard : 0.025 – 0.066 mm (0.0010 – 0.0026 in.)

Limit : 0.15 mm (0.0059 in.)


Tappet outside diameter [A]

Standard : 30.959 – 30.975 mm (1.2189 – 1.2195 in.)

Cylinder head tappet bore [B]

Standard : 31.000 – 31.025 mm (1.2205 – 1.2215 in.)


INSTALLATION



- 1) Install tappets and shims to cylinder head.
Apply engine oil around tappet and then install it to cylinder head.

NOTE:

When installing shim, make sure to direct shim No. side toward tappet.




- 2) Install camshafts (1).


NOTE:

Before installing camshafts, turn crankshaft until key position faces upward. Refer to "TIMING CHAIN AND CHAIN TENSIONER".

Apply engine oil to sliding surface of each camshaft and camshaft journal then install them as shown in figure.




- 3) Install camshaft housing pins (1) as shown in figure.



- 4) Check position of camshaft housings.
Embossed marks are provided on each camshaft housing, indicating position and direction for installation. Install housings as indicated by these marks.

A. I : Intake side or E : Exhaust side
B. Position from timing chain side
C. Pointing to timing chain side




- 5) After applying engine oil to housing bolts, tighten them temporarily first. Then tighten them by the following numerical order in figure. Tighten a little at a time and evenly among bolts and repeat tightening sequence two or three times before they are tightened to specified torque.





Tightening torque

Camshaft housing bolts (a) : 11 N·m (1.1 kg-m, 8.0 lb-ft)

- 6) Install timing chain with crankshaft sprocket referring to "TIMING CHAIN AND CHAIN TENSIONER".
- 7) Install timing chain cover referring to "TIMING CHAIN COVER".
- 8) Check valve lashes as previously outlined.
- 9) Perform Steps 3) to 8) of "INSTALLATION" of "TIMING CHAIN COVER" in this section.


Valves and Cylinder Head



[A]* 1) Tighten all bolts at 40 N-m (4.0 kg-m) 2) Turn all bolts at 60° 3) Then, Turn all bolt at 60° once again	6. Intake valve	12. Knock pin
1. Valve cotter	7. Exhaust valve	 Tightening torque
2. Valve spring retainer	8. Valve guide	 Do not reuse.
3. Valve spring	9. Cylinder head bolt	 Apply engine oil to sliding surface of each part.
4. Valve stem seal	10. Cylinder head	
5. Valve spring seat	 11. Cylinder head gasket : "TOP" mark provided on gasket comes to crankshaft pulley side, facing up.	

REMOVAL


- 1) Remove engine assembly from vehicle referring to "REMOVAL" of "ENGINE ASSEMBLY" in this section.
- 2) Remove intake manifold stiffener (1).



- 3) Remove oil pan.
- 4) Remove cylinder head cover.
- 5) Remove timing chain cover referring to Steps 2) to 7) of "REMOVAL" in "TIMING CHAIN COVER".
- 6) Remove timing chain referring to Steps 2) to 6) of "REMOVAL" in "TIMING CHAIN AND CHAIN TENSIONER".
- 7) Remove intake and exhaust camshafts referring to Steps 3) to 7) of "REMOVAL" in "CAMSHAFT, TAPPET AND SHIM".
- 8) Loosen cylinder head bolts in such order as indicated in figure by using a 12 corner socket wrenches and remove them.

NOTE:

Don't forget to remove bolt (M8) (1) as shown in figure.





- 9) Check all around cylinder head for any other parts required to be removed or disconnected and remove or disconnect whatever necessary.
- 10) Remove exhaust manifold, if necessary, referring to "EXHAUST MANIFOLD".
- 11) Remove cylinder head with intake manifold and exhaust manifold. Use lifting device, if necessary.

DISASSEMBLY

- 1) For ease in servicing cylinder head, remove intake manifold, injectors and exhaust manifold from cylinder head.
- 2) Using special tools (Valve lifter), compress valve spring and then remove valve cotters (1) by using special tool (Forceps).

Special tool**(A) : 09916-14510****(B) : 09916-14910****(C) : 09916-84511**


- 3) Release special tool, and remove spring retainer and valve spring.
- 4) Remove valve from combustion chamber side.



- 5) Remove valve stem seal (1) from valve guide, and then valve spring seat (2).

NOTE:

Do not reuse seal once disassembled. Be sure to use new oil seal when assembling.



- 6) Using special tool (valve guide remover), drive valve guide out from combustion chamber side to valve spring side.


Special tool**(A) : 09916-44910****NOTE:**

Do not reuse valve guide once disassembled. Be sure to use new valve guide (Oversize) when assembling.

- 7) Place disassembled parts except valve stem seal and valve guide in order so that they can be installed in their original position.

INSPECTION

Valve guides



Using a micrometer and bore gauge, take diameter readings on valve stems and guides to check stem-to-guide clearance. Be sure to take reading at more than one place along the length of each stem and guide.

If clearance exceeds limit, replace valve and valve guide.

Valve stem-to-guide clearance

Item	Standard	Limit
In	0.005 – 0.045 mm (0.0002 – 0.0017 in.)	0.07 mm (0.0028 in.)
Ex	0.03 – 0.07 mm (0.0012 – 0.0027 in.)	0.09 mm (0.0035 in.)


Valve stem diameter [A] standard

In : 5.465 – 5.480 mm (0.2150 – 0.2157 in.)

Ex : 5.440 – 5.455 mm (0.2142 – 0.2148 in.)

Valve guide bore [B] standard

In and Ex : 5.485 – 5.51 mm (0.2160 – 0.2170 in.)



If bore gauge is not available, check end deflection of valve stem with a dial gauge instead.

Move stem end in directions (1) and (2) to measure end deflection.

If deflection exceeds its limit, replace valve stem and valve guide.

Valve stem end deflection limit

In : 0.14 mm (0.005 in.)

Ex : 0.18 mm (0.007 in.)


Valves


- Remove all carbon from valves.
- Inspect each valve for wear, burn or distortion at its face and stem end, as necessary, replace it.
- Measure thickness “a” of valve head. If measured thickness exceeds limit, replace valve.

Valve head thickness (In and Ex)


Standard : 1.25 – 1.55 mm (0.049 – 0.061 in.)

Limit : 0.9 mm (0.035 in.)






- Inspect valve stem end face for pitting and wear. If pitting or wear is found there, valve stem end may be resurfaced, but not too much to grind off its chamber. When it is worn out too much that its chamber is gone, replace valve.




- Check each valve for radial runout with a dial gauge and "V" block. To check runout, rotate valve slowly. If runout exceeds its limit, replace valve.

Limit on valve head radial runout
0.08 mm (0.003 in.)



- Seating contact width:
 Create contact pattern on each valve in the usual manner, i.e. by giving uniform coat of marking compound to valve seat and by rotatingly tapping seat with valve head. Valve lapper (tool used in valve lapping) must be used.
 Pattern produced on seating face of valve must be a continuous ring without any break, and the width of pattern must be within specified range.


Standard seating width "a" revealed by contact pattern on valve face
In and Ex : 1.1 - 1.3 mm (0.0433 - 0.0512 in.)



- Valve seat repair:
 A valve seat not producing a uniform contact with its valve or showing width of seating contact that is out of specified range must be repaired by regrinding or by cutting and regrinding and finished by lapping.

- a) EXHAUST VALVE SEAT : Use valve seat cutters (1) to make two cuts as illustrated in figure. Two cutters must be used: the first for making 15° angle, and the second for making 45° angle. The second cut must be made to produce desired seat width.

Seat width for exhaust valve seat
"a" : 1.1 – 1.3 mm (0.0433 – 0.0512 in.)




- b) **INTAKE VALVE SEAT** : Use valve seat cutters (1) to make three cuts as illustrated in figure. Three cutters must be used: the 1st for making 15° angle, the 2nd for making 60° angle, and 3rd for making 45° angle. The 3rd cut (45°) must be made to produce desired seat width.

Seat width for intake valve seat

"b" : 1.1 – 1.3 mm (0.0433 – 0.0512 in.)

- c) **VALVE LAPPING** : Lap valve on seat in two steps, first with coarse size lapping compound applied to face and the second with fine-size compound, each time using valve lapper according to usual lapping method.




Cylinder head

- Remove all carbon deposits from combustion chambers.


NOTE:

Do not use any sharp-edged tool to scrape off carbon deposits. Be careful not to scuff or nick metal surfaces when decarbonizing. The same applies to valves and valve seats, too.



- Check cylinder head for cracks on intake and exhaust ports, combustion chambers, and head surface.
Using a straightedge and thickness gauge, check flatness of gasketed surface at a total of 6 locations. If distortion limit, given below, is exceeded, correct gasketed surface with a surface plate and abrasive paper of about #400 (Waterproof silicon carbide abrasive paper): place abrasive paper on and over surface plate, and rub gasketed surface against paper to grind off high spots. Should this fail to reduce thickness gauge readings to within limit, replace cylinder head.
Leakage of combustion gases from this gasketed joint is often due to warped gasketed surface: such leakage results in reduced power output.

Limit of distortion for cylinder head surface on piston side : 0.03 mm (0.001 in.)




- Distortion of manifold seating faces:

Check seating faces of cylinder head for manifolds, using a straightedge and thickness gauge, in order to determine whether these faces should be corrected or cylinder head replaced.

Limit of distortion for cylinder head surface on intake and exhaust manifold

0.05 mm (0.002 in.)



Valve springs

- Referring to data given below, check to be sure that each spring is in sound condition, free of any evidence of breakage or weakening. Remember, weakened valve springs can cause chatter, not to mention possibility of reducing power output due to gas leakage caused by decreased seating pressure.

Valve spring free length


Standard : 36.83 mm (1.450 in.)

Limit : 35.83 mm (1.411 in.)

Valve spring preload

Standard : 107 – 125 N (10.7 – 12.5 kg) for 31.50 mm (23.6 – 27.6 lb/1.240 in.)

Limit : 102 N (10.2 kg) for 31.5 mm (22.5 lb/1.240 in.)




- Spring squareness:


Use a square and surface plate to check each spring for squareness in terms of clearance between end of valve spring and square. Valve springs found to exhibit a larger clearance than limit given below must be replaced.

Valve spring squareness limit

1.6 mm (0.079 in.)

ASSEMBLY

- 1) Before installing valve guide into cylinder head, ream guide hole with special tool (10.5 mm reamer) so as to remove burrs and make it truly round.

Special tool**(A) : 09916-34542****(B) : 09916-37320**


- 2) Install valve guide to cylinder head.

Heat cylinder head uniformly to a temperature of 80 to 100 °C (176 to 212 °F) so that head will not be distorted, and drive new valve guide into hole with special tools. Drive in new valve guide until special tool (Valve guide installer) contacts cylinder head.

After installing, make sure that valve guide protrudes by specified dimension "a" from cylinder head.

Special tool**(A) : 09916-56011****(B) : 09916-58210****NOTE:**


- **Never reuse once-disassembled valve guide.**
Make sure to install new valve guide.
- **Intake and exhaust valve guides are identical.**

Specification for valve guide protrusion "a"**Intake side : 11.3 mm (0.44 in.)****Exhaust side : 11.3 mm (0.44 in.)**

- 3) Ream valve guide bore with special tool (5.5 mm reamer).
After reaming, clean bore.

Special tool**(A) : 09916-34542****(B) : 09916-34550**

- 4) Install valve spring seat to cylinder head.



- 5) Install new valve stem seal (1) to valve guide.

After applying engine oil to seal and spindle of special tool (Valve guide installer handle), fit oil seal to spindle, and then install seal to valve guide by pushing special tool by hand.

After installing, check to be sure that seal is properly fixed to valve guide.


Special tool

(A) : 09917-98221

(B) : 09916-58210


NOTE:

- Do not reuse once-disassembled seal. Be sure to install new seal.
- When installing, never tap or hit special tool with a hammer or else. Install seal to guide only by pushing special tool by hand. Tapping or hitting special tool may cause damage to seal.



- 6) Install valve to valve guide.

Before installing valve to valve guide, apply engine oil to stem seal, valve guide bore and valve stem.




- 7) Install valve spring and spring retainer.

Each valve spring has top end (large-pitch end (1)) and bottom end (small-pitch end (2)). Be sure to position spring in place with its bottom end (small-pitch end) facing the bottom (valve spring seat side).

A : Valve spring retainer side

B : Valve spring seat side



- 8) Using special tools (Valve lifter), compress valve spring and fit two valve cotters (1) into groove in valve stem.

Special tool

(A) : 09916-14510

(B) : 09916-14910

(C) : 09916-84511



NOTE:

When compressing the valve spring, be carefully to free from damage in inside face of tappet installing hole.

- 9) Install intake manifold, injectors and exhaust manifold to cylinder head.

INSTALLATION


- 1) Clean mating surface of cylinder head and cylinder block.
Remove oil, old gasket and dust from mating surface.
- 2) Install knock pins (1) to cylinder block.
- 3) Install new cylinder head gasket (2) to cylinder block.
“TOP” mark provided on gasket comes to crankshaft pulley side, facing up (toward cylinder head side).



- 4) Make sure that oil jet (venturi plug) (1) is installed and if it is, that it is not clogged.
When installing it, be sure to tighten to specified torque.

Tightening torque

Venturi plug (a) : 5 N·m (0.5 kg-m, 3.5 lb-ft)




- 5) Install cylinder head to cylinder block.
Apply engine oil to new cylinder head bolts and tighten them gradually as follows.
 - a) Tighten cylinder head bolts (“1” – “10”) to 20 N·m (2.0 kg-m, 14.5 lb-ft) according to numerical order as shown by using a 12 corner socket wrenches.
 - b) In the same manner as in Step a), tighten them to 40 N·m (4.0 kg-m, 29.0 lb-ft).
 - c) Turn all bolts 60° according to numerical order in figure.
 - d) Repeat Step c).
 - e) Tighten bolt “A” to specified torque.

NOTE:

Use new cylinder head bolts. If they are reused, check thread diameters of cylinder head bolt for deformation according to the follows and replace them with new ones if thread diameter difference exceeds limit.

Measure each thread diameter of cylinder head bolt (1) at “A” on 83.5mm(2.81in.) from seat side of flange bolt and “B” on 115mm(4.53in.) from seat side of flange bolt by using a micrometer (2).

**Then calculate difference in diameters (“A” – “B”).
If it exceeds limit, replace with new one.**




Cylinder head bolt diameter measurement points**“a” : 83.5mm (2.81in.)****“b” : 115mm (4.53in.)****Cylinder head bolt diameter difference (deformation)****Limit (“A” – “B”) : 0.1mm (0.004in.)****NOTE:**






Be sure to tighten M8 bolt (“A”) after securing the other bolt.

Tightening torque**Cylinder head bolt for M8 (a) : 22 N·m (2.2 kg-m, 16.0 lb-ft)****Cylinder head bolts for M10****(b) : 40 N·m (4.0 kg-m, 29.0 lb-ft) and then turn to 60° twice**

- 6) Install exhaust manifold stiffener.
- 7) Install camshafts, timing chain and chain cover as previously outlined.
- 8) Install cylinder head cover and oil pan.
- 9) Install intake manifold stiffener and connect each hoses.
- 10) Perform Steps 3) to 8) of “INSTALLATION” of “TIMING CHAIN COVER” in this section.


Pistons, Piston Rings, Connecting Rods and Cylinders



[A] : 1) Tighten all nuts to 15 N·m (1.5 kg·m) 2) Turn all nuts to 45° 3) Then, Turn all nuts to 45° once again		7. Connecting rod bearing
1. Top ring		8. Piston pin
2. 2nd ring		9. Piston pin circlip
3. Oil ring		10. Bearing cap nut
4. Piston		 Tightening torque
 5. Connecting rod : Apply engine oil to sliding surface except inner surface of big end, and rod bolts. Make sure rod bolt diameter when reuse it due to plastic deformation tightening. Refer to "INSPECTION" of "CONNECTING ROD".		 Apply engine oil to sliding surface of each parts.
 6. Connecting rod bearing cap : Point arrow mark on cap to crankshaft pulley side.		 Do not reuse.

REMOVAL



- 1) Remove engine assembly from vehicle referring to "REMOVAL" of "ENGINE ASSEMBLY" in this section.
- 2) Remove cylinder head referring to "VALVES AND CYLINDER HEAD".
- 3) Mark cylinder number on all pistons, connecting rods and connecting rod caps using silver pencil or quick drying paint.
- 4) Remove rod bearing caps.



- 5) Install guide hose (1) over threads of rod bolts.
This prevents damage to bearing journal and rod bolt threads when removing connecting rod.
- 6) Decarbonize top of cylinder bore before removing piston from cylinder.
- 7) Push piston and connecting rod assembly out through the top of cylinder bore.

DISASSEMBLY

- 1) Using piston ring expander, remove two compression rings (Top and 2nd) and oil ring from piston.
- 2) Remove piston pin from connecting rod.
 - Ease out piston pin circlips (1), as shown.



- Force piston pin out.



CLEANING

Decarbonize piston head and ring grooves, using a suitable tool.

INSPECTION

Cylinder

- Inspect cylinder walls for scratches, roughness or ridges which indicate excessive wear. If cylinder bore is very rough or deeply scratched or ridged, rebore cylinder and use over-size piston.



- Using a cylinder gauge (1), measure cylinder bore in thrust and axial directions at two positions ("a" and "b") as shown in figure.

If any of the following conditions is noted, rebore cylinder.

- 1) Cylinder bore dia. exceeds limit.
- 2) Difference of measurements at two positions exceeds taper limit.
- 3) Difference between thrust and axial measurements exceeds out-of-round limit.

Cylinder bore diameter

Standard : 78.00 – 78.014 mm (3.0709 – 3.0714 in.)

Limit : 78.114 mm (3.073 in.)

Cylinder taper and out-of-round

Limit : 0.10 mm (0.004 in.)

"a" : 50 mm (1.96 in.)
"b" : 95 mm (3.74 in.)

NOTE:

If any one of four cylinders has to be rebored, rebore all four to the same next oversize. This is necessary for the sake of uniformity and balance.


Pistons


- Inspect piston for faults, cracks or other damaged. Damaged or faulty piston should be replaced.
- Piston diameter :
As indicated in figure, piston diameter should be measured at a position 19.5 mm (0.77 in.) from piston skirt end in the direction perpendicular to piston pin.

Piston diameter specification

Standard size	77.953 – 77.968 mm (3.0690 – 3.0696 in.)
	new one (with coating) 77.969 – 77.984 mm (3.0696 – 3.0702 in.)
Oversize 0.25 mm (0.0098 in.)	78.203 – 78.218 mm (3.0789 – 3.0794 in.)
Oversize 0.50 mm (0.0196 in.)	78.453 – 78.468 mm (3.0887 – 3.0893 in.)

"a" : 19.5 mm (0.77 in.)





- **Piston clearance:**

Measure cylinder bore diameter and piston diameter to find their difference which is piston clearance. Piston clearance should be within specification as given below. If it is out of specification, rebore cylinder and use oversize piston.

Piston clearance

Standard : 0.032 – 0.061 mm (0.0013 – 0.0024 in.)


Standard : 0.016 – 0.045 mm (0.0006 – 0.0018 in.) piston with coating (new one)

Limit : 0.161 mm (0.0065 in.)

NOTE:

Cylinder bore diameters used here are measured in thrust direction at two positions.

"a" : 19.5 mm (0.77 in.)



- **Ring groove clearance:**

Before checking, piston grooves must be clean, dry and free of carbon deposits.

Fit new piston ring (1) into piston groove, and measure clearance between ring and ring land by using thickness gauge (2). If clearance is out of limit, replace piston.

Ring groove clearance

Top ring

Standard : 0.03 – 0.07 mm (0.0012 – 0.0028 in.)

Limit : 0.12 mm (0.0047 in.)

2nd ring

Standard : 0.02 – 0.06 mm (0.0008 – 0.0024 in.)


Limit : 0.10 mm (0.0039 in.)

Oil ring

Standard : 0.03 – 0.17 mm (0.0012 – 0.0067 in.)

Piston pin

- Check piston pin, connecting rod small end bore and piston bore for wear or damage, paying particular attention to condition of small end bore bush. If pin, connecting rod small end bore or piston bore is badly worn or damaged, replace pin, connecting rod and/or piston.



- **Piston pin clearance :**

Check piston pin clearance in small end and piston. Replace connecting rod and/or piston if its small end is badly worn or damaged or if measured clearance exceeds limit.


Piston pin clearance in connecting rod small end
0.003 – 0.014 mm (0.0001 – 0.0006 in.)

Piston pin clearance in piston
0.006 – 0.017 mm (0.00024 – 0.00067 in.)

Small-end bore
20.003 – 20.011 mm (0.7875 – 0.7878 in.)

Piston pin dia.
19.997 – 20.000 mm (0.7873 – 0.7874 in.)

Piston bore
20.006 – 20.014 mm (0.7876 – 0.7880 in.)



Piston rings

To measure end gap, insert piston ring (1) into cylinder bore and then measure the gap by using thickness gauge (2).
If measured gap is out of specification, replace ring.


NOTE:

Decarbonize and clean top of cylinder bore before inserting piston ring.

Piston ring end gap

Item	Standard	Limit
Top ring	0.20 – 0.35 mm (0.0079 – 0.0138 in.)	0.7 mm (0.0276 in.)
2nd ring	0.30 – 0.45 mm (0.0118 – 0.0177 in.)	1.0 mm (0.0394 in.)
Oil ring	0.20 – 0.70 mm (0.0079 – 0.0276 in.)	1.5 mm (0.0591 in.)

"a" : 120 mm (4.72 in.)




Connecting rod

- **Big-end side clearance:**

Check big-end of connecting rod for side clearance, with rod fitted and connected to its crank pin in the normal manner. If measured clearance is found to exceed its limit, replace connecting rod.

Big-end side clearance
Standard : 0.25 - 0.40 mm (0.0098 - 0.0157 in.)
Limit : 0.55 mm (0.0217 in.)




- Connecting rod alignment :
Mount connecting rod on aligner to check it for bow and twist. If limit is exceeded, replace it.

Connecting rod alignment

Limit on bow : 0.05 mm (0.0020 in.)

Limit on twist : 0.10 mm (0.0039 in.)



- Connecting rod bolt deformation (Plastic deformation tightening bolt)
Measure each thread diameter of connecting rod (1) bolt (2) at "A" on 32 mm (1.25 in.) from bolt mounting surface and "B" on 40 mm (1.57 in.) from bolt mounting surface by using a micrometer (3).
Calculate difference in diameters ("A" – "B"). If it exceeds limit, replace connecting rod.

Connecting rod bolt measurement points

"a" : 32 mm (1.25 in.)

"b" : 40 mm (1.57 in.)

Connecting rod bolt diameter difference

limit ("A" – "B") : 0.1 mm (0.004 in.)

Crank pin and connecting rod bearings

- Inspect crank pin for uneven wear or damage. Measure crank pin for out-of-round or taper with a micrometer. If crank pin is damaged or out-of round or taper is out of limit, replace crankshaft or regrind crank pin to undersize and use under-size bearing.

Crank pin diameter


Connecting rod bearing size	Crank pin diameter
Standard	41.982 – 42.000 mm (1.6528 – 1.6535 in.)
Undersize 0.25 mm (0.0098 in.)	41.732 – 41.750 mm (1.6430 – 1.6437 in.)


Crank pin taper and out-of-round

Limit : 0.01 mm (0.0004 in.)

Out-of-round : A – B

Taper : a – b







- Rod bearing :

Inspect bearing shells for signs of fusion, pitting, burn or flaking and observe contact pattern. Bearing shells found in defective condition must be replaced.

Two kinds of rod bearing are available; standard size bearing and 0.25 mm (0.0098 in.) undersize bearing. For identification of undersize bearing, it is painted red at the position as indicated in figure, undersize bearing thickness is 1.605 – 1.615 mm (0.0632 – 0.0635 in.) at the center of it.

1. Red paint



- Rod bearing clearance :

- 1) Before checking bearing clearance, clean bearing and crank pin.
- 2) Install bearing in connecting rod and bearing cap.
- 3) Place a piece of gaging plastic (1) to full width of crank pin as contacted by bearing (parallel to crankshaft), avoiding oil hole.

- 4) Install rod bearing cap (1) to connecting rod.


When installing cap, be sure to point arrow mark (2) on cap to crankshaft pulley side, as shown in figure. After applying engine oil to rod bolts and tighten cap nuts (3) gradually as follows.

- a) Tighten all cap nuts to 15 N·m (1.5 kg-m, 11.0 lb-ft).
- b) Retighten them to 45°.
- c) Repeat step b) once again.

Tightening torque

Connecting rod bearing cap nuts

(a) : 15 N·m (1.5 kg-m, 11.0 lb-ft) and extra tighten 90°



- 5) Remove cap and using a scale (1) on gaging plastic (2) envelope, measure gaging plastic width at the widest point (clearance).

If clearance exceeds its limit, use a new standard size bearing and remeasure clearance.

Connecting rod bearing clearance

Standard : 0.029 – 0.047 mm (0.0011 – 0.0019 in.)

Limit : 0.065 mm (0.0026 in.)


- 6) If clearance can not be brought to within its limit even by using a new standard size bearing, regrind crankpin to undersize and use 0.25 mm undersize bearing.

NOTE:

After checking the rod bearing clearance, make sure that checking for Connecting rod bolt deformation.

Refer to “INSPECTION” of “CONNECTING ROD”.


ASSEMBLY




- 1) Install piston pin to piston (1) and connecting rod (2) :
 - a) After applying engine oil to piston pin and piston pin holes in piston and connecting rod.
 - b) Fit connecting rod as shown in figure.
 - c) Insert piston pin to piston and connecting rod.
 - d) Install piston pin circlips (3).

NOTE:

Circlip should be installed with its cut part facing as shown in figure. Install so that circlip end gap comes within such range as indicated by arrow.



- 2) Install piston rings to piston :
 - a) As indicated in figure, 1st and 2nd rings have “T” mark respectively. When installing these piston rings to piston, direct marked side of each ring toward top of piston.
 - b) 1st ring (1) differs from 2nd ring (2) in thickness, shape and color of surface contacting cylinder wall. Distinguish 1st ring from 2nd ring by referring to figure.
 - c) When installing oil ring (3) install spacer first and then two rails.



- 3) After installing three rings (1st, 2nd and oil rings), distribute their end gaps as shown in figure.


1. Arrow mark
2. 1st ring end gap
3. 2nd ring end gap and oil ring spacer gap
4. Oil ring upper rail gap
5. Oil ring lower rail gap

INSTALLATION


- 1) Apply engine oil to pistons, rings, cylinder walls, connecting rod bearings and crankpins.

NOTE:

Do not apply oil between connecting rod and bearing or between bearing cap and bearing.




- 2) Install guide hoses (1) over connecting rod bolts.
These guide hoses protect crank pin and threads of rod bolt from damage during installation of connecting rod and piston assembly.



- 3) When installing piston and connecting rod assembly into cylinder bore, point front mark (1) on piston head to crankshaft pulley side.


A :	Crankshaft pulley side
B :	Flywheel side



- 4) Install piston and connecting rod assembly into cylinder bore. Use special tool (Piston ring compressor) to compress rings. Guide connecting rod into place on crankshaft.
Using a hammer handle, tap piston head to install piston into bore. Hold ring compressor firmly against cylinder block until all piston rings have entered cylinder bore.

Special tool

(A) : 09916-77310



- 5) Install bearing cap (1):
Point arrow mark (2) on cap to crankshaft pulley side.
After applying oil to rod bolts and tighten cap nuts (3) gradually as follows.
 - a) Tighten all cap nuts to 15 N·m (1.5 kg-m, 11.0 lb-ft).
 - b) Retighten them to 45°.
 - c) Repeat Step b) once again.

Tightening torque

Connecting rod bearing cap nuts

(a) : 15 N·m (1.5 kg-m, 11.0 lb-ft) and then turn to 45° twice.


NOTE:







Before installing bearing cap, make sure that checking for connecting rod bolt deformation.

Refer to “INSPECTION” of “CONNECTING ROD”.

- 6) Reverse removal procedure for installation as previously outlined.
- 7) Perform Steps 3) to 8) of “INSTALLATION” of “TIMING CHAIN COVER” in this section.

Main Bearings, Crankshaft and Cylinder Block




[A] : Sealant application amount	4. Venturi plug	14. Main bearing cap
[B] : 1) Tighten all bolts to 50 N·m (5.0 kg·m) 2) Then, turn all bolts to 60°	5. Main bearing	 15. Flywheel mounting bolt : Apply sealant 99000-31110 to thread part.
 Tightening torque	6. Sensor plate	16. Rear oil seal housing mounting bolt
 Do not reuse.	7. Crankshaft timing sprocket key	17. Main bearing mounting No.2 bolt
 Apply engine oil to inside / sliding surface.	8. Crankshaft	18. Main bearing mounting No.1 bolt
"a" : 3 mm (0.12 in.)	9. Thrust bearing	19. O-ring
"b" : 2 mm (0.08 in.)	 10. Rear oil seal housing : Apply sealant 99000-31150 to mating surface.	20. Oil filter adapter case
 1. CKP sensor (if equipped) : When installing CKP sensor, use new sensor mounting bolt.	11. Rear oil seal	21. Oil filter adapter bolt
2. Knock sensor	12. Input shaft bearing	
3. Cylinder block	13. Flywheel	

REMOVAL

- 1) Remove engine assembly from vehicle as previously outlined.
- 2) Remove clutch cover, clutch disc and flywheel (drive plate for A/T) by using special tool.


Special tool


(A) : 09924-17810



- 3) Remove the following parts from engine as previously outlined.
 - Oil pan and oil pump strainer
 - Intake manifold and exhaust manifold
 - Cylinder head cover
 - Timing chain cover
 - Timing chain guide, chain tensioner adjuster, chain tensioner, timing chain and crankshaft timing sprocket
 - Camshaft, tappet and shim
 - Cylinder head assembly
 - Piston and connecting rod


- 4) Remove rear oil seal housing (1).





- 5) Loosen bearing cap No.1 and No.2 bolts in such order as indicated in figure and remove them.
- 6) Remove crankshaft from cylinder block.

INSPECTION



Measure each thread diameter bearing cap bolts (1) at "A" on 60mm(2.36in.) from seat side of flange bolt and "B" on 90mm(3.54in.) from seat side of flange bolt by using a micrometer (2).

Calculate difference in diameters ("A" – "B").

If it exceeds limit, replace with new one.

Bearing cap No.1 bolt diameter measurement points

"a" : 60mm (2.36in.)

"b" : 90mm (3.54in.)

Bearing cap No.1 bolt diameter difference

Limit ("A" – "B") : 0.2mm (0.008in.)


Crankshaft

Crankshaft runout

Using a dial gauge, measure runout at center journal. Rotate crankshaft slowly. If runout exceeds its limit, replace crankshaft.

Crankshaft runout

Limit : 0.04 mm (0.0016 in.)




Crankshaft thrust play


Measure this play with crankshaft set in cylinder block in the normal manner, that is with thrust bearing (1) and journal bearing caps installed.

Thickness of crankshaft thrust bearing

Standard : 2.500 mm (0.0984 in.)

Oversize (0.125 mm (0.0049 in.)) : 2.563 mm (0.1009 in.)





Tighten bearing cap No.1 bolts (1) – (10) and No.2 bolts (11) – (20) gradually as follows.

- 1) Tighten bolts (1) – (10) to 30 N·m (3.0 kg-m, 22.0 lb-ft) according to numerical order in figure.
- 2) In the same manner as in Step 1), tighten them to 50 N·m (5.0 kg-m, 36.5 lb-ft).
- 3) In the same manner as in step 1), retighten them to 60°.
- 4) Tighten bolts (11) – (20) to 22 N·m (2.2 kg-m, 16.0 lb-ft) according to numerical order in figure.


Tightening torque

Crank shaft bearing cap No.1 bolts (1) – (10) :

50 N·m (5.0 kg-m, 36.5 lb-ft) and extra tighten 60°

Crank shaft bearing cap No.2 bolts (11) – (20) :

22 N·m (2.2 kg-m, 16.0 lb-ft)



Use a dial gauge to read displacement in axial (thrust) direction of crankshaft.

If its limit is exceeded, replace thrust bearing with new standard one or oversize one to obtain standard thrust play.


Crankshaft thrust play

Standard : 0.11 – 0.31 mm (0.0043 – 0.0122 in.)

Limit : 0.35 mm (0.0138 in.)

NOTE:

After checking the thrust play, make sure that thread deformation of each bearing cap No.1 bolt according to previous mentioned “Bearing Cap No.1 Bolt” once again.



Out-of-round and taper (uneven wear) of journals

An unevenly worn crankshaft journal shows up as a difference in diameter at a cross section or along its length (or both). This difference, if any, is determined by taking micrometer readings. If any one of journals is badly damaged or if amount of uneven wear in the sense explained below exceeds its limit, regrind or replace crankshaft.

Crankshaft out-of-round and taper

Limit : 0.01 mm (0.0004 in.)


Out-of-round : A – B

Taper : a – b

Main bearings

General information

- Service main bearings are available in standard size and 0.25 mm (0.0098 in.) undersize, and each of them has 5 kinds of bearings differing in tolerance.



- Upper half of bearing (1) has an oil groove (2) as shown in figure.
Install this half with oil groove to cylinder block.
- Lower half of bearing does not have an oil groove.

Visual inspection



Check bearings for pitting, scratches, wear or damage.

If any malcondition is found, replace both upper and lower halves.
Never replace either half without replacing the other half.

Main bearing clearance

Check clearance by using gaging plastic according to the following procedure.

- 1) Remove bearing caps.
- 2) Clean bearings and main journals.
- 3) Place a piece of gaging plastic (1) the full width of bearing (parallel to crankshaft) on journal, avoiding oil hole.



- 4) Tighten bearing cap No.1 bolts (1) – (10) and No.2 bolts (11) – (20) gradually as follows.
 - a) Tighten bolts (1) – (10) to 30 N·m (3.0 kg-m, 22.0 lb-ft) according to numerical order in figure.
 - b) In the same manner as in Step a), tighten them to 50 N·m (5.0 kg-m, 36.5 lb-ft).
 - c) In the same manner as in step a), retighten them to 60°.
 - d) Tighten bolts (11) – (20) to 22 N·m (2.2 kg-m, 16.0 lb-ft) according to numerical order in figure.

Tightening torque

Crank shaft bearing No.1 bolts (1) – (10) :


50 N·m (5.0 kg-m, 36.5 lb-ft) and extra tighten 60°

Crank shaft bearing No.2 bolts (11) – (20) :

22 N·m (2.2 kg-m, 16.0 lb-ft)

NOTE:

Do not rotate crankshaft while gaging plastic is installed.



- 5) Remove bearing caps and using scale (1) on gaging plastic (2) envelop, measure gaging plastic width at its widest point. If clearance exceeds its limit, replace bearing. Always replace both upper and lower inserts as a unit.

A new standard bearing may produce proper clearance. If not, it will be necessary to regrind crankshaft journal for use of 0.25 mm undersize bearing.

After selecting new bearing, recheck clearance.

Main bearing clearance

Standard : 0.025 – 0.045 mm (0.0010 – 0.0018 in.)

Limit : 0.065 mm (0.0026 in.)


NOTE:

After checking the bearing clearance, make sure that thread deformation of each bearing cap No.1 bolt according to previous mentioned Step 4) once again.

Selection of main bearings

STANDARD BEARING :

If bearing is in malcondition, or bearing clearance is out of specification, select a new standard bearing according to the following procedure and install it.



- 1) First check journal diameter. As shown in figure, crank web No.2 has stamped numbers.


Three kinds of numbers (“1”, “2” and “3”) represent the following journal diameters.

Stamped numbers on crank web No.2 represent journal diameters marked with an arrow in figure respectively.

For example of M13 engine, stamped number “1” indicates that corresponding journal diameter is 44.994 – 45.000 mm (1.7714 – 1.7717 in.).

Crankshaft journal diameter

Engine model	Stamped numbers	Journal diameter
M13 engine	1	44.994 – 45.000 mm (1.7714 – 1.7717 in.)
	2	44.988 – 44.994 mm (1.7712 – 1.7714 in.)
	3	44.982 – 44.988 mm (1.7709 – 1.7712 in.)
M16 engine	1	51.994 – 52.000 mm (2.0470 – 2.0472 in.)
	2	51.988 – 51.994 mm (2.0468 – 2.0470 in.)
	3	51.982 – 51.988 mm (2.0465 – 2.0468 in.)



- 2) Next, check bearing cap bore diameter without bearing. On mating surface of cylinder block, five alphabets are stamped as shown in figure.


Three kinds of alphabets (“A”, “B” and “C”) represent the following cap bore diameters.

Stamped alphabets on cylinder block represent bearing cap bore diameter marked with an arrow in figure respectively.

For example of M13 engine, stamped “A” indicates that corresponding bearing cap bore diameter is 49.000 – 49.006 mm (1.9291 – 1.9294 in.).

Crankshaft bearing cap bore

Engine model	Stamped alphabet	Bearing cap bore diameter (without bearing)
M13 engine	A	49.000 – 49.006 mm (1.9291 – 1.9294 in.)
	B	49.006 – 49.012 mm (1.9294 – 1.9296 in.)
	C	49.012 – 49.018 mm (1.9296 – 1.9298 in.)
M16 engine	A	56.000 – 56.006 mm (2.2047 – 2.2050 in.)
	B	56.006 – 56.012 mm (2.2050 – 2.2052 in.)
	C	56.012 – 56.018 mm (2.2052 – 2.2054 in.)



- 3) There are five kinds of standard bearings differing in thickness. To distinguish them, they are painted in the following colors at the position as indicated in figure.

Each color indicated the following thickness at the center of bearing.

1. Paint

Standard size of crankshaft main bearing thickness [For M13 engine]

Color painted	Bearing thickness
Pink	1.990 – 1.994 mm (0.0783 – 0.0785 in.)
Purple	1.993 – 1.997 mm (0.0785 – 0.0786 in.)
Brown	1.996 – 2.000 mm (0.0786 – 0.0787 in.)
Green	1.999 – 2.003 mm (0.0787 – 0.0789 in.)
Black	2.002 – 2.006 mm (0.0788 – 0.0790 in.)

[For M16 engine]

Color painted	Bearing thickness
Purple	1.992 – 1.996 mm (0.0784 – 0.0786 in.)
Brown	1.995 – 1.999 mm (0.0785 – 0.0787 in.)
Green	1.998 – 2.002 mm (0.0787 – 0.0788 in.)
Black	2.001 – 2.005 mm (0.0788 – 0.0789 in.)
Colorless (no paint)	2.004 – 2.008 mm (0.0789 – 0.0791 in.)

- 4) From number stamped on crank web No.2 and alphabets stamped on cylinder block, determine new standard bearing to be installed to journal, by referring to table shown below.
For example of M13 engine, if number stamped on crank web No.2 is "1" and alphabet stamped on cylinder block is "B", install a new standard bearing painted in "Purple" to its journal.


Specification of new standard crankshaft main bearing size

[For M13 engine]


		Number stamped on crank web No.2 (Journal diameter)		
		1	2	3
Alphabet stamped on cylinder block (Cap bore dia.)	A	Pink	Purple	Brown
	B	Purple	Brown	Green
	C	Brown	Green	Black
		New standard bearing to be installed.		

[For M16 engine]

		Number stamped on crank web No.2 (Journal diameter)		
		1	2	3
Alphabet stamped on cylinder block (Cap bore dia.)	A	Purple	Brown	Green
	B	Brown	Green	Black
	C	Green	Black	Colorless
		New standard bearing to be installed.		



- 5) Using scale (1) on gaging plastic (2), check bearing clearance with newly selected standard bearing.
If clearance still exceeds its limit, use next thicker bearing and recheck clearance.
- 6) When replacing crankshaft or cylinder block due to any reason, select new standard bearings to be installed by referring to number stamped on new crankshaft or alphabets stamped on new cylinder block.

**UNDERSIZE BEARING (0.25 mm) :**

- 0.25 mm undersize bearing is available, in five kinds varying in thickness.

To distinguish them, each bearing is painted in the following colors at such position as indicated in figure.

Each color represents the following thickness at the center of bearing.

1. Paint

Undersize of crankshaft main bearing thickness
[For M13 engine]

Color painted	Bearing thickness
Red and Pink	2.115 - 2.119 mm (0.0833 - 0.0834 in.)
Red and Purple	2.118 - 2.122 mm (0.0834 - 0.0835 in.)
Red and Brown	2.121 - 2.125 mm (0.0835 - 0.0837 in.)
Red and Green	2.124 - 2.128 mm (0.0836 - 0.0838 in.)
Red and Black	2.127 - 2.131 mm (0.0837 - 0.0839 in.)

[For M16 engine]


Color painted	Bearing thickness
Red and Purple	2.117 - 2.121 mm (0.0833 - 0.0835 in.)
Red and Brown	2.120 - 2.124 mm (0.0835 - 0.0836 in.)
Red and Green	2.123 - 2.127 mm (0.0836 - 0.0837 in.)
Red and Black	2.126 - 2.130 mm (0.0837 - 0.0839 in.)
Red only	2.129 - 2.133 mm (0.0838 - 0.0840 in.)

- If necessary, regrind crankshaft journal and select undersize bearing to use with it as follows.
 - a) Regrind journal to the following finished diameter.

Finished diameter

For M13 engine : 44.732 – 44.750 mm (1.7611 – 1.7618 in.)

For M16 engine : 51.732 – 51.750 mm (2.0367 – 2.0374 in.)



- 1) Using micrometer, measure reground journal diameter. Measurement should be taken in two directions perpendicular to each other in order to check for out-of-round.
- 2) Using journal diameter measured above and alphabets stamped on cylinder block, select an undersize bearing by referring to table given below. Check bearing clearance with newly selected undersize bearing.


Specification of new standard undersize crankshaft main bearing
[For M13 engine]

		Measured journal diameter		
		44.732 – 44.738 mm (1.7611 – 1.7613 in.)	44.738 – 44.744 mm (1.7613 – 1.7616 in.)	44.744 – 44.750 mm (1.7616 – 1.7618 in.)
Alphabets stamped on cylinder block	A	Red and Brown	Red and Purple	Red and Pink
	B	Red and Green	Red and Brown	Red and Purple
	C	Red and Black	Red and Green	Red and Brown
		Undersize bearing to be installed		


[For M16 engine]

		Measured journal diameter		
		51.732 – 51.738 mm (2.0367 – 2.0369 in.)	51.738 – 51.744 mm (2.0369 – 2.0372 in.)	51.744 – 51.750 mm (2.0372 – 2.0374 in.)
Alphabets stamped on cylinder block	A	Red and Green	Red and Brown	Red and Purple
	B	Red and Black	Red and Green	Red and Brown
	C	Red only	Red and Black	Red and Green
		Undersize bearing to be installed		

Rear oil seal



Carefully inspect oil seal (1) for wear or damage.
 If its lip is worn or damaged, replace it.



For oil seal installation, press-fit rear oil seal (1) to oil seal housing (2) by using special tool as shown in the figure.

Special tool

(A) : 09911-97820

Crank rear oil seal installing position (dimension)


“a” : 3 mm (0.12 in.)

Flywheel

- If ring gear is damaged, cracked or worn, replace flywheel.
- If the surface contacting clutch disc is damaged, or excessively worn, replace flywheel.
- Check flywheel for face runout with a dial gauge.
If runout exceeds its limit, replace flywheel.


Flywheel on runout

Limit : 0.2 mm (0.0079 in.)



Sensor plate

- Check sensor plate for crack or damage. If malfunction is found, replace it.




Cylinder block

Distortion of gasketed surface

- Using straightedge and thickness gauge, check gasketed surface for distortion and, if flatness exceeds its limit, correct it.

Cylinder block flatness

Limit : 0.05 mm (0.0020 in.)




Honing or reboring cylinders

- 1) When any cylinder needs reboring, all other cylinders must also be rebored at the same time.
- 2) Select oversized piston according to amount of cylinder wear.

Oversize piston diameter

Size	Piston diameter
Oversize 0.25	78.203 - 78.218 mm (3.0789 - 3.0794 in.)
Oversize 0.50	78.453 - 78.468 mm (3.0887 - 3.0893 in.)



3) Using micrometer, measure piston diameter.

Measurement position for piston diameter

"a" : 19.5 mm (0.77 in.)

4) Calculate cylinder bore diameter to be rebored as follows.

$$D = A + B - C$$

D : Cylinder bore diameter to be rebored.

A : Piston diameter as measured.

B : Piston clearance = 0.02 – 0.04 mm (0.0008 – 0.0016 in.)

C : Allowance for honing = 0.02 mm (0.0008 in.)

5) Rebore and hone cylinder to calculated dimension.

NOTE:


Before reboring, install all main bearing caps in place and tighten to specification to avoid distortion of bearing bores.

6) Measure piston clearance after honing.

INSTALLATION

NOTE:

- Use new bearing cap No.1 bolts. If they are reused, check thread diameters of bearing cap No.1 bolt for deformation according to previous mentioned “Bearing Cap No.1 Bolt” check and replace them with new ones if thread diameter exceeds limit.
- All parts to be installed must be perfectly clean.
- Be sure to oil crankshaft journals, journal bearings, thrust bearings, crankpins, connecting rod bearings, pistons, piston rings and cylinder bores.
- Journal bearings, bearings caps, connecting rods, rod bearings, rod bearing caps, pistons and piston rings are in combination sets. Do not disturb such combination and make sure that each part goes back to where it came from, when installing.




- 1) Install sensor plate (1) to crankshaft (2) and tighten bolts to specified torque.

NOTE:


When installing sensor plate, align spring pin (3) on crankshaft and hole of sensor plate.

Tightening torque

Sensor plate bolts (a) : 11 N·m (1.1 kg-m, 8.0 lb-ft)




- 2) Install main bearings to cylinder block.
Upper half of bearing (1), has an oil groove (2).
Install it to cylinder block (3), and the other half without oil groove to bearing cap.
Make sure that two halves are painted in the same color.



- 3) Install thrust bearings (1) to cylinder block between No.2 and No.3 cylinders. Face oil groove (2) sides to crank webs.
- 4) Confirm that dowel pins (3) are installed to intake side of each journal.

- 5) Install crankshaft to cylinder block.



- 6) Install bearing cap to cylinder block, making sure to point arrow mark (on each cap) to crankshaft pulley side. Fit them sequentially in ascending order, 1, 2, 3, 4 and 5, starting from pulley side.

After applying engine oil to new bearing cap No.1 bolts ((1) – (10)) and bearing cap No.2 bolts ((11) – (20)), tighten them gradually as follows.

- Tighten bolts (1) – (10) to 30 N·m (3.0 kg-m, 22.0 lb-ft) according to numerical order as shown by using a 12 corner socket wrenches.
- In the same manner as in Step a), tighten them to 50 N·m (5.0 kg-m, 36.5 lb-ft).
- In the same manner as in Step a), retighten them to 60°.
- Tighten bolts (11) – (20) to 22 N·m (2.2 kg-m, 16.0 lb-ft) according to numerical order as shown.

Tightening torque

Crankshaft bearing cap No.1 bolts (1) – (10)


: 50 N·m (5.0 kg-m, 36.5 lb-ft) and then turn to 60°

Crankshaft bearing cap No.2 bolts (11) – (20)

: 22 N·m (2.2 kg-m, 16.0 lb-ft)

NOTE:

After tightening cap bolts, check to be sure that crankshaft rotates smoothly when turning it by 12 N·m (1.2 kg-m, 9.0 lb-ft) torque or below.




- 7) Apply sealant to mating surface of rear oil seal housing (1).

“A” : Sealant 99000-31150

Sealant amount for rear oil seal housing

Width “a” : 3 mm, 0.12 in.

Height “b” : 2 mm, 0.08 in.



- 8) Install rear oil seal housing (1) and tighten bolts to specified torque by using special tool.


Special tool

(A) : 09911-97720

Tightening torque

Rear oil seal housing bolts : 11 N·m (1.1 kg-m, 8.0 lb-ft)

A : Crankshaft side



9) Install flywheel (drive plate for A/T).

Using special tool, lock flywheel or drive plate, and tighten flywheel or drive plate bolts applied with sealant to specification.

“A” : Sealant 99000-31110

Special tool

(A) : 09924-17810

Tightening torque

Flywheel or drive plate bolts

(a) : 70 N-m (7.0 kg-m, 51.0 lb-ft)

10) Install the following parts to engine as previously outlined.

- Piston and connecting rod
- Cylinder head assembly
- Camshaft, tappet and shim
- Timing chain guide, chain tensioner adjuster, chain tensioner, timing chain and crankshaft timing sprocket
- Timing chain cover
- Cylinder head cover
- Intake manifold and exhaust manifold
- Oil pan and oil pump strainer

11) Install clutch to flywheel (vehicle with M/T) referring to Section 7C1.

12) Install engine assembly to vehicle as previously outlined.

















Required Service Material











Material	Recommended SUZUKI product (Part Number)	Use
Sealant	Sealant 1207C (99000-31150)	<ul style="list-style-type: none"> • To apply to mating surfaces of cylinder block and oil pan. • To apply to mating surfaces of cylinder block and timing chain cover. • To apply to sealing surfaces of cylinder head cover. • To apply to mating surfaces to rear oil seal housing.
	Sealant 1207B (99000-31140)	<ul style="list-style-type: none"> • To apply to mating surface of cylinder block, cylinder head and timing chain cover.
	Sealant 1215 (99000-31110)	<ul style="list-style-type: none"> • To apply to the thread of the bolt of water outlet pipe. • To flywheel (M/T) or drive plate (A/T) bolts.

Tightening Torque Specification

Fastening part	Tightening torque		
	N·m	kg-m	lb-ft
Oil pressure switch	14.0	1.4	10.5
Camshaft housing bolts (for replacement of shim)	8.0	0.8	6.0
Camshaft housing bolts	11.0	1.1	8.0
Cylinder head cover bolts	8.0	0.8	6.0
Intake manifold bolts and nuts	25.0	2.5	18.0
Exhaust manifold bolts and nuts	50.0	5.0	36.5
Exhaust pipe bolts	50.0	5.0	36.5
Exhaust manifold stiffener bolts	50.0	5.0	36.5
Oil pump strainer bolt	11.0	1.1	8.0
Oil pump strainer bracket bolt	11.0	1.1	8.0
Oil pan bolts and nuts	11.0	1.1	8.0
Oil pan drain plug bolt	50.0	5.0	36.5
Timing chain cover bolts	23.0	2.3	17.0
Crank shaft pulley bolt	150.0	15.0	108.5
Oil pump rotor plate bolts	11.0	1.1	8.0
Timing chain No.1 guide bolts	9.0	0.9	6.5
Timing chain tensioner adjuster bolts	11.0	1.1	8.0
Venturi plug	5.0	0.5	3.5
Cylinder head bolt for M8	22.0	2.2	16.0
Cylinder head bolts for M10	a) Tighten 40 N·m b) Turn 60° c) Turn 60°	a) Tighten 4.0 kg-m b) Turn 60° c) Turn 60°	a) Tighten 29.0 lb-ft b) Turn 60° c) Turn 60°
Connecting rod bearing cap nuts	a) Tighten 15 N·m b) Turn 45° c) Turn 45°	a) Tighten 1.5 kg-m b) Turn 45° c) Turn 45°	a) Tighten 11.0 lb-ft b) Turn 45° c) Turn 45°
Engine mounting bolts and nuts for M10	55.0	5.5	40.0
Engine mounting bolts and nuts for M12	75.0	7.5	54.5
Crankshaft bearing cap No.1 bolts (for inspection of crankshaft thrust play)	50.0	5.0	36.5
Crankshaft bearing cap No.2 bolts	22.0	2.2	16.0
Sensor plate bolts	11.0	1.1	8.0
Crankshaft bearing cap No.1 bolts	a) Tighten 50 N·m b) Turn 60°	a) Tighten 5.0 kg-m b) Turn 60°	a) Tighten 36.5 lb-ft b) Turn 60°
Rear oil seal housing bolts	11.0	1.1	8.0
Flywheel or drive plate bolts	70.0	7.0	51.0
Transaxle stiffener bolts	50.0	5.0	36.5
Timing chain tensioner bolt	22.0	2.2	16.0

Special Tool

 <p>09911-97720 Oil seal guide</p>	 <p>09911-97820 Oil seal installer</p>	 <p>09913-75810 Bearing installer</p>	 <p>09915-64510-001 Compression gauge</p>
 <p>09915-64510-002 Connector</p>	 <p>09915-64530 Hose</p>	 <p>09915-67010 Attachment</p>	 <p>09915-67310 Vacuum gauge</p>
 <p>09915-77310 Oil pressure gauge</p>	 <p>09915-78211 Oil pressure gauge attachment</p>	 <p>09916-14510 Valve lifer</p>	 <p>09916-14910 Valve lifer attachment</p>
 <p>09916-34542 Reamer handle</p>	 <p>09916-34550 Reamer (5.5 mm)</p>	 <p>09916-37320 Reamer (10.5 mm)</p>	 <p>09916-44910 Valve guide remover</p>

 <p>09916-56011 Valve guide installer</p>	 <p>09916-58210 Valve guide installer handle</p>	 <p>09916-67020 Tappet holder</p>	 <p>09916-77310 Piston ring compressor</p>
 <p>09916-84511 Forceps</p>	 <p>09917-68221 Camshaft lock holder</p>	 <p>09917-98221 Valve stem seal installer</p>	 <p>09924-17810 Flywheel holder</p>
 <p>09926-58010 Bearing puller attachment</p>	 <p>09944-36011 Steering wheel remover</p>		

SECTION 6B

ENGINE COOLING

CONTENTS


General Description	6B-2	On-Vehicle Service	6B-9
Cooling System Circulation	6B-2	System Components.....	6B-9
Coolant	6B-3	Cooling Water Pipes or Hoses	6B-10
Diagnosis	6B-4	Thermostat	6B-10
Diagnosis Table	6B-4	Water Valve (If Equipped)	6B-11
System Circuit	6B-5	Radiator	6B-12
System Circuit Inspection.....	6B-5	Radiator Cooling Fan	6B-13
Maintenance	6B-5	Radiator Cooling Fan Relay	6B-14
Coolant Level Check	6B-6	Water Pump/Generator Drive Belt	6B-15
Engine Cooling System Inspection and		Water Pump	6B-16
Service	6B-6	ECT Sensor	6B-17
Cooling System Flush and Refill	6B-7	Required Service Material	6B-18
Water Pump/Generator Drive Belt Tension		Tightening Torque Specification	6B-18
Inspection and Adjustment.....	6B-8	Special Tool	6B-18

General Description


The cooling system consists of the radiator cap, radiator, coolant reservoir tank, hoses, water pump, cooling fan and thermostat. The radiator is of tube-and-fin type.

Cooling System Circulation

While the engine is warmed up (thermostat closed), coolant circulates as follows.



When coolant is warmed up to normal temperature and the thermostat opens, coolant passes through the radiator core to be cooled as well as the above flow circuit.



1. Radiator inlet hose	5. Water pump	9. Heater outlet hose
2. Radiator outlet hose	6. Throttle body (Fast idle control plunger)	10. Radiator
3. Water inlet pipe	7. Engine	
4. Thermostat	8. Heater inlet hose	

Coolant

The coolant recovery system is standard. The coolant in the radiator expands with heat, and the overflow is collected in the reservoir.

When the system cools down, the coolant is drawn back into the radiator.

The cooling system has been filled at the factory with a quality coolant that is a 50/50 mixture of water and ethylene glycol antifreeze (70/30; in a market where no freezing temperature is anticipated).

This 50/50 mixture coolant solution provides freezing protection to -36°C (-33°F).

- Maintain cooling system freeze protection at -36°C (-33°F) to ensure protection against corrosion and loss of coolant from boiling. This should be done even if freezing temperatures are not expected.
- Add ethylene glycol base coolant when coolant has to be added because of coolant loss or to provide added protection against freezing at temperature lower than -36°C (-33°F).

NOTE:

- Alcohol or methanol base coolant or plain water alone should not be used in cooling system at any time as damage to cooling system could occur.
- Even in a market where no freezing temperature is anticipated, mixture of 70% water and 30% ethylene glycol antifreeze (Antifreeze/Anticorrosion coolant) should be used for the purpose of corrosion protection and lubrication.

Anti-freeze proportioning table

Freezing temperature	$^{\circ}\text{C}$	-16	-36
	$^{\circ}\text{F}$	3	-33
Anti-freeze/Anti-corrosion coolant concentration	%	30	50
Ratio of compound to cooling water	ltr.	2.07/4.83	3.45/3.45
	US pt.	4.38/10.22	7.29/7.29
	Imp pt.	3.65/8.51	6.08/6.08

Coolant capacity


Engine radiator and heater	6.50 liters (8.87/7.39 US/Imp. pt.)
Reservoir tank	0.40 liters (0.85/0.70 US/Imp. pt.)
Total	6.90 liters (9.72/8.10 US/Imp. pt.)

Diagnosis

Diagnosis Table

Condition	Possible Cause	Correction
Engine overheats (It is in case that radiator fan operates)	Loose or broken water pump belt	Adjust or replace.
	Not enough coolant	Check coolant level and add as necessary.
	Faulty thermostat	Replace.
	Faulty water pump	Replace.
	Dirty or bent radiator fins and/or A/C condenser fins	Clean or remedy.
	Coolant leakage on cooling system	Repair.
	Clogged radiator and/or A/C condenser	Check and replace radiator and/or A/C condenser as necessary.
	Faulty radiator cap	Replace.
	Improper ignition timing	Adjust.
	Dragging brakes	Adjust brake.
	Slipping clutch	Adjust or replace.
	Poor charge battery	Check and replace as necessary.
	Poor generation generator	Check and repair.
	ECT sensor faulty	Check and replace as necessary.
	Radiator cooling fan relay No.2 and/or No.3 faulty	Check and replace as necessary.
	Radiator fan motor faulty	Check and replace as necessary.
	A/C condenser cooling fan relay faulty	Check A/C condenser cooling fan relay (Refer to Section 1B).
	A/C condenser cooling fan motor faulty	Check A/C condenser cooling fan motor (Refer to Section 1B).
	ECM faulty	Check and replace as necessary.
	Wiring or grounding faulty	Repair as necessary.
	Equipped with too much electric load part	Dismount.
	Equipped with too much part to bumper air inlet	Dismount.
	A/C system faulty	Check A/C system (Refer to Section 1B).
	Power steering system faulty	Check power steering system (Refer to Section 3).
	EGR system faulty	Check EGR system (Refer to Section 6E).
	IAC system faulty	Check IAC system (Refer to Section 6).
Engine overheats (It is in case that radiator fan won't operate)	Fuse blown	Check "RADTR fan" fuse and check for short circuit to ground.
	Radiator cooling fan relay No.1	Check and replace as necessary.
	ECT sensor faulty	Check and replace as necessary.
	Radiator cooling fan motor faulty	Check and replace as necessary.
	Wiring or grounding faulty	Repair as necessary.
	ECM faulty	Check and replace as necessary.

System Circuit



1. Main fuse box	7. A/C fuse	13. ECT sensor
2. Generator	8. Radiator and condenser cooling fan relay No.1	14. ECM
3. Battery	9. Radiator and condenser cooling fan relay No.2	15. Condenser fan relay (if equipped with A/C)
4. Battery fuse	10. Radiator and condenser cooling fan relay No.3	16. Ignition switch
5. RADTR fuse	11. Radiator cooling fan motor	17. Condenser fan motor (if equipped with A/C)
6. Ignition switch fuse	12. ECM connectors (viewed from harness side)	18. Circuit fuse box

System Circuit Inspection

Refer to "TABLE B-7 RADIATOR FAN CONTROL SYSTEM CHECK" in Section 6.

Maintenance

WARNING:

- Do not remove radiator cap to check engine coolant level; check coolant visually at the see-through coolant reservoir.
Coolant should be added only to reservoir as necessary.
- As long as there is pressure in the cooling system, the temperature can be considerably higher than the boiling temperature of the solution in the radiator without causing the solution to boil. Removal of the radiator cap while engine is hot and pressure is high will cause the solution to boil instantaneously and possibly with explosive force, spewing the solution over engine, fenders and person removing cap. If the solution contains flammable anti-freeze such as alcohol (not recommended for use at any time), there is also the possibility of causing a serious fire.

Coolant Level Check

To check level, lift hood and look at “see-through” coolant reservoir tank.


It is not necessary to remove radiator cap to check coolant level.

WARNING:

To help avoid danger of being burned:

- do not remove reservoir tank cap while coolant is boiling, and
- do not remove radiator cap while engine and radiator are still hot.

Scalding fluid and steam can be blown out under pressure if either cap is taken off too soon.



When engine is cool, check coolant level in reservoir tank (1).

A normal coolant level should be between FULL mark (2) and LOW mark (3) on reservoir tank (1).

If coolant level is below LOW mark (3), remove reservoir tank cap (4) and add proper coolant to tank to bring coolant level up to FULL mark (2). Then, reinstall cap (4) and align match marks (5) on tank and cap (4).

NOTE:

- If proper quality antifreeze is used, there is no need to add extra inhibitors or additives that claim to improve system. They may be harmful to proper operation of system, and are unnecessary expense.
- When installing reservoir cap, align arrow marks on reservoir and cap.


Engine Cooling System Inspection and Service

WARNING:

To help avoid danger of being burned, do not remove radiator cap while engine and radiator are still hot.

Scalding fluid and steam can be blown out under pressure if cap is taken off too soon.

- 1) Check cooling system for leakage or damage.
- 2) Wash radiator cap and filler neck with clean water by removing radiator cap when engine is cold.
- 3) Check coolant for proper level and freeze protection.



- 4) Using a pressure tester (1), check system and radiator cap (2) for proper pressure holding capacity.
If replacement of cap is required, use a proper cap for this vehicle.

Cooling system and radiator cap holding pressure (for inspection)

: 110 kPa (1.1 kg/cm², 15.6 psi)

NOTE:

After installing radiator cap to radiator, make sure that the ear of cap lines is parallel to radiator.

- 5) Tighten hose clamps and inspect all hoses. Replace hoses whenever cracked, swollen or otherwise deteriorated.
- 6) Clean frontal area of radiator core.


Cooling System Flush and Refill


- 1) Remove radiator cap when engine is cool.
 - a) Turn cap counterclockwise slowly until it reaches a "stop".
(Do not press down while turning it).
 - b) Wait until pressure is relieved (indicated by a hissing sound) then press down on cap and continue to turn it counterclockwise.

WARNING:

To help avoid danger of being burned, do not remove radiator cap while engine and radiator are still hot. Scalding fluid and steam can be blown out under pressure if cap is taken off too soon.

- 2) With radiator cap removed, run engine until upper radiator hose is hot (this shows that thermostat is open and coolant is flowing through system).
- 3) Stop engine and drain coolant.
- 4) Close drain plug. Add water until system is filled and run engine until upper radiator hose is hot again.
- 5) Repeat Steps 3) and 4) several times until drained liquid is nearly colorless.
- 6) Drain system and then close radiator drain plug (1) tightly.






- 7) Remove reservoir tank (1) and remove cap (2) from reservoir tank (1) and pour out any fluid, scrub and clean inside of tank with soap and water.
Flush it well with clean water and drain. Reinstall tank.
- 8) Add coolant that is a mixture of good quality ethylene glycol antifreeze and water to radiator and reservoir tank. For coolant concentration referring to "COOLANT".
Fill radiator to the bottom of filler neck and reservoir tank to FULL level mark (3).
- 9) Reinstall reservoir tank cap and align match marks (4) on reservoir tank and its tank cap.
- 10) Run engine with radiator cap removed, until radiator inlet hose is hot.
- 11) With engine idling, add coolant to radiator until level reaches the bottom of filler neck. Install radiator cap, making sure that the ear of cap lines is parallel to radiator.

Water Pump/Generator Drive Belt Tension Inspection and Adjustment

WARNING:

- Disconnect negative cable at battery before checking and adjusting belt tension.
- To help avoid danger of being burned, do not remove radiator cap while engine and radiator are still hot. Scalding fluid and steam can be blown out under pressure if cap is taken off too soon.




- 1) Inspect belt for cracks, cuts, deformation, wear and cleanliness. If it is necessary to replace belt, refer to "WATER PUMP/GENERATOR DRIVE BELT" in this section.
- 2) Check belt for tension. Belt is in proper tension when it deflects 4.5 to 5.5 mm (0.18 – 0.22 in.) under thumb pressure (about 10 kg or 22 lb.).

Water pump / generator drive belt tension "a"
4.5 – 5.5 mm (0.18 – 0.22 in.) as deflection/10 kg (22 lbs)

NOTE:

When replacing belt with a new one, adjust belt tension to 3 – 4 mm (0.12 – 0.16 in.).



- 3) If belt is too tight or too loose, adjust it to proper tension by displacing generator position.
- 4) Tighten generator adjusting bolt and pivot bolts as specified torque.

Tightening torque

Generator adjusting bolt (a) : 23 N·m (2.3 kg-m, 17.0 lb-ft)

Generator pivot bolt (b) : 50 N·m (5.0 kg-m, 36.0 lb-ft)


- 5) Connect negative cable at battery.

On-Vehicle Service

WARNING:


- Check to make sure that engine coolant temperature is cold before removing any part of cooling system.
- Also be sure to disconnect negative cord from battery terminal before removing any part.

System Components



1. Radiator	14. Radiator cooling fan assembly	27. Thermostat case bolts
2. Reservoir tank	15. Water inlet pipe No.1	28. Heater circulation hose (if equipped)
3. Radiator cap	16. Water inlet pipe No.2	29. Condenser cooling fan assembly (if equipped)
4. Drain plug	17. Thermostat cap	30. Water valve (if equipped) : Install noting its direction as shown
5. Radiator outlet hose	18. Water outlet cap	31. Throttle body water inlet valve
6. Radiator inlet hose	19. Heater inlet hose	32. Throttle body water outlet valve
7. Thermostat	20. Heater outlet hose	33. To cylinder head
8. ECT sensor	21. To timing chain cover	34. To thermostat case
9. Thermostat case	22. O-Ring	35. Throttle body
10. To cylinder head	23. Gasket	Tightening torque
11. To throttle body	24. Water outlet cap O-ring No.1	Do not reuse.
12. To heater unit	25. Water outlet cap O-ring No.2	
13. To water pump	26. Thermostat cap bolts	

Cooling Water Pipes or Hoses



REMOVAL

- 1) Drain cooling system.
- 2) To remove these pipes or hoses, loosen clamp on each hose and pull hose end off.

INSTALLATION



Install removed parts in reverse order of removal procedure, noting the following.

- Tighten each clamp securely.
- Refill cooling system with proper coolant referring to "COOLING SYSTEM FLUSH AND REFILL".

Thermostat


REMOVAL

- 1) Drain cooling system by loosening drain plug of radiator referring to "COOLING SYSTEM DRAINING".
- 2) Remove air cleaner assembly and resonator referring to section 6A1.
- 3) Remove intake manifold referring to Section 6A1.
- 4) Remove generator referring to Section 6H.
- 5) Disconnect water hose (1) and heater hose (2) from each pipe.
- 6) Remove thermostat case (3) with thermostat cap (4) and water inlet pipe (5).
- 7) Remove water inlet pipe with thermostat cap from thermostat case.
- 8) Remove thermostat.



INSPECTION

- Make sure that air bleed valve (1) of thermostat is clean. Should this valve be clogged, engine would tend to overheat.
- Check to make sure that valve seat is free from foreign matters which would prevent valve from seating tight.
- Check thermostat seal (2) for breakage, deterioration or any other damage.



- Check thermostatic movement of wax pellet as follows:
 - a) Immerse thermostat (1) in water, and heat water gradually.
 - b) Check that valve starts to open at specific temperature.

Temperature at which valve begins to open

: 80 – 84°C (176 – 183°F)

Temperature at which valve become fully open

: 95 – 97°C (203°F)

Valve lift


: More than 8 mm at 95°C (203°F)

If valve starts to open at a temperature substantially below or above specific temperature, thermostat unit should be replaced with a new one. Such a unit, if reused, will bring about overcooling or overheating tendency.

2. Thermometer
3. Heater

INSTALLATION

Reverse removal procedure for installation noting the following points.




- When positioning thermostat (1) on thermostat case (2), be sure to position it so that air bleed valve (3) comes at position as shown in figure.
- Use new O-rings when installing.
- Adjust water pump belt tension referring to WATER PUMP/GENERATOR DRIVE BELT TENSION INSPECTION AND ADJUSTMENT in this section.
- Adjust A/C compressor belt tension (if equipped) referring to Section 1B.
- Refill cooling system with proper coolant referring to “COOLING SYSTEM FLUSH AND REFILL”.
- Verify that there is no coolant leakage at each connection.

Water Valve (If Equipped)

REMOVAL

- 1) Drain cooling system by loosening drain plug of radiator referring to “COOLING SYSTEM DRAINING” in this section.
- 2) Remove water valve referring to “SYSTEM COMPONENT” in this section.



INSPECTION

Check water valve operation as follows:

- Connect water valve (1) to vacuum pump gauge (A) discharge side as shown, and then check that air comes out from water valve (1).


Special tool

(A) : 09917-47010

- Immerse water valve (1) in heated water (more than 90°C (194°F)) for 5 minutes, and then check that air does not come out from water valve (1).

If check result is not as specified, replace water valve.

[A]: Fig. for step a)
[B]: Fig. for step b)
2. Heater



INSTALLATION

Reverse removal procedure to install water valve noting the followings.

- Insert water valve (1) to throttle body water inlet hoses (2) directing gold side (5) to cylinder head.


3. To throttle body
4. To cylinder head


- Refill cooling system with proper coolant referring to “COOLING SYSTEM FLUSH AND REFILL”.
- Verify that there is no coolant leakage at each connection.

Radiator

REMOVAL

- Disconnect negative cable at battery.
- Drain cooling system by loosening drain plug of radiator. Refer to “COOLING SYSTEM DRAINING”.
- Disconnect connector of cooling fan motor.
- Remove A/C condenser cooling fan assembly, if equipped with A/C.
- Remove reservoir tank (1), if equipped with A/C.
- Disconnect radiator inlet (2) and outlet hoses from radiator.
- Remove cooling fan assembly (3).
- Disconnect A/T fluid hoses from radiator, if equipped with A/T vehicle.
- Remove radiator.





INSPECTION

Check radiator for leakage or damage. Straighten bent fins, if any.

CLEANING

Clean frontal area of radiator cores.


INSTALLATION

Reverse removal procedures, noting the followings.


- Refill cooling system with proper coolant referring to “COOLING SYSTEM FLUSH AND REFILL”.
- After installation, check each joint for leakage.

Radiator Cooling Fan

INSPECTION



- 1) Check continuity between each terminals.
If there is no continuity, replace radiator fan motor.




- 2) Connect battery to radiator fan motor coupler as shown in figure, then check that the radiator fan motor operates smoothly, fan speed varies and that specified current.
If radiator fan motor does not operate smoothly, replace motor.

Radiator cooling fan motor specified current at 12 V

LOW : 10 A maximum


HIGH : 15 A maximum

REMOVAL

- 1) Disconnect negative cable at battery.
- 2) Disconnect connector of cooling fan motor.
- 3) Remove A/C condenser cooling fan motor, if equipped with A/C.
- 4) Remove radiator cooling fan motor (1) from radiator.

INSTALLATION


Reverse removal procedure for installation.

Radiator Cooling Fan Relay**INSPECTION**

- 1) Disconnect negative (–) cable at battery.
- 2) Remove radiator cooling fan relay No.1 (1), No.2 (2) and No.3 (3) from relay box.
- 3) Check that there is no continuity between terminal “c” and “b”. If there is continuity, replace relay.
- 4) Connect battery positive (+) terminal to terminal “b” of relay. Connect battery negative (–) terminal “a” of relay. Check continuity between terminal “c” and “d”. If there is no continuity when relay is connected to the battery, replace relay.


Water Pump/Generator Drive Belt

REMOVAL




- 1) Disconnect negative cable at battery.
- 2) Remove right side engine under cover and generator cover (if equipped).
- 3) Loosen drive belt adjusting bolt (2) and generator pivot bolt (3).
When servicing car equipped with A/C, remove compressor drive belt before removing water pump belt (1).
Refer to "COMPRESSOR DRIVE BELT" in Section 1B.
- 4) Slacken belt by displacing generator and then remove it.

INSTALLATION



- 1) Install belt (1) to water pump pulley (2), crankshaft pulley (3) and generator pulley (4).
When servicing car equipped with A/C, install compressor drive belt, too.



- 2) Adjust belt tension by referring to "WATER PUMP/GENERATOR DRIVE BELT TENSION INSPECTION AND ADJUSTMENT" in this section.
For adjustment of compressor drive belt tension, refer to COMPRESSOR DRIVE BELT in Section 1B.
- 3) Tighten water pump belt adjusting bolt and pivot bolt to specified torque.

Tightening torque

Generator adjusting bolt (a) : 23 N·m (2.3 kg-m, 17.0 lb-ft)

Generator pivot bolt (b) : 50 N·m (5.0 kg-m, 36.0 lb-ft)

- 4) Install right side engine under cover and generator cover (if equipped).
- 5) Connect negative cable at battery.



WATER PUMP BELT TENSION INSPECTION AND ADJUSTMENT

For this inspection or adjustment, refer to "WATER PUMP/GENERATOR DRIVE BELT TENSION INSPECTION AND ADJUSTMENT".

Water Pump

REMOVAL

- 1) Disconnect negative cable at battery.
- 2) Drain coolant. Refer to "COOLING SYSTEM DRAINING".
- 3) Remove A/C compressor belt by referring to "COMPRESSOR DRIVE BELT" in Section 1B. (if equipped).
- 4) Loosen water pump/generator drive belt adjusting bolt (1) and generator pivot bolt (2). Then remove water pump/generator drive belt (3) and water pump pulley. Refer to "WATER PUMP/GENERATOR DRIVE BELT" in this section.



- 5) Remove water pump assembly (1).

INSPECTION

CAUTION:


Do not disassemble water pump.

If any repair is required on pump, replace it as assembly.

- Rotate water pump by hand to check for smooth operation. If pump does not rotate smoothly or makes abnormal noise, replace it.



INSTALLATION




- 1) Apply sealant (1) to mating surface of water pump as shown in figure.

“A” : Sealant 99000-31150

Sealant quantity (to mating surface of water pump)

Width “a” : 3mm (0.12 in.)

Height “b” : 2mm (0.08 in.)



- 2) Install water pump assembly (1) to cylinder block and tighten bolts and nut to specified torque.

Tightening torque

Water pump bolts and nut (a) : 22 N·m (2.2 kg-m, 16.0 lb-ft)

- 3) Install water pump pulley.
- 4) Install water pump/generator drive belt. Refer to “WATER PUMP/GENERATOR DRIVE BELT” in this Section.
- 5) Install A/C compressor belt (if equipped). Refer to “COMPRESSOR DRIVE BELT” in Section 1B.
- 6) Fill coolant. Refer to “COOLING SYSTEM FLUSH AND REFILL”.
- 7) Connect negative cable at battery.
- 8) Check each part for leakage.

ECT Sensor

Refer to “ECT SENSOR” in Section 6E1.


Required Service Material

Material	Recommended SUZUKI product (Part Number)	Use
Ethylene glycol base coolant (Anti-freeze/ Anti-corrosion coolant)	—	Additive to engine cooling system for improving cooling efficiency and for protection against rusting.
Sealant	SUZUKI BOND NO. 1207C (99000-31150)	To apply to mating surface of water pump

Tightening Torque Specification

Fastening part	Tightening torque		
	N•m	kg-m	lb-ft
Generator adjusting bolt	23	2.3	17
Generator pivot bolt	50	5.0	36
Water pump bolts and nut	22	2.2	16

Special Tool



SECTION 6C

ENGINE FUEL

WARNING:

For vehicles equipped with Supplemental Restraint (Air Bag) System:

- Service on and around the air bag system components or wiring must be performed only by an authorized SUZUKI dealer. Refer to “Air Bag System Components and Wiring Location View” under “General Description” in air bag system section in order to confirm whether you are performing service on or near the air bag system components or wiring. Please observe all WARNINGS and “Service Precautions” under “On-Vehicle Service” in air bag system section before performing service on or around the air bag system components or wiring. Failure to follow WARNINGS could result in unintentional activation of the system or could render the system inoperative. Either of these two conditions may result in severe injury.
- Technical service work must be started at least 90 seconds after the ignition switch is turned to the “LOCK” position and the negative cable is disconnected from the battery. Otherwise, the system may be activated by reserve energy in the Sensing and Diagnostic Module (SDM).

CAUTION:

The engine of this vehicle requires the use of unleaded fuel only. Use of leaded and/or low lead fuel can result in engine damage and reduce the effectiveness of the emission control system.

6C

CONTENTS

General Description	6C-1	Fuel Filler Cap.....	6C-5
On-Vehicle Service	6C-2	Fuel Tank	6C-5
Components	6C-2	Fuel Tank Inlet Valve	6C-9
Precautions	6C-3	Fuel Pump Assembly	6C-10
Fuel Lines	6C-4	Special Tool	6C-14
Fuel Pipe	6C-4	Tightening Torque Specification	6C-14


General Description



The main components of the fuel system are fuel tank, fuel pump assembly (with fuel filter, fuel level gauge and tank pressure control valve), fuel/vapor separator fuel feed line and fuel vapor line.

For the details of fuel flow and fuel vapor flow, refer to “GENERAL DESCRIPTION” in Section 6E1.

On-Vehicle Service


Components




1. Fuel tank	7. Fuel purge line	13. Fuel return line	19. Fuel tank belt pad
2. Fuel pump assembly	8. To EVAP canister	14. Tank protector	20. Fuel pump
3. Breather hose	9. To Delivery pipe	15. Fuel cut valve	21. Fuel filter assembly
4. Fuel filler cap	10. Fuel/vapor separator	16. 2 way check valve	22. Fuel level gauge (Fuel sender gauge)
5. Fuel feed line	11. Fuel pump bolt (6 pcs.)	17. Gasket	 Do not reuse.
6. Wire harness for fuel pump	12. Fuel tank bolt (4 pcs.)	18. O-ring	 Tightening torque

Precautions


[A]




[B]




[C]



[D]



[E]



WARNING:

Before attempting service of any type on fuel system, the followings should be always observed in order to reduce the risk of fire and personal injury.

- Disconnect negative cable at battery.
- Do not smoke, and place no smoking signs near work area.
- Be sure to have CO₂ fire extinguisher handy.
- Be sure to perform work in a well-ventilated area and away from any open flames (such as gas hot heater).
- Wear safety glasses.
- To relieve fuel vapor pressure in fuel tank, remove fuel filler cap from fuel filler neck and then reinstall it.
- As fuel feed line is still under high fuel pressure even after engine was stopped, loosening or disconnecting fuel feed line directly may cause dangerous spout of fuel to occur where loosened or disconnected. Before loosening or disconnecting fuel feed line, make sure to relieve fuel pressure "FUEL PRESSURE RELIEF PROCEDURE" in Section 6.
- A small amount of fuel may be released after the fuel line is disconnected. In order to reduce the chance of personal injury, cover the fitting to be disconnected with a shop cloth. Be sure to put that cloth in an approved container when disconnection is completed.
- Note that fuel hose connection varies with each type of pipe. Be sure to connect and clamp each hose correctly referring to the figure.

[A] : With short pipe, fit hose as far as it reaches pipe joint as shown.

[B] : With the following type pipe, fit hose as far as its peripheral projection as shown.

[C] : With bent pipe, fit hose as far as its bent part as shown or till depth "b".

[D] : With straight pipe, fit hose till depth "b".

[E] : With red marked pipe, fit hose end reaches red mark on pipe.

1. Pipe

2. Hose

3. Clamp


4. Red mark

"a" : Clamp securely at a position 3 to 7 mm (0.12 – 0.27 in.) from hose end.

"b" : 20 to 30 mm (0.79 – 1.18 in.)

"c" : 0 to 5 mm (0 – 0.19 in.)

Fuel Lines



CAUTION:

Due to the fact that fuel feed line is under high pressure, use special care when servicing it.

INSPECTION

Visually inspect fuel lines for evidence of fuel leakage, hose crack and deterioration, or damage.

Make sure all clamps are secure.

Replace parts as needed.

Fuel Pipe

WARNING:

A small amount of fuel may be released after fuel hose is disconnected. In order to reduce the chance of personal injury, cover hose and pipe to be disconnected with a shop cloth.

Be sure to put that cloth in an approved container when disconnection is completed.

REMOVAL

- 1) Relieve fuel pressure in fuel feed line according to "FUEL PRESSURE RELIEF PROCEDURE" in Section 6.
- 2) Disconnect negative cable at battery.

- 3) Disconnect fuel pipe joint and fuel hose from fuel pipe at the front and rear of each fuel pipe.


For quick joint (2), disconnect it as follows :


- a) Remove mud, dust and/or foreign material between pipe (1) and joint by blowing compressed air.
- b) Unlock joint lock by inserting special tool between pipe and joint.

Special tool

(A) : 09919-47020

- c) Disconnect joint (2) from pipe (1).
- 4) Disconnect brake pipe from pipe joint referring to Section 5.





- 5) Mark the location of clamps (1) on fuel pipes (2), so that the clamps can be reinstalled to where they were.
- 6) Remove pipes (2) with clamp (1) from vehicle.
- 7) Remove clamp (1) from pipes (2).

INSTALLATION

- 1) Install clamps to marked location on pipes. If clamp is deformed or its claw is bent or broken, replace it with new one.
- 2) Install pipes with pipe clamps to vehicle.
- 3) Connect fuel hoses and pipes to each pipe.

CAUTION:


When connecting joint, clean outside surfaces of pipe where joint is to be inserted, push joint into pipe till joint lock clicks and check to ensure that pipes are connected securely, or fuel leak may occur.

- 4) With engine OFF, turn ignition switch to ON position and check for fuel leaks.

Fuel Filler Cap

INSPECTION

Remove cap (1), and check gasket for even filler neck imprint, and deterioration or any damage. If gasket (2) is in malcondition, replace cap.



NOTE:

If cap requires replacement, only a cap with the same features should be used. Failure to use correct cap can result in critical malfunction of system.


Fuel Tank

REMOVAL

WARNING:

Before starting the following procedure, be sure to observe "PRECAUTIONS".


- 1) Relieve fuel pressure in fuel feed line according to "FUEL PRESSURE RELIEF PROCEDURE" in Section 6.
- 2) Disconnect negative cable at battery.




- 3) Remove fuel filler cap.
- 4) Insert hose of a hand operated pump into fuel filler hose (1) and drain fuel in space "A" in the figure.

CAUTION:

Do not force pump hose into fuel tank, or pump hose may damage fuel tank inlet valve (2).



- 5) Hoist vehicle.
- 6) Remove muffler referring to Section 6K.
- 7) Remove propeller shaft No.2 referring to Section 4B.
(If equipped)
- 8) Remove EVAP canister with its bracket (1) from vehicle.



- 9) Disconnect fuel filler hose (1) and breather hose (2) from filler neck (3).


CAUTION:

Never disconnect fuel filler hose (1) from fuel tank inlet. If half or more of fuel is remaining to fuel tank, fuel over flows in this case and come out.

- 10) Due to absence of fuel tank drain plug, drain fuel tank by pumping fuel out through fuel tank filler.
Use hand operated pump device to drain fuel tank.

CAUTION:

- **Do not force pump hose into fuel tank, or pump hose may damage fuel tank inlet valve.**
- **Never drain or store fuel in an open container due to possibility of fire or explosion.**



11) Disconnect fuel pipe joints from pipes.

For quick joint, disconnect it as follows:

- Remove mud, dust and/or foreign material between pipe and joint by blowing compressed air.
- Unlock joint (1) lock by inserting special tool between pipe (2) and joint (1).


Special tool

(A) : 09919-47020


- Disconnect joint from pipe.

WARNING:

A small amount of fuel may be released after the fuel hose is disconnected. In order to reduce the chance of personal injury, cover the hose and pipe to be disconnected with a shop cloth. Be sure to put that cloth in an approved container when disconnection is completed.



12) Support fuel tank (1) with jack (2) and remove its mounting bolts.



13) Lower fuel tank a little as to disconnect wire harness at connector (1) and ground wire harness, then remove fuel tank.

INSPECTION

After removing fuel tank, check hoses and pipes connected to fuel tank for leaks, loose connections, deterioration or damage. Also check fuel pump assembly gaskets for leaks, visually inspect fuel tank for leaks and damage.

Replace any damaged or mal-conditioned parts.

FUEL TANK PURGING PROCEDURE

WARNING:

This purging procedure will not remove all fuel vapor. Do not attempt any repair on tank using heat of flame as an explosion resulting in personal injury could occur.

The following procedure is used for purging fuel tank.

- 1) After removing fuel tank, remove all hoses, pipes, fuel pump assembly from fuel tank.
- 2) Drain all remaining fuel from tank.
- 3) Move tank to flushing area.
- 4) Fill tank with warm water or tap water, and agitate vigorously and drain. Repeat this washing until inside of tank is clean. Replace tank if its inside is rusty.
- 5) Completely flush out remaining water after washing.

CAUTION:



Never remain water in fuel tank after washing, or fuel tank inside will get corrosion.

INSTALLATION

- 1) If parts have been removed from fuel tank, install them before installing fuel tank to vehicle.
- 2) Raise fuel tank (1) with jack and connect connector of fuel pump and ground wire harness and clamp wire harness.
- 3) Install fuel tank to vehicle.

Tightening torque


Fuel tank bolt (a): 50 N·m (5.0 kg-m, 69.5 lb-ft)



- 4) Connect fuel filler hose (1) and breather hose (2) to filler neck (3) as shown in figure and clamp them securely.

Tightening torque


Fuel filler hose clamp (a) : 1.5 N·m (0.15 kg-m, 1.0 lb-ft)



- 5) Connect fuel feed pipe (1), fuel return pipe (3) and purge pipe (2) to each pipe as shown in figure and clamp them securely.

CAUTION:

- When connecting joint, clean outside surfaces of pipe where joint is to be inserted, push joint into pipe till joint lock clicks and check to ensure that pipes are connected securely, or fuel leak may occur.
- Never let the fuel hoses touch the ABS sensor harness (if equipped).



- 6) Install EVAP canister with its bracket (1) to vehicle.
 7) Install propeller shaft No.2 referring to Section 4B.
 8) Remove muffler referring to Section 6K.
 9) Connect negative cable at battery.
 With engine OFF, turn ignition switch to ON position and check for fuel leaks.


Fuel Tank Inlet Valve

WARNING:

Refer to the **WARNING** at the beginning of **ON-VEHICLE SERVICE** in this section.

REMOVAL


- 1) Remove fuel tank from vehicle. Refer to "FUEL TANK" in this section.
- 2) Remove clamp and fuel filler hose from fuel tank.
- 3) Remove fuel tank inlet valve (1) using flat-bladed screwdriver.



CAUTION:

Be careful not to damage fuel tank inlet valve (1) with flat-bladed screwdriver.

INSPECTION




Check fuel tank inlet valve for the followings.

- Damage
- Smooth opening and closing

If any damage or malfunction is found, replace.

INSTALLATION



- 1) Install fuel tank inlet valve (1) to fuel tank and then install fuel filler hose.
- 2) Install fuel tank to vehicle. Refer to "FUEL TANK" in this section.

Fuel Pump Assembly

WARNING:


Refer to the **PRECAUTIONS** at the beginning of **ON-VEHICLE SERVICE**.


REMOVAL

- 1) Remove fuel tank from vehicle. Refer to "FUEL TANK".
- 2) Disconnect fuel cut valve hose (1), fuel feed line (2) and fuel return pipe (3) from fuel pump assembly.
When disconnecting joint of fuel feed pipe (2) and fuel return pipe (3) from fuel pump, unlock joint by inserting special tool between pipe and joint lock first.

Special tool

(A): 09919-47020







3) Remove fuel pump assembly (1) from fuel tank (2).

INSPECTION

- Check fuel pump assembly for damage.
- Check fuel suction filter (1) for evidence of dirt and contamination.
If present, replace or clean and check for presence of dirt in fuel tank.
- For operation or electrical circuit inspection by referring to Section 6E1.
- For inspection of fuel level gauge (2) by referring to Section 8.
- Check tank pressure control valve referring to the following procedures.

WARNING:

Do not suck air through fuel vapor line hose. Fuel vapor inside valve is harmful.




- a) Air should pass through valve (2) smoothly from fuel vapor line hose (3) "A" to "B" when blown hard.
- b) Also, when vacuum pump (4) is connected to fuel vapor hose and pump air through valve, air should pass from "B" to "A".

Special tool

(A) : 09917-47011

If air doesn't pass through valve in Step a) or vacuum is maintained in Step b), replace fuel filter assembly (1).




- While removing fuel level gauge, do not contact resistor plate (1) or deform arm (2). It may cause fuel level gauge to fail.
- When removing grommet from fuel tube or bracket sub assembly, be very careful not to cause damage to grommet installed section (sealed section in bore). Should it be damaged, replace it with new one, or fuel will leak from that part.

- When removing fuel level sensor (3), press snap-fit part (4) and slide it in the arrow direction as shown in figure.
- When installing fuel level sensor to housing, fit fuel level sensor securely.

INSTALLATION

1) Clean mating surfaces of fuel pump assembly (1) and fuel tank.


2) Put plate (2) on fuel pump assembly (1) by matching the protrusion of fuel pump assembly (3) to plate hole (4) as shown.




3) Install new gasket (2) and fuel pump assembly (1) with plate (3) to fuel tank.

Tightening torque

Fuel pump assembly bolts (a) : 10 N·m (1.0 kg-m, 7.5 lb-ft)



4) Connect fuel cut valve hose (1), fuel return pipe (2) (pipe joint) and fuel feed line (3) (pipe joint) to fuel pump assembly.





CAUTION:

When connecting joint, clean outside surface of pipe where joint is to be inserted, push joint into pipe till joint lock clicks and check to ensure that pipes are connected securely, or fuel leak may occur.

5) Install fuel tank (1) to vehicle. Refer to "FUEL TANK" in this section.

Special Tool

	
09917-47011 Vacuum pump gauge	09919-47020 Quick joint remover

Tightening Torque Specification

Fastening part	Tightening torque		
	N•m	kg-m	lb-ft
Fuel tank bolts	50	5.0	69.5
Fuel pump assembly bolts	10	1.0	7.5

SECTION 6E1

ENGINE AND EMISSION CONTROL SYSTEM (M13 AND M16 ENGINES)

WARNING:

For vehicles equipped with Supplemental Restraint (Air Bag) System :

- Service on and around the air bag system components or wiring must be performed only by an authorized SUZUKI dealer. Refer to “Air Bag System Components and Wiring Location View” under “General Description” in air bag system section in order to confirm whether you are performing service on or near the air bag system components or wiring. Please observe all WARNINGS and “Service Precautions” under “On-Vehicle Service” in air bag system section before performing service on or around the air bag system components or wiring. Failure to follow WARNINGS could result in unintentional activation of the system or could render the system inoperative. Either of these two conditions may result in severe injury.
- Technical service work must be started at least 90 seconds after the ignition switch is turned to the “LOCK” position and the negative cable is disconnected from the battery. Otherwise, the system may be activated by reserve energy in the Sensing and Diagnostic Module (SDM).

NOTE:

Whether the following system (parts) are used in the particular vehicle or not depends on vehicle specifications. Be sure to bear this in mind when performing service work.

- EGR valve
- Heated oxygen sensor(s) or CO adjusting resistor
- Three way catalytic converter
- Immobilizer indicator lamp
- Knock sensor

6E1

CONTENTS

General Description	6E1-2	Fuel pump	6E1-19
Air Intake System	6E1-5	Fuel pressure regulator	6E1-20
Fuel Delivery System	6E1-6	Fuel injector.....	6E1-21
Fuel pump	6E1-6	Electronic Control System.....	6E1-25
Electronic Control System.....	6E1-7	Engine control module (ECM)	6E1-25
Engine & emission control		Manifold absolute pressure sensor	
input/output table.....	6E1-8	(MAP sensor)	6E1-25
On-vehicle Service	6E1-12	Throttle position sensor (TP sensor)	6E1-26
Accelerator cable adjustment	6E1-12	Intake air temperature sensor	
Idle speed/idle air control (IAC) duty		(IAT sensor)	6E1-27
inspection	6E1-12	Engine coolant temperature sensor	
Idle mixture inspection / adjustment		(ECT sensor).....	6E1-28
(vehicle without heated		Heated oxygen sensor	
oxygen sensor).....	6E1-14	(HO2S-1 and HO2S-2).....	6E1-29
Air Intake System	6E1-15	Camshaft position sensor.....	6E1-30
Throttle body	6E1-15	Crankshaft position sensor.....	6E1-30
Idle air control valve (IAC valve).....	6E1-17	Vehicle speed sensor (VSS)	6E1-31
Fuel Delivery System	6E1-18	Fuel level sensor (gauge).....	6E1-31
Fuel pressure inspection	6E1-18	Knock sensor (if equipped)	6E1-31

Main relay, fuel pump relay, A/C compressor relay and A/C condenser fan relay.....	6E1-31
Fuel cut operation	6E1-32
Radiator fan control system	6E1-32
Radiator fan relay No. 1, No. 2 and No.3.....	6E1-32

Output signals of throttle valve opening and engine coolant temp. (vehicle with A/T only).....	6E1-34
Emission Control System.....	6E1-34
EGR system.....	6E1-34
Evaporative emission control system...	6E1-35
PCV system	6E1-37
Special Tool	6E1-38
Tightening Torque Specification.....	6E1-39


General Description


The engine and emission control system is divided into 4 major sub-systems : air intake system, fuel delivery system, electronic control system and emission control system.

Air intake system includes air cleaner, throttle body, IAC valve and intake manifold.

Fuel delivery system includes fuel pump, delivery pipe, fuel pressure regulator, etc. Electronic control system includes ECM, various sensors and controlled devices.

Emission control system includes EGR, EVAP and PCV system.






1. Air cleaner	18. Knock sensor (vehicle with EGR)	33-2. Test switch terminal (vehicle without immobilizer indicator lamp)
2. EVAP canister purge valve	19. ECT sensor	33-3. Duty output terminal (vehicle without immobilizer indicator lamp)
3. IAT sensor	20. CMP sensor	34. Stop lamp
4. TP sensor	21. CKP sensor	35. Stop lamp switch
5. IAC valve	22. VSS	36. ECM
6. MAP sensor	23. Power steering pressure switch (if equipped)	37. Barometric pressure sensor (if equipped)
7. EGR valve (if equipped)	24. Radiator fan	38. Battery
8. EVAP canister	25. Malfunction indicator lamp in combination meter	39. CO adjusting resistor (vehicle without EGR)
9. Fuel pressure regulator	26. Park/Neutral position switch (A/T)	40. A/C compressor clutch (if equipped)
10. Tank pressure control valve (built-in fuel pump)	27. Ignition switch	41. A/C condenser fan motor (if equipped)
11. Fuel pump	28. Starter magnetic switch	42. A/C switch (if equipped)
12. Fuel level sensor (vehicle with immobilizer indicator lamp)	29. TCM	43. A/C evaporator inlet air temperature sensor (if equipped)
13. Ignition coil assembly	30. Generator	44. A/C evaporator outlet air temperature sensor (if equipped)
14. Fuel injector	31. DLC	45. Immobilizer control module (if equipped)
15. Heated oxygen sensor (HO2S)-1 (vehicle with EGR)	32. Electric load	46. Main relay
16. Heated oxygen sensor (HO2S)-2 (if equipped)	33. Monitor connector (vehicle without immobilizer indicator lamp)	
17. Immobilizer indicator lamp (if equipped)	33-1. Diagnosis switch terminal (vehicle without immobilizer indicator lamp)	

Air Intake System

The main components of the air intake system are air cleaner (1), air cleaner outlet hose (2), throttle body (3), idle air control valve (4) and intake manifold (5).

The air (by the amount corresponding to manifold absolute pressure (6) and engine speed) is filtered by the air cleaner (1), passes through the throttle body (3), is distributed by the intake manifold (5) and finally drawn into each combustion chamber.

When the idle air control valve (4) is opened according to the signal from ECM, the air (7) bypasses the throttle valve (8) through bypass passage and is finally drawn into the intake manifold (5).




Fuel Delivery System

The fuel system consists of fuel tank (1), fuel pump (2) (with built-in fuel filter (3)), fuel pressure regulator (11), delivery pipe (9) and fuel injectors (10).

The fuel in the fuel tank is pumped up by the fuel pump, filtered by the fuel filter and fed under pressure to each injector through the delivery pipe.


As the fuel pressure applied to the injector (the fuel pressure in the fuel feed line) is always kept a certain amount higher than the pressure in the intake manifold by the fuel pressure regulator, the fuel is injected into the intake port of the cylinder head when the injector opens according to the injection signal from ECM.

The fuel relieved by the fuel pressure regulator returns through the fuel return line to the fuel tank.



4. Fuel cut valve	6. To EVAP canister	8. Fuel return line
5. Fuel tank pressure control valve	7. Fuel feed line	12. To intake manifold (vacuum passage)

Fuel pump



An in-tank type electric pump has been adopted for the fuel pump (1). Incorporated in the pump assembly are;

- Tank pressure control valve (2) which keeps the pressure in the fuel tank constant, and prevents the fuel from spouting and tank itself from being deformed.
- Relief valve (3) which prevents the pressure in tank from rising excessively.
- Fuel cut valve (4) which closes as the float rises so that the fuel will not enter the canister when the fuel level in the tank rises high depending on the fuel level in the tank and the vehicle tilt angle.

Also, a fuel filter (5) is included and a fuel level gauge (6) is attached.


Electronic Control System

The electronic control system consists of 1) various sensors which detect the state of engine and driving conditions, 2) ECM which controls various devices according to the signals from the sensors and 3) various controlled devices.

Functionally, it is divided into nine sub systems :

- Fuel injection control system
- Idle speed control system
- Fuel pump control system
- A/C control system (if equipped)
- Radiator fan control system
- EGR system (if equipped)
- Evaporative emission control system
- Oxygen sensor heater control system (if equipped)
- Ignition control system

Also, with A/T model, ECM sends throttle valve opening signal and coolant temp. signal to transmission control module to control A/T.



INFORMATION SENSORS	CONTROL DEVICES	OTHERS
1. MAP sensor	a : Fuel injector	A : ECM
2. TP sensor	b : EVAP canister purge valve	B : Main relay
3. IAT sensor	c : Fuel pump relay	C : EVAP canister
4. ECT sensor	d : EGR valve (step motor) (if equipped)	D : Monitor connector
5. Heated oxygen sensor-1 (if equipped)	e : Malfunction indicator lamp	E : Data link connector
5-1. Heated oxygen sensor-2 (if equipped)	f : Ignition coil assembly	F : A/C EVAP inlet air temp. sensor (if equipped)
6. VSS	g : Radiator fan control relay No.1	G : A/C EVAP outlet air temp. sensor (if equipped)
7. Transmission range switch (A/T)	h : Radiator fan control relay No.2	H : A/C compressor relay
8. Battery	i : Radiator fan control relay No.3	I : A/C condenser fan relay
9. CMP sensor	j : IAC valve	J : TCM (A/T)
10. CKP sensor	k : Immobilizer indicator lamp	
11. Fuel level sensor (gauge) (in fuel tank)		
12. Stop lamp switch		
13. Knock sensor (if equipped)		
14. PSP switch (if equipped)		


Engine & emission control input/output table

<div>INPUT</div> <div>OUTPUT</div>		ELECTRIC CONTROL DEVICE													
		FUEL PUMP RELAY	FUEL INJECTOR	HO2S HEATER	IAC VALVE	IGNITION COIL WITH IGNITER	EGR VALVE (IF EQUIPPED)	EVAP CANISTER PURGE VALVE	A/C COMPRESSOR RELAY	A/C CONDENSER FAN RELAY	RADIATOR FAN RELAY	GENERATOR	MIL	MAIN RELAY	TRANSMISSION CONTROL MODULE
SIGNAL FROM SENSOR, SWITCH AND CONTROL MODULE	DIAGNOSIS SWITCH (VEHICLE WITHOUT EGR)											<input type="radio"/>			
	FUEL LEVEL SENSOR (VEHICLE WITH HO2S-2)	For detecting fuel level													
	BAROMETRIC PRESSURE SENSOR (VEHICLE WITH EGR)		<input type="radio"/>		<input type="radio"/>	<input type="radio"/>		<input type="radio"/>					<input type="radio"/>		
	STOP LAMP SWITCH				<input type="radio"/>										
	START SWITCH	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>		<input type="radio"/>	<input type="radio"/>		<input type="radio"/>	<input type="radio"/>		
	IGNITION SWITCH	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>	<input type="radio"/>
	POWER STEERING PRESSURE SWITCH (IF EQUIPPED)				<input type="radio"/>										
	LIGHTING SWITCH				<input type="radio"/>							<input type="radio"/>			
	REAR DEFOGGER SWITCH				<input type="radio"/>							<input type="radio"/>			
	BLOWER SWITCH				<input type="radio"/>				<input type="radio"/>	<input type="radio"/>		<input type="radio"/>			
	A/C SWITCH				<input type="radio"/>			<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>				
	A/C EVAP INLET / OUTLET AIR TEMP. SENSORS								<input type="radio"/>	<input type="radio"/>					
	VSS		<input type="radio"/>		<input type="radio"/>		<input type="radio"/>		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>
	HEATED OXYGEN SENSOR-1 (VEHICLE WITH EGR VALVE)		<input type="radio"/>					<input type="radio"/>					<input type="radio"/>		
	HEATED OXYGEN SENSOR-2 (IF EQUIPPED)	For detecting deterioration of three way catalytic converter											<input type="radio"/>		
	IAT SENSOR		<input type="radio"/>		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>		
	ECT SENSOR		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>		<input type="radio"/>
	TP SENSOR		<input type="radio"/>		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>	<input type="radio"/>		<input type="radio"/>
	MAP SENSOR		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>			<input type="radio"/>		
	CMP SENSOR	<input type="radio"/>	<input type="radio"/>			<input type="radio"/>							<input type="radio"/>		
	CKP SENSOR	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>	<input type="radio"/>		
	TEST SWITCH TERMINAL(VEHICLE WITHOUT EGR)		<input type="radio"/>		<input type="radio"/>	<input type="radio"/>									
	KNOCK SENSOR (VEHICLE WITH EGR)					<input type="radio"/>							<input type="radio"/>		

6E1-10 ENGINE AND EMISSION CONTROL SYSTEM (M13 AND M16 ENGINES)

1. CKP sensor	22. A/C condenser fan relay	43. Monitor connector (vehicle without immobilizer indicator lamp)
2. CMP sensor	23. A/C condenser fan motor	44. Ignition coil assembly (for No.1 and No.4 spark plugs)
3. VSS	24. A/C compressor relay	45. Ignition coil assembly (for No.2 and No.3 spark plugs)
4. MAP sensor	25. A/C compressor magnet clutch	46. Stop lamp switch
5. Knock sensor (if equipped)	26. Power steering pressure switch	47. Stop lamp
6. TP sensor	27. Generator	48. Lighting switch
7. ECT sensor	28. Immobilizer control module (if equipped)	49. Position lamp
8. IAT sensor	29. Data link connector	50. Rear defogger switch
9. Heated oxygen sensor-1 (if equipped)	30. Injector No.1	51. Rear defogger
10. Heated oxygen sensor-2 (if equipped)	31. Injector No.2	52. Ignition switch
11. A/C evaporator outlet air temp. sensor	32. Injector No.3	53. Main relay
12. A/C evaporator inlet air temp. sensor	33. Injector No.4	54. Transmission range switch (A/T)
13. Fuel level sensor (vehicle with immobilizer indicator lamp)	34. IAC valve	55. Starting motor
14. TCM (A/T)	35. EVAP canister purge valve	56. Shield wire
15. Transmission range switch (A/T)	36. Fuel pump relay	57. Main fuse
16. ABS control module	37. Fuel pump	58. Barometric pressure sensor
17. CO adjusting resistor (if equipped)	38. Radiator fan relay	59. Immobilizer indicator lamp (if equipped)
18. Blower fan motor	39. Radiator fan motor	60. Engine ground
19. Blower fan switch	40. EGR valve (if equipped)	61. Body ground
20. A/C switch	41. Malfunction indicator lamp	
21. A/C pressure switch	42. Combination meter	


CONNecTOR	TERMINAL	WIRE COLOR	CIRCUIT	CONNecTOR	TERMINAL	WIRE COLOR	CIRCUIT
C20	1	BLK/ORN	Ground	C21	12	–	–
	2	BLK	Ground		13	WHT	Heated oxygen sensor-2 (if equipped)
	3	BLK	Ground		14	WHT/BLK	A/C evaporator outlet air temp. sensor
	4	BLU/BLK	EVAP canister purge valve		15	PNK/BLK	Test switch terminal (vehicle without immobilizer indicator lamp)
	5	YEL	Power steering pressure switch (if equipped)		16	GRN/BLK	A/C input signal (if equipped)
	6	GRN/RED	Idle air control valve		17	YEL/BLK	Electric load signal (+)
	7	PNK/BLK	Heater of HO2S-1 (vehicle with EGR)		18	BRN	Radiator fan relay 1
	8	BLU/GRN	Fuel injector No.4		19	PNK	Immobilizer indicator lamp (if equipped)
	9	BLU/YEL	Fuel injector No.1		20	ORN	Sensor ground (vehicle body)
	10	ORN	Sensor ground		21	–	–
	11	BLU	Camshaft position sensor		22	–	–
	12	RED/BLU	Generator control signal		23	BLK/WHT	Ignition switch
	13	WHT	Heated oxygen sensor-1 (vehicle with EGR)		24	PPL	Vehicle speed sensor
	14	LT GRN	Engine coolant temperature sensor	G07	1	LT GRN/BLK	Tachometer
	15	LT GRN/BLK	Intake air temperature sensor		2	–	–
	16	GRY/BLU	Throttle position sensor		3	–	–
	17	GRY/YEL	EGR valve (stepper motor coil 3)		4	–	–
	18	GRY	EGR valve (stepper motor coil 1)		5	GRY/BLK	Engine coolant temp. signal for TCM (A/T)
	19	GRN/WHT	Ignition coil No.2		6	GRY/RED	D-range ID-up signal (A/T)
	20	GRN/YEL	Ignition coil No.1		7	PPL/YEL	Malfunction indicator lamp
	21	BLU/WHT	Fuel injector No.2		8	YEL	Data link connector (SUZUKI serial data line)
	22	GRY/RED	Power source for sensors		9	YEL/GRN	Engine coolant temp. signal for meter
	23	YEL/BLK	Crankshaft position sensor		10	BLU/BLK	Electric load signal (-)
	24	BRN	Fuel pump relay		11	WHT/RED	Power source for back-up
	25	RED	Knock sensor (if equipped)		12	LT GRN/RED	Torque control input signal (A/T)
	26	LT GRN/RED	Manifold absolute pressure sensor		13	BLU	Data link connector
	27	PPL/WHT	Diag. switch terminal (vehicle without immobilizer indicator lamp)		14	PPL/WHT	Throttle opening signal for TCM (A/T)
	28	BRN/WHT	EGR valve (stepper motor coil 4)		15	YEL/RED	Fuel level sensor (gauge) (vehicle with immobilizer indicator lamp)
	29	GRY/WHT	EGR valve (stepper motor coil 2)		16	–	–
	30	BLK/YEL	Engine start switch (Engine start signal)		17	GRN/YEL	Serial data for TCM
	31	BLU/RED	Fuel injector No.3				
C21	1	BRN/YEL	A/C compressor relay (if equipped)				
	2	GRN/WHT	Stop lamp switch				
	3	GRN/RED	Radiator fan relay 2				
	4	PNK/BLU	Heater of HO2S-2 (Vehicle with EGR)				
	5	BLK/RED	Power source				
	6	BLK/RED	Power source				
	7	BLU/ORN	A/C triple pressure switch				
	8	PNK/GRN	Monitor output (vehicle without immobilizer indicator lamp)				
	9	BLU/YEL	A/C condenser fan relay (if equipped)				
	10	BRN/WHT	Main relay				
	11	YEL/WHT	A/C evaporator inlet air temp. sensor				

**NOTE:**

For abbreviation of wire color, refer to Section 0A.

On-vehicle Service

Accelerator cable adjustment



With accelerator pedal depressed fully, check clearance between throttle lever (1) and lever stopper (2) (throttle body) which should be within following specification.

If measured value is out of specification, adjust it to specification with cable adjusting nut (3).

Accelerator cable adjustment clearance (with pedal depressed fully)

“a” : 0.5 – 2.0 mm (0.02 – 0.07 in.)

Idle speed/idle air control (IAC) duty inspection

Before idle speed/IAC duty check, make sure of the following.


- Lead wires and hoses of Electronic Fuel Injection and engine emission control systems are connected securely.
- Accelerator cable has some play, that is, it is not tight.
- Valve lash is checked and adjusted according to maintenance schedule.
- Ignition timing is within specification.
- All accessories (wipers, heater, lights, A/C, etc.) are out of service.
- Air cleaner has been properly installed and is in good condition.
- No abnormal air inhaling from air intake system.

After above items are all confirmed, check idle speed and IAC duty as follows.


NOTE:

Before starting engine, place transmission gear shift lever in “Neutral” (shift selector lever to “P” range for A/T vehicle), and set parking brake and block drive wheels.

[A]



[B]



- 1) Connect SUZUKI scan tool to DLC (1) with ignition switch OFF, if it is available.
- 2) Warm up engine to normal operating temperature.
- 3) Check engine idle speed and "IAC duty" as follows :

When using SUZUKI scan tool :

- a) Select "Data List" mode on scan tool to check "IAC duty".

(A) : SUZUKI scan tool

[A] : When using SUZUKI scan tool

[B] : When using duty meter (Vehicle without immobilizer indicator lamp)
--

When using duty meter (vehicle without immobilizer indicator lamp) :

NOTE:

IAC duty can be checked using monitor connector only for vehicle not equipped with immobilizer indicator lamp.

- b) Set tachometer.
- c) Using service wire (2), ground "Diag. switch terminal" (4) in monitor connector (3) and connect duty meter between "Duty output terminal" (5) and "Ground terminal" (6) of monitor connector (3).
- 4) If duty and/or idle speed is out of specifications, inspect idle air control system referring to Diagnostic Flow Table B-4 IDLE AIR CONTROL SYSTEM CHECK in Section 6.

Engine idle speed and IAC duty

	A/C OFF	A/C ON
M/T vehicle	700 ± 50 r/min (rpm) 5 – 25 %	850 ± 50 r/min (rpm)
A/T vehicle at P/N range	750 ± 50 r/min (rpm) 5 – 25 %	850 ± 50 r/min (rpm)

NOTE:

Above duty values are ON duty (low voltage rate) meter indications.

- 5) Remove service wire from monitor connector (1).
- 6) Check that specified engine idle speed is obtained with A/C ON if vehicle is equipped with A/C.
If not, check A/C ON signal circuit and idle air control system, referring to Table B-5 A/C Signal Circuit Check and Table B-4 Idle Air Control System Check in Section 6.

Idle mixture inspection / adjustment (vehicle without heated oxygen sensor)

All vehicles not equipped with heated oxygen sensor are shipped with their CO % factory adjusted as follows.

Engine idle mixture (CO %)

0.5 – 1.5 % at specified idle speed

Idle mixture adjustment should never be changed from the original factory setting. However, if during diagnosis, the check indicates idle mixture to be the cause of a driver performance complaint or emission failure, the idle mixture can be adjusted using the following procedures.


NOTE:

For this inspection and adjustment, exhaust gas tester (CO meter) and engine tachometer are necessary.

- 1) Check idle speed according to "Idle Speed Inspection" section.
- 2) Using exhaust gas tester, check that idle mixture CO % is within above specification. If it is out of specification, adjust it to specification by turning resistor knob.

NOTE:

Turning CO adjusting resistor knob to "A" increases CO % (A/F mixture becomes rich) and turning it to "B" decreases CO % (A/F mixture becomes lean).




1. CO adjusting resistor

- 3) If idle mixture has been adjusted, confirm that idle speed is within specification.


Air Intake System

Throttle body




1. Throttle body	4. Gasket	7. TP sensor screws
2. Throttle stop screw	5. Idle air control valve	Tightening torque
3. TP sensor	6. IAC valve screws	Do not reuse.

ON-VEHICLE INSPECTION




- Check that throttle valve lever (1) moves smoothly.

REMOVAL



- 1) Disconnect negative cable at battery.
- 2) Drain cooling system.
- 3) Disconnect accelerator cable (1) from throttle valve lever.
- 4) Disconnect IAT sensor connector and remove air cleaner assembly with air cleaner outlet hose.



- 5) Disconnect electric connector from TP sensor (1) and IAC valve (2).
- 6) Remove throttle body from intake manifold.
- 7) Disconnect engine coolant hoses from throttle body.

DISASSEMBLY

Remove TP sensor and IAC valve from throttle body.

NOTE:


While disassembling and assembling throttle body, use special care not to deform levers on throttle valve shaft or cause damage to any other parts.

CLEANING

Clean throttle body bore (1) and idle air passage (2) by blowing compressed air.

NOTE:

TP sensor, idle air control valve or other components containing rubber must not be placed in a solvent or cleaner bath. A chemical reaction will cause these parts to swell, harden or get distorted.





REASSEMBLY

- 1) Install IAC valve to throttle body referring to "IAC valve Installation" section.
- 2) Install TP sensor to throttle body referring to "TP sensor Installation" section.

INSTALLATION

- 1) Clean mating surfaces and install throttle body gasket to intake manifold.
Use new gasket.
- 2) Connect engine coolant hoses.





- 3) Install throttle body (1) to intake manifold.
- 4) Connect connector to TP sensor (2) and IAC valve (3) securely.
- 5) Connect accelerator cable and adjust cable play to specification.
- 6) Install air cleaner assembly with air cleaner outlet hose and connect IAT sensor connector.
- 7) Refill cooling system.
- 8) Connect negative cable at battery.

Idle air control valve (IAC valve)

REMOVAL


- 1) Remove throttle body from intake manifold referring to "Throttle Body Removal" section.
- 2) Remove IAC valve from throttle body.

INSPECTION

- 1) Connect each connector to IAC valve (1), TP sensor and IAT sensor.
- 2) Check that rotary valve (2) of IAC valve opens and closes once and then stops in about 60 ms as soon as ignition switch is turned ON.

NOTE:

- This check should be performed by two people, one person turns ignition switch ON while the other checks valve operation.
 - As valve operation is momentary, it may be overlooked. To prevent this, perform this operation check 3 times or more continuously.
- If rotary valve of IAC valve does not operate at all, check wire harness for open and short. If wire harness is in good condition, replace IAC valve and recheck.




INSTALLATION

- 1) Install new gasket (2) to IAC valve (1).
- 2) Install IAC valve (1) to throttle body (3).
Tighten IAC valve screws to specified torque.

Tightening torque

IAC valve screw (a) : 3.5 N·m (0.35 kg·m, 2.5 lb-ft)

- 3) Install throttle body to intake manifold referring to "Throttle Body Installation" section.



Fuel Delivery System

Fuel pressure inspection


WARNING:

Be sure to perform work in a well-ventilated area and away from any open flames, or there is a risk of a fire breaking out.

- 1) Relieve fuel pressure in fuel feed line referring to “Fuel Pressure Relief Procedure” in Section 6.
- 2) Disconnect fuel feed hose from fuel delivery pipe.

CAUTION:

A small amount of fuel may be released when fuel hose is disconnected. Place container under the joint with a shop cloth so that released fuel is caught in container or absorbed in cloth. Place that cloth in an approved container.



- 3) Connect special tools and hose between fuel delivery pipe and fuel feed hose (1) as shown in figure, and clamp hoses securely to ensure no leaks occur during checking.

Special tool

(A) : 09912-58441

(B) : 09912-58431

(C) : 09912-58490


- 4) Check that battery voltage is above 11 V.

- 5) Turn ignition switch ON to operate fuel pump and after 2 seconds turn it OFF. Repeat this 3 or 4 times and then check fuel pressure.

Fuel pressure specification

CONDITION	FUEL PRESSURE
With fuel pump operating and engine stopped	270 – 310 kPa (2.7 – 3.1 kg/cm ² , 38.4 – 44.0 psi)
At specified idle speed	
With 1 min. after engine (fuel pump) stop (Pressure reduces as time passes)	over 250 kPa (2.5 kg/cm ² , 35.6 psi)

- 6) Start engine and warm it up to normal operating temperature.
- 7) Measure fuel pressure at idling.
If measured pressure does not satisfy specification, refer to "Diagnostic Flow Table B-3" in section 6 and check each possibly defective part. Replace if found defective.



- 8) After checking fuel pressure, remove fuel pressure gauge.

CAUTION:

As fuel feed line is still under high fuel pressure, make sure to release fuel pressure according to following procedures.

- Place fuel container under joint.
- Cover joint with rag and loosen joint nut slowly to release fuel pressure gradually.


- 9) Remove special tools from fuel delivery pipe.
- 10) Connect fuel feed hose to fuel delivery pipe and clamp it securely.
- 11) With engine "OFF" and ignition switch "ON", check for fuel leaks.

Fuel pump

ON-VEHICLE INSPECTION

CAUTION:


When fuel filler cap is removed in any procedure, work must be done in a well-ventilated area, keep away from any open flames and without smoking.



- 1) Remove filler cap and turn ignition switch ON. Then fuel pump operating sound should be heard from fuel filler for about 2 seconds and stop. Be sure to reinstall fuel filler cap after checking.

If above check result is not satisfactory, advance to "Diagnostic Flow Table B-2".

- | |
|--------------------|
| 1. Fuel filler |
| 2. Ignition switch |



- 2) Turn ignition switch OFF and leave over 10 minutes as it is.
- 3) Fuel pressure should be felt at fuel feed hose (1) for about 2 seconds after ignition switch ON.
If fuel pressure is not felt, advance to "Diagnostic Flow Table B-3".

REMOVAL

Remove fuel tank from body according to procedure described in Section 6C and remove fuel pump from fuel tank.

INSPECTION

Check fuel pump filter for evidence of dirt and contamination. If present, clean and check for presence of dirt in fuel tank.

INSTALLATION

- 1) Install fuel pump to its bracket.
- 2) Install fuel pump to fuel tank and then install fuel tank to body according to procedure described in Section 6C.

Fuel pressure regulator

ON-VEHICLE INSPECTION


Perform fuel pressure inspection according to procedure described in "Fuel Pressure Inspection".

REMOVAL


- 1) Relieve fuel pressure according to procedure described on Section 6.
- 2) Disconnect negative cable at battery.
- 3) Disconnect vacuum hose (1) from fuel pressure regulator (2).
- 4) Remove fuel pressure regulator from fuel delivery pipe.

CAUTION:

A small amount of fuel may be released when it is from delivery pipe
Place a shop cloth under delivery pipe so that released fuel is absorbed in it.



- 5) Disconnect fuel return hose (3) from fuel pressure regulator.



INSTALLATION

For installation, reverse removal procedure and note following precautions.

- Use new O-ring (1).
- Apply thin coat of gasoline to O-ring to facilitate installation.
- Tighten fuel pressure regulator bolts to specified torque.

Tightening torque


Fuel pressure regulator bolts

(a) : 10 N·m (1.0 kg-m, 7.5 lb-ft)

- With engine "OFF" and the ignition switch ON position, check for fuel leaks around fuel line connection.


Fuel injector

ON-VEHICLE INSPECTION



- 1) Using sound scope (1) or such, check operating sound of injector (2) when engine is running or cranking. Cycle of operating sound should vary according to engine speed.

If no sound or an unusual sound is heard, check injector circuit (wire or connector) or injector (2).




- 2) Disconnect connector (1) from injector, connect ohmmeter between terminals of injector and check resistance. If resistance is out of specification, replace.

Resistance of fuel injector

: 11.3 – 13.8 Ω at 20°C (68°F)

- 3) Connect connector (1) to injector securely.

REMOVAL



- 1) Relieve fuel pressure according to procedure described in Section 6.
- 2) Disconnect negative cable at battery.
- 3) Disconnect fuel injector couplers and release wire harness from clamps.
- 4) Remove clamp bolt for fuel feed pipe and return pipe.
- 5) Remove fuel delivery pipe bolts (2).
- 6) Remove fuel injector(s) (3).

CAUTION:


A small amount of fuel may come out after removal of fuel injectors, cover them with shop cloth.

1. Fuel delivery pipe

INSPECTION

WARNING:

**As fuel is injected in this inspection, perform in a well ventilated area and away from open flames.
Use special care to prevent sparking when connecting and disconnecting test lead to and from battery.**



- 1) Install injector (3) and fuel pressure regulator (4) to special tool (injector checking tool).

Special tool

(A) : 09912-58421

- 2) Connect special tools (hose and attachment) to fuel feed hose (1) of vehicle.

Special tool



(B) : 09912-58431

- 3) Connect special tool (test lead) to injector.

Special tool

(C) : 09930-88530

2. Fuel return line



- 4) Install suitable vinyl tube onto injector nozzle to prevent fuel from splashing out when injecting.
- 5) Put graduated cylinder under injector as shown.
- 6) Operate fuel pump and apply fuel pressure to injector as follows:

When using SUZUKI scan tool :

- a) Connect SUZUKI scan tool to DLC with ignition switch OFF.
- b) Turn ignition switch ON, clear DTC and select "MISC TEST" mode on SUZUKI scan tool.
- c) Turn fuel pump ON by using SUZUKI scan tool.

(A) : SUZUKI scan tool

Without using SUZUKI scan tool :

- a) Remove fuel pump relay from connector.
- b) Connect two terminals of relay connector using service wire (1) as shown in figure.

CAUTION:

Check to make sure that connection is made between correct terminals. Wrong connection can cause damage to ECM, wire harness, etc.

- c) Turn ignition switch ON.
- 7) Apply battery voltage (3) to injector (2) for 15 seconds and measure injected fuel volume with graduated cylinder. Test each injector two or three times. If not within specification, replace injector.

Injected fuel volume

: 43 – 47 cc/15 sec. (1.45/1.51 – 1.58/ 1.65 US/Imp. oz/15 sec.)


4. Keep as far apart as possible
[A] : When using SUZUKI scan tool
[B] : When not using SUZUKI scan tool

- 8) Check fuel leakage from injector nozzle. Do not operate injector for this check (but fuel pump should be at work). If fuel leaks (1) more than following specifications, replace.

Fuel leakage (1)

: Less than 1 drop/min.

INSTALLATION



For installation, reverse removal procedure and note following precautions.

- Replace injector O-ring (1) with new one using care not to damage it.
- Check if cushion (2) is scored or damaged. If it is, replace with new one.
- Apply thin coat of fuel to O-rings (1) and then install injectors (3) into delivery pipe (4) and intake manifold. Make sure that injectors (3) rotate smoothly (6). If not, probable cause is incorrect installation of O-ring (1). Replace O-ring (1) with new one.
- Tighten delivery pipe bolts (5) and make sure that injectors (3) rotate smoothly (6).

Tightening torque

Delivery pipe bolts (a) : 28 N·m (2.8 kg-m, 20.5 lb-ft)

- After installation, with engine "OFF" and ignition switch "ON", check for fuel leaks around fuel line connection.

Electronic Control System

Engine control module (ECM)

CAUTION:

As ECM consists of precision parts, be careful not to expose it to excessive shock.


REMOVAL

- 1) Disconnect negative cable at battery.
- 2) Disable air bag system, referring to "DISABLING AIR BAG SYSTEM" in Section 10B if equipped.
- 3) Disconnect ECM (1) connectors.
- 4) Remove bolt and nuts, remove ECM.

INSTALLATION

Reverse removal procedure noting the following:

- Connect connectors to ECM securely.



Manifold absolute pressure sensor (MAP sensor)

INSPECTION

Check MAP sensor referring to "MAP Sensor Individual Check" in DTC P0105 (No.11) Flow Table in Section 6. If malfunction is found, replace.

Throttle position sensor (TP sensor)

INSPECTION

- 1) Disconnect negative cable at battery and connector from IAT sensor.
- 2) Remove air cleaner assembly with air cleaner outlet hose and disconnect TP sensor connector.
- 3) Using ohmmeter, check resistance between terminals under each condition given in table below.
If check result is not satisfactory, replace TP sensor.

TP sensor resistance


TERMINALS	RESISTANCE
Between terminals 1 and 3	4.0 – 6.0 kΩ
Between terminals 2 and 3	20 Ω – 6.0 kΩ, varying according to throttle valve opening.

NOTE:

There should be more than 2 kΩ resistance difference between when throttle valve is at idle position and when it is fully open.

- 4) Connect TP sensor connector securely.
- 5) Connect negative cable to battery.

1. Reference voltage terminal
2. Output voltage terminal
3. Ground terminal



REMOVAL

- 1) Disconnect negative cable at battery.
- 2) Remove throttle body from intake manifold referring to “Throttle Body Removal” in this section.
- 3) Remove TP sensor from throttle body.


INSTALLATION

- 1) Install TP sensor (1) to throttle body.
Fit TP sensor to throttle body in such way that its holes (3) are a little away from TP sensor screw holes (2) as shown in left figure and turn TP sensor clockwise so that those holes align (3).

Tightening torque


TP sensor screw (a) : 2.5 N·m (0.25 kg·m, 1.8 lb·ft)

- 2) Connect connector to TP sensor securely.
- 3) Connect negative cable to battery.




Intake air temperature sensor (IAT sensor)

REMOVAL



- 1) Disconnect negative cable at battery.
- 2) Disconnect coupler (1) from IAT sensor.
- 3) Remove IAT sensor from air cleaner case (2).


INSPECTION



Immerse temperature sensing part of IAT sensor in water (or ice) and measure resistance between sensor terminals while heating water gradually.

If measured resistance does not show such characteristic as shown in left figure, replace IAT sensor.

INSTALLATION




Reverse removal procedure noting the following.

- Clean mating surfaces of IAT sensor and air cleaner case.
- Connect IAT sensor connector (1) securely.

Engine coolant temperature sensor (ECT sensor)

REMOVAL



- 1) Disconnect negative cable at battery.
- 2) Drain coolant referring to Section 6B.

WARNING:


To help avoid danger of being burned, do not remove radiator cap while engine and radiator are still hot. Scalding fluid and steam can be blown out under pressure if cap is taken off too soon.

- 3) Remove air intake pipe.
- 4) Disconnect connector from ECT sensor.
- 5) Remove ECT sensor (1) from thermostat case.

INSPECTION

Immerse temperature sensing part of ECT sensor (1) in water (or ice) and measure resistance between sensor terminals while heating water gradually.

If measured resistance does not show such characteristic as shown in left figure, replace ECT sensor (1).



INSTALLATION


Reverse removal procedure noting the following:

- Clean mating surfaces of ECT sensor (1) and thermostat case.
- Check O-ring for damage and replace if necessary.
- Tighten ECT sensor (1) to specified torque.

Tightening torque


ECT sensor (a) : 15 N·m (1.5 kg-m, 11.5 lb-ft)

- Connect connector to ECT sensor (1) securely.
- Refill coolant referring to Section 6B.



Heated oxygen sensor (HO2S-1 and HO2S-2)

Oxygen sensor heater inspection



- 1) Disconnect sensor connector.
- 2) Using ohmmeter, measure resistance between terminals "VB" and "GND" of sensor connector.
If found faulty, replace oxygen sensor.

NOTE:

**Temperature of sensor affects resistance value largely.
Make sure that sensor heater is at correct temperature.**

Resistance of oxygen sensor heater

HO2S-1 : 5.0 – 6.4 Ω at 20°C (68°F)

HO2S-2 : 11.7 – 14.3 Ω at 20°C (68°F)


- 3) Connect sensor connector securely.

1. Viewed from terminal side

REMOVAL

WARNING:

To avoid danger of being burned, do not touch exhaust system when system is hot. Oxygen sensor removal should be performed when system is cool.



- 1) Disconnect negative cable at battery.
- 2) For HO2S-1, disconnect connector of heated oxygen sensor and release its wire harness from clamps, then remove front bumper and heat insulator panel.
- 3) For HO2S-2, disconnect connector of heated oxygen sensor and release its wire harness from clamp and hoist vehicle.
- 4) Remove heated oxygen sensor (1) from exhaust manifold or exhaust pipe.

INSTALLATION

Reverse removal procedure noting the following.

- Tighten heated oxygen sensor (1) to specified torque.

Tightening torque

Heated oxygen sensor (a) : 45 N·m (4.5 kg-m, 32.5 lb-ft)

- Connect connector of heated oxygen sensor (1) and clamp wire harness securely.
- After installing heated oxygen sensor (1), start engine and check that no exhaust gas leakage exists.

[A] : HO2S-1

[B] : HO2S-2

Camshaft position sensor

INSPECTION

Check camshaft position sensor referring to DTC P0340 (No.15) Diag. Flow Table in Section 6. If malfunction is found, replace.

REMOVAL

- 1) Disconnect negative cable at battery.
- 2) Disconnect connector from camshaft position sensor.
- 3) Remove camshaft position sensor from cylinder head.

INSTALLATION


- 1) Check that O-ring is free from damage.
- 2) Check that camshaft position sensor and signal rotor teeth are free from any metal particles and damage.
- 3) Install camshaft position sensor to cylinder head.

Tightening torque

Camshaft position sensor bolt

(a) : 10 N·m (1.0 kg·m, 7.5 lb·ft)

- 4) Connect connector to it securely.
- 5) Connect negative cable to battery.



Crankshaft position sensor

INSPECTION



Check crankshaft position sensor referring to step 1 and 2 of DTC P0335 (No.23) Flow Table. If malfunction is found, replace.

REMOVAL

- 1) Disconnect negative cable at battery.
- 2) Remove generator drive belt, loosen pivot bolt and move generator outward.
- 3) Disconnect connector from crankshaft position sensor.
- 4) Remove crankshaft position sensor (1) from cylinder block.

INSTALLATION

- 1) Check to make sure that crankshaft position sensor and pulley teeth are free from any metal particles and damage.
- 2) Install crankshaft position sensor to cylinder block.
- 3) Connect connector to it securely.
- 4) Adjust generator drive belt tension, refer to Section 6B.
- 5) Connect negative cable to battery.



Vehicle speed sensor (VSS)

INSPECTION

Check vehicle speed sensor referring to step 3 of DTC P0500 (No.16) Flow Table. If malfunction is found, replace.

REMOVAL/INSTALLATION

Refer to Section 7A1.

Fuel level sensor (gauge)

INSPECTION

Refer to Section 8.

REMOVAL/INSTALLATION

Refer to Section 6C.

Knock sensor (if equipped)

INSPECTION

Check knock sensor referring to DTC P0325 (No.17) Flow Table. If malfunction is found, replace.


REMOVAL/INSTALLATION

Refer to Section 6A1.

Main relay, fuel pump relay, A/C compressor relay and A/C condenser fan relay

INSPECTION

- 1) Disconnect negative cable at battery.
- 2) Remove main relay (1), fuel pump relay (2), A/C compressor relay (3) and A/C condenser fan relay (4) from vehicle.
- 3) Check that there is no continuity between terminal "C" and "D". If there is continuity, replace relay.
- 4) Connect battery positive (+) terminal to terminal "B" of relay. Connect battery negative (–) terminal "A" of relay. Check continuity between terminal "C" and "D". If there is no continuity when relay is connected to the battery, replace relay.




Fuel cut operation

INSPECTION

NOTE:

Before inspection, check to make sure that gear shift lever is in neutral position (with A/T model, selector lever in "P" range), A/C is OFF and that parking brake lever is pulled all the way up.



- 1) Warm up engine to normal operating temperature.
- 2) While listening to sound of injector (1) by using sound scope (2) or such, increase engine speed to higher than 3,000 r/min.
- 3) Check to make sure that sound to indicate operation of injector stops when throttle valve is closed instantly and it is heard again when engine speed is reduced to less than about 2,000 r/min.

Radiator fan control system

SYSTEM INSPECTION

WARNING:


Keep hands, tools, and clothing away from engine cooling fan to help prevent personal injury. This fan is electric and can come on whether or not the engine is running. The fan can start automatically in response to the ECT sensor with the ignition switch in the "ON" position.

Check system for operation referring to Flow Table B-7 in Section 6.

If radiator fan fails to operate properly, check relay, radiator fan and electrical circuit.


Radiator fan relay No. 1, No. 2 and No.3

INSPECTION




- 1) Disconnect negative cable at battery.
- 2) Remove relay(s) from connector(s).

1.	Radiator fan relay No. 1
2.	Radiator fan relay No. 2
3.	Radiator fan relay No. 3




- 3) Check that there is no continuity between terminal "C" and "D". If there is continuity, replace relay.
- 4) Connect battery positive (+) terminal to terminal "B" of relay. Connect battery negative (-) terminal "A" of relay. Check continuity between terminal "C" and "D". If there is no continuity when relay is connected to the battery, replace relay.

RADIATOR FAN INSPECTION



- 1) Check continuity between each terminals. If there is no continuity, replace radiator fan motor.



- 2) Connect battery to radiator fan motor coupler as shown in figure, then check that the radiator fan motor operates smoothly and that fan speed varies. If radiator fan motor does not operate smoothly, replace motor.

Output signals of throttle valve opening and engine coolant temp. (vehicle with A/T only)

THROTTLE VALVE OPENING SIGNAL INSPECTION

Check throttle valve opening (throttle position) signal referring to step 1 of DTC P1700 (No.32 or 33) Flow Table in Section 7B1. If check result is not satisfactory, check each wire harness, circuit connections and TP sensor.

ENGINE COOLANT TEMP. SIGNAL INSPECTION

Check engine coolant temp. signal referring to step 1 of DTC P1705 (NO.51) Flow Table in Section 7B1.


If check result is not satisfactory, check each wire harness, circuit connection and ECT sensor.

Emission Control System

EGR system

SYSTEM INSPECTION (USING SUZUKI SCAN TOOL)


- 1) Connect SUZUKI scan tool to DLC with ignition switch OFF.
- 2) Turn ignition switch ON and then select "DATA LIST" mode on scan tool.
- 3) Make sure that vehicle condition is as following.
 - Vehicle speed = 0 km/h (0 KPH)
 - Engine speed ≤ 3000 rpm
- 4) Clear DTC by using "CLEAR INFO" mode.
- 5) With engine idling (without depressing accelerator pedal), open EGR valve by using "STEP EGR" mode in "MISC TEST" menu. In this state, according as EGR valve opening increases engine idle speed drops. If not, possible cause is clogged EGR gas passage, stuck or faulty EGR valve, poor performance of ECT sensor or TP sensor or DTC and/or pending DTC is (are) stored in ECM memory.



1. SUZUKI scan tool display
2. EGR valve opening (0: Close, 100: Full Open)

REMOVAL

- 1) Disconnect negative cable at battery.
- 2) Remove air intake pipe.
- 3) Remove EGR pipe.
- 4) Disconnect EGR valve connector.
- 5) Remove EGR valve and gasket from intake manifold.


INSPECTION

- 1) Check resistance between following terminals of EGR valve (1) in each pair.

If found faulty, replace EGR valve assembly.

EGR valve resistance

Terminal	Standard resistance
A – B	20 – 24 Ω
C – B	
F – E	
D – E	



- 2) Remove carbon from EGR valve gas passage.

NOTE:

Do not use any sharp-edged tool to remove carbon. Be careful not to damage or bend EGR valve (1), valve seat (2) and rod (3).

- 3) Inspect valve (2), valve seat and rod for fault, cracks, bend or other damage.

If found faulty, replace EGR valve assembly.


INSTALLATION

Reverse removal procedure noting following.

- Clean mating surface of valve and intake manifold.
- Use new gaskets.

Evaporative emission control system**EVAP CANISTER PURGE INSPECTION****NOTE:**

Before inspection, check to make sure that gear shift lever is in neutral position (with A/T model, selector lever in “P” range) and that parking brake lever is pulled all the way up.




- 1) Hoist vehicle.
- 2) Disconnect purge hose (1) from EVAP canister.
- 3) Place finger against the end of disconnected hose and check that vacuum is not felt there when engine is cool and running at idle speed.

- 4) Connect purge hose to EVAP canister and warm up engine to normal operating temperature.
- 5) Disconnect purge hose from EVAP canister.
- 6) Also check that vacuum is felt when engine is running at idle speed.

If check result is not satisfactory, check vacuum passage, hoses, EVAP canister purge valve, wire harness and ECM.


NOTE:

The EVAP canister purge system does not perform purging (vacuum is not detected at the purge hose) unless the engine is sufficiently warmed up and the heated oxygen sensor is activated fully. Also, when the purge hose is disconnected in Step 5), the air is drawn into the purge line. As a result, ECM detects a change in the purge gas concentration and sometimes stops purging but this indicates nothing abnormal.

VACUUM PASSAGE INSPECTION

Start engine and run it at idle speed. Disconnect vacuum hose (1) from EVAP canister purge valve (2). With finger placed against hose disconnected, check that vacuum is applied.

If it is not applied, clean vacuum passage by blowing compressed air.

VACUUM HOSE INSPECTION

Check hoses for connection, leakage, clog and deterioration. Replace as necessary.

EVAP CANISTER PURGE VALVE INSPECTION


Check EVAP canister purge valve referring to step 1 of DTC P0443 Flow Table in Section 6.

If found malfunction, replace.

EVAP CANISTER INSPECTION

WARNING:

DO NOT SUCK nozzles on EVAP canister. Fuel vapor inside EVAP canister is harmful.



- 1) Check outside of EVAP canister visually.
- 2) Disconnect vacuum hoses from EVAP canister.
- 3) Check that there should be no restriction of flow through purge pipe (1) and air pipe (2) when air is blown (4) into tank pipe (3).

If any faulty condition is found in above inspection, replace.

PCV system


NOTE:

Be sure to check that there is no obstruction in PCV valve or its hoses before checking IAC duty, for obstructed PCV valve or hose hampers its accurate adjustment.

PCV HOSE INSPECTION


Check hoses for connection, leakage, clog and deterioration. Replace as necessary.

PCV VALVE INSPECTION











- 1) Disconnect PCV valve (1) from cylinder head cover and install plug to head cover hole.
- 2) Run engine at idle.
- 3) Place your finger over end of PCV valve (1) to check for vacuum.


If there is no vacuum, check for clogged valve. Replace as necessary.



- 4) After checking vacuum, stop engine and remove PCV valve (1).
Shake valve and listen for the rattle of check needle inside the valve. If valve does not rattle, replace valve.
- 5) After checking, remove plug and install PCV valve (1).

Special Tool

 <p>09912-57610 Checking tool plate</p>	 <p>09912-58421 Checking tool set (See NOTE "A".)</p>	 <p>09912-58431 Pressure hose</p>	 <p>09912-58441 Pressure gauge</p>
 <p>09912-58490 3-way joint & hose</p>	 <p>09930-88530 Injector test lead</p>	 <p>09931-76011 Tech 1A kit (SUZUKI scan tool) (See NOTE "B".)</p>	 <p>Mass storage cartridge for Tech 1A</p>

**NOTE:**

- **“A”:** This kit includes the following items.
 1. Tool body & washer, 2. Body plug, 3. Body attachment-1, 4. Holder, 5. Return hose & clamp, 6. Body attachment-2 & washer, 7. Hose attachment-1, 8. Hose attachment-2
- **“B”:** This kit includes the following items and substitutes for the Tech 2 kit.
 1. Storage case, 2. Operator's manual, 3. Tech 1A, 4. DLC cable (14/26 pin, 09931-76040), 5. Test lead/probe, 6. Power source cable, 7. DLC cable adaptor, 8. Self-test adaptor
- **“C” :** This kit includes the following items and substitutes for the Tech 1A kit.
 1. Tech 2, 2. PCMCIA card, 3. DLC cable, 4. SAE 16/19 adapter, 5. Cigarette cable, 6. DLC loopback adapter, 7. Battery power cable, 8. RS232 cable, 9. RS232 adaptor, 10. RS232 loopback connector, 11. Storage case, 12. Power supply

Tightening Torque Specification

Fastening part	Tightening torque		
	N•m	kg-m	lb-ft
TP sensor screw	2.5	0.25	1.8
IAC valve screw	3.5	0.35	2.5
ECT sensor	15	1.5	11.5
Heated oxygen sensor-1 and -2	45	4.5	32.5
Camshaft position sensor bolt	10	1.0	7.5
Fuel pressure regulator bolts	10	1.0	7.5
Delivery pipe bolts	28	2.8	20.5

SECTION 6F1

IGNITION SYSTEM (ELECTRONIC IGNITION SYSTEM)

WARNING:

For vehicles equipped with Supplemental Restraint (Air Bag) System:

- Service on and around the air bag system components or wiring must be performed only by an authorized SUZUKI dealer. Refer to “Air Bag System Components and Wiring Location View” under “General Description” in air bag system section in order to confirm whether you are performing service on or near the air bag system components or wiring. Please observe all WARNINGS and “Service Precautions” under “On-Vehicle Service” in air bag system section before performing service on or around the air bag system components or wiring. Failure to follow WARNINGS could result in unintentional activation of the system or could render the system inoperative. Either of these two conditions may result in severe injury.
- Technical service work must be started at least 90 seconds after the ignition switch is turned to the “LOCK” position and the negative cable is disconnected from the battery. Otherwise, the system may be activated by reserve energy in the Sensing and Diagnostic Module (SDM).

CONTENTS

6F1

General Description	6F1-2	Ignition Coil Assembly (Including Igniter)	6F1-7
Diagnosis	6F1-3	Crankshaft Position Sensor (CKP Sensor)	6F1-7
On-vehicle Service	6F1-5	Ignition Timing.....	6F1-8
Ignition Spark Test	6F1-5	Special Tool	6F1-9
High-tension Cords	6F1-5		
Spark Plugs	6F1-6		

General Description

The ignition system is an electronic (distributorless) ignition system. It consists of the parts as described below and has an electronic ignition control system.

- ECM

It detects the engine and vehicle conditions through the signals from the sensors, determines the most suitable ignition timing and time for electricity to flow to the primary coil and sends a signal to the ignitor (power unit) in the ignition coil assembly.

- Ignition coil assembly (including an igniter)

The ignition coil assembly has a built-in ignitor which turns ON and OFF the current flow to the primary coil according to the signal from ECM. When the current flow to the primary coil is turned OFF, a high voltage is induced in the secondary coil.

- High tension cords and spark plugs.

- CMP sensor (Camshaft position sensor) and CKP sensor (Crankshaft position sensor)


Using signals from these sensors, ECM identifies the specific cylinder whose piston is in the compression stroke, detects the crank angle and adjusts initial ignition timing automatically.

- TP sensor, ECT sensor, MAP sensor and other sensors/switches

Refer to Section 6E1 for details.


Although this ignition system does not have a distributor, it has two ignition coil assemblies (one is for No.1 and No.4 spark plugs and the other is for No.2 and No.3 spark plugs). When an ignition signal is sent from ECM to the ignitor in the ignition coil assembly for No.1 and No.4 spark plugs, a high voltage is induced in the secondary coil and that passes through the high-tension cords and causes No.1 and No.4 spark plugs to spark simultaneously. Likewise, when an ignition signal is sent to the ignitor in the other ignition coil assembly, No.2 and No.3 spark plugs spark simultaneously.

System Components



1. ECM	6. MAP sensor	11. Transmission range switch (A/T)
2. Ignition coil assembly for No.1 and No.4 spark plugs	7. ECT sensor	12. High-tension cords
3. Ignition coil assembly for No.2 and No.3 spark plugs	8. IAT sensor	13. Monitor connector
4. CMP sensor	9. TP sensor	14. Knock sensor (if equipped)
5. CKP sensor	10. VSS	15. Data link connector

System Wiring Diagram



1. Ignition switch	7. No.1 spark plug
2. Main relay	8. No.2 spark plug
3. Ignition coil assembly for No.1 and No.4 spark plugs	9. No.3 spark plug
4. Ignition coil assembly for No.2 and No.3 spark plugs	10. No.4 spark plug
5. CMP sensor	11. Sensed information (MAP sensor, ECT sensor, IAT sensor, TP sensor, Knock sensor (if equipped), VSS, Park/Neutral position signal, Electric load signal, Engine start signal, Test switch terminal (Vehicle without immobilizer indicator lamp))
6. CKP sensor	12. ECM

Diagnosis

Condition	Possible Cause	Correction
Engine cranks, but will not start or hard to start (No spark)	Blown fuse for ignition coil	Replace.
	Loose connection or disconnection of lead wire or high-tension cord(s)	Connect securely.
	Faulty high-tension cord(s)	Replace.
	Faulty spark plug(s)	Adjust, clean or replace.
	Faulty ignition coil	Replace ignition coil assembly.
	Faulty CKP sensor or CKP sensor plate	Clean, tighten or replace.
	Faulty ECM	Replace.
Poor fuel economy or engine performance	Incorrect ignition timing	Check related sensors and CKP sensor plate.
	Faulty spark plug(s) or high-tension cord(s)	Adjust, clean or replace.
	Faulty ignition coil assembly	Replace.
	Faulty CKP sensor or CKP sensor plate	Clean, tighten or replace.
	Faulty ECM	Replace.

IGNITION SYSTEM DIAGNOSTIC FLOW TABLE

Step	Action	Yes	No
1	Was "ENGINE DIAG. FLOW TABLE" in Section 6 performed?	Go to Step 2.	Go to "ENGINE DIAG. FLOW TABLE" in Section 6.
2	Ignition Spark Test 1) Check all spark plugs for condition and type referring to "Spark Plugs" section. 2) If OK, perform ignition spark test, referring to "Ignition Spark Test" in this section. Is spark emitted from all spark plugs?	Go to Step 11.	Go to Step 3.
3	Diagnostic Trouble Code (DTC) Check Is DTC stored in ECM?	Go to applicable DTC Diag. Flow Table in Section 6.	Go to Step 4.
4	Electrical Connection Check 1) Check ignition coil assemblies and high-tension cords for electrical connection. Are they connected securely?	Go to Step 5.	Connect securely.
5	High-tension Cords Check 1) Check high-tension cord for resistance referring to "High-Tension Cords" in this section. Is check result satisfactory?	Go to Step 6.	Replace high-tension cord(s).
6	Ignition Coil Assembly Power Supply and Ground Circuit Check 1) Check ignition coil assembly power supply and ground circuits for open and short. Are circuits in good condition?	Go to Step 7.	Repair or replace.
7	Ignition Coil Assembly Check 1) Check ignition coil for resistance referring to "Ignition Coil Assembly" in this section. Is check result satisfactory?	Go to Step 8.	Replace ignition coil assembly.
8	Crankshaft Position (CKP) Sensor Check 1) Check crankshaft position sensor referring to Step 3 and 4 of "DTC P0335 (No.23) Diag. Flow Table" in Section 6. Is check result satisfactory?	Go to Step 9.	Tighten CKP sensor bolt, replace CKP sensor or CKP sensor plate.
9	Ignition Trigger Signal Circuit Check 1) Check ignition trigger signal wire for open, short and poor connection. Is circuit in good condition?	Go to Step 10.	Repair or replace.
10	A Known-good Ignition Coil Assembly Substitution 1) Substitute a known-good ignition coil assembly and then repeat Step 2. Is check result of Step 2 satisfactory?	Go to Step 11.	Substitute a known-good ECM and then repeat Step 2.
11	Ignition Timing Check 1) Check initial ignition timing and ignition timing advance referring to "Ignition Timing" in this section. Is check result satisfactory?	System is in good condition.	Check CKP sensor, CKP sensor plate and input signals related to this system.


On-vehicle Service

Ignition Spark Test

- 1) Disconnect all injector couplers from injectors.

WARNING:


Without disconnection of injector couplers, combustible gas may come out from spark plug holes during this test and may get ignited in engine room.



- 2) Remove spark plug and check it for condition and type referring to "Spark Plugs" in this section.
- 3) If OK, connect ignition coil coupler to ignition coil assembly and connect spark plug to ignition coil assembly or high-tension cord. Ground spark plug.
- 4) Crank engine and check if each spark plug sparks.
- 5) If no spark is emitted, inspect the related parts as described under "Diagnosis" earlier in this section.


High-tension Cords

- 1) Remove cylinder head upper cover.
- 2) Disconnect high-tension cords (2) from ignition coil assemblies (1) while gripping each cap.
- 3) Pull out high-tension cords from spark plugs while gripping each cap.



CAUTION:

- Removal of high-tension cords together with clamps will be recommended so as not to damage their inside wire (resistive conductor).
- For the same reason, pull out each connection by gripping cap portion.




- 4) Measure resistance of high-tension cord (1) by using ohmmeter.

High-tension cord resistance

: 4 -10 kΩ/m (1.2 - 3.0 kΩ/ft)

- 5) If resistance exceeds specification, replace high-tension cord(s).



- 6) Install high-tension cords (2) to spark plugs and ignition coil assemblies (1) while gripping each cap.

CAUTION:

- Never attempt to use metal conductor high-tension cords as replacing parts.
- Insert each cap portion fully when installing high-tension cords.

Spark Plugs

- 1) Remove air intake pipe and cylinder head upper cover.
- 2) Pull out high-tension cords by gripping their caps and then remove ignition coil assemblies referring to "IGNITION COIL ASSEMBLY" in this section.
- 3) Remove spark plugs.
- 4) Inspect them for:
 - Electrode wear
 - Carbon deposits
 - Insulator damage
- 5) If any abnormality is found, adjust air gap, clean with spark plug cleaner or replace them with specified new plugs.
For iridium/platinum spark plugs, replace them with new plugs.

Spark plug air gap

"a" : 1.0 - 1.1 mm (0.040 - 0.043 in.)

Spark plug type

NGK : BKR6E-11, IFR6E11


DENSO : K20PR-U11

NOTE:

NGK IFR6E11 is highly recommended for better engine starting performance under -25°C(-13°F).

CAUTION:

- When servicing the iridium/platinum spark plugs (slender center electrode type plugs), do not touch the center electrode to avoid damage to it. The electrode is not strong enough against mechanical force as it is slender and its material is not mechanically tough.
- Do not clean or adjust gap for the iridium/platinum spark plugs.



- 6) Install spark plugs and torque them to specification.

Tightening torque



Spark plug : 25 N·m (2.5 kg-m, 18.0 lb-ft)

- 7) Install ignition coil assemblies referring to "IGNITION COIL ASSEMBLY" in this section.
- 8) Install high-tension cords securely by gripping their caps.
- 9) Install cylinder head upper cover.

Ignition Coil Assembly (Including Igniter)

Inspection

- 1) Disconnect negative cable at battery.
- 2) Remove cylinder head upper cover.
- 3) Disconnect ignition coil coupler.
- 4) Disconnect high-tension cord (3) from ignition coil assembly (2).
- 5) Remove ignition coil bolts (1) and then pull out ignition coil assembly.



- 6) Measure secondary coil for resistance.
If resistance is out of specification, replace ignition coil assembly.

Secondary coil resistance

: 7.6 - 10.2 kΩ at 20°C, 68°F

- 7) Install ignition coil assembly.
- 8) Tighten ignition coil bolts, and then connect ignition coil coupler.
- 9) Install high-tension cord to ignition coil assembly while gripping its cap.
- 10) Install cylinder head upper cover.

Crankshaft Position Sensor (CKP Sensor)


Refer to Section 6E1 for removal, inspection and installation.

Ignition Timing

NOTE:

- Ignition timing is not adjustable. If ignition timing is out of specification, check system related parts.
- Before starting engine, place transmission gear shift lever in "Neutral" (shift selector lever to "P" range for A/T model), and set parking brake.

INSPECTION




- 1) When using SUZUKI scan tool, connect SUZUKI scan tool to DLC with ignition switch OFF.


Special tool

(A) : SUZUKI scan tool

- 2) Start engine and warm it up to normal operating temperature.
- 3) Make sure that all of electrical loads except ignition are switched off.
- 4) Check to be sure that idle speed is within specification.
(Refer to Section 6E1.)



- 5) Fix ignition timing to initial one as follows.
Select "MISC" mode on SUZUKI scan tool and fix ignition timing to initial one.
If scan tool is not available (vehicle without immobilizer indicator lamp), connect D and E terminals of monitor connector (1) by using service wire so that ignition timing is fixed to initial one.



- 6) Using timing light (1), check that ignition timing is within specification.

Initial ignition timing (test switch terminal grounded or fixed with SUZUKI scan tool)





: $5 \pm 3^\circ$ BTDC at idle speed

Ignition order

: 1-3-4-2

- 7) If ignition timing is out of specification, check the followings:
 - CKP sensor
 - CKP sensor plate
 - TP sensor
 - Test switch signal circuit
 - VSS
 - Timing chain cover installation
- 8) After checking Initial Ignition Timing, release ignition timing fixation by using SUZUKI scan tool or disconnect service wire from monitor connector.
- 9) With engine idling (test switch terminal ungrounded, throttle opening at closed position and car stopped), check that ignition timing is about 3°–17° BTDC. (Constant variation within a few degrees from 3°–17° indicates no abnormality but proves operation of electronic timing control system.) Also, check that increasing engine speed advances ignition timing. If above check results are not satisfactory, check CKP sensor, test switch terminal circuit and ECM.

Special Tool

 <p>09931-76011 Tech 1A kit (SUZUKI scan tool) (See NOTE "A".)</p>	 <p>Mass storage cartridge for Tech 1A</p>	 <p>09931-76030 16/14 pin DLC adapter for Tech 1A</p>	 <p>Tech 2 kit (SUZUKI scan tool) (See NOTE "B".)</p>
---	---	---	--

NOTE:

- **"A"** : This kit includes the following items and substitutes for the Tech 2 kit.
 1. Storage case, 2. Operator's manual, 3. Tech 1A, 4. DLC cable (14/26 pin, 09931-76040), 5. Test lead/probe, 6. Power source cable, 7. DLC cable adaptor, 8. Self-test adaptor
- **"B"** : This kit includes the following items and substitutes for the Tech 1A kit.
 1. Tech 2, 2. PCMCIA card, 3. DLC cable, 4. SAE 16/19 adapter, 5. Cigarette cable, 6. DLC loopback adapter, 7. Battery power cable, 8. RS232 cable, 9. RS232 adaptor, 10. RS232 loopback connector, 11. Storage case, 12. Power supply

SECTION 6G

CRANKING SYSTEM

WARNING:

For vehicles equipped with Supplemental Restraint (Air Bag) System:

- Service on and around the air bag system components or wiring must be performed only by an authorized SUZUKI dealer. Refer to AIR BAG SYSTEM COMPONENTS and WIRING LOCATION VIEW under DIAGNOSIS in air bag system section in order to confirm whether you are performing service on or near the air bag system components or wiring. Please observe all WARNINGS and SERVICE PRECAUTIONS under PRECAUTIONS in air bag system section before performing service on or around the air bag system components or wiring. Failure to follow WARNINGS could result in unintentional activation of the system or could render the system inoperative. Either of these two conditions may result in severe injury.
- Technical service work must be started at least 90 seconds after the ignition switch is turned to the “LOCK” position and the negative cable is disconnected from the battery. Otherwise, the system may be activated by reserve energy in the Sensing and Diagnostic Module (SDM).

NOTE:

Starting motor varies depending on specifications, etc. Therefore, be sure to check model and specification of the vehicle being serviced before replacing parts.


CONTENTS

6G

General Description	6G-2	Starting Motor	6G-5
Cranking Circuit.....	6G-2	Dismounting	6G-5
Diagnosis	6G-2	Remounting.....	6G-5
Diagnosis Table	6G-2	Disassembly and reassembly	6G-6
Performance Test.....	6G-4	Inspection.....	6G-8
Pull-in test.....	6G-4	Specification.....	6G-12
Hold-in test	6G-4	1.0 kW type	6G-12
Plunger and pinion return test	6G-4	1.2 kW type	6G-12
No-load performance test.....	6G-5	1.4 kW type	6G-12
ON-Vehicle Service	6G-5	Required Service Material	6G-13

General Description

Cranking Circuit



1. Pinion drive lever	5. Plunger	9. Blank
2. Pinion & Over-running clutch	6. Magnetic switch contacts	10. A/T: Transmission range switch (shift lever switch)
3. Magnetic switch	7. Pull-in coil	11. Ignition & Starter switch
4. Hold-in coil	8. Starting motor	12. Battery

Diagnosis

Diagnosis Table

Possible symptoms due to starting system trouble would be as follows:

- Starting motor does not run (or runs slowly)
- Starting motor runs but fails to crank engine
- Abnormal noise is heard

Proper diagnosis must be made to determine exactly where the cause of each trouble lies.....in battery, wiring harness, (including starting motor switch), starting motor or engine.

Do not remove motor just because starting motor does not run. Check following items and narrow down scope of possible causes.

- 1) Condition of trouble
- 2) Tightness of battery terminals (including ground cable connection on engine side) and starting motor terminals
- 3) Discharge of battery
- 4) Mounting of starting motor


Condition	Possible Cause	Correction
Motor not running (No operating sound of magnetic switch)	Shift lever switch is not in P or N, or not adjusted (A/T)	Shift in P or N, or adjust switch.
	Battery run down	Recharge battery.
	Battery voltage too low due to battery deterioration	Replace battery.
	Poor contact in battery terminal connection	Retighten or replace.
	Loose grounding cable connection	Retighten.
	Fuse set loose or blown off	Tighten or replace.
	Poor contacting action of ignition switch and magnetic switch	Replace.
	Lead wire coupler loose in place	Retighten.
	Open-circuit between ignition switch and magnetic switch	Repair.
	Open-circuit in pull-in coil	Replace magnetic switch.
	Brushes are seating poorly or worn down	Repair or replace.
	Poor sliding of plunger and/or pinion	Repair.
Motor not running (Operating sound of magnetic switch heard)	Battery run down	Recharge battery.
	Battery voltage too low due to battery deterioration	Replace battery.
	Loose battery cable connections	Retighten.
	Burnt main contact point, or poor contacting action of magnetic switch	Replace magnetic switch.
	Brushes are seating poorly or worn down	Repair or replace.
	Weakened brush spring	Replace.
	Burnt commutator	Replace armature.
	Layer short-circuit of armature	Replace.
Starting motor running but too slow (small torque) (If battery and wiring are satisfactory, inspect starting motor)	Crankshaft rotation obstructed	Repair.
	Insufficient contact of magnetic switch main contacts	Replace magnetic switch.
	Layer short-circuit of armature	Replace.
	Disconnected, burnt or worn commutator	Repair commutator or replace armature.
	Worn brushes	Replace brush.
	Weakened brush springs	Replace spring.
	Burnt or abnormally worn end bush	Replace bush.
Starting motor running, but not cranking engine	Worn pinion tip	Replace over-running clutch.
	Poor sliding of over-running clutch	Repair.
	Over-running clutch slipping	Replace over-running clutch.
	Worn teeth of ring gear	Replace flywheel.
Noise	Abnormally worn bush	Replace bush.
	Worn pinion or worn teeth of ring gear	Replace pinion or flywheel.
	Poor sliding of pinion (failure in return movement)	Repair or replace.
	Worn internal or planetary gear teeth	Replace.
	Lack of oil in each part	Lubricate.
Starting motor does not stop running	Fused contact points of magnetic switch	Replace magnetic switch.
	Short-circuit between turns of magnetic switch coil (layer short-circuit)	Replace magnetic switch.
	Failure of returning action in ignition switch	Replace.

Performance Test

CAUTION:

Each test must be performed within 3 - 5 seconds to avoid coil from burning.

Pull-in test




Connect battery to magnetic switch as shown.
Check that plunger and pinion move outward.
If plunger and pinion don't move, replace magnetic switch.

NOTE:

Before testing, disconnect lead wire from terminal M.


1. Terminal "S"
2. Terminal "M"
3. Lead wire (switch to motor)

Hold-in test




While connected as above with plunger out, disconnect negative lead from terminal "M".
Check that plunger and pinion remain out.
If plunger and pinion return inward, replace magnetic switch.

Plunger and pinion return test



Disconnect negative lead from starting motor body.
Check that plunger and pinion return inward.
If plunger and pinion don't return, replace magnetic switch.

No-load performance test




Connect battery and ammeter to starter as shown. Check that starter rotates smoothly and steadily with pinion moving out. Check that ammeter indicates specified current.

Specified current (No-load performance test)
: 90 A MAX. at 11 V

ON-Vehicle Service

Starting Motor



Dismounting

- 1) Disconnect negative (–) battery lead at battery.
- 2) Disconnect magnetic switch lead wire (1) and battery cable (2) from starting motor terminals.
- 3) Remove starting motor mount bolt (3) and nut (4).
- 4) Remove starting motor (5).

Remounting

Reverse the dismounting procedure.


Tightening torque

Starting motor battery cable nut (a) : 10 N·m (1.0 kg-m, 7.5 lb-ft)


Starting motor mount bolt and nut (b) : 23 N·m (2.3kg-m, 16.5 lb-ft)

1.0 kW TYPE

1.2 kW AND 1.4 kW TYPES




1. Front housing	8. Plunger	15. Planetary gear	22. Rear bush
2. Bush	9. Plate	16. Packing	Tightening torque
3. Snap ring	10. Seal rubber	17. Yoke	Do not reuse.
4. Pinion stop ring	11. Magnetic switch	18. Armature	
5. Pinion gear	12. Ball	19. Brush	
6. Over-running clutch	13. Internal gear	20. Brush holder	
7. Lever	14. Planetary carrier shaft	21. Rear bracket	



Inspection


PLUNGER

Inspect plunger for wear. Replace if necessary.




MAGNETIC SWITCH

Push in plunger and release it. The plunger should return quickly to its original position. Replace if necessary.




Pull-in coil open circuit test

Check for continuity across magnetic switch 'S' terminal (1) and 'M' terminal (2). If no continuity, coil is open and should be replaced.




Hold-in coil open circuit test

Check for continuity across magnetic switch 'S' terminal (1) and coil case. If no continuity, coil is open and should be replaced.



REAR BRACKET BUSH

Inspect bush for wear or damage. Replace if necessary.



BRUSH

- Check brushes for wear.
Measure length of brushes and if below limit, replace brush.

Brush length

	1.0 kW	1.2 kW and 1.4 kW
Standard	14.0 mm (0.55 in.)	12.3 mm (0.48 in.)
Limit	9.0 mm (0.35 in.)	7.0 mm (0.28 in.)


- Install brushes to each brush holder and check for smooth movement.

SPRING

Inspect brush springs for wear, damage or other abnormal conditions. Replace if necessary.

Brush spring tension

	1.0 kW	1.2 kW and 1.4 kW
Standard	1.6 kg (3.53 lb)	2.2 kg (4.85 lb)
Limit	0.9 kg (1.98 lb)	0.6 kg (1.32 lb)




BRUSH HOLDER

- Check movement of brush in brush holder. If brush movement within brush holder is sluggish, check brush holder for distortion and sliding faces for contamination.
Clean or correct as necessary.
- Check for continuity across insulated brush holder (positive side) and grounded brush holder (negative side).
If continuity exists, brush holder is grounded due to defective insulation and should be replaced.


[A]: 1.0 kW

[B]: 1.2 kW and 1.4 kW



ARMATURE

- Inspect commutator for dirt or burn. Correct with sandpaper or lathe, if necessary.



- Check commutator for uneven wear with armature supported on V-blocks. If deflection of dial gauge pointer exceeds limit, repair or replace.


NOTE:

Below specification presupposes that armature is free from bend. Bent armature must be replaced.

Commutator out of round

	1.0 kW	1.2 kW and 1.4 kW
Standard	0.02 mm (0.0008 in.) or less	0.05 mm (0.002 in.) or less
Limit	0.05 mm (0.002 in.)	0.4 mm (0.015 in.)


1. Armature
2. V-block
3. Magnetic stand
4. Dial gauge



- Inspect commutator for wear. If diameter is below limit, replace armature.

Commutator outside diameter


	1.0 kW	1.2 kW and 1.4 kW
Standard	28.0 mm (1.10 in.)	29.4 mm (1.16 in.)
Limit	27.0 mm (1.06in.)	28.8 mm (1.13 in.)




- Inspect commutator for insulator depth. Correct or replace if below limit.

Commutator insulator depth “a”
Standard: 0.4 – 0.6 mm (0.015 – 0.024 in.)
Limit: 0.2 mm (0.008 in.)


1. Commutator segment
2. Insulator



- Check commutator and armature core. If there is continuity, armature is grounded and must be replaced.




- Check for continuity between segments. If there is no continuity at any test point, there is an open circuit and armature must be replaced.




GEARS

Inspect internal gear and planetary gears for wear, damage or other abnormal conditions. Replace if necessary.




PINION AND OVER-RUNNING CLUTCH

- Inspect pinion for wear, damage or other abnormal conditions.
Check that clutch locks up when turned in direction of drive and rotates smoothly in reverse direction. Replace if necessary.



- Inspect spline teeth for wear or damage. Replace if necessary.
Inspect pinion for smooth movement.



FRONT HOUSING NEEDLE BEARING OR BUSH

Inspect needle bearing (for 1.0 kW type) or bush (for 1.2 and 1.4 kW types) for wear or damage. Replace if necessary.

Specification

1.0 kW type

Voltage		12 volts	
Output		1.0 kW	
Rating		30 seconds	
Direction of rotation		Clockwise as viewed from pinion side	
Brush length		Standard: 14.0 mm (0.55 in.)	Limit: 9.0 mm (0.35 in.)
Number of pinion teeth		8	
Performance		Condition	Guarantee
Around at 20°C (68°F)	No load characteristic	11.5 V	90 A maximum 3,000 rpm minimum
	Load characteristic	8.7 V 230 A	6.9 N·m (0.69 kg-m, 5.0 lb-ft) minimum 1130 rpm minimum
	Locked characteristic	2.5 V	325 A maximum 8.2 N·m (0.82 kg-m, 6.0 lb-ft) minimum
	Magnetic switch operating voltage		8 volts maximum

1.2 kW type

Voltage		12 volts	
Output		1.2 kW	
Rating		30 seconds	
Direction of rotation		Clockwise as viewed from pinion side	
Brush length		Standard: 12.3 mm (0.48 in.)	Limit: 7.0 mm (0.27 in.)
Number of pinion teeth		8	
Performance		Condition	Guarantee
Around at 20°C (68°F)	No load characteristic	11.0 V	90 A maximum 2,500 rpm minimum
	Load characteristic	7.5 V 300 A	10.5 N·m (1.05 kg-m, 7.59 lb-ft) minimum 880 rpm minimum
	Locked characteristic	4.0 V	760 A maximum 19.5 N·m (1.95 kg-m, 14.1 lb-ft) minimum
	Magnetic switch operating voltage		8 volts maximum

1.4 kW type

Voltage		12 volts	
Output		1.4 kW	
Rating		30 seconds	
Direction of rotation		Clockwise as viewed from pinion side	
Brush length		Standard: 12.3 mm (0.48 in.)	Limit: 7.0 mm (0.27 in.)
Number of pinion teeth		8	
Performance		Condition	Guarantee
Around at 20°C (68°F)	No load characteristic	11.0 V	90 A maximum 2,400 rpm minimum
	Load characteristic	7.5 V 300 A	10.8 N·m (1.08 kg-m, 8.0 lb-ft) minimum 870 rpm minimum
	Locked characteristic	3.0 V	840 A maximum 19.8 N·m (1.98 kg-m, 14.5 lb-ft) minimum
	Magnetic switch operating voltage		8 volts maximum

Required Service Material

Material	Recommended SUZUKI product (Part Number)	Use
Lithium grease	SUZUKI SUPER GREASE A (99000-25010)	<ul style="list-style-type: none">• Front and rear bush (for 1.2 kW and 1.4 kW types only)• Plunger• Pinion drive lever• Internal gear• Planetary carrier shaft• Planetary gear• Ball

SECTION 6H

CHARGING SYSTEM

WARNING:

For vehicles equipped with Supplemental Restraint (Air Bag) System:

- Service on and around the air bag system components or wiring must be performed only by an authorized SUZUKI dealer. Refer to “Air Bag System Components and Wiring Location View” under “General Description” in air bag system section in order to confirm whether you are performing service on or near the air bag system components or wiring. Please observe all WARNINGS and “Service Precautions” under “On-Vehicle Service” in air bag system section before performing service on or around the air bag system components or wiring. Failure to follow WARNINGS could result in unintentional activation of the system or could render the system inoperative. Either of these two conditions may result in severe injury.
- Technical service work must be started at least 90 seconds after the ignition switch is turned to the “LOCK” position and the negative cable is disconnected from the battery. Otherwise, the system may be activated by reserve energy in the Sensing and Diagnostic Module (SDM).

CONTENTS

General Description	6H-2	On-Vehicle Service	6H-9
Battery	6H-2	Battery	6H-9
Carrier and hold-down	6H-2	Jump starting in case of emergency	6H-9
Electrolyte freezing	6H-2	Dismounting	6H-10
Sulfation	6H-2	Handling	6H-10
Built-in indicator (if equipped)	6H-2	Remounting	6H-10
Care of battery	6H-3	Generator	6H-10
Generator	6H-4	Generator belt	6H-10
Diagnosis	6H-5	Dismounting and remounting	6H-11
Battery	6H-5	Disassembly and reassembly	6H-11
Visual inspection	6H-5	Inspection	6H-12
Hydrometer test	6H-5	Specification	6H-14
Generator	6H-6	Battery	6H-14
Charging indicator lamp operation	6H-6	Generator	6H-14
Undercharged battery	6H-7	Tightening Torque Specification	6H-14
Overcharged battery	6H-8		

General Description

Battery

The battery has three major functions in the electrical system.

- It is a source of electrical energy for cranking the engine.
- It acts as a voltage stabilizer for the electrical system.
- It can, for a limited time, provide energy when the electrical load exceeds the output of the generator.

Carrier and hold-down

The battery carrier should be in good condition so that it will support the battery securely and keep it level. Before installing the battery, the battery carrier and hold-down clamp should be clean and free from corrosion and make certain there are no parts in carrier. To prevent the battery from shaking in its carrier, the hold-down bolts should be tight enough but not over-tightened.

Electrolyte freezing







The freezing point of electrolyte depends on its specific gravity. Since freezing may ruin a battery, it should be protected against freezing by keeping it in a fully charged condition. If a battery is frozen accidentally, it should not be charged until it is warmed.

Sulfation

If the battery is allowed to stand for a long period in discharged condition, the lead sulfate becomes converted into a hard, crystalline substance, which will not easily turn back to the active material again during the subsequent recharging. “Sulfation” means the result as well as the process of that reaction. Such a battery can be revived by very slow charging and may be restored to usable condition but its capacity is lower than before.

Built-in indicator (if equipped)

The battery has a built-in temperature compensated indicator in the top of the battery. This indicator is to be used with the following diagnostic procedure. When checking the indicator, make sure that the battery has a clean top. A light may be needed in some poorly-lit areas.

D I A G N O S I S I N D I C A T O R G R A V I T Y B A L L	OK	CHARGING NECESSARY	LOW LEVEL ELECTROLYTE REPLACE BATTERY
	Green dot 	Dark 	Clear 
			

Three types of indication available under normal operation are as follows.

- Green Dot
Battery is sufficiently charged for testing.
- Dark
Battery must be charged before testing.
If there is a cranking complaint, battery should be tested as described in Diagnosis section. Charging and electrical systems should also be checked at this time.
- Clear or Light Yellow
This means that fluid level is below the bottom of hydrometer. Its possible cause is excessive or prolonged charging, a broken case, excessive tipping or normal battery deterioration. When the battery is found in such condition, it is possible that high charging voltage is caused by the faulty charging system and therefore, charging and electrical systems need to be checked. If there is a trouble in cranking and its cause lies in the battery, it should be replaced.

Care of battery

WARNING:

- **Never expose battery to open flame or electric spark because of battery generate gas which is flammable and explosive.**
- **Do not allow battery fluid to contact eyes, skin, fabrics, or painted surfaces as fluid is a corrosive acid. Flush any contacted area with water immediately and thoroughly.**
- **Batteries should always be kept out of reach of children.**

- 1) The battery is a very reliable component, but needs periodical attentions.
 - Keep the battery carrier clean
 - Prevent rust formation on the terminal posts
 - Keep the electrolyte up to the upper level uniformly in all cells.
 - When keeping battery on vehicle over a long period of time, follow instructions given below.
 - Weekly, start the engine and run it until it reaches normal operating temperature with engine speed of 2000 to 3000 rpm. Make sure all electric switches are off before storing the vehicle.
 - Recharge the battery twice a month to prevent it from discharging excessively. This is especially important when ambient temperature is low.

The battery discharges even when it is not used, while vehicles are being stored. Battery electrolyte can freeze and battery case can crack at cold ambient condition if battery is not properly charged.
- 2) Keep the battery cable connections clean.

The cable connections, particularly at the positive (+) terminal post, tend to become corroded. The product of corrosion, or rust, on the mating faces of conductors resists the flow of current.


Clean the terminals and fittings periodically to ensure good metal-to-metal contact, and grease the connections after each cleaning to protect them against rusting.
- 3) Be always in the know as to the state of charge of the battery. The simplest way to tell the state of charge is to carry out a hydrometer test. The hydrometer is an instrument for measuring the specific gravity (S.G.) of the battery electrolyte. The S.G. of the electrolyte is indicative of the state of charge. Refer to “BATTERY” under “DIAGNOSIS” in this section.

Generator


The generator is a small and high performance type with an IC regulator incorporated. The internal components are connected electrically as shown below figure.

The generator features are as follows:

- Solid state regulator is mounted inside the generator.
- All regulator components are enclosed into a solid mold.
- This unit along with the brush holder assembly is attached to the rear housing.
- The IC regulator uses integrated circuits and controls the voltage produced by the generator, and the voltage setting cannot be adjusted.
- The generator rotor bearings contain enough grease to eliminate the need for periodic lubrication. Two brushes carry current through the two slip rings to the field coil mounted on the rotor, and under normal conditions will provide long period of attention-free service.
- The stator windings are assembled on the inside of a laminated core that forms part of the generator frame.
- A condenser mounted in the rear housing suppresses radio noise.



1. Generator with regulator ass'y	3. Stator coil	5. Field coil (rotor coil)	7. Main switch	9. ECM
2. I.C. regulator	4. Diode	6. Charge indicator light	8. Battery	10. Load



1. Pulley	5. Stator core	9. Rear end frame	E: Ground
2. Pulley nut	6. Field coil	10. Drive end frame	F: Field coil terminal
3. Rotor fan	7. Regulator	B: Generator output (Battery terminal)	IG: Ignition terminal
4. Stator coil	8. Brush	C: C terminal	L: Lamp terminal

Diagnosis

Battery

Visual inspection

Check for obvious damage, such as cracked or broken case or cover, that could permit loss of electrolyte. If obvious damage is noted, replace battery. Determine cause of damage and correct as needed.

Hydrometer test


The direct method of checking the battery for state of charge is to carry out a high rate discharge test, which involves a special precise voltmeter and an expensive instrument used in the service shops, but not recommendable to the user of the vehicle.

At 20 °C of battery temperature (electrolyte temperature):

- The battery is in FULLY CHARGED STATE if the electrolyte S.G. is 1.280.
- The battery is in HALF CHARGED STATE if the S.G. is 1.220.
- The battery is in NEARLY DISCHARGED STATE if the S.G. is 1.150 and is in danger of freezing.

As the S.G. varies with the temperature, if battery temperature is not at 20°C (68°F), you have to correct your S.G. reading (taken with your hydrometer) to the value at 20°C (68°F) and apply the corrected S.G. value to the three-point guide stated value.

For the manner of correction, refer to the graph showing the relation between S.G. value and temperature at the left.




How to use the temperature-corrected state-of-charge graph

Suppose your S.G. reading is 1.28 and the battery temperature is -5°C (23°F). Locate the intersection of the -5°C line and the 1.28 S.G. line.

The intersection is within the "A" zone (shaded area in the graph) and that means CHARGED STATE.

To know how much the battery is charged, draw a line parallel to the zone demarcation line and extend it to the right till it meets with the percentage scale. In the present example, the line meets at about 85% point on the percentage scale. Therefore, the battery is charged up to the 85% level.

Generator



CAUTION:

- Do not mistake polarities of IG terminal and L terminal.
- Do not create short circuit between IG and L terminals. Always connect these terminals through a lamp.
- Do not connect any load between L and E.
- When connecting charger or booster battery to vehicle battery, refer to this section describing battery charging.

Trouble in charging system will show up as one or more of the following conditions:

- 1) Faulty indicator lamp operation.
- 2) An undercharged battery as evidenced by slow cranking or indicator dark.
- 3) An overcharged battery as evidenced by excessive spewing of electrolyte from vents.

Noise from generator may be caused by loose drive pulley, loose mounting bolts, worn or dirty bearings, defective diode, or defective stator.

B:	Generator output (Battery terminal)
C:	C terminal
E:	Ground
F:	Field coil terminal
IG:	Ignition terminal
L:	Lamp terminal

Charging indicator lamp operation

Condition	Possible Cause	Correction
Charge light does not light with ignition ON and engine off	Fuse blown	Check fuse.
	Light burned out	Replace light.
	Wiring connection loose	Tighten loose connection.
	IC regulator or field coil faulty	Check generator.
	Poor contact between brush and slip ring	Repair or replace.
Charge light does not go out with engine running (battery requires frequent recharging)	Drive belt loose or worn	Adjust or replace drive belt.
	IC regulator or generator faulty	Check charging system.
	Wiring faulty	Repair wiring.

Undercharged battery

This condition, as evidenced by slow cranking or low specific gravity can be caused by one or more of the following conditions even though indicator lamp may be operating normal.

Following procedure also applies to cars with voltmeter and ammeter.


- Make sure that undercharged condition has not been caused by accessories left on for extended period of time.
- Check drive belt for proper tension.
- If battery defect is suspected, refer to BATTERY section.
- Inspect wiring for defects. Check all connections for tightness and cleanliness, battery cable connections at battery, starting motor and ignition ground cable.

NO-LOAD CHECK

- 1) Connect voltmeter and ammeter as shown in left figure.

NOTE:

Use fully charged battery.



1. Generator
2. Ammeter (between generator (B) terminal and battery (+) terminal)
3. Voltmeter (between generator (B) terminal and ground)
4. Battery
5. Load
6. Switch

- 2) Run engine from idling up to 2,000 rpm with all accessories turned off and read meters.

If voltage is higher than standard value, check ground of brushes.

If brushes are not grounded, replace IC regulator.

If voltage is lower than standard value, proceed to following check.

Specification for undercharged battery (No-load check)


Current: 10 A

Voltage: 14.2 – 14.8 V at Hi (H) (at 25°C, 77°F)


Voltage: 12.5 – 13.1 V at Lo (L) (at 25°C, 77°F)

NOTE:

Consideration should be taken that voltage will differ somewhat with regulator case temperature as shown in left figure.



A: Regulated voltage (V)
B: Heatsink temperature (°C)



3) Ground F terminal and start engine, then measure voltage at B terminal as shown in left figure.

- Voltage is higher than standard value
It is considered that generator itself is good but IC regulator has been damaged, replace IC regulator.

- Voltage is lower than standard value
It is considered that generator itself has problem, check the generator.


If the generator is in good condition, check generator control signal (See Diag. Flow Table B-9 in Section 6).

LOAD CHECK

- 1) Run engine at 2,000 rpm and turn on head light and heater motor.
- 2) Measure current and if it is less than 20 A repair or replace generator.

Overcharged battery

- 1) To determine battery condition, refer to BATTERY section.
- 2) If obvious overcharge condition exists as evidenced by excessive spewing of electrolyte, measure generator B terminal voltage at engine 2000 rpm.
- 3) If measured voltage is higher than upper limit value, disassemble generator.
- 4) Check ground of brushes. If brushes are not grounded, replace IC regulator. Then check field coil for grounds and shorts.



A: Regulated voltage (V)

B: Heatsink temperature (°C)

On-Vehicle Service

Battery

Jump starting in case of emergency

WITH AUXILIARY (BOOSTER) BATTERY

CAUTION:

If vehicle is manual transmission model and has a catalytic converter, do not push or tow it to start. Damage to its emission system and/or to other parts may result.

Both booster and discharged battery should be treated carefully when using jumper cables. Follow procedure outlined below, being careful not to cause sparks.

WARNING:

- Departure from these conditions or procedure described below could result in:
 - Serious personal injury (particularly to eyes) or property damage from such causes as battery explosion, battery acid, or electrical burns.
 - Damage to electronic components of either vehicle.
- Remove rings, watches, and other jewelry. Wear approved eye protection.
- Be careful so that metal tools or jumper cables do not contact positive battery terminal (or metal in contact with it) and any other metal on vehicle, because a short circuit could occur.

WARNING:

Do not connect negative cable directly to negative terminal of dead battery.


- 1) Set parking brake and place automatic transmission in PARK (NEUTRAL on manual transmission). Turn off ignition, turn off lights and all other electrical loads.
- 2) Check electrolyte level. If it is below low level line, add distilled water.
- 3) Attach end of one jumper cable to positive terminal of booster battery and the other end of the same cable to positive terminal of discharged battery. (Use 12-volt battery only to jump start engine).
- 4) Attach one end of the remaining negative cable to negative terminal of booster battery, and the other end to a solid engine ground (such as exhaust manifold) at least 45 cm (18 in.) away from battery of vehicle being started.
- 5) Start engine of vehicle with booster battery and turn off electrical accessories. Then start engine of the vehicle with discharged battery.
- 6) Disconnect jumper cables in the exact reverse order.

WITH CHARGING EQUIPMENT

CAUTION:

When jump starting engine with charging equipment, be sure equipment used is 12-volt and negative ground. Do not use 24-volt charging equipment. Using such equipment can cause serious damage to electrical system or electronic parts.

Dismounting



- 1) Disconnect negative cable (1).
- 2) Disconnect positive cable (2).
- 3) Remove retainer (3).
- 4) Remove battery (4).

5. Body ground bolt

6. Nut

Handling

When handling battery, following safety precautions should be followed:

- Hydrogen gas is produced by battery. A flame or spark near battery may cause the gas to ignite.
- Battery fluid is highly acidic. Avoid spilling on clothing or other fabric. Any spilled electrolyte should be flushed with large quantity of water and cleaned immediately.

Remounting

- 1) Reverse removal procedure.
- 2) Torque battery cables to specification.

NOTE:

Check to be sure that ground cable has enough clearance to hood panel by terminal.

Tightening torque

Body ground bolt

(a): 8.0 N·m (0.8 kg-m, 6.0 lb-ft)

Generator

Generator belt

Refer to "WATER PUMP/GENERATOR DRIVE BELT" in Section 6B "ENGINE COOLING".

1

2 8.0 N-m (0.8 kg-m)

3 23 N-m (2.3 kg-m)

4


5

6 50 N-m (5.0 kg-m)

7 65 N-m (6.5 kg-m)


Inspection

ROTOR




- 1) Using ohmmeter, check for continuity between slip rings of rotor. If there is no continuity, replace rotor.

Standard resistance between slip rings of rotor
: 2.7 – 3.1 Ω at 20°C (68°F)



- 2) Using ohmmeter, check that there is no continuity between slip ring and rotor. If there is continuity, replace rotor.



- 3) Check slip rings for roughness or scoring. If rough or scored, replace rotor.

Using a vernier caliper, measure the slip ring diameter.


If the diameter is less than minimum, replace the rotor.

Slip ring diameter


Standard: 14.2 – 14.4 mm (0.557 – 0.567 in.)

Limit: 12.8 mm (0.504 in.)

STATOR




- 1) Using an ohmmeter, check all leads for continuity. If there is no continuity, replace stator.



- 2) Using ohmmeter, check that there is no continuity between coil leads and stator core. If there is continuity, replace stator.

BRUSH AND BRUSH HOLDER




Check each brush for wear by measuring its length as shown. If brush is found worn down to service limit, replace brush.

Exposed brush length "a"


Standard: 10.5 mm (0.41 in.)

Limit: 1.5 mm (0.06 in.)

RECTIFIER



- 1) Using an ohmmeter, connect one tester probe to the "B" terminal (1) and the other to each rectifier terminal (2).
- 2) Reverse the polarity of the tester probes and repeat step 1).
- 3) Check that one shows continuity and the other shows no continuity.
If there is continuity, replace the rectifier.



- 4) Using an ohmmeter, connect one tester probe to each negative terminal (1) and the other to each rectifier terminal (2).
- 5) Reverse the polarity of the tester probes and repeat step 4).
- 6) Check that one shows continuity and the other shows no continuity.
If there is continuity, replace the rectifier.

Specification

Battery

NOTE:

The battery used in each vehicle is one of the following three types, depending on specification.

Battery type	38B20L	55B24L	75D23L
Rated capacity AH/5HR, 12 Volts	28	38	54
Electrolyte L (US/Imp. pt)	2.1 (4.44/3.70)	2.8 (5.92/4.93)	3.9 (8.24/6.86)
Electrolyte S.G.	1.28 when fully charged at 20°C (68°F)		

Generator

Type	75 A type
Rated voltage	12 V
Nominal output	75 A
Permissible max. speed	18000 r/min.
No-load speed	1020 r/min (rpm)
Setting voltage	14.2 – 14.8 V (Hi), 12.5 – 13.1 V (Lo)
Exposed brush length	Standard: 10.5 mm (0.41 in.) Limit: 1.5 mm (0.06 in.)
Permissible ambient temperature	–30 to 90°C (–22 to 194°F)
Polarity	Negative ground
Rotation	Clockwise viewed from pulley side

Tightening Torque Specification

Fastening part	Tightening torque		
	N•m	kg-m	lb-ft
Body ground bolt	8	0.8	6.0
Generator bolts	23	2.3	16.5
“B” terminal inner nut	3.6	0.36	2.5
“B” terminal outer nut	8	0.8	6.0
Pulley nut	111	11.1	80.5
Rear end frame nuts	4.5	0.45	3.5
Rear end cover nuts	4.5	0.45	3.5
Stator stud bolts	9.8	0.98	7.0
Drive end bearing plate screws	3.0	0.30	2.0
Rectifier screws	3.0	0.30	2.0
Regulator and brush holder screws	2.0	0.20	1.5
Terminal plate bolt	3.8	0.38	3.0

SECTION 6K

EXHAUST SYSTEM

CONTENTS


General Description	6K-1	Exhaust Manifold	6K-3
On-Vehicle Service	6K-2	Exhaust Pipe	6K-3




General Description

The exhaust system consists of an exhaust manifold, three-way catalytic converter (TWC) in catalyst case, exhaust pipes, a muffler and seals, gasket and etc.

The three-way catalytic converter is an emission control device added to the exhaust system to lower the levels of Hydrocarbon (HC), Carbon Monoxide (CO), and Oxides of Nitrogen (NOx) pollutants in the exhaust gas.

On-Vehicle Service



1. Exhaust manifold cover (with oxygen sensor)	8. Muffler	15. Exhaust chamber (without oxygen sensor)
2. Gasket	9. Muffler mounting No.1	16. Muffler mounting No.2
3. Exhaust manifold (with oxygen sensor)	10. Gasket	17. Exhaust manifold stiffener (with transmission stiffener)
4. Oxygen sensor No.1	11. Exhaust manifold cover (without oxygen sensor)	 18. Exhaust pipe nut: Tighten exhaust pipe nut (a) first and next (b) as shown in viewed "A".
5. Seal ring	12. Exhaust manifold (without oxygen sensor)	19. Top side
6. Exhaust No.1 pipe	13. Oxygen sensor No.2	 Tightening torque
7. Exhaust No.2 pipe	14. Catalyst case (with oxygen sensor)	 Do not reuse.

WARNING:

To avoid the danger of being burned, do not touch the exhaust system when the system is hot. Any service on the exhaust system should be performed when the system is cool.

Exhaust Manifold

REMOVAL AND INSTALLATION

Refer to Section 6A1 for removal and installation procedures of exhaust manifold.

INSPECTION

Check gasket and seal for deterioration or damage.

Replace them as necessary.

Exhaust Pipe

REMOVAL AND INSTALLATION

For replacement of exhaust pipe, be sure to hoist vehicle and observe WARNING under “MAINTENANCE” and the following.

CAUTION:

Exhaust pipe have three way catalytic converter in it, it should not be exposed to any impulse. Be careful not to drop it or hit it against something.

- Tighten bolts and nuts to specified torque when reassembling. Refer to “ON-VEHICLE SERVICE” for location of bolts and nuts.
- After installation, start engine and check each joint of exhaust system for leakage.

Prepared by
SUZUKI MOTOR CORPORATION
Overseas Service Department

1st Ed. March, 2001

Printed in Japan

Printing: March, 2001

1222