

# PARKING BRAKE SYSTEM

3309G-01

## PROBLEM SYMPTOMS TABLE

Use the table below to help you find the cause of the problem. The numbers indicate the priority of the likely cause of the problem. Check each part in order. If necessary, replace these parts.

Symptom	Suspect Area	See page
Brake drag	1. Parking brake pedal travel (Out of adjustment)	<a href="#">33-2</a>
	2. Parking brake wire (Sticking)	<a href="#">33-7</a>
		<a href="#">33-11</a>
	3. Parking brake shoe clearance (Out of adjustment)	<a href="#">33-15</a>
	4. Parking brake shoe lining (Cracked or distorted)	<a href="#">33-15</a>
	5. Tension or return spring (Damaged)	<a href="#">33-15</a>