

REMOVING - REFITTING : FASCIA CENTRE PANEL

"RD4" RDS COMPACT DISC AUDIO SYSTEM OR "RT3" RADIOTELEPHONE SYSTEM OR "RD4/MP3" RDS COMPACT DISC AUDIO SYSTEM

URGENT : Observe the safety and cleanliness recommendations ⓘ .

1. Tooling




Figure : E5AP30WD

[1] Trim removal tools (-).1350-ZZ.

2. Preliminary operations

Disconnect the battery ⓘ .

"RT3" RADIOTELEPHONE SYSTEM OR "RD4/MP3" RDS COMPACT DISC AUDIO SYSTEM

Remove : **The radio (/)** ⓘ .

"RD4" RDS COMPACT DISC AUDIO SYSTEM

Remove : **The audio CD changer** ⓘ (According to equipment).

3. Removing




Figure : C5FP1CSD

Unclip the trims (1) (as "a") ; Using tool [1].
Remove the finishers (1).




Figure : C5FP1CTD

Remove the bolts (3).
Release all the controls (2) (ESP, central locking) by pulling towards you.




Figure : C5FP1CUD

Disconnect the connectors (as "b") (according to equipment).
Remove all the controls (2) (ESP/Central locking of the doors).




Figure : C5FP1CVD

Remove the bolts (5).
Release the air conditioning control (4).




Figure : C5FP1CWD

Unclip at "d" by rotating (in "c") the air conditioning control (4) to access the connections .

3.1. Manual air conditioning control




Figure : C5FP1CXD

CAUTION : Mark the position of the cables (6) before unclipping them.

Disconnect the connectors (as "e").

Unclip the cables (6) (as "f").

Remove : The manual air conditioning control (4a).

3.2. Automatic air conditioning control




Figure : C5FP1CYD

Disconnect the connectors (as "g").

Remove : The automatic air conditioning control (4b).

4. Refitting

Proceed in the reverse order to removal.

Connect the battery.

Check that the electrical equipment is working correctly.