

REMOVING - REFITTING : HANDBRAKE CABLE

VENTILATED FRONT DISCS/REAR DRUMS

1. Removing

Place the vehicle on a two-post ramp.

Lift and support the vehicle.

Remove the rear wheels.

Remove the central console .




Figure : B3FK83FD

Unscrew nut (1).

Unhook the cables (2) from the handbrake compensator (3).

Uncouple the handbrake sheaths from the body .




Figure : B3FK83GD

Disconnect the brake cable at (A) (2) (each side) .

VENTILATED FRONT DISCS/REAR DRUMS

Remove the rear brake drums .




Figure : B3FK83HD

Detach the handbrake cable (2) (as (B) - each side) .

2. Refitting

Proceed in the reverse order to removal.

VENTILATED FRONT DISCS/REAR DRUMS

Refit the rear brake drums .

Adjust the handbrake cables .

Refit the central console .

Fit the wheels.

Tighten the wheel bolts to 9.0 ± 1.0 da.Nm.